

FactoryIQ Demo Corpus — CNC-01_SOP_v2.1.pdf

Document Family: CNC-01_SOP | Revision: 2.1

Revision status

CURRENT REVISION. This revision supersedes v1.8.

Troubleshooting E42

For E42, stop the cycle and place the machine in a safe state. Verify coolant level and circulation. Inspect the coolant sensor connection. If the abnormal condition remains, stop troubleshooting and contact maintenance.

Startup

Before startup, verify coolant condition, machine safety interlocks and emergency-stop readiness according to the approved startup procedure.