


POUNAMU ELECTRONICS
RE_SWC
USER GUIDE

Rev 3




**POUNAMU
ELECTRONICS**

Contents

3	<u>OVERVIEW</u>
4	<u>ASSEMBLY</u>
5	<u>CONFIGURATION - HEADUNIT SELECTION</u>
6	<u>HEADUNIT LEGEND</u>
7	<u>FUNCTIONS</u>
8	<u>VOLUME KNOB DIMENSIONS</u>
9	<u>RE_SWC SPECS</u>
10	<u>DISCLAIMERS</u>
11	<u>COMPLIANCE</u>
12	<u>DOCUMENT REVISION HISTORY</u>

OVERVIEW



1. UPDATE BUTTON

**2. WHITE STATUS
LIGHT**

**3. RED POWER
LIGHT**

**4. DIA 6mm
ENCODER SHAFT**

ASSEMBLY

USB HID

- *Connect the RE_SWC kit to your device with a USB C cable (must support data & power)*
- *The RED power indicator on the RE_SWC will illuminate and stay on*

Others

- *Solder the RED wire from the 2-pin connector on the RE_SWC kit to your headunit's steering wheel control input pin*
- *Connect the RE_SWC to power with a USB C cable*
- *The RED power indicator on the RE_SWC will illuminate and stay on*

CONFIGURATION

HEADUNIT SELECTION

- *Ensure RE_SWC is not powered*
- *Press and hold the volume knob. Connect power to the RE_SWC while keeping the volume knob held*
- *Release the volume knob after the WHITE status light is illuminated*
- *Press the volume knob once. The WHITE status light will flash once. Headunit number 1 is now programmed. Repeat this step until the desired headunit number is reached - refer to the headunit legend*
- *When the desired headunit number is entered, press and hold the volume knob. The WHITE status light will flash. Release the volume knob. The RE_SWC will flash x times where x is the headunit number entered*


HEADUNIT LEGEND

HEADUNIT NUMBER	HEADUNIT TYPE / BRAND
1	<i>GENERIC RESISTIVE</i>
2	<i>JVC</i>
3	<i>KENWOOD</i>
4	<i>ALPINE</i>
5	<i>PIONEER / SONY</i>
6	<i>USB HID</i>

FUNCTIONS

INPUT	GENERIC RESISTIVE	JVC	KENWOOD	ALPINE	PIONEER / SONY	USB HID
Volume Knob CW	<i>Any</i>	<i>Volume +</i>	<i>Volume +</i>	<i>Volume +</i>	<i>Volume +</i>	<i>Volume +</i>
Volume Knob CCW	<i>Any</i>	<i>Volume -</i>	<i>Volume -</i>	<i>Volume -</i>	<i>Volume -</i>	<i>Volume -</i>
Button Short Press	<i>Any</i>	<i>Mute</i>	<i>Mute</i>	<i>Mute</i>	<i>Mute</i>	<i>Mute</i>
Button Long Press	<i>Any</i>	<i>Next Track</i>	<i>Next Track</i>	<i>Next Track</i>	<i>Next Track</i>	<i>Next Track</i>
Button Double Press	<i>Enter Learning Mode</i>	<i>Previous Track</i>	<i>Previous Track</i>	<i>Previous Track</i>	<i>Previous Track</i>	<i>Previous Track</i>

VOLUME KNOB DIMENSIONS



RE_SWC SPECS

Input

5V / 100mA USB-C

CONNECTORS

VOLUME KNOB: JST SHR-05V-S-B

SWC OUT: JST SHR-02V-S-B

MCU:

WCH CH32X035F8U6

Digital Rheostat:

MCP4131-104E/SN

SPI @ 250kHz

DISCLAIMERS

- *Pounamu Electronics is not affiliated or associated with any headunit manufacturers or brands*
- *Pounamu Electronics is not affiliated or associated with the USB Implementers Forum (USB-IF)*


COMPLIANCE

FCC Compliance Statement

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference, and*
- 2. this device must accept any interference received, including interference that may cause undesired operation.*



Document Revision History

- *Rev 1 - Initial release*
- *Rev 2 - FW V2.0.0*
 - *Added instructions for JVC headunit interface*
 - *Added instructions for Kenwood headunit interface*
- *Rev 3*
 - *Overhaul for RE_SWC V2*
 - *Added disclaimers section*
 - *Added compliance section*