itself, a slight touch of the finger will set it in motion. If the battery stops during application, it may be started again by shaking the zinc to remove the hydrogen gas from the surface of the negative plates, when that causes the stoppage.

The rubber on the hydrostat may be turned around occasionally in order to present a new and closer surface to the edges of the aperture. In replacing a broken carbon with a new one, use sealing-wax to make the aperture fluid-tight.

When the battery-fluid grows weaker with use, or becomes decomposed (of a greenish-black color), it should be renewed. Also, when the current becomes very weak it is usually an indication that the fluid needs to be renewed, or the zinc reamalgamated.

The greatest care should be exercised to keep the battery as clean as possible, in order to insure its perfect working. The metallic parts especially should be kept scrupulously free from all dust, dirt, and oxidation.