

Intersight UCS Health Check

User manual: server, fabric and network health from Cisco Intersight, plus multi-vendor capacity from RVTools, with an Excel sizing workbook

Intersight UCS Health Check

Filter by name, serial, model, IP...

Collected 9/30/2026, 10:00:00 AM

CPU/Memory Summary

Export to Excel

Save Report

Settings

Servers

Fabric Interconnects

Network Devices

Data from "Demo Lab" collected 9/30/2026, 10:00:00 AM. No live connection — your API key was used once to collect this, then discarded. [Collect new data](#)

demo-esx-01	UCSX-210C-M7	FCHDEMO0001	10.10.20.11	5.2(2.240074)	2x / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-esx-02	UCSX-210C-M7	FCHDEMO0002	10.10.20.12	5.2(2.240074)	2x / 64 cores	1024 GiB / 1024 GiB	Ok	1
demo-esx-03	UCSX-210C-M7	FCHDEMO0003	10.10.20.13	5.2(2.240074)	2x / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-esx-04	UCSX-210C-M7	FCHDEMO0004	10.10.20.14	5.2(2.240074)	2x / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-esx-05	UCSX-210C-M7	FCHDEMO0005	10.10.20.15	5.2(2.240074)	2x / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-esx-06	UCSX-210C-M7	FCHDEMO0006	10.10.20.16	5.2(2.240074)	2x / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-vdi-01	UCSC-C240-M6SN	FCHDEMO0007	10.10.20.17	4.3(4.242038)	2x / 36 cores	1024 GiB / 1024 GiB	Ok	0
demo-vdi-02	UCSC-C240-M6SN	FCHDEMO0008	10.10.20.18	4.3(4.242038)	2x / 36 cores	1024 GiB / 1024 GiB	Ok	0
demo-vdi-03	UCSC-C240-M6SN	FCHDEMO0009	10.10.20.19	4.3(4.242038)	2x / 36 cores	1024 GiB / 1024 GiB	Degraded	1

Overview

Inventory

Alarms (2)

Advisories (1)

HEALTH / ALARMS

Critical1

Warning0

Info0

COMPUTE

CPU's2

CPU's not OK0

DIMMs16

STORAGE

Physical disks6

Disks not online1

Drives low on life0

Controllers1

POWER / COOLING

PSUs2

PSUs not OK0

Fans not OK0

SECURITY ADVISORIES

Active1

Total tracked1

demo-vdi-04	UCSC-C240-M6SN	FCHDEMO0010	10.10.20.20	4.3(4.242038)	2x / 36 cores	1024 GiB / 1024 GiB	Ok	0
demo-infra-01	UCSC-C220-M7S	FCHDEMO0011	10.10.20.21	4.3(4.242038)	2x / 64 cores	512 GiB / 512 GiB	Ok	0
demo-infra-02	UCSC-C220-M7S	FCHDEMO0012	10.10.20.22	4.3(4.242038)	2x / 64 cores	512 GiB / 512 GiB	Ok	0
demo-db-01	UCSC-C245-M8SX	FCHDEMO0013	10.10.20.23	4.3(5.250001)	1x / 32 cores	1536 GiB / 1536 GiB	Ok	1
demo-db-02	UCSC-C245-M8SX	FCHDEMO0014	10.10.20.24	4.3(5.250001)	1x / 32 cores	1536 GiB / 1536 GiB	Ok	0

Version 0.1.0 · September 2026 · For macOS and Windows

All screenshots use invented demo data ("Demo Lab"). No real customer or lab information is shown.

Contents

- | | | | |
|----------|--------------------------------|-----------|-------------------------------------|
| 1 | What the app does | 9 | Fabric Interconnects |
| 2 | Installing the app | 10 | Network Devices |
| 3 | Creating an Intersight API key | 11 | RVTools (Dell, HPE and other hosts) |
| 4 | Quick start | 12 | Exporting to Excel |
| 5 | The Settings panel | 13 | The Sizing & Staging sheet |
| 6 | Servers | 14 | Saving and opening reports |
| 7 | Server detail | 15 | Privacy & security |
| 8 | CPU/Memory Summary & SPEC | 16 | Troubleshooting |

Not an official Cisco product

This is an independent tool that reads data through the public Cisco Intersight API. It isn't supported by Cisco TAC. Always confirm critical findings in Intersight itself.

1 · What the app does

The app gives you a single, offline view of a data center's hardware health and capacity:

- **Cisco servers** (UCS X-Series, B-Series and C-Series) from Intersight: inventory, alarms, drive wear and security advisories.
- **Fabric Interconnects**: port state, real uplink traffic, and best-practice checks for each UCS domain.
- **Nexus and MDS switches** that Intersight manages.
- **Any other vendor's hosts** (Dell, HPE, Lenovo...) from an RVTools export of vCenter.
- **An Excel workbook** with everything above, plus a Sizing & Staging sheet for planning a hardware refresh against the current fleet.

Data is collected **once** when you click *Collect*, then you browse it offline. Your API key is used for that single collection and then discarded.

2 · Installing the app

macOS

- 1 Open `Intersight UCS Health Check-0.1.0-arm64.dmg` and drag the app into **Applications**.
- 2 The app isn't signed with an Apple Developer ID, so macOS blocks the first launch. **Right-click** the app, choose **Open**, then click **Open** again. On recent macOS versions you may need **System Settings** → **Privacy & Security** → **Open Anyway** instead.
- 3 After that it opens normally.

The DMG is built for Apple silicon (M1 and later).

Windows

- 1 Run `Intersight UCS Health Check Setup 0.1.0.exe`. The installer works on both x64 and ARM64 PCs.
- 2 The installer isn't code-signed, so SmartScreen may say "Windows protected your PC". Click **More info** → **Run anyway**.
- 3 Choose an install folder and finish the wizard. The app appears in the Start menu.

3 · Creating an Intersight API key

You only need a key to collect live data. Opening a saved report or importing RVTools needs no key.

- 1 Sign in to Intersight and open **Settings** (gear icon) → **API Keys**.
- 2 Click **Generate API Key**, enter a description, and choose **API key for OpenAPI schema version 3** (recommended). Use version 2 only if your tenant requires it.
- 3 Copy the **API Key ID** and save the **Secret Key** (private key). Intersight shows the secret key only once.

Prefer a read-only role

A key gets the privileges of the role you're signed in with when you create it. The app only reads data, so if your account has a read-only role (or one scoped to fewer organizations), switch to it before generating the key. That limits the damage if the key is ever exposed.

4 · Quick start

- 1 Launch the app. The **Settings** panel opens automatically.
- 2 Paste your **API Key ID** and **private key**, pick the **Key type**, and click **Test connection**.

- 3 Click **Collect**. The button shows progress, first for servers, then for fabric data. Large fleets can take several minutes.
- 4 Browse the **Servers**, **Fabric Interconnects** and **Network Devices** tabs. Click any row to expand it.
- 5 Click **Save Report** to keep the data as a file you can reopen later without a key.
- 6 Click **Export to Excel** to create the workbook.

5 • The Settings panel

Intersight API Settings

Already have a saved report?

Open a saved report...

Browse a report saved earlier with "Save Report" — no API connection needed.

Have an RVTools export?

Import RVTools export (.xlsx, .xls, .csv)...

Dell, HPE, and any other non-Cisco hosts only ever come in this way — RVTools' own vHost tab, not a live API. Works with a full "export all" report, a single-tab vHost export, or one CSV from RVTools' bulk "export all to CSV" — any of them, as long as they have vHost's columns. Adds a "VM Hosts (RVTools)" tab alongside (not instead of) any Intersight data below.

OR COLLECT FROM INTERSIGHT

Base URL

https://intersight.com

Use https://intersight.com unless you connect through an Intersight Virtual Appliance.

API Key ID

5f...a1/5f...b2/5f...c3

Show

Key type

API Key v3 (RSA/EC/Ed25519, hs2019)

Pick the type shown when you generated the key under Settings → API Keys in Intersight.

Private key (PEM)

-----BEGIN PRIVATE KEY-----
...
-----END PRIVATE KEY-----

Show

Used once to collect your data, then discarded immediately — never written to disk, and never kept in memory afterward. Paste it again the next time you want to collect (or open a saved report instead).

Test connection

Cancel

Collect

Three ways to get data in

The Settings panel opens on every launch, and from the **Settings** button at any time. It offers three ways to load data:

Open a saved report...

Loads a `.json` file saved earlier with *Save Report*. No key or network is needed.

Import RVTools export...

Adds non-Cisco hosts from RVTools (chapter 11). This can be combined with Intersight data.

Collect from Intersight

Field	What to enter
Base URL	https://intersight.com (US SaaS), your regional URL such as https://eu-central-1.intersight.com, or your Intersight Virtual Appliance address.
API Key ID	The key ID from chapter 3. Masked; use <i>Show</i> to check it.
Key type	v3 (RSA/EC/Ed25519) or v2 (legacy RSA), matching how the key was created.
Private key (PEM)	The whole secret key, including the BEGIN / END lines. Masked by default.

Test connection checks the key and shows the account name. **Collect** fetches everything, and the key fields are cleared afterwards whether it succeeds or not.

6 • Servers

Intersight UCS Health Check

Filter by name, serial, model, IP...

Collected 9/30/2026, 10:00:00 AM

CPU/Memory Summary

Export to Excel

Save Report

Settings

Servers

Fabric Interconnects

Network Devices

Data from "Demo Lab" collected 9/30/2026, 10:00:00 AM. No live connection — your API key was used once to collect this, then discarded. [Collect new data](#)

NAME	MODEL	SERIAL	MGMT IP	FIRMWARE	CPU	MEMORY	STATE	FAULTS
demo-esx-01	UCSX-210C-M7	FCHDEMO0001	10.10.20.11	5.2(2.240074)	2× / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-esx-02	UCSX-210C-M7	FCHDEMO0002	10.10.20.12	5.2(2.240074)	2× / 64 cores	1024 GiB / 1024 GiB	Ok	1
demo-esx-03	UCSX-210C-M7	FCHDEMO0003	10.10.20.13	5.2(2.240074)	2× / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-esx-04	UCSX-210C-M7	FCHDEMO0004	10.10.20.14	5.2(2.240074)	2× / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-esx-05	UCSX-210C-M7	FCHDEMO0005	10.10.20.15	5.2(2.240074)	2× / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-esx-06	UCSX-210C-M7	FCHDEMO0006	10.10.20.16	5.2(2.240074)	2× / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-vdi-01	UCSC-C240-M6SN	FCHDEMO0007	10.10.20.17	4.3(4.242038)	2× / 36 cores	1024 GiB / 1024 GiB	Ok	0
demo-vdi-02	UCSC-C240-M6SN	FCHDEMO0008	10.10.20.18	4.3(4.242038)	2× / 36 cores	1024 GiB / 1024 GiB	Ok	0
demo-vdi-03	UCSC-C240-M6SN	FCHDEMO0009	10.10.20.19	4.3(4.242038)	2× / 36 cores	1024 GiB / 1024 GiB	Degraded	1
demo-vdi-04	UCSC-C240-M6SN	FCHDEMO0010	10.10.20.20	4.3(4.242038)	2× / 36 cores	1024 GiB / 1024 GiB	Ok	0
demo-infra-01	UCSC-C220-M7S	FCHDEMO0011	10.10.20.21	4.3(4.242038)	2× / 64 cores	512 GiB / 512 GiB	Ok	0
demo-infra-02	UCSC-C220-M7S	FCHDEMO0012	10.10.20.22	4.3(4.242038)	2× / 64 cores	512 GiB / 512 GiB	Ok	0
demo-db-01	UCSC-C245-M8SX	FCHDEMO0013	10.10.20.23	4.3(5.250001)	1× / 32 cores	1536 GiB / 1536 GiB	Ok	1
demo-db-02	UCSC-C245-M8SX	FCHDEMO0014	10.10.20.24	4.3(5.250001)	1× / 32 cores	1536 GiB / 1536 GiB	Ok	0

One row per server (blades and rack units). The banner confirms which account the data came from and when it was collected.

Column	Meaning
Name / Model / Serial	As registered in Intersight.
Mgmt IP	The CIMC / management address.
Firmware	The running server firmware bundle.
CPU	Sockets × total cores.
Memory	Available / total memory.
State	Intersight's operational state. Ok is healthy; amber and red badges need attention.
Faults	The number of active faults on the server.

Use the **filter box** in the header to narrow the list by name, serial, model or IP. The filter also limits what *CPU/Memory Summary* and *Export to Excel* include.

7 · Server detail

Click a server row to expand it. There are four tabs.

Overview

Intersight UCS Health Check

Filter by name, serial, model, IP...

Collected 9/30/2026, 10:00:00 AM

CPU/Memory Summary

Export to Excel

Save Report

Settings

Servers

Fabric Interconnects

Network Devices

Data from "Demo Lab" collected 9/30/2026, 10:00:00 AM. No live connection — your API key was used once to collect this, then discarded. [Collect new data](#)

demo-esx-01	UCSX-210C-M7	FCHDEMO0001	10.10.20.11	5.2(2.240074)	2x / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-esx-02	UCSX-210C-M7	FCHDEMO0002	10.10.20.12	5.2(2.240074)	2x / 64 cores	1024 GiB / 1024 GiB	Ok	1
demo-esx-03	UCSX-210C-M7	FCHDEMO0003	10.10.20.13	5.2(2.240074)	2x / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-esx-04	UCSX-210C-M7	FCHDEMO0004	10.10.20.14	5.2(2.240074)	2x / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-esx-05	UCSX-210C-M7	FCHDEMO0005	10.10.20.15	5.2(2.240074)	2x / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-esx-06	UCSX-210C-M7	FCHDEMO0006	10.10.20.16	5.2(2.240074)	2x / 64 cores	1024 GiB / 1024 GiB	Ok	0
demo-vdi-01	UCSC-C240-M6SN	FCHDEMO0007	10.10.20.17	4.3(4.242038)	2x / 36 cores	1024 GiB / 1024 GiB	Ok	0
demo-vdi-02	UCSC-C240-M6SN	FCHDEMO0008	10.10.20.18	4.3(4.242038)	2x / 36 cores	1024 GiB / 1024 GiB	Ok	0
demo-vdi-03	UCSC-C240-M6SN	FCHDEMO0009	10.10.20.19	4.3(4.242038)	2x / 36 cores	1024 GiB / 1024 GiB	Degraded	1

Overview

Inventory

Alarms (2)

Advisories (1)

HEALTH / ALARMS

Critical1

Warning0

Info0

COMPUTE

CPUs2

CPUs not OK0

DIMMs16

STORAGE

Physical disks6

Disks not online1

Drives low on life0

Controllers1

POWER / COOLING

PSUs2

PSUs not OK0

Fans not OK0

SECURITY ADVISORIES

Active1

Total tracked1

demo-vdi-04	UCSC-C240-M6SN	FCHDEMO0010	10.10.20.20	4.3(4.242038)	2x / 36 cores	1024 GiB / 1024 GiB	Ok	0
demo-infra-01	UCSC-C220-M7S	FCHDEMO0011	10.10.20.21	4.3(4.242038)	2x / 64 cores	512 GiB / 512 GiB	Ok	0
demo-infra-02	UCSC-C220-M7S	FCHDEMO0012	10.10.20.22	4.3(4.242038)	2x / 64 cores	512 GiB / 512 GiB	Ok	0
demo-db-01	UCSC-C245-M8SX	FCHDEMO0013	10.10.20.23	4.3(5.250001)	1x / 32 cores	1536 GiB / 1536 GiB	Ok	1
demo-db-02	UCSC-C245-M8SX	FCHDEMO0014	10.10.20.24	4.3(5.250001)	1x / 32 cores	1536 GiB / 1536 GiB	Ok	0

A degraded server: one critical alarm and one disk not online.

Five cards summarize alarms by severity, compute, storage (including disks not online and drives low on life), power and cooling, and security advisories. Any non-zero red or amber count is worth a closer look.

Inventory

Intersight UCS Health Check

Filter by name, serial, model, IP...

Collected 9/30/2026, 10:00:00 AM

CPU/Memory Summary

Export to Excel

Save Report

Settings

Servers

Fabric Interconnects

Network Devices

Data from "Demo Lab" collected 9/30/2026, 10:00:00 AM. No live connection — your API key was used once to collect this, then discarded. [Collect new data](#)

Physical disks (6)

ID	PID	TYPE	SIZE (MB)	DRIVE STATE	DISK STATE	LIFE USED / LEFT	THERMAL	LINK SPEED	ENCRYPTED
1	UCS-M2-480G	SSD	457862 MB	Online	Good	3% used / 97% left	ok	6.0 Gb/s	false
2	UCS-M2-480G	SSD	457862 MB	Online	Good	7% used / 93% left	ok	6.0 Gb/s	false
3	UCS-SD960GBM3XEP	SSD	915715 MB	Online	Good	3% used / 97% left	ok	12.0 Gb/s	false
4	UCS-SD960GBM3XEP	SSD	915715 MB	Failed	Failed	2% used / 98% left	ok	12.0 Gb/s	false
5	UCS-SD960GBM3XEP	SSD	915715 MB	Online	Good	12% used / 88% left	ok	12.0 Gb/s	false
6	UCS-SD960GBM3XEP	SSD	915715 MB	Online	Good	1% used / 99% left	ok	12.0 Gb/s	false

Storage controllers (1)

ID	TYPE	STATUS	RAID SUPPORT	STATE
MRAID	SAS	Optimal	RAID0, RAID1, RAID5, RAID6, RAID10	Optimal

Power supplies (2)

ID	PID	TYPE	WATTAGE	STATE
1	UCSC-PSU1-2300W	—	2300	operable
2	UCSC-PSU1-2300W	—	2300	operable

Fans (6)

ID	PID	STATE
1	UCSC-FAN-C240M6	operable
2	UCSC-FAN-C240M6	operable
3	UCSC-FAN-C240M6	operable
4	UCSC-FAN-C240M6	operable
5	UCSC-FAN-C240M6	operable
6	UCSC-FAN-C240M6	operable

demo-vdi-04

UCSC-C240-M6SN

FCHDEMO0010

10.10.20.20

4.3(4.242038)

2x / 36 cores

1024 GiB / 1024 GiB

Ok

0

Physical disks, storage controllers, power supplies and fans.

Inventory lists processor models, each CPU, every DIMM, physical disks, storage controllers, power supplies and fans, with their state.

SSD life is shown as "used / left" and colored by what remains: **green** above 20%, **amber** at 20% or less, and **red** at 10% or less. Hard drives don't report wear, so they show "—".

Alarms

demo-vdi-03

UCSC-C240-M6SN

FCHDEMO0009

10.10.20.19

4.3(4.242038)

2x / 36 cores

1024 GiB / 1024 GiB

Degraded

1

Overview

Inventory

Alarms (2)

Advisories (1)

Critical

UCS-F0181

Local disk 4 on server demo-vdi-03 operability: inoperable

Created 9/27/2026, 10:12:00 PM Affects storage.PhysicalDisk

Cleared

UCS-F0717

Management Interface Link Down: check the network cable connection

Created 9/1/2026, 3:00:00 AM Affects management.Interface

Every alarm raised on the server or its components, with severity, fault code, description and time. Cleared alarms are kept for context.

Advisories

demo-vdi-01UCSC-C240-M6SNFCHDEMO000710.10.20.174.3(4.242038)2x / 36 cores1024 GiB / 1024 GiBOk0

OverviewInventoryAlarms (1)Advisories (1)

active

ucs-m6-rack-eol-info

Cisco announces the end-of-sale and end-of-life dates for the Cisco UCS C220 M6 and C240 M6 Rack Servers.
Recommendation: Plan migration to a current-generation platform.
[View advisory](#)

Cisco security advisories and end-of-life notices that Intersight has matched to this server, with CVSS score, CVEs where applicable, and a link to the full notice.

8 · CPU/Memory Summary & SPEC

The screenshot shows the Intersight UCS Health Check interface. At the top, there's a header with 'Intersight UCS Health Check', a filter box, and a date/time stamp 'Collected 9/30/2026, 10:00:00 AM'. Below the header, there are tabs for 'Servers', 'Fabric Interconnects', and 'Network Devices'. A message states: 'Data from "Demo Lab" collected 9/30/2026, 10:00:00 AM. No live connection — your API key was used once to collect this, then discarded. [Collect new data](#)'. The main content area is divided into a table of servers and a modal window titled 'Fleet CPU/Memory Summary'.

The modal window shows a summary of 26 processors across 14 servers with 14.00 TiB total memory. It includes two sections for SPEC CPU results: 'SPEC CPU2017' (1067 results) and 'SPEC CPU2026' (10 results). Below these, there's a table of CPU models with their specifications and performance metrics.

Model	Qty	Servers	Total RAM	SPECrate2017 (per server)	SPECrate2026 (per server)	Total SPECrate2017	Total SPECrate2026	Per core (2017 / 2026)
Intel(R) Xeon(R) Gold 6448Y 2.10 GHz 225W 32C 60.0MB Cache DDR5 4800MHz	12	6	6.00 TiB	570.3	N/A	3421.8	N/A	8.91 / N/A
Intel(R) Xeon(R) Gold 6354 3.00 GHz 205W 18C 39.0MB Cache DDR4 3200MHz 6TB	8	4	4.00 TiB	309	N/A	1236	N/A	8.58 / N/A
Intel(R) Xeon(R) Gold 6430 2.10 GHz 270W 32C 60.0MB Cache DDR5 4400MHz	4	2	1.00 TiB	522.3	N/A	1044.6	N/A	8.16 / N/A
AMD EPYC 9355 32-Core Processor 3.55 GHz 280W 256MB Cache DDR5 6000MHz	2	2	3.00 TiB	469	N/A	938	N/A	14.66 / N/A

The modal also includes buttons for 'Replace...', 'Clear', and 'Close'.

CPU/Memory Summary in the header rolls up the servers currently listed by CPU model: how many processors and servers use each model, total RAM and cores, and estimated **SPECrate®2017_int_base** and **SPECrate®2026_int_base** per server, per core and in total.

Loading SPEC results

SPEC scores come from results that Cisco and other vendors publish on [spec.org](https://www.spec.org). There's no API, so you upload a CSV once:

- 1 Open the [spec.org](https://www.spec.org/cgi-bin/osgresults?conf=rint2017&op=fetch&field=COMPANY&pattern=cisco) results browser export, for example:
`https://www.spec.org/cgi-bin/osgresults?conf=rint2017&op=fetch&field=COMPANY&pattern=cisco`
Use `rint2026` for the newer suite. Change `pattern` to include other vendors if you import Dell or HPE hosts.
- 2 Save the CSV, then click **Upload CSV...** (or **Replace...**) next to the matching suite in the summary.

CPUs are matched by SKU (e.g. "Gold 6448Y", "EPYC 9355"), and all matching results are averaged per chip. If a result was published at a different socket count, it is scaled linearly. That's an approximation, not a published figure for your exact configuration. A CPU with no match shows **N/A**. The uploaded data stays in the app until you replace or clear it.

9 • Fabric Interconnects

One row per UCS domain, with Fabric A and B side by side. Expand a domain to see five tabs.

Intersight UCS Health Check

Export to ExcelSave ReportSettings

ServersFabric InterconnectsNetwork Devices

Data from "Demo Lab" collected 9/30/2026, 10:00:00 AM. No live connection — your API key was used once to collect this, then discarded. [Collect new data](#)

DOMAIN	FABRIC A	FABRIC B	HA LINK	FAULTS
• DEMO-FI	A: UCS-FI-6536 (4.3(4.240066)) Connected	B: UCS-FI-6536 (4.3(4.240066)) Connected	Up	1

OverviewEthernet Ports (24)FC Ports (4)Alarms (1)Best Practices (1)

FABRIC A

Model

UCS-FI-6536

Serial

FDO DEMO000A

Firmware

4.3(4.240066)

Connection

Connected

Ethernet mode

end-host

FC mode

end-host

Ether ports (up/cfg/total)

12/12/36

FC ports (up/cfg/total)

2/2/4

HA link

Up

UPLINK TRAFFIC (LAST 4H)

RX / TX

27.3 TB / 12.7 TB

Peak RX / TX utilization

34.95% / 29.73%

CRC errors

0

Discards

12

FABRIC B

Model

UCS-FI-6536

Serial

FDO DEMO000B

Firmware

4.3(4.240066)

Connection

Connected

Ethernet mode

end-host

FC mode

end-host

Ether ports (up/cfg/total)

11/12/36

FC ports (up/cfg/total)

2/2/4

HA link

Up

UPLINK TRAFFIC (LAST 4H)

RX / TX

21.8 TB / 11.8 TB

Peak RX / TX utilization

28.96% / 27.42%

CRC errors

0

Discards

24

Overview: model, firmware, modes, port counts and uplink traffic for each fabric.

Intersight UCS Health Check • User manual • v0.1.0

10 / 17

Ethernet and FC ports

Intersight UCS Health Check

Export to ExcelSave ReportSettings

ServersFabric InterconnectsNetwork Devices

Data from "Demo Lab" collected 9/30/2026, 10:00:00 AM. No live connection — your API key was used once to collect this, then discarded. [Collect new data](#)

DOMAIN	FABRIC A	FABRIC B	HA LINK	FAULTS
DEMO-FI	A: UCS-FI-6536 (4.3(4.240066)) Connected	B: UCS-FI-6536 (4.3(4.240066)) Connected	Up	1

OverviewEthernet Ports (24)FC Ports (4)Alarms (1)Best Practices (1)

FABRIC	SLOT	PORT	ROLE	OPER STATE	OPER SPEED	PORT-CHANNEL	PEER	RX / TX (4H)	PEAK RX% / TX%	CRC ERRORS	DISCARDS
A	1	1	Server	up	100G	—	sys/chassis-1/slot-1	—	—	—	—
A	1	2	Server	up	100G	—	sys/chassis-1/slot-2	—	—	—	—
A	1	3	Server	up	100G	—	sys/chassis-1/slot-3	—	—	—	—
A	1	4	Server	up	100G	—	sys/chassis-1/slot-4	—	—	—	—
A	1	5	Server	up	100G	—	sys/chassis-1/slot-5	—	—	—	—
A	1	6	Server	up	100G	—	sys/chassis-1/slot-6	—	—	—	—
A	1	7	Server	up	100G	—	sys/chassis-1/slot-7	—	—	—	—
A	1	8	Server	up	100G	—	sys/chassis-1/slot-8	—	—	—	—
A	1	31	Uplink PC Member	up	100G	10	—	7.3 TB / 3.6 TB	34.95% / 29.73%	0	12
A	1	32	Uplink PC Member	up	100G	10	—	6.4 TB / 2.7 TB	21.62% / 13.52%	0	0
A	1	33	Uplink PC Member	up	100G	10	—	8.2 TB / 2.7 TB	18.29% / 26.62%	0	0
A	1	34	Uplink PC Member	up	100G	10	—	5.5 TB / 3.6 TB	18.10% / 18.38%	0	0
B	1	1	Server	up	100G	—	sys/chassis-1/slot-1	—	—	—	—
B	1	2	Server	up	100G	—	sys/chassis-1/slot-2	—	—	—	—
B	1	3	Server	up	100G	—	sys/chassis-1/slot-3	—	—	—	—
B	1	4	Server	up	100G	—	sys/chassis-1/slot-4	—	—	—	—
B	1	5	Server	up	100G	—	sys/chassis-1/slot-5	—	—	—	—
B	1	6	Server	up	100G	—	sys/chassis-1/slot-6	—	—	—	—
B	1	7	Server	up	100G	—	sys/chassis-1/slot-7	—	—	—	—

Every physical port with its role, state, speed, port-channel and peer. Where Intersight telemetry is available, you also get **real traffic** over the last 4 hours: RX/TX volume, **peak** utilization, CRC errors and discards. Peak utilization is the highest value in that window, not a live reading.

No traffic columns?

Telemetry depends on the license tier and platform, and idle ports may simply have no data. Everything else on the tab still works without it.

Best Practices

Intersight UCS Health Check

Export to ExcelSave ReportSettings

ServersFabric InterconnectsNetwork Devices

Data from "Demo Lab" collected 9/30/2026, 10:00:00 AM. No live connection — your API key was used once to collect this, then discarded. [Collect new data](#)

DOMAIN	FABRIC A	FABRIC B	HA LINK	FAULTS
• DEMO-FI	A: UCS-FI-6536 (4.3(4.240066)) Connected	B: UCS-FI-6536 (4.3(4.240066)) Connected	Up	1

OverviewEthernet Ports (24)FC Ports (4)Alarms (1)Best Practices (1)

Based on provisioned configuration and link state — Intersight's API doesn't expose live traffic/bandwidth counters, so nothing here measures actual network load.

pass

Redundant fabric interconnect pair
Both Fabric A and Fabric B are present.

pass

Firmware in sync between fabrics
Both fabrics on 4.3(4.240066).

pass

Inter-fabric HA link
Cluster HA link reports up.

pass

Ethernet end-host mode
Running Ethernet End-Host Mode.

pass

Jumbo frame setting consistent
Jumbo frame setting matches on both fabrics.

warn

Ethernet uplink capacity balanced across fabrics
Fabric A has 400Gbps of uplink capacity vs Fabric B's 300Gbps — asymmetric fabrics mean uneven bandwidth/failover capacity if one side goes down.

pass

FC uplink capacity balanced across fabrics
Fabric A: 64Gbps, Fabric B: 64Gbps.

pass

Uplinks port-channelled (Fabric A)
Ethernet uplinks are bundled into port-channel(s).

pass

Uplinks port-channelled (Fabric B)
Ethernet uplinks are bundled into port-channel(s).

Configuration and link-state checks for the domain. These measure how the domain is provisioned, not how busy it is:

- Both fabrics present; firmware in sync; HA cluster link up
- Ethernet end-host mode (Cisco's usual recommendation); jumbo frame setting matching on both fabrics
- Ethernet and FC uplink capacity balanced between fabrics
- Uplinks bundled into port-channels
- Server-to-uplink oversubscription ratio (informational only)

In the demo, one uplink on fabric B is down, so the capacity-balance check turns amber.

10 • Network Devices

Intersight UCS Health Check

Export to Excel

Save Report

Settings

Servers

Fabric Interconnects

Network Devices

Data from "Demo Lab" collected 9/30/2026, 10:00:00 AM. No live connection — your API key was used once to collect this, then discarded. [Collect new data](#)

DEVICE	PRIMARY	PEER	HA LINK	FAULTS
demo-n9k-01	—: N9K-C93180YC-FX (10.4(3)) unknown	not present	unknown	0

Nexus and MDS switches managed by Intersight appear here with the same expandable layout. Most are standalone, so they show a single member rather than an A/B pair.

11 · RVTools (Dell, HPE and other hosts)

Intersight only covers Cisco hardware. For other vendors, export vCenter with **RVTools** and import the file in **Settings** → **Import RVTools export...**. The hosts appear in a separate **VM Hosts (RVTools)** tab, alongside any Intersight data.

Intersight UCS Health Check

CPU/Memory Summary Export to Excel Save Report Settings

Servers Fabric Interconnects Network Devices VM Hosts (RVTools)

Data from "Demo Lab" collected 9/30/2026, 10:00:00 AM. No live connection — your API key was used once to collect this, then discarded. [Collect new data](#)

RVTools import: 10 hosts from RVTools_export_all_DEMO.xlsx (2 non-physical rows excluded). [Import a different file](#)

CLUSTER	HOST	VENDOR / MODEL	CPU MODEL	SOCKETS	CORES	CPU %	MEMORY	VMS (ON / TOTAL)	VCPUS	VCPU : CORE	PROVISIONED RAM
Dev-HPE											
	hpe-esx-01.demo.local	HPE — ProLiant DL380 Gen11	Intel(R) Xeon(R) Gold 6448Y	2	64	30%	768 GiB	20 / 34	138	2.16	406 GiB
	hpe-esx-02.demo.local	HPE — ProLiant DL380 Gen11	Intel(R) Xeon(R) Gold 6448Y	2	64	25%	768 GiB	23 / 33	140	2.19	512 GiB
	hpe-esx-03.demo.local	HPE — ProLiant DL380 Gen11	Intel(R) Xeon(R) Gold 6448Y	2	64	15%	768 GiB	21 / 36	189	2.95	386 GiB
	hpe-esx-04.demo.local	HPE — ProLiant DL380 Gen11	Intel(R) Xeon(R) Gold 6448Y	2	64	31%	768 GiB	25 / 27	153	2.39	512 GiB
Prod-Dell											
	dell-esx-01.demo.local	Dell Inc. — PowerEdge R760	Intel(R) Xeon(R) Gold 6430	2	64	42%	1.00 TiB	35 / 38	188	2.94	653 GiB
	dell-esx-02.demo.local	Dell Inc. — PowerEdge R760	Intel(R) Xeon(R) Gold 6430	2	64	36%	1.00 TiB	36 / 39	256	4.00	613 GiB
	dell-esx-03.demo.local	Dell Inc. — PowerEdge R760	Intel(R) Xeon(R) Gold 6430	2	64	25%	1.00 TiB	35 / 47	248	3.88	625 GiB
	dell-esx-04.demo.local	Dell Inc. — PowerEdge R760	Intel(R) Xeon(R) Gold 6430	2	64	33%	1.00 TiB	34 / 38	206	3.22	757 GiB
	dell-esx-05.demo.local	Dell Inc. — PowerEdge R760	Intel(R) Xeon(R) Gold 6430	2	64	34%	1.00 TiB	36 / 48	224	3.50	754 GiB
	dell-esx-06.demo.local	Dell Inc. — PowerEdge R760	Intel(R) Xeon(R) Gold 6430	2	64	33%	1.00 TiB	34 / 39	242	3.78	719 GiB

- **Accepted files:** a full "export all" `.xlsx` or `.xls`, a single-tab vHost export, or the vHost CSV from RVTools' "export all to CSV".
- vSAN Witness Appliances and other non-physical rows are excluded automatically, and the banner shows how many were skipped.
- Hosts are grouped by cluster, with CPU, memory, VM density, vCPUs and vCPU-per-core ratio.
- **CPU/Memory Summary** works on this tab too, and uses the same SPEC data.

Intersight UCS Health Check

CPU/Memory Summary Export to Excel Save Report Settings

Servers Fabric Interconnects Network Devices VM Hosts (RVTools)

Data from "Demo Lab" collected 9/30/2026, 10:00:00 AM. No live connection — your API key was used once to collect this, then discarded. [Collect new data](#)

RVTools import: 10 hosts from RVTools_export_all_DEMO.xlsx (2 non-physical rows excluded). [Import a different file](#)

CLUSTER	HOST	VENDOR / MODEL	CPU MODEL	SOCKETS	CORES	CPU %	MEMORY	VMS (ON / TOTAL)	VCPUS	VCPU : CORE	PROVISIONED RAM
Dev-HPE											
	hpe-esx-01.demo.local	HPE — ProLiant DL380 Gen11	Intel(R) Xeon(R) Gold 6448Y	2	64	30%	768 GiB	20 / 34	138	2.16	406 GiB
	hpe-esx-02.demo.local	HPE — ProLiant DL380 Gen11	Intel(R) Xeon(R) Gold 6448Y	2	64	25%	768 GiB	23 / 33	140	2.19	512 GiB
	hpe-esx-03.demo.local	HPE — ProLiant DL380 Gen11	Intel(R) Xeon(R) Gold 6448Y	2	64	15%	768 GiB	21 / 36	189	2.95	386 GiB
	hpe-esx-04.demo.local	HPE — ProLiant DL380 Gen11	Intel(R) Xeon(R) Gold 6448Y	2	64	31%	768 GiB	25 / 27	153	2.39	512 GiB
Prod-Dell											
	dell-esx-01.demo.local	Dell Inc. — PowerEdge R760	Intel(R) Xeon(R) Gold 6430	2	64	42%	1.00 TiB	35 / 38	188	2.94	653 GiB
	dell-esx-02.demo.local	Dell Inc. — PowerEdge R760	Intel(R) Xeon(R) Gold 6430	2	64	36%	1.00 TiB	36 / 39	256	4.00	613 GiB
	dell-esx-03.demo.local	Dell Inc. — PowerEdge R760	Intel(R) Xeon(R) Gold 6430	2	64	25%	1.00 TiB	35 / 47	248	3.88	625 GiB
	dell-esx-04.demo.local	Dell Inc. — PowerEdge R760	Intel(R) Xeon(R) Gold 6430	2	64	33%	1.00 TiB	34 / 38	206	3.22	757 GiB
	dell-esx-05.demo.local	Dell Inc. — PowerEdge R760	Intel(R) Xeon(R) Gold 6430	2	64	34%	1.00 TiB	36 / 48	224	3.50	754 GiB
	dell-esx-06.demo.local	Dell Inc. — PowerEdge R760	Intel(R) Xeon(R) Gold 6430	2	64	33%	1.00 TiB	34 / 39	242	3.78	719 GiB

Fleet CPU/Memory Summary

20 processors across 10 servers. 8.00 TiB total memory

SPEC CPU2000

1087 results (since vint2007.csv, uploaded 9/30/2026)

Replace... Clear

SPEC CPU2000

10 results (since vint2007.csv, uploaded 9/30/2026)

Replace... Clear

Model

Qty

Serials

Total RAM

SPECint2007 (per server)

SPECint2007 (all servers)

Total SPECint2007

Total (2017-2026)

Pro ratio

hpe-esx-01.demo.local

12

6

8.00 TiB

522.3

N/A

3938.8

N/A

8.16 / N/A

4.00

hpe-esx-02.demo.local

12

6

8.00 TiB

510.3

N/A

2281.2

N/A

8.91 / N/A

3.88

hpe-esx-03.demo.local

12

6

8.00 TiB

510.3

N/A

2281.2

N/A

8.91 / N/A

3.22

hpe-esx-04.demo.local

12

6

8.00 TiB

510.3

N/A

2281.2

N/A

8.91 / N/A

3.78

dell-esx-01.demo.local

12

6

8.00 TiB

522.3

N/A

3938.8

N/A

8.16 / N/A

4.00

dell-esx-02.demo.local

12

6

8.00 TiB

510.3

N/A

2281.2

N/A

8.91 / N/A

3.88

dell-esx-03.demo.local

12

6

8.00 TiB

510.3

N/A

2281.2

N/A

8.91 / N/A

3.22

dell-esx-04.demo.local

12

6

8.00 TiB

510.3

N/A

2281.2

N/A

8.91 / N/A

3.78

dell-esx-05.demo.local

12

6

8.00 TiB

522.3

N/A

3938.8

N/A

8.16 / N/A

4.00

dell-esx-06.demo.local

12

6

8.00 TiB

510.3

N/A

2281.2

N/A

8.91 / N/A

3.78

12 · Exporting to Excel

Export to Excel writes a formatted workbook for the servers currently listed (respecting the filter). Which sheets appear depends on the data loaded:

Sheet	Contents	When
Overview	Account and report details, fleet-wide counts, and a list of servers needing attention (faults, critical alarms, active advisories, or a drive at $\leq 10\%$ life). With RVTools data, it also shows a live Fleet Sizing Summary and Per-Cluster Summary.	Always
Servers	The server table with alarm and advisory counts	Intersight data
Processors	The CPU/Memory rollup with SPEC estimates	Intersight data
Memory, Disks, Controllers, Power & Cooling	Every component, one row each, color-coded by state and drive life	Intersight data
Alarms, Advisories	Flattened across the fleet, with clickable advisory links	Intersight data
Fabric Interconnects, FI Ports, FI Best Practices	Domains, every port with traffic counters, and every check	Intersight data
RVTools Hosts	Imported hosts, including SPEC per server	RVTools data
Sizing & Staging	Refresh-planning sheet (chapter 13)	RVTools data
CPU Catalog, Memory Catalog, Model Lookup	Reference data that drives the Sizing & Staging dropdowns. Don't edit these.	RVTools data

13 · The Sizing & Staging sheet

This sheet helps you plan replacement Cisco UCS servers for each RVTools cluster and compare them with the hardware running today. It uses live Excel formulas, so totals update as you choose options.

Layout

- **Rows 1–7:** fleet-wide totals: *Staged (all clusters)*, *Original (all clusters)* and *Staged vs Original*.
- **One block per cluster**, each with six staging slots. Slot 1 is visible, and slots 2–6 are collapsed under the + in the margin.
- Below each block: *Staged Subtotal*, *Original (current fleet)* (cores, memory and SPEC of that cluster's existing hosts), and *Staged vs Original*.

Filling in a slot

- 1 **Generation:** M7, M8 Intel or M8 AMD.

- 2 **Server Model:** only models of that generation are offered.
- 3 **Processor (SKU):** only CPUs valid for that model. Cores, base GHz, TDP and socket limits fill in automatically.
- 4 **Sockets Used.** The *Compatibility* column warns if the CPU or model doesn't support that count.
- 5 **Memory Capacity (GB)** per DIMM, then **DIMM Cnt/CPU**. Only DIMM counts validated by Cisco's memory guide for that platform and capacity are offered.
- 6 **Qty:** the number of servers. Total cores, memory and SPEC are then calculated.

Resetting a cluster

Excel can't run a button without macros, so each cluster has a named range instead. Click the **Name Box** (left of the formula bar), pick that cluster's `Clear_...` entry (also shown at the right of its banner), then press **Delete**.

SPEC cells show 0 when no published result exists for a CPU, so totals always add up. Upload SPEC CSVs before exporting to get SPEC comparisons (chapter 8).

14 · Saving and opening reports

- **Save Report** writes everything collected (all servers with full inventory, and every domain and switch with ports, alarms and traffic) to one `.json` file.
- **Settings** → **Open a saved report...** loads it again, with no key or network needed. Every tab, the CPU/Memory Summary and the Excel export work exactly as they did after the live collection.
- Reports are a good way to share a snapshot with a colleague who doesn't have Intersight access. Treat them as confidential: they contain serial numbers, IP addresses and host names.

15 · Privacy & security

Item	Where it goes
API Key ID and private key	Never written to disk , not even encrypted. They are used for one Collect or Test call, then cleared from the form and from memory.
Base URL and key type	Saved as preferences so you don't retype them.
SPEC CSV data	Saved in the app's data folder (public benchmark data) until you clear it.
Collected data	Kept in memory only, until you choose <i>Save Report</i> or <i>Export to Excel</i> .
Network access	Only to the Intersight URL you enter, when you click Test or Collect.

API requests are signed inside the app's background process. The user interface never sees the private key.

16 · Troubleshooting

Any error returned by Intersight is shown in a red banner with its HTTP status and message.

Symptom	What to check
macOS says the app can't be opened	Right-click → Open (chapter 2).
Test connection fails with HTTP 401	The key ID and private key don't match, the key type is wrong (v2 vs v3), or the key was deleted or has expired.
HTTP 403 or missing servers	The key's role or organization scope doesn't cover those servers, or the Base URL points to the wrong region or appliance.
No traffic data on FI ports	Telemetry isn't available for that platform, license or time window (chapter 9).
SPEC shows N/A	No CSV is uploaded for that suite, or spec.org has no published result for that CPU.
RVTools import rejected	The file needs the vHost tab's columns. Export again with RVTools and pick the full report or the vHost CSV.