

OUTPUT

you can use this input to demodulate with an

external generator.

no longer processes the error and keeps the control signal on the laser constant.