L77392000YA Page 1 of 3

Designation	Description	Coordina
<u>A1</u>	Instrument cluster	47L
<u>A1p8</u>	Electronic speedometer	47L
<u>A7/5</u>	RB and power soft top hydraulic unit	3L 5L
<u>A7/5k1</u>	Hydraulic unit relay	4L
<u>A7/5m1</u>	Hydraulic unit motor	3L
<u>A7/5x1</u>	RB and power soft top hydraulic unit connector	2H
<u>A7/5y1</u>	Main valve	6L
<u>A22</u>	Left soft top fabric bow switch group	33L
<u>A22s1</u>	Bow "closed" switch	33L
<u>A22s2</u>	Bow "locked" switch	32L
<u>A22x1</u>	Left soft top fabric bow switch group connector	32K
<u>A23</u>	Right soft top fabric bow switch group	26L
<u>A23s1</u>	Bow "closed" switch	26L
<u>A23s2</u>	Bow "locked" switch	26L
<u>A23x1</u>	Right soft top fabric bow switch group connector	25K
<u>A24</u>	Left soft top compartment cover switch group	23L
<u>A24s1</u>	Cover "closed" switch	22L
<u>A24s2</u>	Cover "locked" switch	23L
<u>A24x1</u>	Cover switch group connector	22K
<u>A25</u>	Right soft top compartment cover switch group	16L
<u>A25s1</u>	Cover "closed" switch	17L
<u>A25s2</u>	Cover "locked" switch	16L
<u>A25x1</u>	Cover switch group connector	15K
<u>E15</u>	Dome lamp (with shut-off delay and reading lamp)	51L
<u>F1</u>	Fuse and relay box	45L
<u>F1f6</u>	Fuse 6	46K
<u>F20</u>	Rear auxiliary fuse box (trunk)	1L 7L
F20f3	Fuse 3	1K
F20f7	Fuse 7	7K
<u>N4/1</u>	EA/CC/ISC control module	57L
N10/2	Combination relay module (turn signal with trailer coupling, rear window defroster, wiper motor, ATA)	46L
<u>N16</u>	Engine systems control module	56L
<u>N22</u>	AAC pushbutton control module	34L
<u>N26</u>	ATA control module	59L
<u>N30</u>	ABS control module	53L
<u>N30/1</u>	ABS/ASR control module	54L 58L
<u>N51</u>	ADS suspension control module	52L
<u>N52</u>	Power soft top control module	4A 12A 20A 28A 36A

L77392000YA Page 2 of 3

		44A 53A 59A
S21/2	Right front power window switch (front center console)	41L
<u>S83</u>	RB switch (manual operation)	44L
<u>S83/1</u>	RB "retracted" switch	28L
<u>S84</u>	Power soft top switch	38L
<u>S84/1</u>	Left front soft top "locked" switch	30L
S84/1x1	Left front soft top "locked" switch connector	30K
<u>S84/2</u>	Right front soft top "locked" switch	31L
S84/2x1	Right front soft top "locked" switch connector	31K
<u>S84/3</u>	Soft top "open" switch (soft top in storage compartment)	25L
S84/3x1	Soft top "open" switch connector (soft top in storage compartment)	24K
<u>S84/4</u>	Soft top "closed" switch (reed contact as of 01/94)	24L
S84/4x1	Soft top "closed" switch connector	24K
<u>S84/5</u>	Soft top compartment "open" switch	27L
<u>S84/6</u>	Soft top fabric bow "raised" switch	29L
S84/6x1	Soft top fabric bow "raised" switch connector	29K
<u>W6</u>	Ground (left wheelhousing in trunk)	28G 32G
<u>W7</u>	Ground (right wheelhousing in trunk)	2G 5G 26G 28G
<u>W17</u>	Ground (right rear seat)	2E 8G 9G 18G
<u>W19</u>	Ground (right front seat crossmember)	15E 31E 43H
<u>X2/3</u>	VSS connector (ABS/engine) (2-pole)	53E 54E
<u>X6</u>	Terminal block (circuit 58d) (2-pole)	42H
<u>X11/4</u>	Diagnostic test clutch	36E 40H
<u>X11/12</u>	Soft top control test connector	14E
<u>X18</u>	Interior/taillamp harness connector (12-pole)	45E
X18/14	Interior/taillamp harness connector (CL/interior lamp) (2-pole)	34E
X23/1	Power soft top lock limit switch connector	30G
X30/1	Multi-function connector block	53G
<u>X35/15</u>	Module box/taillamp harness separation point	35H 57E
X85/2	Heater/interior connector (12-pole)	34H
<u>Y55</u>	Left RST valve block (4 connections)	19L
<u>Y55y6</u>	Soft top "open" valve	18L
VEE7	and the second s	
<u>Y55y7</u>	Soft top "close" valve	19L

L77392000YA Page 3 of 3

<u>Y55y9</u>	Fabric bow "lower" valve	21L
<u>Y56</u>	Right RST valve block (4 connections)	11L
Y56y2	Rear locks valve	13L
Y56y3	Center locks valve	12L
Y56y4	Front locks valve	11L
<u>Y56y5</u>	Soft top compartment cover valve	10L
<u>Y57</u>	RB valve block	8L
Y57y10	Rod side valve	8L
Y57y11	Piston side valve	9L
<u>Z88</u>	LF VSS sensor connector sleeve feed from traction system control modules	57G
*U29	00.19-2000 Front axle VSS	0
*U34	82.20-2000 Interior lighting	0