



SCAN TO DOWNLOAD APP

A GATEGPS PUBLICATION

Manual for

GG

-411


free **PLUS**

Life-time App Access

**SINGLE-COMMAND
DEVICE**

TERMS AND CONDITIONS APPLY

Sign Up/Registration



Download GateGPS APP on your mobile phone and sign up.

Log in with the newly created username.


If user already has an account, just log in with existing account details.


Please note that the actual image might be different. Do not worry, it still has the same function.

Product Parameters

- Size: 75 mm x 30 mm x 13 mm
- Weight: 35g
- Battery life: 06-24hours
- GPS sensitivity: Tracking: -165 dBm
- Position accuracy: 5 m
- Working voltage: 9-90 V
- GSM: 850/900/1800/1900 Quad band
- GPRS: Class12, TCP/IP
- Working current: 22 mA (DC12 V), 12 mA (DC24 V)
- GPS locating time: Cold start 32 seconds (open sky)

Wiring Diagram





Installation Steps


- Using the cable provided in the box with this terminal, make connections as shown in the wiring diagram.
- Ensure the ACC wire (Orange wire) is connected for proper and timely functioning on APP.
- Insert a valid SIM card in the device.
- Switch on the device with the pin included in the box.
- Plug the device to the socket.
- Hide in a good location in the vehicle. (*Away from extreme temperature, dust and moisture*).

By default, the mini-relay is provided with this terminal. Feel free to change with any 4pin relay 12v/24v relay of choice. GG Devices are compactible with a wide range of relays

Components



Add Vehicle to Account



For first-time registration, click on the + sign to add a vehicle. Note that you can register multiple vehicle in the same account.

Add Device

Save

Basic Information

Vehicle Name

IMEI Number

Device Type

Select device category

Aircraft

Arrow

Boat

Bus

Car

Default

Motorcycle

Tricycle

Truck

Person

Van

Others

Additional Information

Phone Number (Optional)

Device Model (Optional)

Contact Person (Optional)

Vehicle Name: Name you want the vehicle to be known as on the app

Imei/ID: IMEI number from the GateGPS device.
Sms *imei#* to tracker number to get this

Phone Number: Tracker Number inside the device

Contact Person: The installer or company phone number in international format for easy communication on app to installers (e.g +2348067617019)

SMS COMMAND LIST

	SEND	RESPONSE
Query Parameter	PARAM#	Current parameter info
Cut relay	relay,1#	<i>Command would shutdown the vehicle</i>
On Relay	relay,0#	<i>Command would restart the vehicle</i>

	SEND	RESPONSE
Get Location	• Call Tracker Number • Send url# as SMS	Location link Coordinates
Query Relay Status	Relay#	Replies with relay status
Add SOS number	SOS,A,num1,2,3# <i>where 1,2,3 are sos phone numbers</i>	Sos_Ok
Delete SOS number	SOS,D,1# <i>1 or 2 or 3 will delete the corresponding SOS number</i>	Sos del_Ok
Query SOS	SOS#	List Sos numbers
Get imei	imei#	imei number
change ip/port	Server,0,IP,Port,0 #	Server_ok
Activate Voice	Monitor#	Monitor Ok!
Cancel Voice	Tracker #	Tracker Ok!
LBS reporting switch	LBS,A# A=1,Enable LBS base station location reporting A=0,Disable LBS base station location reporting	LBS,A#
Set driving mode (ACC detection mode)	DRV,A# A=0/1/2 A=0: Vibration-based; sleeps after 3 min stillness (default). A=1: ACC-based; A=2: Vibration + ACC-based	Dvr,A#

ALERTS	SEND
Low Battery Alarm	BATALM,ON,M# <i>M=0~1: Alarm reporting mode 0 for App only, 1 for SMS + App</i>
Disable Battery Alarm	BATALM,OFF#
Disconnection Alarm	POWERALM,ON,M,T1,T2,# <i>M=0~2; Alarm reporting mode 0 for App only 1 for SMS + App 2 for GPRS + SMS + CALL T1 = 2-60 seconds; power-off detection time T2=1-300 seconds; minimum reconnection time</i>
Disable Disconnection Alarm	POWERALM,OFF#
Vibration alarm	SENALM,ON,M# <i>M=0~2; Alarm reporting mode 0 App only 1 SMS + App 2 App + SMS + CALL;</i>
Disable Vibration Alarm	SENALM,OFF#

ALERTS	SEND
Motion Alarm	MOVING,ON,R,M# <i>R = 100-1000; the displacement radius M=0~2; Alarm reporting method 0 for App only 1 for SMS + App 2 for App + SMS + CALL</i>
Disable Motion Alarm	MOVING,OFF#
Query Motion Status	MOVING#
Overspeeding Alarm	SPEED,ON,B,C,M# <i>B = 5 to 600 sec; time range C = 1-255 km/h; overspeed threshold range M=0~1; Alarm reporting method 0 for App only 1 for SMS + App</i>
Disable Overspeeding Alarm	SPEED,OFF#
Query Overspeeding Status	SPEED#

LED Light

Power Light

RED LIGHT	STATE
Slow Flash	Switched on and powered by only in-built battery
Long Bright	Normal operation (Connected to Vehicle/External power source)
Not on	Device failure or hibernation

GSM (Network) Signal Light

YELLOW LIGHT	STATE
Slow Flash	Searching for Network signal
Long Bright	Normal operation (Network Signal found and connected)
Not on	No Network or hibernation

GSM (Network) Signal Light

BLUE LIGHT	STATE
Flash	Searching for GPS Signal
Slow Flash	Normal operation (Signal found and connected)
Not on	No GPS signal or hibernation

Troubleshooting

ISSUE	CAUSE	SOLUTION
TRACKER NUMBER UNAVAILABLE/ SWITCHED OFF	Tracker is switched off.	Make sure device is properly connected.
	Poor Network reception in the area.	Check if vehicle battery is removed.
IMEI NOT VALIDATED	Wrong IMEI number	Get correct IMEI by requesting from device send imei# to Tracker Number
	IMEI not approved for life-time Access	Contact your dealer
VEHICLE NOT COMING ONLINE AFTER INSTALLATION	Invalid SIM	Check your SIM validity
	No Data on SIM Card	Ensure your SIM has an active data plan
	Re-directing to wrong server	Send SERVER,1,gategps.com,5023,0# to Tracker Number
APP REPORTING WRONG LOCATION OR LATE	GPS signal not located	Drive out of the current location
	ACC detection cable not connected	Ensure you connect the orange cable to an ignition indicator in the vehicle
NO SMS RESPONSE	Network issues	Reposition vehicle or wait out the network issue
	No credit in SIM Card	Recharge SIM Card