

GG terminal

SUPPORTS THE FOLLOWING
APPS BY DEFAULT



Effortlessly switch between
GateGPS App and **GPS-Go** App

	Feature items	Instruction format	Response or note
1	APN query	APN#	Reply: APN: cmnet,
2	APN set up	APN,cmnet,,# APN,cmnet,aaa,bbb#	Reply: APN: cmnet,aaa,bbb When no username or password is provided, it is recommended to leave the placeholder as a comma.
3	Server parameter query	SERVER#	Response: SERVER: 0,58.61.154.247,7018,0
4	Server parameter settings	1 、 Set domain name: SER- VER, 1, domain name, port, 0# 2 、 Set IP: SERVER, 0, IP, port,0# The last digit 0 repr- esents: TCP	Send: SERVER,0,58.61.154.247,7018,0# Response: SERVER: 0,58.61.154.247,7018,0
5	Address Query (Domestic)	123	http://mo.amap.com/?q=22.601862,113.832383&dev=1
6	Address Query (International)	666# URL# POSITION#	<03-20 22:45>http://maps.google.com/maps?q=+22.601862,+113.832383
7	Status query	STATUS#	Battery:4.23V;GPRS:Offline;GSMSignal Level:25;ACC:OFF;GPS:OFF;Defense:ON;
8	Version Query	VERSION#	Reply: J14_H18_GT06_54 V4.11 20220312
9	Latitude and longitude location query instruction	WHERE#	LastPosition! Lati:N22.601993,E113.832423,Course:169,Speed:0,DateTime:2022-03-20 22:48:49
10	Query parameter settings	PARAM#	IMEI:123456781911111;TIMER:10,3600;SN EDS:3;HBT:180Sec;Defense:2;
11	Restart instruction	RESET#	Reply: RESET OK
12	Check the fuel and power control status	RELAY#	Reply: RELAY: 0

13	Oil-electric control	RELAY,A# A=0/1; 0 turns on the fuel power,1 turns it off	Reply: RELAY 1 OK
14	Add central number 1	CENTER,A,Center number #	Send: CENTER,A,8613912345678# Reply: CENTER,A: 8613912345678
15	Delete Center Number 1	CENTER,D#	Reply: Center Del OK
16	Add central number 2	CENTER,A2,Center Number #	To: CENTER,A2,8613912345678# Reply: CENTER,A2: 8613912345678
17	Delete Center Number 2	CENTER,D2#	Reply: CENTER D2 Del OK
18	Add central number 3	CENTER,A3,Center Number #	To: CENTER,A3,8613912345678# Reply: CENTER,A3: 8613912345678
19	Delete Center Number 3	CENTER,D2#	Reply: CENTER D3 Del OK
20	Check call center number	CENTER#	Reply: CENTER,A: 8613812345678 CENTER,A2:8613912345678 CENTER,A3:8613812345678
21	Add a SOS number	SOS,A,Number 1,Number 2, Number 3#	SOS,A,8613912345678# SOS,A,8613912345678,8613912345678# SOS,A,8613912345678,8613912345678,8613912345678# You can set one or more numbers at once
22	Delete SOS number	SOS,D,Number 1,Number 2, Number 3#	SOS,D,1# SOS,D,1,2# SOS,D,1,2,3# You can delete one or more numbers at a time
23	Search for SOS number	SOS#	Reply: SOS: 8613912345678,8613912345678,8613912345678
24	Allow auto-reception	777#	Response: Automatic incoming call answer- ing is enabled After setup,the device automatically answers calls from any number.

25	Do not allow auto-reception	888#	Response: Automatic incoming call answer- ing has been disabled After setup,the device automatically answ- ers calls from SOS or the central number.
26	Set up incoming call features	SZCS#CALL_FUN=A	A=0: Voice monitoring after incoming call A= 1: Reply with a Google link after incoming call: SZCS#CALL_FUN= 1 Reply: SETOK: CALL_FUN= 1
27	Check incoming call function	CXCS#CALL_FUN	Reply: READOK: CALL_FUN= 1
28	Heartbeat interval	HBT,T1,T2# T1=60-300 seconds,ACC ON heart rate packet upload inter- val T2=60~300 minutes, ACC OFF interval for heart rate packet upload	Send: HBT,180,180# Response: HBT ACC ON: 180 seconds,ACC OFF: 180 seconds
29	Check heartbeat packet interval	HBT#	Response: HBT ACC ON: 180 seconds,ACC OFF: 180 seconds
30	Set GPS data transmission interval	TIMER,T1,T2# T1=5~60 seconds; upload interval under ACC ON state T2=5~1800 seconds; upload interval in ACC OFF state	Send: Timer,30,300# Response: Timer ACC ON: 30 seconds,ACC OFF: 300 seconds
31	Query GPS data transmission interval	TIMER#	Response: timer ACC ON: 30 seconds,ACC OFF: 300 seconds
32	Delayed fortification	DEFENSE,A# A: 1 to 60 minutes,with a delay time for defense	Send: DEFENSE,3# Reply: DEFENSE: 3
33	Query delay defense time	DEFENSE#	Reply: DEFENSE: 2
34	SENSOR control GPS time	SENDS,A# A=0-300 minutes	Send: SENDS,5# Reply: SENDS: 5

		0 Enable GPS	
35	Query SENSOR to control GPS time	SENDS#	Reply: SENDS: 3
36	Enable vibration alert settings	SENALM,A,M# A=ON M=0~2; Alarm reporting method 0 only GPRS 1 SMS+GPRS, 2 GPRS+SMS+CALL;	Send: SENALM,ON,2# Reply: SENALM: ON,2
37	Turn off vibration alert	SENALM,OFF#	Reply: SENALM: OFF
38	Check vibration alarm settings	SENALM#	Reply: SENALM: OFF
39	Turn off power outage alarm	POWERALM,A,M,T1,T2,# A=ON M=0~2; 0 for GPRS only, 1 for SMS+GPRS, 2 GPRS+SMS+CALL T1=2 to 60 seconds; power-off detection time T2= 1 to 3600 seconds; minimum charging time	Send: POWERALM,ON,2,10,10,# Response: POWERALM: ON,2,10,10
40	Disable power outage alarm	POWERALM,OFF#	Reply: POWERALM: OFF
41	Check power outage alarm status	POWERALM#	Response: POWERALM: ON,2,10,10
42	Enable low battery alarm	BATALM,A,M# A=ON M=0~1 0 Representative: Only GPRS, 1 represents: SMS+GPRS,	Send: BATALM,ON,1# Reply: BATALM: ON,1
43	Turn off low power alarm settings	BATALM,OFF#	Reply: BATALM: OFF
44	Check low power alarm status	BATALM#	Reply: BATALM: ON,1
	Enable displacement alarm	MOVING,A,R,M# A=ON R: 100-	Send: MOVING,ON,1000,2# Reply: MOVING:

45	setting	1000; Displacement radius M: 0-2; 0: GPRS only; 1: SMS+GPRS; 2	Send: MOVING,ON,1000,2# Reply: MOVING: ON,1000,2
		GPRS+SMS+CALL	
46	Displacement alarm off	MOVING,OFF#	Reply: MOVING: OFF
47	Check displacement setting status	MOVING#	Reply: MOVING: ON,1000,2
48	Enable speed limit violation alert	SPEED,A,B,C,M# A=ON B=5~ 600 seconds; C= 1~255 km/h; M=0~1; Alarm report- ing mode: 0 only GPRS, 1 SMS+GPRS;	Send: SPEED,ON,10,120,1# Reply: SPEED: ON,10,120,1
49	Turn off the speed limit alarm	SPEED,OFF#	Reply: SPEED: OFF
50	Check speed limit status	SPEED#	Reply: SPEED: ON,10,120,1
51	Enable ACC ignition warn- ing	ACCALM,A,M# A=ONM=0~3 0 : Only GPRS, 1 : GPRS+SMS, 2 : GPRS+CALL, 3 : GPRS+SMS+CALL	Send: ACCALM,ON,3# Reply: ACCALM: 3,OK
52	Turn off ACC ignition warning	ACCALM,OFF#	Reply: ACCALM,OFF OK
53	Check ACC ignition warn-ing	ACCALM#	Reply: ACCALM: 3,OK
54	Enable ACC fire alarm	ACCOFFALM,A,M# A=ON M=0~3 0 : Only GPRS, 1 : GPRS+SMS, 2 : GPRS+CALL,	Send: ACCOFFALM,ON,3# Reply: ACCOFFALM: 3,OK

		3 : GPRS+SMS+CALL	
55	Turn off the ACC fire alarm	ACCOFFALM,OFF#	Reply: ACCOFFALM,OFF OK
56	Check ACC fire alarm	ACCOFFALM#	Reply: ACCOFFALM: 3,OK
57	Set sleep mode	SZCS#SLPDISCONNECT=A	A=0 Keep platform connection after sleep (default) A= 1 After power-off sleep, the platform connects and SMS is available A=2 After the platform disconnects during sleep, SMS cannot be sent: SZCS#SLPDI- SCONNECT=0 Response: SETOK: SLPDISCONNECT=0
58	SMS Time Zone Settings	GMT,A,B,C#	A: E or W;"E" means eastern time zone,"W" means western time zone;default: E B: 0~12;time zone default: 8 C: 0/15/30/45; half time zone; default: 0; send: GMT,E,8,0# Reply: GMT: E,8,0
59	Check SMS time zone	GMT#	Reply: GMT: E,8,0
60	GPRS Time Zone Settings	SZCS#GT06GPRSGMT=A	A=0 Fixed to use the 0 time zone reporting platform (default) When A= 1,the platform time zone synchronizes with the SMS time zone for sending: SZCS#GT06GPRSGMT= 1 Reply: SETOK: GT06GPRSGMT= 1
61	GPRS time zone query	CXCS#GT06GPRSGMT	Response: READOK: GT06GPRSGMT= 1
62	change the mode to GPSGO mode	GPSGo	
6	change the mode to GateGPS mode (default)	GateGPS	

64	cut off the oil and electricity	Stop123456
65	resume the oil and electricity	Resume123456
66	cancel monitoring	Tracker123456
67	open monitoring	Monitor123456
68	get imei	Imei123456
6	change server	adminip123456 ip/port port
70	change password	Password123456 *****

D U A L -
C O M M A N D S