

Task 1 – Keyboard and Mouse Troubleshooting

1. Keyboard or Mouse is Not Detected

- **Problem:** The computer does not recognize the keyboard or mouse.
- **Solution:** Disconnect the USB device and plug it into a different USB port. Check whether the device is detected.

2. Keyboard or Mouse is Not Responding

- **Problem:** The keyboard or mouse is connected but does not respond to input.
- **Solution:** Restart the laptop/computer and reconnect the USB device. Check whether it starts working after the restart.

3. USB Connection Disconnects Frequently

- **Problem:** The keyboard or mouse keeps disconnecting and reconnecting.
- **Solution:** Connect the device to another USB port. Also inspect the USB cable for any damage or loose connection.

4. Mouse Cursor is Slow or Moving Irregularly

- **Problem:** The mouse pointer moves slowly, jumps, or does not move properly.
- **Solution:** Clean the mouse sensor and use the mouse on a clean, flat, and non-reflective surface.

5. Certain Keyboard Keys are Not Working

- **Problem:** One or more keys on the keyboard do not function.
- **Solution:** Remove dust and dirt from around the affected keys and reconnect the keyboard. If the issue remains, test with another keyboard.

Task 2 – Bluetooth Headphones Troubleshooting

1. Check the Headphone Power

- Switch on the Bluetooth headphones.
- Check the battery level.
- If the battery is almost empty, charge the headphones before trying to connect.

2. Verify Bluetooth on the Phone

- Open **Settings → Bluetooth**.
- Make sure Bluetooth is enabled.
- Check whether the headphones are visible in the available devices list.

3. Enable Pairing Mode

- Press and hold the **Power/Bluetooth button**.

- Wait until the indicator starts flashing, generally blue or blue/white.
- This means the headphones are ready for pairing.

4. Connect the Headphones

- Select the headphone name from the Bluetooth list.
- Wait for the device status to show **Connected**.
- Play some audio to verify the connection.

5. Check Other Connected Devices

- Check nearby phones, laptops, tablets, or TVs.
- Turn Bluetooth off on devices that may already be connected to the headphones.
- Try connecting again.

6. Remove and Pair the Device Again

- Go to **Settings → Bluetooth**.
- Select the headphones and choose **Forget/Remove Device**.
- Put the headphones into pairing mode again.
- Search for the headphones and connect them.

7. Restart the Devices

- Turn the headphones off and switch them on again.
- Restart the phone.
- Enable Bluetooth and try the connection again.

8. Observe the Bluetooth Light

- **Flashing light:** Usually means pairing mode.
- **Steady light:** Usually indicates an active connection.
- **No light:** The headphones may be switched off or have a low battery.

9. Try Another Phone

- Connect the headphones to another Bluetooth-enabled phone.
- If they work with the second phone, the issue may be related to the Bluetooth settings of the first phone.

10. Reset the Headphones

- If none of the above methods work, perform the headphone's factory reset.
- After resetting, put them into pairing mode and connect them again.

Task 3 – External Webcam Not Showing in Zoom

1. Verify the USB Connection

- Disconnect the external webcam.
- Plug it into another USB port.
- Check whether the webcam's indicator light turns on.

2. Check Windows Device Manager

- Press **Windows + X** → **Device Manager**.
- Find **Cameras** or **Imaging Devices**.
- Confirm that the external webcam is listed.
- If there is a warning symbol, try updating the webcam driver.

3. Check Camera Privacy Settings

- Open **Settings** → **Privacy & security** → **Camera**.
- Turn on **Camera access**.
- Make sure applications are allowed to use the camera.

4. Enable Camera Access for Desktop Applications

- In **Settings** → **Privacy & security** → **Camera**, enable **Allow desktop apps to access your camera**.
- This allows applications such as Zoom to use the webcam.

5. Choose the External Webcam in Zoom

- Open **Zoom**.
- Go to **Settings** → **Video**.
- Select the external webcam from the Camera option.
- Check the preview to confirm that the camera is working.

6. Close Other Camera Applications

- Close applications such as **Microsoft Teams**, **Skype**, **Google Meet**, or **Camera**.
- These applications may already be using the webcam.
- Restart Zoom and check the camera again. If required, restart the computer.

Task 4 – Fixing an Offline Printer Using Windows Troubleshooter

1. Open Windows Settings

- Press **Windows + I** to open the Windows Settings window.

2. Find the Printer

- Go to **Bluetooth & devices** → **Printers & scanners**.
- Select the printer that is showing an **Offline** status.

3. Start Printer Troubleshooting

- Select the printer and open its management options.
- Choose the **Troubleshoot** option if available.
- Follow the instructions provided by Windows.

4. Allow Windows to Detect the Problem

Windows may check different printer-related issues, such as:

- Printer connectivity
- Incorrect or outdated drivers
- Print Spooler service
- Printer settings
- Network communication problems

5. Check the Troubleshooting Report

- After the scan, Windows will display the detected problems.
- It may provide an automatic solution or instructions to resolve the issue.

6. Apply the Suggested Solution

- If Windows provides a recommended fix, select **Apply this fix** or follow the given instructions.
- Finally, print a **test page** to confirm that the printer is working correctly.