Troubleshooting method

Capture the symptom, when it began, load, ambient conditions, recent maintenance, alarms, and measurements before changing settings or parts. Compare with the equipment record. Check one hypothesis at a time and record results. Stop when observations indicate an electrical hazard, unexpected motion, smoke, burning odor, repeated protection trip, or a condition beyond staff authorization. This guide gives screening checks, not a confirmed diagnosis.

Excessive vibration

Possible contributors include looseness, imbalance, belt misalignment, bearing wear, soft mounting, or a change in the driven load. Record vibration at consistent locations and operating conditions using an appropriate instrument; compare against baseline and site limits. With equipment isolated, inspect accessible mounts, fasteners, guards, and belt condition. Do not run equipment with a guard removed. If vibration rises suddenly, includes impact sounds, or exceeds a site limit, keep the motor stopped and request qualified assessment.

Original synthetic content · Not manufacturer guidance

Motor will not start or trips

Record the protection device indication, trip timing, recent load changes, and any odor or sound. Do not repeatedly reset a tripping device. Qualified personnel may compare supply and current measurements against the nameplate and approved site limits after applying required electrical safety controls. Mechanical binding, overload, supply loss, and winding faults require different checks; the symptom alone does not identify the cause. Escalate repeated trips, smoke, arcing, or uncertain readings.

Original synthetic content · Not manufacturer guidance

Belt heat and wear

A hot belt or uneven edge wear may be associated with misalignment, incorrect tension, damaged pulleys, overload, or contamination. After isolation, inspect belt and pulley condition and verify alignment and tension against the drive specification with suitable tools. Never adjust a moving drive. If the specification is unavailable, do not guess; obtain the equipment data or qualified support.

Original synthetic content · Not manufacturer guidance

Abnormal bearing sound

Note whether the sound is continuous, intermittent, or load dependent and identify the bearing location without touching moving or hot parts. Compare with historical observations. After isolation, inspect for visible leakage and check service records. Sound alone cannot establish bearing condition. Persistent noise, roughness, heat, or increasing vibration needs qualified evaluation; do not inject lubricant without checking the specified type and service procedure.