## **CSE 438 Assignment 2: GPIO control in Linux Answers**

## Group 30

Prasanth Sukhapalli 1215358560

Kai Yuan Leong 1215666010

- 1. Writing 74 to /sys/class/gpio/export will create a folder /sys/class/gpio/gpio74. An error will occur when trying to open /sys/class/gpio/gpio74/direction because GPIO74 is a Mux GPIO and you can only write 0 or 1 to /sys/class/gpio/gpio74/value and the direction folder does not exist. You can set the direction of the corresponding GPIO10 by changing the value of GPIO74 or by writing in or out to /sys/class/gpio/gpio10/direction.
- 2. GPIO38 which is connected to IO7 has no interrupt modes therefore a rising edge will not trigger an interrupt on the Galileo Gen 2 Board.
- 3. When you export 3 to /sys/class/pwm/pwmchip0/export, it selects the 3<sup>rd</sup> channel in the 16 channel PWM. The period is 5000000 nano seconds. The period counter cannot be modified individually as all 16 channels in PCA9685 use a single period counter, and the period can only be set up per device at pwmchip0/device/pwm\_period.