
how to use the temperature and humidity sensor !!

what you will need:



you also need to download this zip file to add to your libraries! DHTLib


once you download it, open your arduino program, go to: Sketch —> Include Library —> Add .ZIP Library and find it in your downloads then:


Sketch —> Include Library —> select DHTLib under Contributed Libraries

how to set up your arduino:


- 1. plug in your arduino to your computer
- 2. plug the three prongs of the temp/hum sensor into the bread board, running parallel to the middle split (the blue part should be facing the center) (this piece will not lay flat!)

- 3. plug the black wire into GND on your arduino and into the line of the **third** prong on your breadboard
- 4. plug the orange wire into 5V on your arduino and into the line of the **second** prong on your breadboard
- 5. plug the white wire into the pin number of your choice (i chose 7) and into the line of the **first** prong on your breadboard





CONNECTING A THREE PIN DHT11:



see attached for the code! and the video!

helped by & code modified from: http://www.circuitbasics.com/how-to-set-up-the-dht11-humidity-sensor-on-an-arduino/