

## **Single Motor Command Description**

- 2.1 Read PID Parameter Command (0x30)
- 2.2 Write PID Parameters to RAM Command (0x31)
- 2.3 Write PID Parameters to ROM Command (0x32)
- 2.4 Read Acceleration Command (0x42)
- 2.5 Write Acceleration to RAM and ROM Command (0x43)
- 2.6 Read Multi-Turn Encoder Position Data Command (0x6)
- 2.7 Read Multi-Turn Encoder Original Position Data Command
- 2.8 Read Multi-Turn Encoder Zero Offset Data Command
- 2.9 Write Encoder Multi-Turn Value to ROM as Motor Zero
- 2.10 Write the Current Multi-Turn Position of the Encoder
- 2.11 Read Single-Turn Encoder Command (0x90)
- 2.12 Read Multi-Turn Angle Command (0x92)
- 2.13 Read Single-Turn Angle Command (0x94)
- 2.14 Read Motor Status 1 and Error Flag Command (0x9A)
- 2.15 Read Motor Status 2 Command (0x9C)
- 2.16 Read Motor Status 3 Command (0x9D)
- 2.17 Motor Shutdown Command (0x80)
- 2.18 Motor Stop Command (0x81)
- 2.19 Torque Closed-Loop Control Command (0xA1)
- 2.20 Speed Closed-Loop Control Command (0xA2)
- 2.21 Absolute Position Closed-Loop Control Command
- 2.22 Single-Turn Position Control Command (0xA6)
- 2.23 Incremental Position Closed-Loop Control Command
- 2.24 System Operating Mode Acquisition (0x70)
- 2.25 System Reset Command (0x76)
- 2.26 System Brake Release Command (0x77)
- 2.27 System Brake Lock Command (0x78)
- 2.28 System Runtime Read Command (0xB1)
- 2.29 System Software Version Date Read Command (0xB2)
- 2.30 Communication Interruption Protection Time Setting
- 2.31 Communication Baud Rate Setting Command (0xB4)
- 2.32 Motor Model Reading Command (0xB5)
- 2.33 Active Reply Function Command (0xB6)
- 2.34 Function Control Command (0x20)
- 7.0a Set Motor Id
- 7.0b Get Motor Id