### **Production Supporting Systems in Factories**

ระบบสนับสนุนการผลิตในโรงงานอุตสาหกรรม


### Context

#### Scope


The scope of a particular context value.

- Node only visible to the node that set the value
- Flow visible to all nodes on the same flow (or tab in the editor)
- Global visible to all nodes

#### Use flow context to pass values




# Upper inject node




### function node

```
msg.payload = Math.random();
return msg;
```

## change node




# Lower inject node




#### Side note

- You can use MQTT protocol to pass "context" information.
  - This is actually a better way.



### **Counter with reset button**


# Flow



## Random Number (function) node

```
msg.payload = Math.random();
return msg;
```


### Switch node



### Set Counter (Function) node

```
const curCounter = flow.get("counter") || 0;
flow.set("counter", curCounter + 1);
msg.payload = curCounter + 1;
return msg;
```

### button node



## change node

