

## Firestop Collar CP 644

### Product description

- A ready-to-use firestop collar, made of galvanized steel housing and intumescent inserts for firestopping large combustible pipes

### Product features

- No expiration date alleviates shelf life concerns
- Ready-to-use collar
- Fast installation time
- Adjustable/movable fastening tabs

### Areas of application

- Sealing of penetrations for a variety of combustible pipes from 8" to 10" in diameter
- Vented or closed pipe

### For use with

- Concrete, masonry, and gypsum walls
- Wall and floor assemblies

### Types of installation


- Wall: two collars, one on each side
- Floor: one collar on underside (bottom)

### Examples

- Waste water pipes
- Fresh water pipes
- Combustible pipe applications

### Installation instructions

- See Hilti Literature or third-party listings for complete application and installation details



Technical Data		CP 644		
Description	Pipe outside dia. (in.)	Collar outside dia. (in.)	Collar Height (in.)	No. of hooks and fasteners
CP 644-200/8"	8.8	10.0	6.9	10
CP 644-250/10"	10.0	12.4	9.1	12
<b>Temperature resistance</b>		-40°F to 140°F (-40°C to 60°C)		
<b>Intumescent Activation</b>		Approx. 392°F (200°)		
<b>Expansion ratio (unrestricted)</b>		Up to 1:17		
<b>Tested in accordance with</b>		UL 1479 ASTM E 814 ASTM G21		




Siesmic




Mould & Mildew

### Fixing Method




EN 1366-3


British Standard  
BS 476




### Application Procedure




- Close remaining gap by mortar or by CP606 for smoke and acoustic seal




2. Clean plastic pipe



3. Close jacket



4. Attach fastening hooks



5. Repeat the same jacket installation procedure for the other side of the wall