

GLOBAL

; up · . down · , / left/right · **ENTER** select · **`/DEL** back · { } page · **b** screenshot · **h** help

HOME

ENTER opens item; menu scrolls: Satellites, Next Passes, Passes, Track, Sun/Moon, Location, Update, Settings, Log, About

SATELLITES

f favorite · **v** favs-only · **n** new GP sat · **o** orbital · **s** sim · **d** 10-day · **i** illum · **ENTER** passes · right edge: dot = AMSAT heard, square = telemetry, ring = not heard

NEXT PASSES (favs)

ENTER track · **m** world map · **r** refresh · **z** deep-sleep until AOS

PASSES (sel)

;/. select · **d** detail · **t/ENTER** track · **n** add TX · **r** recompute · **x** mutual-DX · **v** 10-day · **i** illum · **g** workable grids

TRACK (sel)

m TUNE/CAL · **d** tune mode (FULL/DL/UL/hold) · **t** next TX · **c** CTCSS · **r** radio · **o** rotator · **p** polar · **f** Manual · **l** log QSO · **g** grids now · **ENTER** save cal

MANUAL (no radio)

Fix one leg, read Doppler freq to tune the other by hand. **u** toggle HOLD/TUNE leg · ,// passband (linear) · **m** CAL · **t** next TX · **l** log · **p** polar · **g** grids · **`/f** Track

TRACK · TUNE

,// tune -/+ · **s** step 100/1k/5k · **x** recenter

TRACK · CAL

,// downlink · ;/. uplink · **s** step 10/100/1k · **x** zero

WORKABLE GRIDS

4-char Maidenhead grids under the footprint (per-pass union or live now); count on a cyan line above the list. ;/. & {/} scroll · **`** back

POLAR / PASS DETAIL

Pass detail: **p** polar of this pass. Polar: **l** log QSO · **p/ENTER/`** back

SUN / MOON

Graphic sky-dome (Sun/Moon glyphs by az/el) · **g** graphic/list · **;/.** pick Sun/Moon · **o** rotor track on/off · **x** stop · **`** back

ORBITAL ANALYSIS

;/ pages: Info / Live / Next pass / Ground track / Doppler / Nodal / Sun-Beta · **r** recompute. Info: footprint dia (= longest QSO) + decay range. Doppler **f** sets beacon freq. Nodal: J2 drift, sun-sync, LTAN. Sun/Beta: beta angle, eclipse %/orbit.

SIMULATION

;/ step time · **;/.** step size · **m** world-map view (sub-point + footprint) · **x** reset to now · **`** back

LOCATION

e/o/a lat/lon/alt · **g** grid · **p** GPS on/off · **s** GPS source · **c** set clock · **ENTER** GPS sky plot

GPS SKY PLOT

Live GNSS by az/el, coloured by signal (green=strong, grey=weak) · **`** back

WORLD MAP

All footprints · **f** highlight favorite · **y** sun · **c** eclipse · **`** back

SCHEDULES

10-day: **;/.** scroll +/-1 day (fills full days), **r** recompute · **lllum:** **;/** scroll +/-1 day · Mutual: **;/.** scroll

LOG

Menu: **ENTER** new / browse / export ADIF · List: **;/.** scroll, **ENTER** edit · Entry: **;/.** field, **ENTER** edit, **s** save, **x** x2 delete

UPDATE

k/ENTER GP + clock · **a** cache all transponders · **w** WiFi connect only

SETTINGS

;/ change · **ENTER** edit/toggle · **s** scan WiFi (SSID row) · reset = type ERASE

GP SOURCE

AMSAT / any **CelesTrak** JSON-PP category (Amateur first) / Custom URL · **;/.** move · **{/}** page · **ENTER** select

ROTATOR (manual)

;/ az · **;/.** el · **s** step · **x** stop · **`** back

NETWORK SERVERS

rigctld: PC drives the rig via CardSat over TCP (VFOA=downlink, VFOB=uplink) · **rotctld:** PC drives the wired GS-232 via CardSat · **rigctl:** CAT type drives a remote rig

EDIT

type · **DEL** backspace · **ENTER** ok · **`** cancel

ABOUT

Build/version, IP, free heap and diagnostics (read-only).