Aerotherm AH18 Series Heat Pump: Homeowner's Manual (Excerpt)

Aerotherm is a fictional manufacturer created for ServiceIQ testing · Document AH18-HO-2025 rev A

Models covered

AH18HP024, AH18HP036, AH18HP048 and AH18HP060 variable-speed heat pumps (up to 18.0 SEER2, 9.0 HSPF2), R-454B refrigerant.

Normal winter operation

- **Defrost cycle:** In cold, damp weather frost builds up on the outdoor coil. The unit automatically runs a defrost cycle for 2-10 minutes. During defrost the outdoor fan stops, you may see steam rising from the unit and hear a whoosh when the reversing valve shifts. This is normal.
- **Auxiliary heat:** When the heat pump alone cannot keep up, the thermostat turns on backup heat and may display "Aux Heat". Brief periods of auxiliary heat during cold weather or recovery from a setback are normal.
- **Emergency heat:** "Em Heat" runs only the backup heat source and should be used only if the heat pump has failed, until service arrives. It is more expensive to operate.

When to call for service

- The outdoor unit is completely covered in ice and does not clear after a defrost cycle
- Auxiliary heat runs continuously in mild weather
- The unit makes grinding or loud banging noises

Homeowner maintenance

- Keep 24 inches of clearance around the outdoor unit and keep it raised above snow level.
- Never pour hot water on the outdoor coil or chip ice from it.
- Replace indoor air filters regularly. Have the system serviced twice a year (spring and fall).

Warranty

10-year limited parts warranty when registered within 60 days of installation; 5-year limited parts warranty if not registered. Labor is not covered by the manufacturer.