Aerotherm AT16 Series Split-System Air Conditioner: Homeowner's Manual (Excerpt)

Aerotherm is a fictional manufacturer created for ServiceIQ testing · Document AT16-HO-2025 rev B

Models covered

Model	Nominal capacity	Efficiency	Refrigerant
AT16AC024	2 ton	16.2 SEER2	R-454B
AT16AC036	3 ton	16.0 SEER2	R-454B
AT16AC048	4 ton	15.6 SEER2	R-454B
AT16AC060	5 ton	15.2 SEER2	R-454B

Safety

- This unit contains a mildly flammable (A2L) refrigerant. Only certified technicians may service the refrigerant circuit.
- Disconnect all power before cleaning around the unit.
- Do not operate the unit with panels removed.

Homeowner maintenance

- Keep at least 24 inches (2 feet) of clearance around the outdoor unit and 5 feet above it.
- Remove leaves, grass clippings and debris from the coil fins. You may gently rinse the coil with a garden hose from the inside out after disconnecting power. Do not use a pressure washer.
- Replace or clean the indoor air filter regularly.
- Have the system professionally inspected once a year.

Normal operation

- The outdoor fan may continue to run briefly after the compressor stops.
- The unit has a built-in 5-minute anti-short-cycle delay. After a power interruption or thermostat change, the compressor may wait up to 5 minutes before starting. This is normal.

Before calling for service

- Confirm the thermostat is set to Cool and below room temperature.
- Check the outdoor disconnect and the circuit breakers.
- Check the indoor air filter.
- If the unit still does not run, contact your Aerotherm dealer.

Warranty

10-year limited parts warranty when registered within 60 days of installation; 5-year limited parts warranty if not registered. Labor is not covered by the manufacturer.