

USER MANUAL

Thank you for purchasing our product. Please read it carefully before use The following three points are explained.

1、Warning

1. Do not disassemble or repair the machine on your own.
2. Do not use or store this machine in environments with high temperature, humidity, dirt, or high voltage.
3. Do not let the machine fall or hit hard surfaces.
4. Do not damage the surface of Hei Sui with the help of regulations or drugs
5. If the machine is not used for a long time, please disconnect the power.

2、Usage

1. Connect the power supply to the machine, press the switch, and the machine will start working.
2. Connect the machine to your guitar/device, adjust the knob to achieve the desired sound effect.
3. Press the switch again to turn off the machine.

3、Parameter specifications

	Input Impedace	Out Impedace	Running Current	Power	Speed Range	Delay Time
Vintage Overdrive	500K Ω	10K Ω	7mA	DC 9V	/	
Ultimate Drive	1M Ω	1K Ω	6mA	DC 9V	/	
Crunch Distortion	1M Ω	1K Ω	10mA	DC 9V	/	
Us Dream	1M Ω	1K Ω	10mA	DC 9V	/	
Classic Chorus	500K Ω	10K Ω	9mA	DC 9V	/	
Vintage Phase	500K Ω	10K Ω	13mA	DC 9V	0.2Hz-16Hz	
Analog Chorus	1M Ω	1K Ω	12mA	DC 9V	/	
Digital Delay	500K Ω	10K Ω	26mA	DC 9V	/	20ms-600ms
Tremolo	1M Ω	1K Ω	7mA	DC 9V	1Hz-25Hz	
Analog Delay	1M Ω	1K Ω	13mA	DC 9V	/	