

TerraLift Industrial Equipment

Model RS-450 Reach Stacker — Machine Error Code Reference

This manual documents fault codes, causes, and recommended corrective actions for the RS-450 Reach Stacker reach stacker and its compatible variants. All error codes, thresholds, and corrective procedures below apply specifically to the RS-450 Reach Stacker platform unless otherwise noted. Technicians should confirm the machine's model designation on its nameplate matches RS-450 Reach Stacker before applying any procedure in this document.

Fault codes, causes and recommended corrective actions for the RS-450 Reach Stacker.

Code	Name	Possible Cause	Action
E-001	Loaded_overspeed	The traveling speed is above the safety speed limit.	1. Lower the traveling speed. 2. Lower the load height. 3. Decrease the forward tilting angle of mast.
E-002	GearboxTemp_H	Gearbox temperature is too high, checked to be higher than 120°C.	1. Check whether the radiator temperature control switch, driving motor and the radiator fin are dirty. 2. Check whether the voltage-distributing circuit of resistor is normal.
E-003	Hyd_OilTemp_H	Hydraulic oil temperature is too high, checked to be higher than 65°C.	1. Check whether the sensor connector is normal. 2. Check whether the sensor is effective. 3. Check the radiator or the temperature control switch on it. Check if the radiator fin is dirty.
E-004	Oilwater_Alarm	The signal of oil-water separator is abnormal.	1. Check if the filter is too dirty or clogged. Replace or clean it if necessary. 2. Check the switch components with universal meter. 3. Check if the switch is too dirty. 4. Check if the wire-out of switch is disconnected.
E-005	ACC_PL_Alarm	The pressure switch of accumulator functions.	Check if the parking oil-way pressure and circuit of parking valve are normal.
E-006	Engine_coolant_L	The signal of coolant level switch is abnormal.	1. Check the coolant level.
E-007	HYD_FJ_Alarm	The signal of hydraulic oil filter is abnormal.	1. Check if the filter is too dirty or clogged. Replace or clean it if necessary. 2. Check the switch components with universal meter.
E-008	Brake_FJ_Alarm	The signal of brake oil filter is abnormal.	1. Check if the filter is too dirty or clogged. Replace or clean it if necessary. 2. Check the switch components with universal meter.
E-009	Sensor_Error	The signal of sensor is abnormal.	1. Check the function of sensor. 2. Check if the wires are loose. 3. Check the power supply.
E-010	FueLevel_L	The fuel level is lower than 50L.	1. Check the oil level of tank. 2. Check the sensor and circuit.
E-011	GearboxPressure_L	The pressure is lower than 16 bar.	1. Dismantle the sensor to see if it is blocked. 2. Check the function of sensor. 3. Check the disconnection alarm of sensor.
E-012	Engine_Tem_H	The water temperature of engine is above 103°C.	1. Check if the engine radiator is dirty. If yes, clean it. 2. Check the water level and pipe of tank. 3. Check the fan and belt.
E-013	Engine_OilPress_L	Oil pressure of engine oil is lower than 55 kPa.	1. Check if the oil is refilled during maintenance. 2. Check if the filter is changed at regular intervals. 3. Check the oil sensor and circuit.

Code	Name	Possible Cause	Action
E-014	Battery_voltage_L	Battery voltage is lower than 23V.	1. Check the working condition of generator. 2. Check if there is enough power for battery.
E-015	Safe_bypass	Use the safety bypass.	Check if the safety bypass is functioning.
E-016	LockUnlock_Alarm	Spreader proximity switch is abnormal.	Check the working condition of spreader proximity switch.
E-017	Load_Over_90%	Load percentage is above 90% of the maximum load.	1. Check if the load percentage is too large. 2. Check if the heavy pressure sensor is working normally.
E-018	Over_Load	The lifting weight is above the max. load.	1. Check if the load percentage is too large. 2. Check if the heavy pressure sensor is working normally.
E-019	SYMT_CanFault	No receiving of GPS internal signal for long interval.	1. Check if the GPS power line is connected well. 2. Check the signal of GPS.