

Industrial Water Pump Maintenance Manual

Overview

The PX-400 industrial water pump is designed for continuous operation in manufacturing plants. Rated speed: 1450 RPM. Maximum discharge pressure: 12 bar.

Safety

Disconnect power before maintenance. Apply lockout/tagout. Wear gloves, eye protection, and safety shoes.

Daily Inspection

Check vibration, motor temperature, pressure gauge readings, unusual noise, oil leaks, and seal condition.

Weekly Maintenance

Inspect coupling alignment, tighten fasteners, clean cooling vents, inspect electrical terminals, verify lubrication.

Monthly Maintenance

Inspect bearings, replace contaminated lubricant, inspect impeller, clean suction filter, inspect mechanical seal.

Common Faults

High vibration: worn bearings or shaft misalignment. Low pressure: clogged filter or damaged impeller. Motor overheating: blocked ventilation or overload.

Corrective Actions

Replace worn bearings, realign shaft, clean suction filter, inspect impeller, refill ISO VG 68 lubricant, verify motor load.

Maintenance Schedule

Daily: visual inspection. Weekly: alignment and lubrication. Monthly: bearings and seals. Quarterly: vibration analysis.