

1. List 5 common issues users face with USB keyboards or mice on laptops, and write one possible solution for each.

Issue	Possible Solution
1. Keyboard or mouse is not detected	Unplug the device and reconnect it to another USB port.
2. Device works intermittently	Check for a loose connection or damaged USB cable.
3. Keyboard keys or mouse buttons are not responding	Restart the laptop and test the device again.
4. Device driver is corrupted or outdated	Update or reinstall the USB/HID drivers from Device Manager.
5. USB ports are not supplying power	Disable USB power saving settings or try a powered USB hub.

2. Simulate a troubleshooting flow: Your Bluetooth headphones are not connecting to your phone. Write the exact step-by-step actions you would take to diagnose and fix the issue, mentioning any settings or indicators you would check.

Step-by-step actions:

- 1. Check battery level**
 - Ensure the Bluetooth headphones are charged.
 - Look for battery indicator lights.
- 2. Turn Bluetooth ON**
 - Open **Settings** → **Bluetooth** on the phone.
 - Verify Bluetooth is enabled.
- 3. Check if headphones are in pairing mode**
 - Press and hold the power button until the LED flashes (usually blue/red).
- 4. Check previously paired devices**
 - If the headphones appear as "Connected to another device", disconnect them from that device.
- 5. Forget and reconnect**
 - On the phone:
 - Settings → Bluetooth
 - Tap the headphone name
 - Select **Forget Device**
 - Scan again and reconnect.

6. Restart both devices

- Turn OFF the phone.
- Turn OFF the headphones.
- Turn both back ON.

7. Move closer

- Keep both devices within 1–2 meters.
- Remove interference from other Bluetooth devices.

8. Check for software updates

- Update the phone's operating system if available.

9. Reset the headphones

- Follow the manufacturer's reset procedure.

10. Test with another phone

- If it still doesn't connect, test the headphones with another device to identify whether the problem is with the phone or the headphones.

3. A user reports that their external webcam is not detected during a Zoom call on Windows 10. Write a checklist of 6 things to check or try to resolve the problem.

Hint: Consider device manager, privacy settings, and app permissions.

1. Check the USB connection

- Unplug and reconnect the webcam.
- Try another USB port.

2. Verify Device Manager

- Press **Windows + X** → **Device Manager**.
- Expand **Cameras** or **Imaging Devices**.
- Check for warning symbols.

3. Allow camera permissions

- Open **Settings** → **Privacy** → **Camera**.
- Turn ON:
 - Camera access for this device
 - Allow apps to access your camera
 - Allow desktop apps to access your camera

4. Check Zoom camera selection

- Open Zoom.
- Go to **Settings** → **Video**.
- Select the correct webcam from the drop-down menu.

5. Close other applications

- Exit Teams, Skype, Discord, or other apps that may already be using the camera.

6. Update or reinstall webcam drivers

- Device Manager → Right-click webcam → Update driver.
- If necessary, uninstall and restart Windows.

4. You are helping a friend whose printer is showing 'offline' status on their PC. Describe how you would use the Windows Troubleshooter tool to try to fix the issue, and explain what information the tool provides during the process.

Steps:

1. Turn on the printer and ensure it is connected to the same Wi-Fi network or connected by USB.
2. Open **Settings**.
3. Click **Update & Security**.
4. Select **Troubleshoot**.
5. Click **Additional troubleshooters**.
6. Select **Printer**.
7. Click **Run the troubleshooter**.
8. Choose the printer that shows **Offline**.
9. Windows will automatically check for problems.

The troubleshooter checks:

- Printer connectivity
- Printer spooler service status
- Driver problems
- Printer queue errors
- Incorrect default printer settings
- Network communication issues

Information provided during the process:

Windows will display messages such as:

- **Checking printer status**
- **Checking spooler service**
- **Repairing printer queue**
- **Setting printer as default**
- **Applying fixes**