Communication To(RX)-From(TX) Global State Machine

RX - Data

Duty_de[4]	10000 = 100%

CMD

Reset	5
StandBy	2
Run	3

TX - Data

Duty_fb	1000 = 100%
Speed	10 * rpm

STATUS

Stop	1
Ready	2
Run	4
Error	11

Errors Description

Overcurrent ph U	x01h
Overcurrent ph V	x02h
Overcurrent ph W	x04h
DClink overvoltage	x08h
DClink undervoltage	x10h
Overtemperature	x20h

TX - Data

Voltage (DC?)	2 * V
Current (DC? - estimated)	5 * A
Device Temperature	deg