



Series, not shunt: F1 protects the run it is in.
C1 is bulk where power enters the board, not decoupling
at a load -- every capsule carries its own. See design.py.

REVERSED J10 SHORTS CH1-6 TO GND

Verified against cycfi/nu @ github.com/cycfi/nu -- nu_capsule/nu_preamp.sch and internal_breakout/internal_breakoutsch.sch

J10, pin for pin against the breakout's own:

- ```
1 = CH2
2 = CH1
3 = CH4
4 = CH3
5 = CH6
6 = CH5
7 = CH8 not fitted (this hub carries six channels)
8 = CH7 not fitted (this hub carries six channels)
9 = GND
10 = CH9 not fitted (this hub carries six channels)
```

J11, pin for pin against the breakout's own:

- ```
1 = CH11 not fitted (this hub carries six channels)
2 = CH10 not fitted (this hub carries six channels)
3 = CH13 not fitted (this hub carries six channels)
4 = CH12 not fitted (this hub carries six channels)
5 = CH15 not fitted (this hub carries six channels)
6 = CH14 not fitted (this hub carries six channels)
7 = VIN
8 = VIN
9 = GND
10 = GND
```

Reversed, a 2x5 maps pin n to pin $11-n$. On J10 that puts pin 2 (CH1) on pin 9 (GND) and shorts the capsule outputs to ground -- recoverable, but NOT harmless the way a reversed cable is on the breakout variant. Check first.

Two parts, and only two. Each capsule carries its own 100 nF (C1) + 4.7 uF (C2) across VCC1, on the capsule, and its power pin is Schottky protected on the capsule, so

Nothing here is decoupling or reverse protection. F1 is in series and C1 is bulk at the point power enters the board.

M2 clearance, unplated, --, not on GND
No regulator: Cycfi deleted theirs in breakout v2.6 because
the Nu capsules run from 5 V to 18 V. V+ is whatever VIN is.