

MEDIATEK

MT8676 Android GPS User Manual

Version: 1.0
Release date: 2024-08-12

Use of this document and any information contained therein is subject to the terms and conditions set forth in Exhibit. This document is subject to change without notice.

Version History

Version	Date	Author	Description
1.0	2024-08-12	Neo.Sun	Official release

Table of Contents

Version History2

Table of Contents3

List of Figures3

List of Tables3

1 GPS4

1.1 Overview4

1.1.1 Brief Introduction4

1.1.2 GPS Abbreviations4

1.2 Architecture/Process Overview4

1.3 Configuration/Customization Guideline6

1.3.1 Fix Rate Configuration6

1.3.2 GNSS Mode Configuration6

1.4 Frequently Asked Questions/Troubleshooting7

1.4.1 AOSP Raw Measurement7

1.4.2 Log Related Issues8

1.4.3 Testing Related Issues8

1.4.4 GNSS Path9

Exhibit 1 Terms and Conditions10

List of Figures

Figure 1-1. GPS architecture5

Figure 1-2. Fix Rate configuration6

Figure 1-3. GNSS configuration7

Figure 1-4. AOSP Raw Measurement process8

List of Tables

Table 1-1. Abbreviations4

1 GPS

1.1 Overview

1.1.1 Brief Introduction

This section introduces the basic functions of the MT8676 Global Positioning System (GPS) and the solutions to common problems.

1.1.2 GPS Abbreviations

Table 1-1. Abbreviations

Abbreviation	Explanation
COLD start	With time-assisted information, the end user will not encounter this scenario.
FULL start	Without any auxiliary information, equivalent to the scenario where an end user uses a positioning application for the first time after purchasing a mobile phone.
GNSS	Global Navigation Satellite System
GPS	Global Positioning System
Hot start	With all auxiliary information, the end user's current positioning occurs less than 2 to 4 hours after the last positioning.
NMEA	National Marine Electronics Association. A communication protocol used for data exchange between marine electronic devices, widely applied in GPS/GNSS receiver data output.
TTFF	Time To First Fix. The time required for a navigation device to successfully acquire the first valid positioning data from startup.
WARM start	With time and location-assisted information, the end user's current positioning occurs more than 2 to 4 hours after the last positioning.

1.2 Architecture/Process Overview

MT8676 GPS architecture is shown in [Figure 1-1](#).




Figure 1-1. GPS architecture

1.3 Configuration/Customization Guideline

1.3.1 Fix Rate Configuration

Fix Rate refers to the rate at which GNSS reports position information. The fixed rates currently supported by MT8676 include: 1Hz, 2Hz, 5Hz, and 10Hz, with the default configuration being 1Hz output. The method to change the fixed rate is as follows:

Method1: Modify the code to configure the `fix_interval` parameter. `fix_interval = 100` corresponds to 10Hz; `fix_interval = 1000` corresponds to 1Hz.



Figure 1-2. Fix Rate configuration

Method2: Dynamically modify the configuration file, which will take effect after restarting GNSS.

Command: `echo fix_interval=1000 >> /data/vendor/gps/mnl.prop /Set to 1Hz, effective after GPS restart.`

1.3.2 GNSS Mode Configuration

MT8676 supports GPS + GLONASS + Galileo + BeiDou multi-satellite navigation positioning systems. The default configuration for `gnssopmode` is set to `MTK_CONFIG_GPS_GLONASS_BEIDOU_GALILEO_NAVIC` (the default configuration offers the best GNSS performance, and it is recommended to use the default configuration).

```
885 typedef enum
886 {
887     MTK_CONFIG_GPS_GLONASS = 0,
888     MTK_CONFIG_GPS_BEIDOU,
889     MTK_CONFIG_GPS_GLONASS_BEIDOU,
890     MTK_CONFIG_GPS_ONLY,
891     MTK_CONFIG_BEIDOU_ONLY,
892     MTK_CONFIG_GLONASS_ONLY,
893     MTK_CONFIG_GPS_GLONASS_BEIDOU_GALILEO,
894     MTK_CONFIG_GPS_GALILEO,
895     MTK_CONFIG_GPS_GLONASS_GALILEO,
896     MTK_CONFIG_GALILEO_ONLY,
897     MTK_CONFIG_GPS_GLONASS_BEIDOU_GALILEO_NAVIC,
898     MTK_CONFIG_GNSS_END
899 } MTK_GNSS_CONFIGURATION;
```

Figure 1-3. GNSS configuration

1.4 Frequently Asked Questions/Troubleshooting

1.4.1 AOSP Raw Measurement

AOSP Raw Measurement refers to GNSS satellite observations, including both raw and processed information. The MT8676 GPS supports AOSP raw measurements, which belong to the native Android process. The workflow is shown in [Figure 1-4](#). For detailed usage, please refer to the *Google Developer Documentation*.




Figure 1-4. AOSP Raw Measurement process

1.4.2 Log Related Issues

- What logs do MediaTek engineers need for problem analysis?
/data/debuglogger/mobilelog, and /data/debuglogger/connsyslog
- How to determine if the GPS software is working properly through logs?
Please check if there are NMEA Sentences appearing in the log. If they appear, it indicates that the software is functioning properly.

1.4.3 Testing Related Issues

- Before testing, it is necessary to check whether there is a satellite signal and whether it is in an open sky environment.
To test GNSS satellite search or positioning functions, the signal needs to be in an open sky environment, such as an open outdoor area or a laboratory with a signal amplifier.
The prerequisite for successful positioning is having more than six satellites with a CNR of 40~43 dBm. ---> It is crucial to pay attention to this when testing GNSS. If you are unsure whether the current signal environment meets the requirements, place a comparison device in the same environment for comparison.

- How to test the Time To First Fix (TTFF) for different startup modes such as FULL start, WARM start, COLD start, and HOT start?

Please use the YGPS in engineering mode or use the following adb command to open YGPS and test using the FULL, COLD, WARM, and HOT buttons.

```
adb shell am start com.mediatek.ygps/.YgpsActivity
```

1.4.4 GNSS Path

Source code:

```
vendor\mediatek\proprietary\hardware\connectivity\gnss
```

Exhibit 1 Terms and Conditions

Your access to and use of this document and the information contained herein (collectively this “Document”) is subject to your (including the corporation or other legal entity you represent, collectively “You”) acceptance of the terms and conditions set forth below (“T&C”). By using, accessing or downloading this Document, You are accepting the T&C and agree to be bound by the T&C. If You don’t agree to the T&C, You may not use this Document and shall immediately destroy any copy thereof.

This Document contains information that is confidential and proprietary to MediaTek Inc. and/or its affiliates (collectively “MediaTek”) or its licensors and is provided solely for Your internal use with MediaTek’s chipset(s) described in this Document and shall not be used for any other purposes (including but not limited to identifying or providing evidence to support any potential patent infringement claim against MediaTek or any of MediaTek’s suppliers and/or direct or indirect customers). Unauthorized use or disclosure of the information contained herein is prohibited. You agree to indemnify MediaTek for any loss or damages suffered by MediaTek for Your unauthorized use or disclosure of this Document, in whole or in part.

MediaTek and its licensors retain titles and all ownership rights in and to this Document and no license (express or implied, by estoppels or otherwise) to any intellectual propriety rights is granted hereunder. This Document is subject to change without further notification. MediaTek does not assume any responsibility arising out of or in connection with any use of, or reliance on, this Document, and specifically disclaims any and all liability, including, without limitation, consequential or incidental damages.

THIS DOCUMENT AND ANY OTHER MATERIALS OR TECHNICAL SUPPORT PROVIDED BY MEDIATEK IN CONNECTION WITH THIS DOCUMENT, IF ANY, ARE PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE. MEDIATEK SPECIFICALLY DISCLAIMS ALL WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, FITNESS FOR A PARTICULAR PURPOSE, COMPLETENESS OR ACCURACY AND ALL WARRANTIES ARISING OUT OF TRADE USAGE OR OUT OF A COURSE OF DEALING OR COURSE OF PERFORMANCE. MEDIATEK SHALL NOT BE RESPONSIBLE FOR ANY MEDIATEK DELIVERABLES MADE TO MEET YOUR SPECIFICATIONS OR TO CONFORM TO A PARTICULAR STANDARD OR OPEN FORUM.

Without limiting the generality of the foregoing, MediaTek makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does MediaTek assume any liability arising out of the application or use of any product, circuit or software. You agree that You are solely responsible for the designing, validating and testing Your product incorporating MediaTek’s product and ensure such product meets applicable standards and any safety, security or other requirements.

The above T&C and all acts in connection with the T&C or this Document shall be governed, construed and interpreted in accordance with the laws of Taiwan, without giving effect to the principles of conflicts of law.