

MEDIATEK

MT8676 Android I2C User Manual

Version: 1.0
Release date: 2024-11-15

Use of this document and any information contained therein is subject to the terms and conditions set forth in Exhibit 1. This document is subject to change without notice.

Version History

Version	Date	Author	Description
1.0	2024-11-15	Housong Zhang	Official release

Table of Contents

Version History 2

Table of Contents 3

List of Figures 3

List of Tables 3

1 I2C 4

1.1 Overview 4

1.1.1 Brief Introduction 4

1.1.2 Abbreviations 4

1.2 Architecture/Process Overview 4

1.2.1 I2C Introduction 5

1.2.2 MT8676 I2C Features 5

1.2.3 I2C Transmission Format 5

1.3 Configuration/Customization Guideline 6

1.3.1 DTS Configuration 6

1.3.2 Frequency 6

1.4 Frequently Asked Questions/Troubleshooting 7

1.4.1 I2C Issue Debugging Methods 7

1.4.2 GPIO Mode Check 7

1.4.3 Waveform Measurement 7

1.4.4 How to Print I2C Register Information 7

1.4.5 MediaTek Support Seeking 8

Exhibit 1 Terms and Conditions 9

List of Figures

Figure 1-1. Pin connection between I2C master and I2C slave 4

Figure 1-2. I2C transmission format 5

List of Tables

Table 1-1. Abbreviations 4

1 I2C

1.1 Overview

1.1.1 Brief Introduction

This chapter introduces the hardware, software and functions of the MT8676 I2C controller.

1.1.2 Abbreviations

Table 1-1. Abbreviations

Abbreviation	Explanation
DMA	Direct Memory Access
FIFO	First Input First Output
FM	Fast Mode
FM+	Fast Mode Plus
GPIO	General Purpose Inputs-Outputs
HS mode	High Speed Mode
I/O	Input/Output
I2C	Inter-IC
SCL	Serial Clock Line
SDA	Serial Data Line
SM	Standard Mode

1.2 Architecture/Process Overview




Figure 1-1. Pin connection between I2C master and I2C slave

1.2.1 I2C Introduction

The I2C controller is a bi-directional, two-wire serial interface that utilizes Serial Clock Line (SCL) and Serial Data Line (SDA) signals. These signals are capable of being driven by either the master or the slave in I2C. This generic controller supports the master role and conforms to the I2C specification.

1.2.2 MT8676 I2C Features

- Start, repeated start and stop conditions generation
- Bus detection
- Acknowledge bit generation and detection
- 7-bit/10-bit addressing
- Clock stretching
- Active drive/wired-and I/O configuration
- I2C has four operating speeds:
 - I2C Standard mode (SM) with speed up to 100 kbit/s
 - I2C Fast mode (FM) with speed up to 400 kbit/s
 - I2C Fast mode Plus (FM+) with speed up to 1 Mbit/s
 - I2C High Speed (HS) mode with speed up to 3.4 Mbit/s
- Adjustable clock speed for SM/FM/FM+/HS mode operation
- FIFO mode and DMA mode
- Multiple transfer formats:
 - Multi-write per transfer
 - Multi-read per transfer
 - Multi-transfer per transaction
 - Combined format transfer with length change capability
 - Combined format transfer with direction change capability
 - Multi-transfer with repeated start condition

1.2.3 I2C Transmission Format

Figure 1-2 illustrates the basic transfer format utilized by the SM/FM/FM+ of I2C. Initially, the master sends a start condition. Following this, the master sends the 7-bit static address of the I2C slave device with which it intends to communicate. Once the slave responds to the addressing, the master sends/receives the data. Upon completion of the data transfer, the master sends a stop condition and the bus returns to the free state.




Figure 1-2. I2C transmission format

1.3 Configuration/Customization Guideline

1.3.1 DTS Configuration

Path: src/kernel/linux/v-xx/arch/arm64/boot/dts/mediatek/xxxx.dts

- Add I2C pin to set I2C pinmux

```
&pio {
    i2c2_pins: i2c2-default {
        pins-bus {
            pinmux = <PINMUX_GPIO188_FUNC_SCL2>,
                    <PINMUX_GPIO189_FUNC_SDA2>;
            bias-pull-up = <MTK_PULL_SET_RSEL_111>;
        };
    };
};
```

- Add slave device node

```
&i2c2 {
    status = "okay";
    pinctrl-names = "default";
    pinctrl-0 = <&i2c2_pins>;

    nxp_eusb2_repeater_p2: nxp-eusb2-repeater-p2@4f {
        compatible = "mtk,nxp-eusb2-repeater";
        pinctrl-names = "enable", "disable";
        pinctrl-0 = <&ptn3222_enable_p2>;
        pinctrl-1 = <&ptn3222_disable_p2>;
        reg = <0x4f>;
        #phy-cells = <0>;
        status = "okay";
    };
};
```

1.3.2 Frequency

I2C controller supports data rates of 100 Kbps, 400 Kbps, and 1 Mbps.

Add **clock-frequency = <xxxxxx>** to set I2C frequency.

```
&i2c2 {
    status = "okay";
    pinctrl-names = "default";
    pinctrl-0 = <&i2c2_pins>;
    clock-frequency = <400000>;
};
```

1.4 Frequently Asked Questions/Troubleshooting

1.4.1 I2C Issue Debugging Methods

Most I2C problems can be debugged by trying the following methods:

- Check the slave device initialization and power supply
- Check whether the DTS configuration and GPIO mode attributes are correct
- Check whether the I2C register information is correct (you can provide log to RD)

1.4.2 GPIO Mode Check

To view the status of pins in the Kernel, enter the following commands:

```
# cd /sys
# find -name mt_gpio
# cat mt_gpio //
```

For example:

```
# cat /sys/devices/platform/soc/1000b000.pinctrl/mt_gpio
PIN: [MODE] [DIR] [DOUT] [DIN] [PULL_EN] [PULL_SEL] [IES] [SMT] [DRIVE] ( [R1] [R0] )
0: 0 0 0 0 1 0 1 0 0
1: 0 0 0 0 1 0 1 0 0
2: 0 1 1 1 1 0 1 0 0
3: 6 0 0 0 1 0 1 0 0
```

1.4.3 Waveform Measurement

Use an oscilloscope to measure if the I2C waveforms meet expectations.

1.4.4 How to Print I2C Register Information

Add the following content in `driver/i2c/busses/i2c-mt65xx.c`

```
static void i2c_dump_register(struct mtk_i2c *i2c)
{
    dev_dbg(i2c->dev, "SLAVE_ADDR: 0x%x, INTR_MASK: 0x%x\n",
            mtk_i2c_readw(i2c, OFFSET_SLAVE_ADDR),
            mtk_i2c_readw(i2c, OFFSET_INTR_MASK));
    dev_dbg(i2c->dev, "INTR_STAT: 0x%x, CONTROL: 0x%x\n",
            mtk_i2c_readw(i2c, OFFSET_INTR_STAT),
            mtk_i2c_readw(i2c, OFFSET_CONTROL));
}
```

Modify `dev_dbg` as `dev_err`.

1.4.5 MediaTek Support Seeking

If you are still unable to resolve your issue after the troubleshooting steps mentioned earlier, and when seeking help from MediaTek, please also provide the relevant logs containing I2C register information, waveform charts, DTS, and the output from `cat mt_gpio` as mentioned previously.

Exhibit 1 Terms and Conditions

Your access to and use of this document and the information contained herein (collectively this “Document”) is subject to your (including the corporation or other legal entity you represent, collectively “You”) acceptance of the terms and conditions set forth below (“T&C”). By using, accessing or downloading this Document, You are accepting the T&C and agree to be bound by the T&C. If You don’t agree to the T&C, You may not use this Document and shall immediately destroy any copy thereof.

This Document contains information that is confidential and proprietary to MediaTek Inc. and/or its affiliates (collectively “MediaTek”) or its licensors and is provided solely for Your internal use with MediaTek’s chipset(s) described in this Document and shall not be used for any other purposes (including but not limited to identifying or providing evidence to support any potential patent infringement claim against MediaTek or any of MediaTek’s suppliers and/or direct or indirect customers). Unauthorized use or disclosure of the information contained herein is prohibited. You agree to indemnify MediaTek for any loss or damages suffered by MediaTek for Your unauthorized use or disclosure of this Document, in whole or in part.

MediaTek and its licensors retain titles and all ownership rights in and to this Document and no license (express or implied, by estoppels or otherwise) to any intellectual propriety rights is granted hereunder. This Document is subject to change without further notification. MediaTek does not assume any responsibility arising out of or in connection with any use of, or reliance on, this Document, and specifically disclaims any and all liability, including, without limitation, consequential or incidental damages.

THIS DOCUMENT AND ANY OTHER MATERIALS OR TECHNICAL SUPPORT PROVIDED BY MEDIATEK IN CONNECTION WITH THIS DOCUMENT, IF ANY, ARE PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE. MEDIATEK SPECIFICALLY DISCLAIMS ALL WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, FITNESS FOR A PARTICULAR PURPOSE, COMPLETENESS OR ACCURACY AND ALL WARRANTIES ARISING OUT OF TRADE USAGE OR OUT OF A COURSE OF DEALING OR COURSE OF PERFORMANCE. MEDIATEK SHALL NOT BE RESPONSIBLE FOR ANY MEDIATEK DELIVERABLES MADE TO MEET YOUR SPECIFICATIONS OR TO CONFORM TO A PARTICULAR STANDARD OR OPEN FORUM.

Without limiting the generality of the foregoing, MediaTek makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does MediaTek assume any liability arising out of the application or use of any product, circuit or software. You agree that You are solely responsible for the designing, validating and testing Your product incorporating MediaTek’s product and ensure such product meets applicable standards and any safety, security or other requirements.

The above T&C and all acts in connection with the T&C or this Document shall be governed, construed and interpreted in accordance with the laws of Taiwan, without giving effect to the principles of conflicts of law.