

MEDIATEK

MT8676 Yocto AEE User Manual

Version: 1.0
Release date: 2024-11-04

Use of this document and any information contained therein is subject to the terms and conditions set forth in Exhibit 1. This document is subject to change without notice.

Version History

Version	Date	Author	Description
1.0	2024-11-04	Cheng Lee	Official release

Table of Contents

Version History	2
Table of Contents	3
List of Figures	3
List of Tables	3
1 AEE	4
1.1 Purpose	4
1.2 Scope	4
1.3 Definitions and Abbreviations	4
1.3.1 Definition	4
1.3.2 Abbreviation	4
1.4 Architecture Overview	5
1.4.1 DB Type Introduction	5
1.4.2 DB Type Introduction	5
1.5 Architecture Overview	5
1.5.1 How to Enable AEE	5
1.5.2 Set AEE Mode	6
1.5.3 Set Max DB Count	6
1.6 How to Use DB	6
1.6.1 Pull DB	6
1.6.2 Download GAT Tool	6
1.6.3 Extract DB	6
1.6.4 Get Symbols	7
1.6.5 Analyze DB	7
Exhibit 1 Terms and Conditions	9

List of Figures

Figure 1-1. Download GAT tool from MediatekOnline	6
Figure 1-2. MediatekDBViewer tool UI	7
Figure 1-3. Analyze DB	7
Figure 1-4. Launch GDB	8

List of Tables

Table 1-1. Abbreviation	4
Table 1-2. DB type information	5

1 AEE

1.1 Purpose

This document provides the guidelines for using the AEE feature to debug exceptions on devices.

1.2 Scope

This document is applicable to MediaTek Yocto system.

1.3 Definitions and Abbreviations

1.3.1 Definition

For the purposes of the present document, the following terms and definitions are applied.

1.3.1.1 AEE

Advanced Exception Engine (AEE) is an exception catching and debugging information generation mechanism. When an exception happens, the device will collect debug information and package into DB (database) files.

1.3.2 Abbreviation

Please note the abbreviations and their explanations are provided in [Table 1-1](#). They are used in many fundamental definitions and explanations in this document and are specific to the information that this document contains.

Table 1-1. Abbreviation

Abbreviation	Description
AEE	Advanced Exception Engine
EE	External Exception
HW Reboot	Hardware Reboot Exception
HWT	Hardware Watchdog Timeout
KE	Kernel Driver Exception
NE	Native Process Exception

1.4 Architecture Overview

1.4.1 DB Type Introduction

AEE generates different types of DB as shown in Table 1-2.

Table 1-2. DB type information

Layer	Type	Level	When DB is Generated?
Native	NE	Exception	When userspace processes receive an exception signal (SIGILL/SIGABRT/SIGBUS/SIGFPE/SIGSEGV)
	System API dump		When userspace processes call AEE-provided interface
Kernel	KE	Fatal	When kernel panic occurs
	HWT		When kernel watchdog timeout occurs
	HW Reboot		When watchdog timeout occurs and the device hangs for a long time
	Kernel API dump	Exception	When kernel driver calls AEE-provided interface
External	EE	Exception	When external IC exception occurs

1.4.2 DB Type Introduction

After exception happens, AEE DB will be stored to /data/aee_exp. Those *.dbg files are DB files.

e.g.

--db.00.SystemAPI

--db.00.SystemAPI.dbg : This is a DB file which has the .dbg suffix.

--ZZ_INTERNAL : This file simply describes the exception.

--db.01.NE

--db.01.NE.dbg

--ZZ_INTERNAL

1.5 Architecture Overview

All AEE configurations are in conf file: meta/meta-mediatek-<platform>/conf/machine/<project>.conf.

1.5.1 How to Enable AEE

AEE feature will be disabled by default on customer side.

If customer needs to enable AEE, please add MTK_LOG_CUSTOMER_SUPPORT = "yes" to conf file.

1.5.2 Set AEE Mode

AEE mode is set to 4 by default on customer side, which only generates fatal DB. If customers want to generate normal DB and fatal DB, they need to set `setprop persist.vendor.mtk.aee.mode 3`.

If customers want to specify AEE mode during build time, please add `MTK_AEE_MODE="3"` to conf file.

1.5.3 Set Max DB Count

According to DB types described in [Table 1-2](#), the DB level includes Fatal and Normal.

The default max count of fatal DB is 8 and the default max count of Normal DB is 8.

Users can modify `MTK_AEE_FATAL_DB_CNT/MTK_AEE_DB_CNT` to change the max count.

e.g.

```
MTK_AEE_DB_CNT = "4"
```

```
MTK_AEE_FATAL_DB_CNT = "4"
```

1.6 How to Use DB

1.6.1 Pull DB

Pull platform DB to PC: `adb pull /data/aee_exp`

1.6.2 Download GAT Tool

Please search GAT on MOL to download the latest version, as shown in [Figure 1-1](#).

Filter Result							 Download Filter Result
Name	Version	Release Date↓	Category	Product Line	Tool Type	Download	Release Note
GAT	v4.2244.1	2022-12-02	Official	ALPS	Debugging Tools	 binary	 Release Note

Figure 1-1. Download GAT tool from MediatekOnline

1.6.3 Extract DB

Open MediatekDBViewer in GAT tool. If your PC is running in a Windows operating system, please execute:

```
GAT(Official)_ALPS\GAT_exe_v4.2034.3\gat-win32-x86_64-4.2034.3.c\gat-win32-x86_64-4\tools\MediatekDBViewer.bat.
```




Figure 1-2. MediatekDBViewer tool UI

Click “Select DB File” button in Figure 1-2, then select the DB file (*.dbg) you want to analyze and click “start” to begin extraction. All the extracted files will be listed on the left side of the UI.

The basic file is __exp_main.txt which describes the basic information of the exception.

1.6.4 Get Symbols

You may need to get debug symbols before analyzing DB. You can use `unpack-symbols.sh` to get symbols:

1. Find script: `meta/meta-mediatek/recipes-devtools/unpack-symbols-tool/files/unpack-symbols.sh`
2. Copy the `unpack-symbols.sh` to the path: `build/tmp/deploy/images/<project>/`
3. Run script: `bash unpack_symbols.sh`
4. Symbol folders will be generated in the new path, which includes all the symbols.

1.6.5 Analyze DB

1. For NE/KE/HWT issue:

Method 1:

Click “Set Symbols path” and “Analyze” (as shown in Figure 1-3), and then `out.json` file will show the detailed trace.




Figure 1-3. Analyze DB

Method 2:

Click “Set Symbols path” and “Launch GDB” (as shown in [Figure 1-4](#)), GDB window will show up, then you can get backtrace by using bt command in GDB.




Figure 1-4. Launch GDB

2. For HW_Reboot issue:

HW_Reboot is a special issue: it cannot get backtrace, so you can only check some other debug files in DB (SYS_LAST_CPU_BUS/DFD).

Exhibit 1 Terms and Conditions

Your access to and use of this document and the information contained herein (collectively this “Document”) is subject to your (including the corporation or other legal entity you represent, collectively “You”) acceptance of the terms and conditions set forth below (“T&C”). By using, accessing or downloading this Document, You are accepting the T&C and agree to be bound by the T&C. If You don’t agree to the T&C, You may not use this Document and shall immediately destroy any copy thereof.

This Document contains information that is confidential and proprietary to MediaTek Inc. and/or its affiliates (collectively “MediaTek”) or its licensors and is provided solely for Your internal use with MediaTek’s chipset(s) described in this Document and shall not be used for any other purposes (including but not limited to identifying or providing evidence to support any potential patent infringement claim against MediaTek or any of MediaTek’s suppliers and/or direct or indirect customers). Unauthorized use or disclosure of the information contained herein is prohibited. You agree to indemnify MediaTek for any loss or damages suffered by MediaTek for Your unauthorized use or disclosure of this Document, in whole or in part.

MediaTek and its licensors retain titles and all ownership rights in and to this Document and no license (express or implied, by estoppels or otherwise) to any intellectual propriety rights is granted hereunder. This Document is subject to change without further notification. MediaTek does not assume any responsibility arising out of or in connection with any use of, or reliance on, this Document, and specifically disclaims any and all liability, including, without limitation, consequential or incidental damages.

THIS DOCUMENT AND ANY OTHER MATERIALS OR TECHNICAL SUPPORT PROVIDED BY MEDIATEK IN CONNECTION WITH THIS DOCUMENT, IF ANY, ARE PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE. MEDIATEK SPECIFICALLY DISCLAIMS ALL WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, FITNESS FOR A PARTICULAR PURPOSE, COMPLETENESS OR ACCURACY AND ALL WARRANTIES ARISING OUT OF TRADE USAGE OR OUT OF A COURSE OF DEALING OR COURSE OF PERFORMANCE. MEDIATEK SHALL NOT BE RESPONSIBLE FOR ANY MEDIATEK DELIVERABLES MADE TO MEET YOUR SPECIFICATIONS OR TO CONFORM TO A PARTICULAR STANDARD OR OPEN FORUM.

Without limiting the generality of the foregoing, MediaTek makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does MediaTek assume any liability arising out of the application or use of any product, circuit or software. You agree that You are solely responsible for the designing, validating and testing Your product incorporating MediaTek’s product and ensure such product meets applicable standards and any safety, security or other requirements.

The above T&C and all acts in connection with the T&C or this Document shall be governed, construed and interpreted in accordance with the laws of Taiwan, without giving effect to the principles of conflicts of law.