

MEDIATEK

MT8676 Yocto AI User Manual

Version: 1.0
Release date: 2024-11-22

Use of this document and any information contained therein is subject to the terms and conditions set forth in Exhibit 1. This document is subject to change without notice.

Version History

Version	Date	Author	Description
1.0	2024-11-22	Maolei Wang	Official release

Table of Contents

Version History 2

Table of Contents 3

List of Figures 3

List of Tables 3

1 AI 4

1.1 Overview 4

1.1.1 Abbreviations 4

1.2 Architecture/Process Overview 4

1.2.1 AI Architecture 4

1.2.2 NeuroPilot Development Guideline 5

1.3 Configuration/Customization Guideline 6

1.3.1 Explanation of NeuroPilot Debug Commands 6

1.3.2 The APU Trace Tool Captures the Trace 7

1.4 Information about the Operators Supported by Specific MediaTek Platform’s NPU 9

Exhibit 1 Terms and Conditions 10

List of Figures

Figure 1-1. AI architecture 5

Figure 1-2. NeuroPilot online documents 6

Figure 1-3. APU HW status 8

Figure 1-4. APU frequency status 8

Figure 1-5. Relationship between supported operators 9

List of Tables

Table 1-1. Abbreviations 4

1 AI

1.1 Overview

This section describes the functions related to MT8676 AI/VPU.

1.1.1 Abbreviations

Table 1-1. Abbreviations

Abbreviation	Explanation
AI	Artificial Intelligence
MDLA	MediaTek Deep Learning Accelerator
MVPU	MediaTek Vision Processing Unit
NeuroPilot	MediaTek’s Ecosystem for AI Development

1.2 Architecture/Process Overview

1.2.1 AI Architecture

NeuroPilot is a set of software tools and APIs for developing efficient artificial intelligence applications on the MediaTek platform; it is the core of the MediaTek artificial intelligence ecosystem. “Edge AI” is supported by NeuroPilot, which means executing AI on local devices rather than remotely on servers. This can result in faster AI tasks while also protecting data and privacy.




Figure 1-1. AI architecture

The MT8676 Yocto software stack, as illustrated in Figure 1-1, offers developers diverse development pathways. Developers can utilize the NCC-TFLite tool to convert TFLite models into DLA format, and subsequently deploy these models seamlessly to the MediaTek target platform using the Neuron Runtime API. Additionally, this software stack supports direct access to MTK's built-in computer vision (CV) algorithms through OpenVX, facilitating rapid implementation of common CV tasks. For scenarios requiring higher levels of customization, developers can opt to use OpenCL to write and implement their own CV algorithms, thereby meeting specific application requirements.

1.2.2 NeuroPilot Development Guideline

To access NeuroPilot Online Document, customers are required to apply for an account first. This account can then be used to access MediaTek online document website. The website provides various development materials including development-related data, conversion tools, SDKs, SampleCode, as well as information on the support and limitations of model OP for each target. Customers seeking access to the online document can reach out to CPM for assistance with the application process.




Figure 1-2. NeuroPilot online documents

After applying for access to NeuroPilot, go to <https://neuropilot.MediaTek.com/> -> Software Development -> log in to your account -> under "NeuroPilot SDK & Document", select the target NeuroPilot {version} -> Latest Version NeuroPilot Online Doc -> 2. Getting Started Guide -> 2.2. NeuroPilot Workflow -> 2.2.3.1. Android Development.

1.3 Configuration/Customization Guideline

1.3.1 Explanation of NeuroPilot Debug Commands

If customers encounter an apusys error issue, please first turn on the following log switches, reproduce the problem, and then provide MediaTek with the complete machine log and the apusys_rv_xfile (used to decode apusys_log) on the test machine. The log options and retrieval paths are as follows:

```
Enable NNAPI AOSP log : adb shell "setprop debug.nn.vlog 1"
Enable TFlite log      : adb shell setprop debug.mtk_tflite.vlog true
Enable Execution plan  : adb shell setprop debug.neuron.runtime.ShowExecPlan true
Enable ShowQoSInfo    : adb shell setprop debug.neuron.runtime.ShowQoSInfo true
Enable Kernel Log      : adb shell "echo 15 > /sys/class/misc/apusys/log/klog"
Enable uPLog           : adb shell "echo 5 > /proc/apusys_logger/log"
Enable User Log        : adb shell setprop debug.apusys.loglevel 15
Enable apusys_rv_xfile: adb pull /proc/apusys_rv/apusys_rv_xfile (used for decoding apusys_log)
```

After turning on these required switches, a service restart is needed for the changes to take effect:

- adb shell stop neuralnetworks_hal_service_mtk_neuron
- adb shell start neuralnetworks_hal_service_mtk_neuron

1.3.2 The APU Trace Tool Captures the Trace

1.3.2.1 Use the Trace Tool to Obtain the Path

APU Systrace is a tool used for analyzing and debugging the operational status of basic computing units (such as EDMA, MDLA, MVPU) on the AI Processing Unit (APU) of MediaTek platforms. It helps developers quickly analyze the performance of model algorithms running on the APU and debug issues.

To get the APU trace tool, go to <https://neuropilot.MediaTek.com/> -> Software Development -> log in -> select the target NeuroPilot {version} under "NeuroPilot SDK & Document" -> Latest Version NeuroPilot Online Doc -> Downloads to download APU Systrace Tool.

1.3.2.2 How to Use APU Trace Tool

To record APU trace, execute 02-trace_start_all.bat -> run the test program -> 02-trace_stop.bat.

- 02-trace_start_all.bat - start recording trace
- 02-trace_stop.bat - stop tracing and pull trace files

The following two scripts are optional to run. Enabling them will result in the system trace containing APU middleware and neuron trace.

- 08-mdw_trace_enable.bat - To obtain tracing information from the APU middleware.
- 08-neuron_rt_trace_enable.bat - To obtain tracing information from the neuron runtime.

Three files will be generated in the end, choose to view as needed (Please use <https://ui.perfetto.dev/> to open the trace.)

- apusys.trace - apusys trace only
- System trace - system trace only
- combine.trace - apusys + system trace

1.3.2.3 Analysis Example of APU Trace

There are usually three trace files obtained by capturing and parsing with MediaTek APU Systrace as shown below:

- apusys.trace (Only including the status of tasks on various devices such as MDLA/MVPU during APU operation and information on APU Frequency, DRAM access, TCM access, etc.)
- system.trace (Regular system trace only, including CPU information and information about other processes/threads in the system)
- combine.trace (apusys + system trace)

In actual scenarios, there is often a need to clarify the debugging requirements for the threads running APU in the current system. The following SOP can be referred to:

- Open the apusys.trace file using Perfetto UI, find the Tasks block running on the MDLA or MVPU (Main AI Compute Unit) Core, and you can obtain the following information:
 - Does the corresponding Task run in SMP multi-core parallel mode? If running in multi-core MDLA mode, there will be multiple Tasks with the same color/pid as shown in Figure 1-3:



Figure 1-3. APU HW status

- The DRAM/TCM occupancy situation corresponding to the Task
- The operating frequency of the MDLA/MVPU Cores during the corresponding Task execution period.
- You can also check whether the AI algorithm is executed periodically by running Tasks with the same pid on MDLA Core.




Figure 1-4. APU frequency status

1.4 Information about the Operators Supported by Specific MediaTek Platform's NPU




Figure 1-5. Relationship between supported operators

As shown in [Figure 1-5](#), the operators supported by the MediaTek platform NPU are divided into three levels from small to large:

- PyTorch/TensorFlow Ops -> TFLite Ops: By using the mtk_converter tool, the original Ops in .pt or .pb models are converted to TFLite Ops. This mapping process will undergo initial Ops filtering to block Ops not supported by the platform's NPU (HW). For a list of PyTorch/TensorFlow Ops that can be recognized and converted to TFLite Ops by the converter tool, please refer to the online documents: Developer Tools -> Model Development -> Converter -> Converter Tool Supported Operators.
- TFLite Ops -> NPU HW(MDLA/MVPU) Operations: By using the ncc-tflite (compiler) in neuronsdk, the converted TFLite model is compiled into a dla file. During this mapping process, the Specification (Restrictions) in the NPU HW (MDLA/MVPU) Operations Guidelines will be referenced to check the detailed parameters of each op in TFLite. For information on which TFLite Ops can be recognized and compiled into dla files by the ncc-tflite tool, please refer to Supported Operations.
- NPU HW (MDLA/MVPU) Operations: Ops that can truly run on NPU (MDLA or MVPU).

Exhibit 1 Terms and Conditions

Your access to and use of this document and the information contained herein (collectively this “Document”) is subject to your (including the corporation or other legal entity you represent, collectively “You”) acceptance of the terms and conditions set forth below (“T&C”). By using, accessing or downloading this Document, You are accepting the T&C and agree to be bound by the T&C. If You don’t agree to the T&C, You may not use this Document and shall immediately destroy any copy thereof.

This Document contains information that is confidential and proprietary to MediaTek Inc. and/or its affiliates (collectively “MediaTek”) or its licensors and is provided solely for Your internal use with MediaTek’s chipset(s) described in this Document and shall not be used for any other purposes (including but not limited to identifying or providing evidence to support any potential patent infringement claim against MediaTek or any of MediaTek’s suppliers and/or direct or indirect customers). Unauthorized use or disclosure of the information contained herein is prohibited. You agree to indemnify MediaTek for any loss or damages suffered by MediaTek for Your unauthorized use or disclosure of this Document, in whole or in part.

MediaTek and its licensors retain titles and all ownership rights in and to this Document and no license (express or implied, by estoppels or otherwise) to any intellectual propriety rights is granted hereunder. This Document is subject to change without further notification. MediaTek does not assume any responsibility arising out of or in connection with any use of, or reliance on, this Document, and specifically disclaims any and all liability, including, without limitation, consequential or incidental damages.

THIS DOCUMENT AND ANY OTHER MATERIALS OR TECHNICAL SUPPORT PROVIDED BY MEDIATEK IN CONNECTION WITH THIS DOCUMENT, IF ANY, ARE PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE. MEDIATEK SPECIFICALLY DISCLAIMS ALL WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, FITNESS FOR A PARTICULAR PURPOSE, COMPLETENESS OR ACCURACY AND ALL WARRANTIES ARISING OUT OF TRADE USAGE OR OUT OF A COURSE OF DEALING OR COURSE OF PERFORMANCE. MEDIATEK SHALL NOT BE RESPONSIBLE FOR ANY MEDIATEK DELIVERABLES MADE TO MEET YOUR SPECIFICATIONS OR TO CONFORM TO A PARTICULAR STANDARD OR OPEN FORUM.

Without limiting the generality of the foregoing, MediaTek makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does MediaTek assume any liability arising out of the application or use of any product, circuit or software. You agree that You are solely responsible for the designing, validating and testing Your product incorporating MediaTek’s product and ensure such product meets applicable standards and any safety, security or other requirements.

The above T&C and all acts in connection with the T&C or this Document shall be governed, construed and interpreted in accordance with the laws of Taiwan, without giving effect to the principles of conflicts of law.