

MEDIATEK

MT8676 Yocto FastRVC User Manual

Version: 1.0
Release date: 2024-08-12

Use of this document and any information contained therein is subject to the terms and conditions set forth in Exhibit 1. This document is subject to change without notice.

Version History

Version	Date	Author	Description
1.0	2024-08-12	YunJie Wu	Official release

Table of Contents

Version History 2

Table of Contents 3

List of Figures 3

1 FastRVC 4

1.1 Overview 4

1.2 Architecture/Process Overview 4

1.3 Configuration/Customization Guideline 5

1.4 Frequently Asked Questions/Troubleshooting 6

1.4.1 FastRvc Issue Debug 6

1.4.2 FastRVC Debug Log Function 6

Exhibit 1 Terms and Conditions 7

List of Figures

Figure 1-1. FastRVC flow 4

Figure 1-2. instantcam flow 5

1 FastRVC

1.1 Overview

This chapter introduces the basic functions of MT8676 FastRVC and how to debug FastRVC problems.

Fast RVC stands for Fast Rear View Camera, which is used to achieve fast reversing. Fast reversing requires the rear camera image to be displayed within 4 to 6 seconds after cold start and within 1 second after hot start. The FastRVC (instantcam) program was developed to realize the fast reversing function.

1.2 Architecture/Process Overview




Figure 1-1. FastRVC flow

Fast RVC (instantcam) is a process started by systemd during the boot phase. It mainly monitors the reversing events and sends them to the framebuffer to display the reversing screen.




Figure 1-2. instantcam flow

The modules involved in the process of starting FastRVC and displaying the image are shown in Figure 1-2. The functions of each module are as follows:

- IPC binder provides inter-process communication between instantcam and camerahalservice.
- Turbo is a new architecture of MediaTek MW, which is used to manage upper-layer requests and obtain sensor image data from the underlying isp.
- ISP is responsible for processing sensor data and passing it to turbo through conversion.
- FBS is a part of MediaTek display, which is used to process the frame obtained from instantcam and send it to DRM for display.

1.3 Configuration/Customization Guideline

The reversing signal is enabled by default at startup:

```
src/multimedia/mtkcam-mt8678/mtkInstantCam/instantcam.cpp
- property_get("vendor.ins.rvc.test", value, "3");
+ property_get("vendor.ins.rvc.test", value, "1");
```

Specify the sensor type of the current project:

```
src/multimedia/mtkcam-mt8678/mtkInstantCam/instantcam.cpp
param.sensorType = Mtk::MTK_SENSOR_FEATURE_SENSOR_TYPE_DMS
```

Indicates using the DMS sensor in muti as the sensor of FastRVC, which can be modified as needed.

1.4 Frequently Asked Questions/Troubleshooting

1.4.1 FastRvc Issue Debug

1.4.1.1 FastRvc Quick Reverse Function Show Image Time

Time nodes of the startup phase:

```
adb shell cat /proc/bootprof [unit:ms]
```

There are differences across different hardware platforms, requiring customer debugging. Actual measured data should be used as a reference.

1.4.1.2 FastRVC Customization Function Causing Image Stuck

Customers reported that the screen freezes during the boot phase. The reason is that customers use the `PROP_SET` function in the main thread of the display function, which makes the boot phase more time-consuming. It is recommended that customers avoid setting `PROP_SET` for each frame, and use sub-threads to handle time-consuming operations to avoid jamming the main thread.

1.4.2 FastRVC Debug Log Function

Basic analysis requires providing boot-up phase log, serial port log and logcat log.

For problems with instantcam log that cannot be printed or is missing during the boot-up phase, customers can use the `add_boot_event` function to output the log to bootprof for subsequent customized development. For key log troubleshooting, refer to this method to print and troubleshoot.

Exhibit 1 Terms and Conditions

Your access to and use of this document and the information contained herein (collectively this “Document”) is subject to your (including the corporation or other legal entity you represent, collectively “You”) acceptance of the terms and conditions set forth below (“T&C”). By using, accessing or downloading this Document, You are accepting the T&C and agree to be bound by the T&C. If You don’t agree to the T&C, You may not use this Document and shall immediately destroy any copy thereof.

This Document contains information that is confidential and proprietary to MediaTek Inc. and/or its affiliates (collectively “MediaTek”) or its licensors and is provided solely for Your internal use with MediaTek’s chipset(s) described in this Document and shall not be used for any other purposes (including but not limited to identifying or providing evidence to support any potential patent infringement claim against MediaTek or any of MediaTek’s suppliers and/or direct or indirect customers). Unauthorized use or disclosure of the information contained herein is prohibited. You agree to indemnify MediaTek for any loss or damages suffered by MediaTek for Your unauthorized use or disclosure of this Document, in whole or in part.

MediaTek and its licensors retain titles and all ownership rights in and to this Document and no license (express or implied, by estoppels or otherwise) to any intellectual propriety rights is granted hereunder. This Document is subject to change without further notification. MediaTek does not assume any responsibility arising out of or in connection with any use of, or reliance on, this Document, and specifically disclaims any and all liability, including, without limitation, consequential or incidental damages.

THIS DOCUMENT AND ANY OTHER MATERIALS OR TECHNICAL SUPPORT PROVIDED BY MEDIATEK IN CONNECTION WITH THIS DOCUMENT, IF ANY, ARE PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE. MEDIATEK SPECIFICALLY DISCLAIMS ALL WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, FITNESS FOR A PARTICULAR PURPOSE, COMPLETENESS OR ACCURACY AND ALL WARRANTIES ARISING OUT OF TRADE USAGE OR OUT OF A COURSE OF DEALING OR COURSE OF PERFORMANCE. MEDIATEK SHALL NOT BE RESPONSIBLE FOR ANY MEDIATEK DELIVERABLES MADE TO MEET YOUR SPECIFICATIONS OR TO CONFORM TO A PARTICULAR STANDARD OR OPEN FORUM.

Without limiting the generality of the foregoing, MediaTek makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does MediaTek assume any liability arising out of the application or use of any product, circuit or software. You agree that You are solely responsible for the designing, validating and testing Your product incorporating MediaTek’s product and ensure such product meets applicable standards and any safety, security or other requirements.

The above T&C and all acts in connection with the T&C or this Document shall be governed, construed and interpreted in accordance with the laws of Taiwan, without giving effect to the principles of conflicts of law.