

MEDIATEK

MT8676 Yocto Thermal User Manual

Version: 1.0
Release date: 2024-08-12

Use of this document and any information contained therein is subject to the terms and conditions set forth in Exhibit 1. This document is subject to change without notice.

Version History

Version	Date	Author	Description
1.0	2024-08-12	Zhaoqing Jiu	Official release

Table of Contents

Version History 2

Table of Contents 3

List of Figures 3

List of Tables 3

1 Thermal 4

1.1 Overview 4

1.2 Architecture/Process Overview 4

1.3 Configuration/Customization Guideline 5

1.3.1 Thermal Policy 5

1.3.1.1 Thermal Policy Commands 5

1.3.1.2 Thermal Policy Format 5

1.4 Frequently Asked Questions/Troubleshooting 7

Exhibit 1 Terms and Conditions 8

List of Figures

Figure 1-1. Thermal 2.0 software architecture 4

List of Tables

Table 1-1. Available thermal policies on device (under/data/thermal/) 5

1 Thermal

1.1 Overview

Thermal management on device has two main goals:

- Controls component temperature to avoid being damaged by heat
- Controls the temperature of the whole product for human safety and meet safety regulation

Heat in the device is accumulated from high power of ICs. High power is side effect of high clock speed, voltage, and performance.

The approach to control temperature from thermal management is to control power dissipation and consumption. Power dissipation control can be achieved by adding various thermal solutions such as TIM, copper foil, tube, etc to efficiently spread the heat to the whole product and to the air or contact surface. Power consumption control can be achieved by reducing/limiting power consumption based on temperature which is the focus of this document.

1.2 Architecture/Process Overview




Figure 1-1. Thermal 2.0 software architecture

thermal_core is a native Linux application. Its main function is to parse a thermal policy of the .conf format.

CPU/GPU/APU will each perform thermal throttling based on the target T_j set by thermal_core and the monitored temperature.

1.3 Configuration/Customization Guideline

1.3.1 Thermal Policy

Policy path in codebase is `src/apps/spm-base/thermal-conf/mt8676`, supporting encrypted format.

Table 1-1. Available thermal policies on device (under/data/thermal/)

Thermal policy	Permanent?	Encrypted?	Description
thermal.conf	Yes	Yes	Default thermal policy
disable_thermal.conf	Yes	Yes	Disable thermal throttling and thermal protection
disable_thermal_temp.conf	No	Yes	Same as the above, except it needs to re-apply after device rebooted.
disable_throttling.conf	No	Yes	Disable thermal throttling
disable_skin_control.conf	No	Yes	Disable MTK skin control close loop (always keep Target T_j to 95°C)
Thermal_policy_XX.conf (XX = 00~19 except 00, 02, 08)	On demand	Yes	Can add your own policy setting and switch via power HAL
thermal_policy_08.conf	No	Yes	Thermal policy for benchmark

1.3.1.1 Thermal Policy Commands

Apply a thermal policy:

```
adb shell "thermal-int apply [policy_name]"
```

E.g., `adb shell "thermal-int apply disable_throttling.conf"`

1.3.1.2 Thermal Policy Format

- Permanent policy**

```
[policy_type]
# If permanent= Yes, this policy is still valid after reboot
permanent= Yes
```

- Linux thermal framework (LTF)**

- “policy”: Support power_allocator and step_wise.

```
[LTF]
thermal_zone= soc_max
mode= enabled
policy= power_allocator
switch_on_temp= 85000
control_temp= 95000
critical_temp= 115000
cooler= [thermal-cpufreq-0, thermal-devfreq-0]
cooler_weight= [1024, 1024]
```

- **Disable LTF throttling**

```
[LTF-disable-throttling]
# If HW_protection= disabled, it will turn off
# SW shutdown protections and LVTS HW reboot protection
HW_protection= enabled
```

- **Disable LTF shutdown cooler and LVTS thermal reboot**

```
[LTF-disable-throttling]
# If HW_protection= disabled, it will turn off
# SW shutdown protections and LVTS HW reboot protection
HW_protection= disabled
```

- **Closed loop Tskin control**

- trip_pcb: PCB temperature to enable closed loop.
- target_tpcb: Target PCB temperature for closed loop.

```
[mtk-skin-control]
max_target_tj= 95000
min_target_tj= 63000
trip_tpcb= 47000
target_tpcb= 50000
```

- **Backlight cooler**

- “reduce-brightness”: Reduce brightness xx %.

```
[backlight-cooler]
mode= enabled
sensor= ap_ntc
threshold= [43000, 46000, 49000, 53000]
hysteresis= [2000, 2000, 2000, 2000]
reduce-brightness= [10, 50, 80, 95]
```

- **CPU frequency table mapping**

- “cluster”: CPU cluster id.

```
[mtk-cpu-table-mapping]
mode= enabled
sensor= ap_ntc
cluster= 0
threshold= [39000, 42000, 44000, 46000, 48000, 50000, 52000]
hysteresis= [2000, 2000, 2000, 2000, 2000, 2000, 2000]
freq= [2000000, 1800000, 1800000, 1800000, 1800000, 1725000, 1725000]
```

- **CPU core isolation table mapping**

- “CPU”: CPU core to be isolated.

```
[mtk-cpu-isolate]
mode= enabled
sensor= ap_ntc
cpu= [cpu4, cpu5, cpu6, cpu7]
threshold= [52000, 52000, 48000, 48000]
hysteresis= [2000, 2000, 2000, 2000]
```

- **GPU frequency table mapping**

```
[mtk-gpu-table-mapping]
mode= enabled
sensor= ap_ntc
threshold= [39000, 42000, 44000]
hysteresis= [2000, 2000, 2000]
freq= [854000, 815000, 715000]
```

1.4 Frequently Asked Questions/Troubleshooting

Turn on more thermal_core log:

```
adb shell "thermal-int debug_log 1"
```

How to decrypt or encrypt thermal configuration files:

<https://online.mediatek.com/apps/fag/detail?list=HW&faqid=FAQ27718>

Exhibit 1 Terms and Conditions

Your access to and use of this document and the information contained herein (collectively this “Document”) is subject to your (including the corporation or other legal entity you represent, collectively “You”) acceptance of the terms and conditions set forth below (“T&C”). By using, accessing or downloading this Document, You are accepting the T&C and agree to be bound by the T&C. If You don’t agree to the T&C, You may not use this Document and shall immediately destroy any copy thereof.

This Document contains information that is confidential and proprietary to MediaTek Inc. and/or its affiliates (collectively “MediaTek”) or its licensors and is provided solely for Your internal use with MediaTek’s chipset(s) described in this Document and shall not be used for any other purposes (including but not limited to identifying or providing evidence to support any potential patent infringement claim against MediaTek or any of MediaTek’s suppliers and/or direct or indirect customers). Unauthorized use or disclosure of the information contained herein is prohibited. You agree to indemnify MediaTek for any loss or damages suffered by MediaTek for Your unauthorized use or disclosure of this Document, in whole or in part.

MediaTek and its licensors retain titles and all ownership rights in and to this Document and no license (express or implied, by estoppels or otherwise) to any intellectual propriety rights is granted hereunder. This Document is subject to change without further notification. MediaTek does not assume any responsibility arising out of or in connection with any use of, or reliance on, this Document, and specifically disclaims any and all liability, including, without limitation, consequential or incidental damages.

THIS DOCUMENT AND ANY OTHER MATERIALS OR TECHNICAL SUPPORT PROVIDED BY MEDIATEK IN CONNECTION WITH THIS DOCUMENT, IF ANY, ARE PROVIDED “AS IS” WITHOUT WARRANTY OF ANY KIND, WHETHER EXPRESS, IMPLIED, STATUTORY, OR OTHERWISE. MEDIATEK SPECIFICALLY DISCLAIMS ALL WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, FITNESS FOR A PARTICULAR PURPOSE, COMPLETENESS OR ACCURACY AND ALL WARRANTIES ARISING OUT OF TRADE USAGE OR OUT OF A COURSE OF DEALING OR COURSE OF PERFORMANCE. MEDIATEK SHALL NOT BE RESPONSIBLE FOR ANY MEDIATEK DELIVERABLES MADE TO MEET YOUR SPECIFICATIONS OR TO CONFORM TO A PARTICULAR STANDARD OR OPEN FORUM.

Without limiting the generality of the foregoing, MediaTek makes no warranty, representation or guarantee regarding the suitability of its products for any particular purpose, nor does MediaTek assume any liability arising out of the application or use of any product, circuit or software. You agree that You are solely responsible for the designing, validating and testing Your product incorporating MediaTek’s product and ensure such product meets applicable standards and any safety, security or other requirements.

The above T&C and all acts in connection with the T&C or this Document shall be governed, construed and interpreted in accordance with the laws of Taiwan, without giving effect to the principles of conflicts of law.