

## **ACS SERVO**

## HARDWARE & INSTALLATION GUIDE

## ACS – Actuator Control Solutions Servo Drive/Controller and Motors



**LINEAR SOLUTIONS MADE EASY** 



3800 County Road 116, Hamel, MN 55340

Phone: 763.478.8000

Toll Free: 1.800.328.2174

Fax: 763.478.8080

Email: help@tolomatic.com
www.tolomatic.com

Copyright © 2019 Tolomatic, Inc. All rights Reserved.

All brand and product names are trademarks of their respective owners. Information in this document is believed to be accurate at time of publication.

Tolomatic reserves the right to change the design or operation of the equipment described herein and any associated motion products without notice. Information in this document is subject to change without notice.

201912201003

#### **Contents**

Lis	st of Figures	5
Lis	st of Tables	6
Не	ealth and Safety Regulations	7
	Safety Symbols	
	EMC Wiring Guidelines	
	Proper and Safe Use of Product	8
	Handling and Unpacking	9
	Product Warnings	9
1.	Product Overview	10
	1.1 The ACS Servo Drive/Controller for Actuator Control Solutions	10
	1.1.1 ACS Servo Drive/Controller - Overview	10
	1.1.2 Optional Accessories	11
2.	Environment, Dimensions & Mounting	12
	2.1 Operating Environment	
	2.2 ACS Drive Dimensions	12
	2.3 Mounting the ACS Drive	13
3.	CD & USB Cable	14
4.	ACS Drive Setup	15
	4.1 ACS Drive and Actuator Basic Setup	
	4.1.1 Setup Procedures	
5.	Connections & Cables	
-	5.1 Connections and Cables Overview	
	5.2 Motor Power/Encoder Connection and Cables	
	5.3 Encoder Connection and Cable	18
	5.4 I/O Connection and Cable	19
	5.5 Input Power Connection	20
	5.6 Brake Connection	20
	5.7 USB 2.0 Connection	21
	5.8 RS-485 Connection	22
	5.8.1 RS-485 Cable Length	22
	5.8 .2 RS-485 Grounding	22
	5.9 EtherNet/IP™ Connection	23
	5.10 Cable Routing	23
	5.10.1 EtherNet/IP Cable	24
	5.10.2 EtherNet/IP Cable Length	24
6.	Specifications & Wiring	25
	6.1 Digital Inputs	25
	6.1.1 Specifications	25

#### CONTENTS

	6.1.2 Typical Wiring Diagrams	26
	6.2 Digital Outputs	27
	6.2.1 Specifications	27
	6.2.2 Typical Wiring Diagrams	27
	6.3 Analog Input	28
	6.3.1 Specifications	28
	6.3.2 Equivalent Circuit	28
	6.4 Analog Output	29
	6.4.1 Specifications	29
	6.4.2 Equivalent Circuit	29
	6.5 Brake Output	30
	6.5.1 Specifications	30
	6.5.2 Equivalent Circuit	30
	6.6 Input Power	30
	6.6.1 Drive Specifications	30
	6.6.2 Power Supply Sizing Guidelines	31
	6.6.3 Calculating Wattage of Power Supply	32
	6.6.4 Suggested Power Supplies	32
7.	I/O Timing Diagrams	34
	7.1 I/O Timing Diagrams	34
	7.1.1 Move Timing Rules	35
8.	Move Select Logic	36
	8.1 Move Select Logic Table	36
9.	LED Codes and Faults	38
	9.1 LED Codes	38
	9.2 Fault Descriptions and Recovery	38
10	). Troubleshooting	40
	10.1.1 Troubleshooting the ACS Servo Drive	
Αı	opendix 1	
	Motors	
Δı	pendix 2	
<b>~</b> !	Previous Revisions of Wire Colors for Motor Power Connection pinouts	
	Previous Revisions of Wire Colors for I/O Connection	
۸.	pendix 3	
Αļ	Product Warranty	
	CE COMPLIANCE	
۸.		
Αļ	pendix 4	4/
•	EU Declaration of Conformity	4-

### **List of Figures**

Figure 2-1: ACS Drive Dimensions	12
Figure 2-2 Mounting the ACS Drive	13
Figure 4-1: ACS Drive and ERD Actuator- Basic Setup	15
Figure 5-1: Motor Power/Encoder Cable 3604-1842, 3604-1843	17
Figure 5-2: Motor Power Connection on ACS Servo Drive	18
Figure 5-3: Encoder Connection on ACS Drive	18
Figure 5-4: I/O Connection on ACS Drive	19
Figure 5-5: I/O Cable 3604-1770	20
Figure 5-6: Input Power Connection	20
Figure 5-7: Brake Connection	21
Figure 5-8: Brake Cable	21
Figure 5-9: USB 2.0 Connection	21
Figure 5-10: ACS 2-Wire RS485 with RJ45 Socket	22
Figure 5-11: Resistors in ground wire to limit current	23
Figure 5-12: EtherNet/IP™ Connection for ACS Drive Programmability	23
Figure 5-13 Cable Routing for Top and Side Facing Connectors	24
Figure 6-1: Digital Input Circuit	25
Figure 6-2: Input Source (switched) Connection	26
Figure 6-3: Input Source (PNP) Connection	26
Figure 6-4: Input Sink (switched) Connection	26
Figure 6-5: Input Sink (NPN) Connection	27
Figure 6-6: Output Circuit	27
Figure 6-7: Digital Output Sinking Connection	27
Figure 6-8: Digital Output Sourcing Connection	28
Figure 6-9: Analog Input Equivalent Circuit	29
Figure 6-10: Analog Output Equivalent Circuit	29
Figure 6-11: Brake Output Equivalent Circuit	30
Figure 6-12: Keep Alive wiring diagram	31
Figure 6-13: Power Supply Configuration with Shunt Regulator	33
Figure 7-1 Input Requirement	34
Figure 7-2 System Startup Timing	34
Figure 7-3 Jog Move Timing	34
Figure 7-4 Absolute & Incremental Move Timing	35
Figure 7-5 Brake Subsystem Timing	35

#### **List of Tables**

Table 2-1: ACS Drive Operating Conditions	2
Table 3-1: It may be convenient to order the CD and USB cable14	4
Table 5-1: Motor Power Cable and Connector Parts1	7
Table 5-2: Motor Power Connection pinouts	8
Table 5-3: Encoder Connection pinouts	9
Table 5-4: I/O Connection pinouts	0
Table 5-5: I/O Cable and Connector Parts	0
Table 5-6: Input Power Cable Parts	0
Table 5-7: Input Power pinouts	1
Table 5-8: Brake Pinout.	1
Table 5-9 EtherNet/IP™ pinouts and Connections	3
Table 5-10: Cable Wire Type versus Cable Length24	4
Table 6-1: Controller Specifications	5
Table 6-2: Opto-Isolated Digital Input Specifications	6
Table 6-3: Digital Output Specifications	7
Table 6-4: Analog Input Specifications	8
Table 6-5: Analog Output Specifications	9
Table 6-6: Brake Output Specifications	9
Table 6-7: ACS Internal Drive Specifications	0
Table 6-8: Software Faults Trigger Values	1
Table 6-9: ACS Internal Drive Specifications	2
Table 8-1: 4 Move Commands Mode Logic	6
Table 8-2: 8 Move Commands Mode Logic	6
Table 8-3: 16 Move Commands Mode Logic	7
Table 9-1: LED Indicators	8
Table 9-2: Safety Faults	9
Table 9-3: Critical Faults	9
Table A-1: Tolomatic Servo Motor Specifications	2
Table A-2: Tolomatic Motor Part Numbers	3
Table A-3: Motor Connector pinout	3
Table A-4: Previous Revisions of Wire Colors for Motor Power Connection pinouts4	4
Table A-5: Previous Revisions of Wire Colors for I/O Connection4	5

#### **Health and Safety Regulations**

Read through the applicable sections of the manual before the equipment is unpacked, installed or operated. Pay attention to all of the dangers, warnings, cautions and notes stated in the manual.

Serious injury to persons or damage to the equipment may result if the information in the manual is not followed.

#### Safety Symbols

Items that are specifically marked DANGER!, WARNING!, CAUTION! or NOTE! are arranged in a hierarchical system and have the following meaning:



#### **DANGER!**

Indicates a very hazardous situation which, if not avoided, could result in **death or serious injury**. This signal word is limited to the most extreme situations.



#### **WARNING!**

Indicates a potentially hazardous situation which, if not avoided, could result in **death or serious injury**.



#### **CAUTION!**

Indicates a potentially hazardous situation which, if not avoided, may result in property damage, minor or moderate injury.





#### **CAUTION!**

Indicates hot surfaces. Avoid contact.

#### NOTE!

Information that requires special attention is stated here.

#### EMC Wiring Guidelines

#### **Cable routing**

It is recommended that the power and signal cables for the ACS Drive be routed as far apart as possible to minimize system noise.

**NOTE!** The standard cables from Tolomatic are not flex rated and have a minimum bend radii of 3.75 inches. Any repeated flexing or excessive bending can result in broken conductors and intermittent faults.

#### **Shielding and grounding**

When cabling the system, high quality braided or foil with braided shielded cables are recommended. The standard motor cables provided by Tolomatic have a braided shield with drain wires. The metal angle bracket on the drive/controller is also a case ground and should be tied to earth ground. To minimize EMI and ensure system reliability, all shield drain wires from all cables should be tied to a common earth ground.

#### Proper and Safe Use of Product

#### **Protection circuits and external fuses**

A fuse should be added to the input power line to protect the drive/controller and power supply from any potential over current conditions that may occur. (See Section 6: Specifications & Wiring)

#### **Fail Safe Emergency Stop Recommendations**

A means for a fail safe e-stop is highly recommended to ensure equipment and personal safety. The e-stop should provide a means to remove main power from the actuator to cease and prevent any unwanted motion.

#### **Device Damage Prevention**

To prevent permanent damage to the device, proper care should be taken not to exceed published voltage, current, temperature, and load ratings. In addition, proper wiring should be verified and safety measures checked before applying power.

#### **Personal Safety**

During normal operation the motor can become hot. It is highly recommended to display proper safety notices and implement proper safety measures to prevent contact with hot surfaces.



The manufacturer takes no responsibility whatsoever if the equipment is modified or if the equipment is used in any way beyond performance specifications.
Unauthorized modifications or changes to the equipment are strictly

forbidden and void all

warranties.



#### CAUTION!

Proper ESD measures should be taken to avoid static electricity from contacting the signal and power lines of the drive, motor and encoder.

#### Handling and Unpacking

When unpacking and handling, care should be taken not to drop the drive/controller as this can damage the connectors and internal electronics.

#### Product Warnings

The following precautions should be observed to prevent erratic behavior or damage:

- Do not short circuit the motor power at the power connector. Doing so may damage the drive power electronics. The motor/cable is part of the current regulation circuitry. For a short occurring in a motor, the motor leads should provide enough resistance and inductance to prevent dangerous peak currents from occurring.
- Do not reverse bias the drive power.
- Do not apply voltages above the maximum rated voltage.
- Do not expose drive to conductive contaminants, moisture, or excessive temperature.
- Do not disassemble or modify the drive/controller.
- Do not plug and unplug cables while the drive is energized.

#### **Product Overview**

#### 1.1 The ACS Servo Drive/Controller for Actuator Control Solutions


Tolomatic's ACS Drive/Controller is a brushless DC servo motor drive and controller intended for use with electric actuators. Tolomatic's Motion Interface software allows the user to select the compatible Tolomatic electric linear actuator of choice. The software automatically sets most of the necessary parameters to create the desired motion of the selected actuator reducing setup and programming time. (See Tolomatic Motion Interface Software Manual 3600-4167 for more information).

Currently there are three ACS Servo Drive/Controller choices:

- #3604-9661 ACS Servo Drive/Controller, Modbus RTU over RS485 firmware 36043177UD.tol
- #3604-9662 ACS Servo Drive/Controller, EtherNet/IP™ (Analog Output) firmware 36043177UD.tol
- #3604-9663 ACS Servo Drive/Controller, Modbus TCP (Analog Output) firmware 36043177UD.tol

NOTE: They will collectively be referred to as ACS Drive throughout this guide

#### 1.1.1 ACS Servo Drive/Controller — Overview MODELS: 3604-9661, 3604-9662, 3604-9663



Tolomatic Hardware & Installation Guide: ACS Servo Drive/Controller

#### ACS Drive/Controller (3604-9661) Capabilities

- 4, 8, or 16 move command modes (absolute, force, incremental and jog or home
- Analog position mode (0-10 VDC or 4-20 mA)
- Pneumatic mode replaces pneumatic valve logic for simple motion
- ModBus RTU over RS485 provides infinite positioning
- Adjustable motion profile parameters (velocity, accel/decel,

- force). Parameters are independently configurable for each move
- Zone output based on position
- Force limiting capability
- Configurable digital I/O (24 VDC Opto-Isolated) (sinking or sourcing)
- Compatible with most 24-48 VDC servo motors
- Brake output

#### ACS Drive/Controller (3604-9662, 3604-9663) Additional Capabilities

- EtherNet/IP™ mode provides infinite positioning using EtherNet/IP and Modbus TCP protocols
- Dual EtherNet/IP port with internal switch for easy daisy chaining
- Analog output for Analog Position Mode

#### 1.1.2 Optional Accessories

#### **Cable Options**



Tolomatic offers a motor power cable with drive and motor/encoder mating connector, combined with encoder cable with drive and motor/encoder connector. Cables are available in either 3-meter or 5-meter lengths.

#### **Disc and Cable**



Tolomatic software is always available online at www.tolomatic.com. For your convenience a software CD and optional USB computer connections are available:

Tolomatic Motion Interface Software CD (3604-9526) and a USB Type B cable (3604-1852)

#### **Brake Cable**



Tolomatic offers a 5-meter brake power cable with drive and brake mating connectors

Tolomatic Hardware & Installation Guide: ACS Servo Drive/Controller

#### **Environment, Dimensions & Mounting**



#### 2.1 Operating Environment



#### **WARNING!**

Do not expose the drive to conductive contaminants, moisture, or exceed temperature ratings.

The ACS Drive is designed to be operated in ambient conditions from  $0^{\circ} - 40^{\circ}$ C (32°  $- 104^{\circ}$ F), and humidity from 0 - 90% non-condensing. There is no ingress protection (IP) for the drive, so it is important to protect the drive from water and other conductive contamination. In addition, proper ESD procedures should be observed to prevent static discharge and damage to electronic components.

ACS Drive Operating Conditions		
Ambient Temperature	77° F, 25° C Nominal	
Operating Temperature	32°-104° F, 0°-40° C Non Freezing	
Storage Temperature	32°-158° F, 0°-70° C	
Humidity	0-90% non-condensing	

**Table 2-1: ACS Drive Operating Conditions** 

#### 2.2 ACS Drive Dimensions




Figure 2-1: ACS Drive Dimensions

#### 2.3 Mounting the ACS Drive

The drive/controller is intended to be mounted vertically (as shown in Figure 2-2) to provide the vents with enough clearance on the top and bottom of the drive to allow air flow. The metal bracket should also be mounted to a metal surface for best thermal dissipation. A 2-inch head space is recommended from the drive vents to another surface to ensure the proper ambient temperature ratings are maintained.

It is recommended to have a minimum of 1-inch spacing between drives. This spacing may be relaxed provided the ambient temperature is kept within limits and the drive is mounted to a metal surface suitable enough to heat sink the drives.




Figure 2-2 Mounting the ACS Drive

#### 3.1 CD & USB Cable

NOTE: The most current version of software and firmware is always available at www.tolomatic.com

Tolomatic offers a CD with Tolomatic Motion Interface software, drive firmware and firmware upgrade utility. A USB type B cable is also available for connecting your computer to the ACS drive.



ACS Servo Drive Accessories		
ITEM TOLOMATIC PART NUMBE		
Tolomatic Motion Interface Software CD	3604-9526	
1 meter USB Cable	3604-1852	

Table 3-1: It may be convenient to order the CD and USB cable.

#### 4.1 ACS Drive and Actuator Basic Setup

Figure 4-1 shows the simple setup of the ACS Drive, the Tolomatic ERD actuator and the necessary cables and power source.




Figure 4-1: ACS Drive and ERD Actuator—Basic Setup

Please refer to the following sections and page numbers for cable part numbers and wiring specifications:

Motor Power Cable: Section 5 Encoder Cable: Section 5 I/O Cable: Section 5


For recommended power supplies: Section 6

#### 4.1.1 Setup Procedures

- 1. Install drive/controller and actuator into appropriate fixtures.
- 2. Wire the 10 to 60VDC power supply to the drive. See Section 6: Power Supply Selection.
- 3. Wire input and output signals to the desired logic device. See Section 5: Connections and Cables.
- 4. Attach motor and encoder cables.
- 5. Attach USB programming cable and install the Tolomatic Motion Interface software.
- 6. Configure ACS Drive.
- 7. Program the logic device.

#### **5.1 Connections and Cables Overview**

All cables for the ACS Drive can be ordered through Tolomatic with the exception of the power supply. When using cables other than those provided by Tolomatic, reference the cable mating connector style to ensure the proper cabling is supplied.



#### 5.2 Motor Power/Encoder Connection and Cables

The ACS Drive has a maximum output of 20A peak of Sine. 10A continuous.



Do not connect or disconnect motor cables while the drive is powered.




Figure 5-1: Motor Power/Encoder Cable 3604-1842, 3604-1843, 3604-1943

CABLE	TOLOMATIC PART NO.	DRIVE MOTOR CONNECTOR	DRIVE ENCODER CONNECTOR	MOTOR MATING CONNECTOR	MOTOR CONTACTS
Motor Power / Encoder: 3-meter	3604-1842				0 . 51
Motor Power / Encoder: 5-meter	3604-1843	On Shore P/N: OSTTJ055153	JST P/N: PHDR-14VS use with contacts SPHD-001T-P0.5	Souriau P/N: UTG11619S	Souriau Phase P/N: RC16M23T Signal P/N: SC24M1TK6
Motor Power / Encoder: 10-meter	3604-1943				OOZ-HWITTING

Table 5-1: Motor Power Cable and Connector Parts




Figure 5-2: Motor Power Connection on ACS Servo Drive

#### NOTE!

See Appendix 2 for previous wire color/ pin numbers

SOURIAU P/N UTG11619S	ON SHORE P/N OSTTJ055153 21901027			
PIN	PIN NUMBER	COLOR* SS2 OPTION REV 6 COLOR (REV 3)	ACS SIGNAL	MOTOR SIGNAL
В	1	RED (16AWG)	PHASE R	PHASE R
D	2	BRN (16AWG)	PHASE S	PHASE T
Е	3	SHIELD	DRAIN	NC
С	4	BLK (16 AWG)	PHASE T	PHASE S
R		NC	NC	DRAIN

**Table 5-2: Motor Power Connection pinouts** 

#### ■ 5.3 Encoder Connection and Cable

The ACS Drive has an encoder port that supports differential quadrature encoders. Single ended encoders may be used with additional external circuitry. It is highly recommended to use differential encoders as they are more resistant to noise issues. The drive can supply +5VDC power to the feedback device up to 100mA.




Figure 5-3: Encoder Connection on ACS Drive

SOURIAU P/N UTG11619S	JST P/N PHDR-14VS 21901028			
PIN	PIN NUMBER	COLOR (REV 1)	ACS SIGNAL	MOTOR SIGNAL
K	1	WHT/BLU (24 AWG)	ENC A	ENC A~
J	2	BLU/WHT (24 AWG)	ENC A~	ENC A
V	3	WHT/OR (24 AWG)	ENC B	ENC B
F	4	OR/WHT (24 AWG)	ENC B~	ENC B~
U	5	WHT/GRN (24 AWG)	ENC Z	ENC Z

<sup>\*</sup>Colors valid for standard cable Rev 3+ and SS2 cable Rev 6+

SOURIAU P/N UTG11619S	JST P/N PHDR-14VS 21901028			
PIN	PIN NUMBER	COLOR (REV 1)	ACS SIGNAL	MOTOR SIGNAL
N	6	GRN/WHT (24 AWG)	ENC Z~	ENC Z~
T	7	RED/BLU (24 AWG)	+5VDC	+5VDC
Н	8	WHT/BRN (24 AWG)	HALL U	COMM R-S
S	9	BLU/RED (24 AWG)	GROUND	GROUND
L	10	BRN/WHT (24 AWG)	HALL V	COMM T-R
Р	11	ORG/RED (24 AWG)	GROUND	NA
Α	12	RED/ORG (24 AWG)	+5VDC IN	NA
M	13	DRAIN / SHIELD	ENCODER DRAIN	DRAIN
G	14	WHT/GRY (24 AWG)	HALL W	COMM S-T

**Table 5-3: Encoder Connection pinouts** 

#### ■ 5.4 I/O Connection and Cable




Figure 5-4: I/O Connection on ACS Drive

#### NOTE!

See Appendix 2 for previous wire color/ pin numbers

JST #PHDR-30VS				
PIN NUMBERS	SIGNAL	CABLE WIRE COLOR (REV 5)		
1	Input ISO 1	PNK/BLK		
2	Input ISO 2	PNK		
3	Input ISO 3	RED/WHT		
4	Input ISO 4	TEAL/WHT		
5	Input ISO 5	BLU/WHT		
6	Input ISO 6	YEL/BLK		
7	Input ISO 7	YEL		
8	Input ISO 8	ORG/WHT		
9	Input ISO COM	TEAL/BLK		
10	Output 1 -	RED/BLK		
11	Output 1 +	WHT		
12	Output 2 -	GRN		
13	Output 2 +	BLU		
14	Output 3 -	GRY/BLK		
15	Output 3 +	ORG		
16	Output 4 -	ORG/BLK		
17	Output 4 +	RED		
20	Case Ground	SHIELD		
23	*Step Input	BRN/WHT		
24	*Direction Input	BRN		
25	NA	TEAL		
26	NA	GRY		

\*Not yet supported by software

#### NOTE!

See Appendix 2 for previous wire color/ pin numbers

JST #PHDR-30VS				
PIN NUMBERS SIGNAL		CABLE WIRE COLOR (REV 5)		
27	Analog Out	VIO/WHT		
28	Analog In	VIO		
29	Signal Ground	BLK		
30	Signal Ground	BLK/WHT		

Table 5-4: I/O Connection pinouts




Figure 5-5: I/O Cable 3604-1770

CABLE	TOLOMATIC PART NO.	DRIVE MATING CONNECTOR	DRIVE MATING CONTACTS
I/0: 3-meter	3604-1770	JST PN: PHDR-30VS	JST PN: SPHD-001T-P0.5
I/0: 5-meter	3604-1771	J31 FN. FHDN-30V3	JST FN. 3FHD-0011-F0.3

Table 5-5: I/O Cable and Connector Parts


#### 5.5 Input Power Connection

The input power is connected via pins on the drive with customer supplied cabling. The input power mating connector is supplied by Tolomatic.



#### **CAUTION!**

Reversing polarity of the input power will damage the drive electronics.



CABLE	INPUT POWER MATING CONNECTOR
Customer Supplied	OnShore PN: ED950/4 - provided

**Table 5-6: Input Power Cable Parts** 

PIN NUMBERS	SIGNAL
1	Main Power 10 to 60VDC
2	Keep Alive 10 to 60VDC
3	Brake Power 24 VDC
4	Ground – Power



**Table 5-7: Input Power pinouts** 

If you want to take advantage of Keep Alive, and not be required to re-home after power up, a second supply is required that is a minimum of 10 VDC with 200mA current capability.

#### **5.6 Brake Output Connection**

The brake output is controlled via an onboard rely by the drive Power is supplied via the Input Power Connection and output on the Brake Output Connection.




Figure 5-7: Brake Connection

MOLEX #00	050579702	M8 CONNECTOR	
PIN NUMBERS	FUNCTION	PIN NUMBERS	4 2
1	Brake -	1	
2	Brake +	2	3 1
			Brake Side

**Table 5-8: Brake Pinout** 




Figure 5-8: Brake Cable

The USB port connector is a standard B type connector.

#### 5.7 USB 2.0 Connection




Figure 5-9: USB 2.0 Connection

#### 5.8 RS-485 Connection

The ACS RS485 connection requires an RJ45 plug with 3 conductors. The ACS controller/drive uses a two-wire configuration for RS485 connection. This requires three signals: A, B, and Common. Signals A and B are a differential pair. Signals A and B are duplicated on pins 7 and 8. Common is used as a reference voltage. Figure 5-10 shows the pin assignment on the ACS socket.




Figure 5-10: ACS 2-Wire RS485 with RJ45 Socket

#### 5.8.1 RS-485 Cable Length

A multipoint serial line bus is made of a main cable (the trunk) which connects to a Master device, and derivation cables that tap off from the trunk to Slave devices. RS-485 transceivers have a wide (-7V to +12V) common mode range. This differential signal has good noise immunity for long distance transmission lines. The absolute maximum cable length of the trunk is 4,000 feet. If more than one Slave device is tapped from the trunk, then terminating 150 Ohm resistors must be placed across lines A and B at both ends of the trunk. The derivation cable to the Slave device must be short with a maximum cable length of 60 feet. Some factors that may reduce cable length are: the number of devices on a multi-drop application, the quality of cabling used, and the baud rate selected.

#### 5.8.2 RS-485 Grounding

The Common wire must be connected to protective ground. This wire should only

be connected at one point on the bus, preferably at the Master device. If ground potentials are too large, resistors must be placed in the Common wire at each device to limit the current and prevent damage to the circuit. This is shown in Figure 5-11.




Figure 5-11: Resistors in ground wire to limit current

#### 5.9 Ethernet Connection

The following parts have two Ethernet ports with a built-in switch to be used for daisy chaining.

3604-9662 - ACS Servo Drive/Controller, EtherNet/IP™

3604-9663 - ACS Servo Drive/Controller, Modbus TCP





Figure 5-12: EtherNet/IP Connection for ACS Drive Programmability



FUNCTION
Transmit Port (+) Data Terminal
Transmit Port (-) Data Terminal
Receive Port (+) Data Terminal
NA
NA
Receive Port (-) Data Terminal
NA
NA

Table 5-9 EtherNet/IP pinouts and Connections

#### 5.10 Cable Routing

Over time, liquid contaminants such as oil and cleaning solutions may accumulate on the cables and in the connectors if they are an exposed type. To minimize the introduction of contaminants into the connector, route the cables so that there is a loop in the cable just prior to its attachment to the connector.

In Figure 5-13 proper cable looping is shown for connectors located on the top or side of the unit. Units mounted with connectors on the bottom surface require no cable looping.




Figure 5-13 Cable Routing for Top and Side Facing Connectors

#### 5.10.1 Ethernet Cable

The selection of cables has a profound impact on network performance and reliability. Selecting the correct cable requires an understanding of the environment where the cable is installed.

Due to high data rate and reliability considerations, at the minimum, Cat5e cables should be used with the ACS Drive. If the cables are made on site, they must be tested to meet performance criteria set according to TIA/EIA -568-B standard. This cable definition is the general cable requirements for copper and fiber cabling installations.

#### 5.10.2 Cable Length

The following information regarding cable length is from commercial building telecommunications cabling standard ANSI/TIA/EIA-568-B.1. The maximum length of a cable segment is 100 meters (328 ft). Category 5e cable is capable of transmitting data at speeds up to 1000 Mbps — 1Gbps (ACSI has a maximum speed of 100 Mbps). The specifications for 10BASE-T network—ing specify a 100-meter length between active devices. This allows for 90 meters of fixed cabling, two connectors, and two patch leads of 5 meters, one at each end.

MOTOR CO	NTROL SECTION
Commutation Method	Field Oriented Commutation
PWM Mode	Centered
PWM Efficiency	>90%
PWM Switching Frequency	12 KHz
PWM Ripple Frequency	24 KHz
Minimum PWM pulse duration	4.16uS
Dead Band	50ns - 500ns
Velocity Loop Frequency	1.2 KHz
ENCOD	ER SECTION
Maximum encoder rate	800 kHz
Index pulse	Required
Halls	Required
Electrical Pinout	A+/A-/B+/B-/Z+/(Z- optional)
COMMUNIC	CATION SECTION
	USB
Communication ports	Ethernet
	RS485,
USB Type	USB device only
USB Speed	USB Full Speed
Ethernet Speed	10/100M (Auto Negotiate)
Ethernet Duplex	Full/Half-Duplex (Auto Negotiate)
	19200
RS485 Baud Rate	38400
	115200

**Table 6-1: Controller Specifications** 

#### 6.1 Digital Inputs

#### 6.1.1 Specifications

The ACS Drive has a total of 8 opto-isolated digital inputs. These digital inputs are opto-isolated from the controller's drive circuitry and can be wired either as sinking or sourcing. All of the digital inputs have a common return.

NOTE: ACSI supports configuration of a digital input as a limit switch. This configuration requires the use of 'Normally Open' switches




Figure 6-1: Digital Input Circuit

Opto-isolated Digital Input Specifications			
Parameter	Value	Units	
Input Voltage Range	0 to 28	VDC	
On State Voltage Range	16 to 28	VDC	
Off State Voltage Range	0 to 5	VDC	
On State Current:			
16VDC (minimum)	1.9	A	
24VDC (nominal)	3.4	mA	
28VDC (maximum)	4.2		
Nominal Input Impedance (24V)	7	ΚΩ	
Off State Current (maximum)	0.4	mA	
Update Rate (maximum)	2	ms	

**Table 6-2: Opto-Isolated Digital Input Specifications** 

#### 6.1.2 Typical Wiring Diagrams




Figure 6-2: Input Source (switched) Connection




Figure 6-3: Input Source (PNP) Connection




Figure 6-4: Input Sink (switched) Connection




Figure 6-5: Input Sink (NPN) Connection

#### **6.2 Digital Outputs**

#### 6.2.1 Specifications

The ACS Drive has four digital outputs. These digital outputs are opto-isolated from the drive circuitry and can be configured for sinking or sourcing. The outputs are protected against over current and short circuit conditions. If an over current condition is present, the output turns off until the load is removed.




Figure 6-6: Output Circuit

Digital Output Specifications			
Parameter	Value	Units	
Switched Voltage (max)	24	V	
Output Voltage drop (20mA)	2	V	
Continuous Current (max)	20	mA	
Fold Back Current	80	mA	
Update Rate (10K0hm Load)	2	ms	
Output Leakage Current	30	uA	

**Table 6-3: Digital Output Specifications** 

#### 6.2.2 Typical Wiring Diagrams




Figure 6-7: Digital Output Sinking Connection




Figure 6-8: Digital Output Sourcing Connection

#### 6.3 Analog Input

#### 6.3.1 Specifications

The ACS Drive comes with one analog input. The input is configurable through software to be 0-10V or 0-20mA input. The analog input is referenced to the analog ground pin.

Parameter	Value	Units
Voltage Mode Input Voltage (min)	0	V
Voltage Mode Input Voltage (max)	10	V
Current Mode Input Current (min)	0	mA
Current Mode Input Current (max)	25	mA
Current Mode Input impedance (nom)	500	Ohm
Resolution	12	Bits

**Table 6-4: Analog Input Specifications** 

#### 6.3.2 Equivalent Circuit




Figure 6-9: Analog Input Equivalent Circuit



#### IMPORTANT!

Devices sharing analog inputs and outputs must have their grounds connected together for proper and reliable operation.

#### 6.4 Analog Output



#### **NOTE:**

Analog output only available with EtherNet/IP and Modbus TCP models

#### 6.4.1 Specifications

The ACS Drive can have one analog output capable of 0-10V or 0-20mA operation (on EtherNet/IP and Modbus TCP models). The analog output is referenced to the analog output ground pin.

Parameter	Value	Units
Output Voltage (min)	0	V
Output Voltage (max)	10	V
Output Current (min)	0	mA
Output Current (max)	20	mA
Resolution	12	Bits

**Table 6-5: Analog Output Specifications** 



#### IMPORTANT!

Devices sharing analog inputs and outputs must have their grounds connected together for proper and reliable operation.



#### **IMPORTANT!**

Devices sharing analog inputs and outputs must be referenced to the analog GND pin for proper and reliable operation.



#### **IMPORTANT!**

The analog GND is shared with the power cable GND internal to ACSI it should be connected to a high impedance or isolated source or else it will sink current from the motor driver potentially causing a noisy signal

#### 6.4.2 Equivalent Circuit




Figure 6-10: Analog Output Equivalent Circuit

#### 6.5 Brake Output

#### 6.5.1 Specifications

Parameter	Value	Units
Input Voltage	24	V
Absolute Maximum Voltage	70	V
Output Current	0 - 500	mA

**Table 6-6: Brake Output Specifications** 

#### 6.5.2 Equivalent Circuit




Figure 6-11: Brake Output Equivalent Circuit

#### 6.6 Input Power



#### **CAUTION!**

Voltage above the absolute maximum can result in permanent damage to the ACS internal drive components.



#### **WARNING!**

Do not reverse bias the power inputs. Doing so will result in permanent damage to the drive.

#### 6.6.1 Drive Specifications

ACS Internal Drive Specifications			
Parameter	Value	Units	
Current - Continuous (max)	10	А	
Current - Peak (max)	20	А	
Over Voltage <sup>1</sup>	65	V	
Under Voltage <sup>2</sup>	9	V	
Absolute Maximum Voltage	70	V	
Logic Current Draw Maximum (24V)	200	mA	

**Table 6-7: ACS Internal Drive Specifications** 

The drive and logic (keep alive) power share the same ground. Drive logic circuitry can be powered from the keep alive input or the main drive power.

<sup>&</sup>lt;sup>1</sup> Drive will fault at 65V; any voltage above the absolute max voltage can result in permanent damage.

<sup>&</sup>lt;sup>2</sup> Drive will fault below 9V.

Software Fault - Overvoltage and Undervoltage Trigger Values			
<b>Configured Motor Voltage</b>	Undervoltage Trigger Value	Overvoltage Trigger Value	
12	*10	18	
24	14.4	36	
36	21.6	54	
48	28.8	*65	

<sup>\*</sup>NOTE: The absolute minimum/maximum voltage will over-ride the calculated voltage threshold of 0.6x for undervoltage and 1.5 for overvoltage

**Table 6-8: Software Faults Trigger Values** 

**Keep Alive Wiring Diagram** 

## Keep Alive not required

Providing 10 to 60Vdc to keep alive maintains the drive logic memory when main power is de-energized; which stops all motion; the drive keeps all control logic active and position information.

# AC KEEP ALIVE - DIGITAL CIRCUITRY & LOGIC MAIN POWER - MOTOR DRIVE

Figure 6-12: Keep Alive wiring diagram

#### A

#### **WARNING!**

Do not short circuit the motor power at the power connector. Doing so may damage the drive power electronics. The motor cable is part of the current regulation circuitry. For a short occurring in a motor, the motor leads should provide enough resistance and inductance to prevent dangerous peak currents from occurring.

#### 6.6.2 Power Supply Sizing Guidelines

Both unregulated and regulated power supply can be used to power the ACS Drive.

Regulated supplies work well with ACSI drive, but additional measures may need to be taken. To prevent regenerative energy from reaching the supply or from damaging the drive, a shunt regulator should be installed. A shunt regulator is available as Tolomatic Part Number 2180-1163 (Applied Motion RC-050, 1000-237). These regulators can support multiple drives when the power supply is sized correctly. This regulator will clamp the dc voltage to within just a couple volts of the supply voltage and either store excess energy or dissipate it with an internal power resistor. When there is the risk of the drive suddenly losing power, the regulator will prevent the drive from being permanently damaged.

When using a single clamp for multiple drives, individual power cables should come directly off of the clamp. They should not be daisy chained between drives. The clamp should be close as possible to the drive which is the source of the Back EMF.

The ACS Drive is intended to run off of an isolated DC power source. The power supply required will depend on the application. A 48V supply will allow the actuator

(continued)

#### (continued)

to operate at maximum speed. A 24V supply will result in approximately half the rated velocity. Input current will depend on the actuator power needed in the installation. If operating more than one actuator on the same power supply, add the required power supply rating for each actuator.

#### 6.6.3 Calculating Wattage of Power Supply

Watts = I (amps) x V (volts)

Where

I = Torque Peak (in-lbs) / Kt (in-lb/amp-peak)

And

 $V = Ke (Vp / krpm) \times Speed Peak (rpm) / 1000$ 

We get

Watts = (Torque Peak / Kt) x (Ke x Speed Peak) / 1000

Use the following table to help determine the proper power source voltage for an application or call Tolomatic at 1-800-328-2174 or 763-478-8000 for assistance.

Tolomatic	Motor	Max Speed	Torque Peak	Kt	Ke
Part Number	Config. Code	rpm	in-lbs	in-lb/amp-pk	Vp/krpm
3604-1844*	AMV2C4A1*	6000	9.056	0.5228	6.19
3604-1845	AMV2C1A1	6000	5.225	0.3015	3.57
3604-1846	AMV2C3A1	6000	15.36	0.8868	10.50
3604-1847	AMV2C2A1	6000	8.8625	0.5118	6.06
3604-1848*	AMV2D3A1*	5000	20.73	1.1976	14.18
3604-1849	AMV2D1A1	5000	11.98	0.6918	8.19
3604-1850*	AMV2D4A1*	5000	34.2	1.974	23.38
3604-1851	AMV2D2A1	5000	19.75	1.1401	13.50

<sup>\*</sup>Not available with standard 15 day Built-To-Order delivery

#### **Table 6-9: ACS Internal Drive Specifications**

**EXAMPLE:** If we size a power supply for an AMV2C4A1 motor where the max speed will be 800rpm and the peak torque will be 6 in-lbs we can calculate the watts used.

Watts = (6/0.5228) x  $(6.19 \times 800) / 1000 = 56.83$  Watts

It is never a good idea to buy a power supply that just meets the drive's wattage requirements. To avoid nuisance overcurrent shut downs a power supply power rating should be at least 25% greater than the calculated value.

#### 6.6.4 Suggested Power Supplies:



#### WARNING!

All installations should provide a means for a hardware emergency stop that removes power from the drive in an emergency condition. The drive emergency stop function should not be relied on when safety is required. It is recommended to disconnect only the + bus power and keep the power ground line connected.

#### **Suggested Power Supplies:**

Switching Power Supply:			
Manufacturer	Tolomatic Part No.	Specs	
Meanwell	3604-2147	48V, 2.5A, 120 W	
	3604-2148	48V, 5A, 240 W	
	3604-2149	48V, 10A, 480 W	

Unregulated Power Supply: International Power IP500U36

Bus Fuse: 15 Amp, 125V or equivalent or sized for application

Logic Power Fuse: 2 Amp, 125V or equivalent

A shunt regulator (2180-1163) may be needed to disipate excess energy.




Figure 6-13: Power Supply Configuration with Shunt Regulator

#### **I/O Timing Diagrams**

#### 7.1 I/O Timing Diagrams

The opto-isolated digital inputs require a minimum of 2ms of time to guarantee that the input signal is registered by the drive. This is an important consideration to take into account, especially if limit switches are used. If limit switches are used, careful consideration should be used to prevent missed triggering due to high velocities. Output timing assumes 10K  $\Omega$  load. Additional software filtering of digital inputs as configured by TMI will increase response time.

```
1.15ms Avg 1.15ms Avg
```

Figure 7-1 Input Requirement

```
INPUT MAIN POWER

SYSTEM STARTUP

SYSTEM READY

SYSTEM READY
```

Figure 7-2 System Startup Timing




Figure 7-3 Jog Move Timing




Figure 7-4 Absolute & Incremental Move Timing




Figure 7-5 Brake Subsystem Timing

#### **7.1.1 Move Timing Rules**

- 1. While the Motion Complete signal is low, the drive will ignore Start Motion pulses and Motion Selection lines.
- 2. If the enable signal is low or Software Stop signal is high, the drive will ignore start motion pulses.

#### 8.1 Move Select Logic Table

The Index Move Mode (4/8/16 move commands), require digital inputs to select the desired move for execution. The digital inputs are called Move Select 1 through 4 (MS1-MS4) in the digital input map. To select the desired move command refer to the three logic tables below.

NOTE 1: MS# stands for Move Select #

**NOTE 2:** 1 = 0n; 0 = 0ff

4 Move Commands Mode Logic Table			
MOVE	MS1	MS2	
1	0	0	
2	1	0	
3	0	1	
4	1	1	

**Table 8-1: 4 Move Commands Mode Logic** 

8 Move Commands Mode Logic Table				
MOVE	MS1	MS2	MS3	
1	0	0	0	
2	1	0	0	
3	0	1	0	
4	1	1	0	
5	0	0	1	
6	1	0	1	
7	0	1	1	
8	1	1	1	

**Table 8-2: 8 Move Commands Mode Logic** 

16 Move Commands Mode Logic Table						
MOVE	MS1	MS2	MS3	MS4		
1	0	0	0	0		
2	1	0	0	0		
3	0	1	0	0		
4	1	1	0	0		
5	0	0	1	0		
6	1	0	1	0		
7	0	1	1	0		
8	1	1	1	0		
9	0	0	0	1		
10	1	0	0	1		
11	0	1	0	1		
12	1	1	0	1		
13	0	0	1	1		
14	1	0	1	1		
15	0	1	1	1		
16	1	1	1	1		

**Table 8-3: 16 Move Commands Mode Logic** 

#### 9.1 LED Codes

LED Indicators				
Green, Off	Motor is not powered			
Green, On Motor is powered				
Red, On and Solid	A critical fault has occurred			
Red, On and Blinking	A safety fault has occurred			
Green, On and Blinking	Firmware Upgrade Mode			
Red, On and Blinking	riiiiwale opylade Mode			

**Table 9-1: LED Indicators** 

To clear a fault, the enable input needs to be lowered, and then raised. Faults can also be cleared by the PC software. Faults that result in a blinking red LED indicator, are cleared automatically once the fault condition is no longer present.

## 9.2 Fault Descriptions and Recovery

NOTE: To clear faults; PLC needs to lower/raise the enable digital input or TMI user must press the Enable button on the motion manager

Faults are divided into Safety Faults and Critical Faults.

Safety Faults are configurable. If the fault is configured as a stop motion, the fault will be cleared automatically once the fault condition is no longer present. If a safety fault is enabled and configured for disable motor, the fault will be latched until it is cleared in the same manner as the critical faults described at left.

All Critical Faults will disable the motor when they occur. To clear these faults, the fault condition cannot be present and the enable input line must be lowered and then raised to proceed with motion.

Safety Faults Table							
Positive Limit Switch	Positive limit switch has been reached. If configured to stop						
	motion, motion will be allowed in the reverse direction. The						
	fault will be cleared once the positive limit switch input is no						
	longer active and there is motion in the negative direction.						
Negative Limit Switch	The negative limit switch has been reached. If configured as						
	stop motion, motion will be allowed in the positive direction.						
	The fault will be cleared once the negative limit switch						
	input is no longer active and there is motion in the positive						
	direction.						

Safety Faults Table							
<b>Position Error</b>	If an encoder is present, the position error fault can be						
	enabled. If encoder position and commanded position differ						
	by a larger magnitude than the defined position error, the						
	position error fault will be activated. If fault is configured as a						
	stop motion, fault will be cleared on next move command.						
Software Stop	If an input is configured as an Software Stop and fault is						
	enabled, this fault will be activated when the signal level						
	on the pin is high. This fault is configured as a stop motion,						
	it will be cleared once the Software Stop input is lowered.						
	Motion will not be allowed until Software Stop has been						
	cleared.						

Table 9-2: Safety Faults

	Critical Faults Table				
Feedback Error	Feedback device is malfunctioning.				
Over Current	If a short circuit occurs from output to ground, this fault will be triggered.				
Drive Over Temp	Drive temperature is greater than the maximum allowed temperature (75°C).				
Drive Over Voltage	ver Voltage Main power voltage exceeds the threshold defined in				
	hardware manual: "Input Power" section.				
Drive Under Voltage Main power voltage below the threshold defined in ha					
	manual: "Input Power" section.				
Flash Error	Flash memory checksum error or firmware version mismatch				
I2T Limit	Drive power usage greater than max allowed				
Short Circuit	Short circuit to ground condition on motor				
Watchdog Timeout	Firmware did not respond in time				

**Table 9-3: Critical Faults** 

# Troubleshooting

# 10.1 Troubleshooting

## ■ 10.1.1 Troubleshooting the ACS Servo Drive

Troubleshooting Table				
SYMPTOM / TROUBLE	POSSIBLE CAUSE / RESOLUTION			
No communication to drive	Check power connection.			
	Verify that the communication cable is plugged in securely.			
	3. Verify that USB drivers are up-to-date.			
	4. Try a different computer.			
	5. If communication fails when enabling the motor, then the motor tuning needs to be adjusted.			
Actuator cannot move load	1. The load is too large.			
	2. There is too much friction.			
	3. Side load is excessive.			
	4. Power supply does not have enough current capability.			
	5. Current limits are set too low.			
Drive is overheating	1. Ambient temperature is too high.			
	2. Cooling is insufficient.			
Actuator is operating erratically	Motor encoder is not aligned to Tolomatic spec.			
	Motor encoder signals disconnected, damaged or wired incorrectly.			
	3. Determine if power supply has enough current.			
	4. Check to see if any faults are being generated.			
	5. Verify that the drive has been configured properly for the actuator.			
No response from drive in I/O	1. Verify the enable signal is on.			
mode	2. Verify that all of the I/O are configured properly.			
	3. Verify wiring to the actuator and drive.			
	Disconnect from software or select digital input controlled radio button on mode setup tab			
Red and Green LEDs blink	Cycle power to drive			
alternately	2. Verify Firmware Upgrade completed without interruption			

Troubleshooting Table					
SYMPTOM / TROUBLE	POSSIBLE CAUSE / RESOLUTION				
No EtherNet/IP™	1. Check EtherNet/IP cables.				
Communication	2. Verify EtherNet/IP cable is plugged in securely.				
	Incorrect combination of IP address, subnet mask & gateway. Check with your network administrator.				
Audible noise from motor when TMI is connected over USB	Running TMI and connecting using a virtual server has been known to cause USB connection issues. It is not recommended to control ACS drives using a virtual machine				
	2. Check different USB ports.				
	3. Check different computers.				
	4. Check different USB cables.				

**Table 10-1: Troubleshooting Descriptions** 

#### Motors

There are currently 5 different motor selections available from Tolomatic for the ACS Servo drive - three NEMA 23, and two NEMA 34. Each motor has an integrated 500 line (2000 count) encoder with differential A/B, single-ended index and hall signals. A 12 inch pigtail with circular connector is standard on each motor.

Tolomatic Motor Specifications							
SPEC	AMV2C1A1	AMV2C2A1	AMV2C3A1				
NEMA	NEMA 23	NEMA 23	NEMA 23				
Continuous Torque	2.63 in-lbs	4.25 in-lbs	4.29 in-lbs				
Peak Torque	5.25 in-lbs	8.5 in-lbs	13 in-lbs				
Resistance	0.23 Ohms	0.205 Ohms	0.616 Ohms				
Inductance	0.244 mH	0.305 mH	0.915 mH				
Torque Constant (Kt)	4.824 oz-in/A 8.189 oz-in/A		14.189 oz-in/A				
Back EMF Constant (Ke)	3.570 V/kRPM	6.06 V/kRPM	10.5 V/kRPM				
Max. Continuous Current	10 Amps	10 Amps	3.5 Amps				
Max. RPM	6,000 RPM	6,000 RPM	6,000 RPM				
Rotor Inertia	0.001 oz-in-s <sup>2</sup>	0.002 oz-in-s <sup>2</sup>	0.002 oz-in-s <sup>2</sup>				
Motor Poles	8	8	8				
Max Case Temp	85C	85C	85C				


Tolomatic Motor Specifications					
SPEC	AMV2D1A1	AMV2D2A1			
NEMA	34	34			
Continuous Torque	5.9 in-lbs	9.87 in-lbs			
Peak Torque	11.9 in-lbs	21.46 in-lbs			
Resistance	0.250 Ohms	0.208 Ohms			
Inductance	0.325 mH	0.399 mH			
Torque Constant (Kt)	11.068 oz-in/A	18.243 oz-in/A			
Back EMF Constant (Ke)	MF Constant (Ke) 8.190 V/kRPM 13.5 V/kRP				
Max. Continuous Current	10 Amps	10 Amps			
Max. RPM	5,000 RPM	5,000 RPM			
Rotor Inertia	Rotor Inertia 0.01 oz-in-s <sup>2</sup> 0.02 oz-				
Motor Poles	8	8			
Max Case Temp 85C 85C					

**Table A-1: Tolomatic Servo Motor Specifications** 

#### **Tolomatic Motor Part Numbers**

NEMA	CONFIGURATOR CODE	PART NUMBER	
Nema 23	AMV2C1A1	3604-1845	
Nema 23	AMV2C2A1	3604-1847	
Nema 23	AMV2C3A1	3604-1846	
Nema 34	AMV2D1A1	3604-1849	
Nema 34	AMV2D2A1	3604-1851	

**Table A-2: Tolomatic Motor Part Numbers** 



**GND** 

**Table A-3: Motor Connector pinout** 

BLK

S

## **Previous Revisions of Wire Colors for Motor Power Connection pinouts**

#### NOTE!

See section 5 for current wire color/pin numbers




Figure 5-2: Motor Power Connection on ACS Servo Drive (repeated for reference)

	SOURIAU P/N UTG11619S		ON SHORE P/N 0STTJ055153 21901027						
3604-1842 3604-1843	PIN	PIN Number	COLOR (REV 5)	COLOR (REV 6)	ACS SIGNAL	MOTOR SIGNAL			
	В	1	RED	GRN/YEL	PHASE R	PHASE R			
	D	2	WHT	BLK #1	PHASE S	PHASE T			
	E	3	SHIELD	SHIELD	SHIELD	SHIELD			
	С	4	BLK	BLK #2	PHASE T	PHASE S			
	NC	5	NC	NC	NC	NC			
	R	NC	NC	NC	NC	NC			

	SOURIAU P/N Utg11619S	ON SHORE P/N OSTTJ055153 21901027							
		DIN	REV	0.1	RE\	12			MOTOR
3604-1943	PIN	PIN NUMBER	COLOR (REV 0)	COLOR (REV 1)	COLOR (REV 2)	COLOR (REV 3)	REV 3	ACS SIGNAL	MOTOR SIGNAL
	В	1	GRN/YEL	RED	GRN/YEL	RED	RED	PHASE R	PHASE R
	D	2	BLK #1	WHT	BLK #1	BRN	BRN	PHASE S	PHASE T
	Е	3	SHIELD	SHIELD	SHIELD	SHIELD	SHIELD	DRAIN	SHIELD
	С	4	BLK #2	BLK	BLK #2	BLK	BLK	PHASE T	PHASE S
	NC	5	NC	NC	NC	NC	NC	NC	NC
	R	NC	NC	NC	NC	NC	NC	NC	NC

**Table A-4: Previous Revisions of Wire Colors for Motor Power Connection pinouts** 

#### **Previous Revisions of Wire Colors for I/O Connection**

#### NOTE!

See section 5 for current wire color/pin numbers




Figure 5-4: I/O Connection on ACS Drive (repeated for reference)

JST #PHDR-30VS					
PIN NUMBERS	SIGNAL	CABLE WIRE COLOR			
		REV 0,1	REV 2	REV 3	REV 5
1	Input ISO 1	RED/BLK/WHT	RED/BLK/WHT	PNK/BLK	PNK/BLK
2	Input ISO 2	ORG/GRN	ORG/GRN	ORG/GRN	PNK
3	Input ISO 3	RED/WHT	RED/WHT	RED/WHT	RED/WHT
4	Input ISO 4	GRN/WHT	GRN/WHT	GRN/WHT	TEAL/WHT
5	Input ISO 5	BLU/WHT	BLU/WHT	BLU/WHT	BLU/WHT
6	Input ISO 6	WHT/BLK/RED	WHT/BLK/RED	WHT/BLK/RED	YEL/BLK
7	Input ISO 7	WHT/RED	WHT/RED	WHT/RED	YEL
8	Input ISO 8	ORG/RED	ORG/RED	ORG/RED	ORG/WHT
9	Input ISO COM	GRN/BLK	GRN/BLK	GRN/BLK	TEAL/BLK
10	Output 1 -	RED/BLK	RED/BLK	RED/BLK	RED/BLK
11	Output 1 +	WHT	WHT	WHT	WHT
12	Output 2 -	WHT/BLK	WHT/BLK	WHT/BLK	GRN
13	Output 2 +	BLU	BLU	BLU	BLU
14	Output 3 -	BLU/BLK	BLU/BLK	BLU/BLK	GRY/BLK
15	Output 3 +	ORG	ORG	ORG	ORG
16	Output 4 -	ORG/BLK	ORG/BLK	ORG/BLK	ORG/BLK
17	Output 4 +	RED	RED	RED	RED
20	Case Ground	SHIELD	SHIELD	SHIELD	SHIELD
23	*Step Input	BLU/RED	BLU/RED	BLU/RED	BRN/WHT
24	*Direction Input	RED/GRN	RED/GRN	RED/GRN	BRN
25	NA	GRN	GRN	GRN	TEAL
26	NA	BLK/RED	BLK/RED	BLK/RED	GRY
27	Analog Out	GRN/BLK/WHT	GRN/BLK/WHT	GRN/BLK/WHT	VIO/WHT
28	Analog In	BLK/WHT/RED	BLK/WHT/RED	BLK/WHT/RED	VIO
29	Signal Ground	BLK	BLK	BLK	BLK
30	Signal Ground	BLK/WHT	BLK/WHT	BLK/WHT	BLK/WHT

Table A-5: Previous Revisions of Wire Colors for I/O Connection

## Product Warranty

Tolomatic, Inc. warrants all products manufactured by it to be free from defects in material and workmanship for a period of one year from date of shipment by Tolomatic. If, within this period, any product is proven to be defective by Tolomatic, the product will either be repaired or replaced at Tolomatic's option.

This warranty shall not apply to:

- Products not manufactured by Tolomatic. Warranty of these products will conform and be limited to the warranty actually extended to Tolomatic by its supplier.
- 2. Damage to the product caused by circumstances beyond the control of Tolomatic, such as negligence, improper maintenance, or storage.
- 3. This warranty shall be void in the case of: any repairs or alterations made to the product by parties other than Tolomatic.

The foregoing warranties are exclusive and in lieu of all other express and implied warranties. Tolomatic is not subject to any other obligations or liabilities for consequential damages.

#### **CE COMPLIANCE**

The ACS Servo Drive is certified to be meet CE emission standard

#### EN 55011:2009/A1:2010

Industrial, scientific and medical equipment - Radio-frequency disturbance characteristics - Limits and methods of measurement.

And CE immunity standard

#### EN 61000-6-1:2007

Electromagnetic compatibility (EMC) -- Part 6-1: Generic standards - Immunity for residential, commercial and light-industrial environments.

The above emission and immunity standards can only be guaranteed if high quality shielded cables are used and proper grounding techniques are applied to the installation. Tolomatic recommends that only trained and qualified personal familiar with sound industrial wiring techniques perform the installation. If the ACS Servo Drive is to be included in a system that intends to have emissions and immunity certification Tolomatic recommends that ferrite suppression cores such the Fair-Rite 0431164281 (or similar) be attached to all cables leading to and from the ACS Drive.

## D.1 Certification



## **EU Declaration of Conformity**

No: 3600-4704\_00

We the manufacturer,

**Tolomatic** 3800 County Road 116 Hamel, MN 55340 USA

declare under our sole responsibilty that the product(s),

ACS

All variations of Models

Fulfills the essential requirements of the following directives:

EMC Directive (2014/30/EU)

EN61000-6-1 2007 Immunity

EN55011: 2009 +A1:2010 Emissions

RoHS Directive (EU 2015/863)

**REACH (No 1907/2006)** 

Assumptions of conformity is based on the application of the harmonized or applicable technical standards and, when applicable or required, a European community notified body certification.

Gary Rosengren

**Director of Engineering** 

03.10,2019

Date (dd.mm.yyyy)

© 2019 Tolomatic
Tolomatic. All rights reserved.
Tolomatic and Excellence In Motion are
registered trademarks of Tolomatic Incorporated.
All other products or brand names are
trademarks of their respective holders.
www.tolomatic.com

201912201003

3604-4181 14



# USA Tolomatic Inc. To

3800 County Road 116 Hamel, MN 55340, USA **Phone:** (763) 478-8000 **Fax:** (763) 478-8080 Toll-Free: **1-800-328-2174** sales@tolomatic.com

www.tolomatic.com

# CHINA Tolomatic Automation Products

(Suzhou) Co. Ltd. (ServoWeld® inquiries only)

No. 60 Chuangye Street, Building 2 Huqiu District, SND Suzhou Jiangsu 215011 - P.R. China **Phone:** +86 (512) 6750-8506

Fax: +86 (512) 6750-8507 ServoWeldChina@tolomatic.com

#### **EUROPE**

Certified site: Hamel, MN

COMPANY WITH
QUALITY SYSTEM
CERTIFIED BY DNV GL
= ISO 9001 =

#### **Tolomatic Europe GmbH**

Elisabethenstr. 20 65428 Rüsselsheim

Germany

Phone: +49 6142 17604-0 help@tolomatic.eu

All brand and product names are trademarks or registered trademarks of their respective owners. Information in this document is believed accurate at time of printing. However, Tolomatic assumes no responsibility for its use or for any errors

that may appear in this document. Tolomatic reserves the right to change the design or operation of the equipment described herein and any associated motion products without notice. Information in this document is subject to change without notice.