# iTools

# User Guide

Last updated by: Quan Nguyen

Effective date: Aug 14, 2018

Version: 1.0

# **Document Control**

Version	Change description	Changed by	Date	Approved by	Date
0.1	Initiate and draf	Quan Nguyen	16-Aug-2018		
1.0	Modify and finalize the document	Quan Nguyen	16-Aug-2018	Quan Nguyen	16-Aug-2018

# Table of Contents

1.	Overview	5
	1.1. Requirement	5
	1.2. Approach	5
2.	Installation	5
	2.1. Java	5
	2.2. MySQL	5
	2.3. iTools	5
3.	Configuration	6
4.	User Guide	7
	4.1. Common Feature	7
	4.1.1. Login	7
	4.1.2. Forgot Password	8
	4.1.3. Change Password	
	4.2. Company Admin	12
	4.2.1. Reset Password	12
	4.2.2. Lock - Unlock Account	14
	4.2.3. Sync manually	14
	4.3. Accounting	15
	4.3.1. Lock/Unlock machine	15
	4.3.2. Putin	19
	4.3.3. TakeOver	24
	4.4. Normal User	25
	4.4.1. Get Tool	25
5.	Error Message	27
6.	Troubleshoot	27
7.	Portrait page style	27

# Index of Tables

# No table of figures entries found.

# Index of Figure

Figure 1: Configuration	6
Figure 2: Login Page	7
Figure 3: Forgot Password Page1	8
Figure 4: Forgot Password Page2	9
Figure 5: Forgot Password 3	10
Figure 6: Change Password	11
Figure 7: Dashboard	12
Figure 8: Reset Password	13
Figure 9: Lock – Unlock Account	14
Figure 10: Login by accounting account	15
Figure 11: Show Dashboard	16
Figure 12: Wait for result	17
Figure 13: Enable Putins and TakeOver button after unlock	18
Figure 14: Putins Page	19
Figure 15: Select Tools	20
Figure 16: Select Trays	21
Figure 17: Edit quantity and process	22
Figure 18: Review result	23
Figure 19: Review result	24
Figure 20: Get Tool Page	25
Figure 21: Processing	26
Figure 22: Review result	27

#### 1. Overview

**TBD** 

### 1.1. Requirement

TBD

## 1.2. Approach

• TBD

#### 2. Installation

#### 2.1. Java

Version: JRE 1.8 - jre-8u172-windows-i586.exe (<a href="http://download.oracle.com/otn-pub/java/jdk/8u181-b13/96a7b8442fe848ef90c96a2fad6ed6d1/jre-8u181-windows-i586.exe">http://download.oracle.com/otn-pub/java/jdk/8u181-b13/96a7b8442fe848ef90c96a2fad6ed6d1/jre-8u181-windows-i586.exe</a>)

## 2.2. MySQL

- MySQL server 5.7: https://dev.mysql.com/downloads/file/?id=479142
- MySQL Workbench: <a href="https://dev.mysql.com/downloads/file/?id=474210">https://dev.mysql.com/downloads/file/?id=474210</a>
- Configuration user to logon: admin/<password>

#### 2.3. iTools

- Provide basic information of Industry PC (IPC)
  - Database configuration
  - Board ID + VendorID will provide the tool to get information later.
  - Machine Code
  - Company Code
- Copy iTools\_<version>.jar to IPC and run

#### 3. Configuration

```
# Database Section
                                                                                    # Database Section
mDbUser = NvglO4oQMvZ1sdJWnWjdZA==
                                                                                    mDbUser = NvglO4oQMvZ1sdJWnWjdZA==
mDbHost = UpHaAGLI5nA2ZjFEXfHGuQ==
                                                                                    mDbHost = localhost
mDbPwds = OrsBxLv9C9D2SFmJ3CPqqQ==
                                                                                    mDbPwds = admin
mDbName = eBKtu7D/Xq7eS2Ok3NS/uw==
                                                                             5
                                                                                    mDbName = iTools_v1p0
mDbPort = JWWCJKiJkRk7Xvjrt/TBOA==
                                                                                    mDbPort = 3306
                                                                             8
#Application config
                                                                                    #Application config
Expired_Time = 30000
                                                                             9
                                                                                    Expired_Time = 30000
INTERVAL_SYNC = 300
                                                                            10
                                                                                    INTERVAL SYNC = 300
Employee_Page_WO_Min_Length = 2
                                                                                    Employee_Page_WO_Min_Length = 2
                                                                            11
Employee Page OP Min Length = 2
                                                                                    Employee Page OP Min Length = 2
MAX ITEM PER TRAY = 20
                                                                                    MAX ITEM PER TRAY = 20
                                                                            13
                                                                            14
                                                                            15
# Company config
                                                                            16
                                                                                    # Company config
                                                                                    COMPANY_CODE_UH = UHCOM
COMPANY_CODE_UH = fc29iLQb/6RzY78LZbsUDA==
COMPANY CODE = 4/Yj79kc+/3YHljZ9MMQiw==
                                                                            18
                                                                                    COMPANY CODE = COM1
MACHINE_CODE = Ex3cQddpgX5+0LrLI4bBsA==
                                                                                    MACHINE_CODE = MAC1
                                                                            19
VENDOR ID = 0 \times 461
                                                                                    VENDOR ID = 0 \times 461
                                                                            22
                                                                                    PRODUCT_ID = 0x20
PRODUCT ID = 0 \times 20
                                                                            23
READ_WAIT_TIME = 10
                                                                                    READ_WAIT_TIME = 10
# Return code
                                                                            25
                                                                                    # Return code
MOTOR_START = 121
                                                                                    MOTOR START = 121
                                                                            26
MOTOR_STOP = 122
                                                                            27
                                                                                    MOTOR STOP = 122
PRODUCT OK = 123
                                                                                    PRODUCT OK = 123
                                                                            28
                                                                                    PRODUCT_FAIL = 124
PRODUCT_FAIL = 124
                                                                            30
###Config item
                                                                                    ###Config item
                                                                            31
TRAY 01 = 01
                                                                                    TRAY_01 = 01
TRAY 02 = 02
                                                                            33
                                                                                    TRAY 02 = 02
                                                                                    TRAY_03 = 03
TRAY_04 = 04
TRAY_03 = 03
                                                                            34
TRAY 04 = 04
                                                                            35
TRAY 05 = 05
                                                                                    TRAY 05 = 05
TRAY_06 = 06
                                                                                    TRAY_06 = 06
                                                                            37
TRAY_07 = 07
                                                                                    TRAY_07 = 07
TRAY_08 = 08
                                                                            39
                                                                                    TRAY_08 = 08
                                                                            40
. . . .
                                                                            41
                                                                            42
. . . .
                                                                                    . . . .
                                                                            43
                                                                            44
                                                                            45
#Email config
                                                                            46
                                                                                    #Email config
EMAIL_USERNAME = fCBLDZEmSL3EzORzYJpyUoHa0cm+cnlWiQh9k8hyg9c=
                                                                            47
                                                                                    EMAIL_USERNAME = iTools_App
EMAIL PASSWORD = KG68kUlf8UKiI+qZYZFt5A==
                                                                            48
                                                                                    EMAIL PASSWORD = <PasswordEmail>
                                                                                    EMAIL_HOST = tqteam.net
EMAIL_PORT = 25
EMAIL HOST = iNsabt5tGQ4+JPjalpYuvQ==
                                                                            49
EMAIL_PORT = evNaJwjjy9s1qudJ3/VSUA==
                                                                            50
IS SEND MAIL = 1
                                                                            51
                                                                                    IS SEND MAIL = 1
```

Figure 1: Configuration

#### 4. User Guide

#### 4.1. Common Feature

# 4.1.1. Login




Figure 2: Login Page

## 4.1.2. Forgot Password




Figure 3: Forgot Password Page1




Figure 4: Forgot Password Page2




Figure 5: Forgot Password 3

# 4.1.3. Change Password




Figure 6: Change Password

## 4.2. Company Admin

#### 4.2.1. Reset Password




Figure 7: Dashboard




Figure 8: Reset Password

#### 4.2.2. Lock - Unlock Account




Figure 9: Lock – Unlock Account

# 4.2.3. Sync manually

TBD

## 4.3. Accounting

#### 4.3.1. Lock/Unlock machine




Figure 10: Login by accounting account




Figure 11: Show Dashboard




Figure 12: Wait for result




Figure 13: Enable Putins and TakeOver button after unlock

#### 4.3.2. Putin




Figure 14: Putins Page




Figure 15: Select Tools




Figure 16: Select Trays




Figure 17: Edit quantity and process




Figure 18: Review result

#### 4.3.3. TakeOver




Figure 19: Review result

#### 4.4. Normal User

#### 4.4.1. Get Tool




Figure 20: Get Tool Page




Figure 21: Processing




Figure 22: Review result

- 5. Error Message
- 6. Troubleshoot
- 7. Portrait page style