

HEXBOARD SEQUENCER MODE

QUICK MANUAL

Overview

Sequencer mode is a separate mode from Keyboard mode. It is a single-track, 32-step sequencer. Each step can hold up to 4 notes, its own note length, and can play through MIDI or the onboard synth.

Enter And Exit

- From the main menu, choose Sequencer.
- In the Sequencer menu, choose Keyboard to return to normal keyboard mode.

Main Controls

- Steps: the first 8 playable keys of the first 4 rows are steps 1-32.
- Play/Stop: the top-right key starts and stops playback.
- Overview: the 9th key on the second row pages through an 8-step note view.
- Blue action key: the far-right key on the second row does undo on short press and clears the selected step on a 1-second hold.
- Encoder:
 - Turn while holding a selected step to change that step's length.
 - Press during file or folder naming to save the name.

Step Editing

- Press a step once to select it.
- Press the same step again to deselect it.
- With a step selected, play note keys on the lower part of the board to add or remove notes from that step.
- Step notes are kept sorted from lowest to highest.
- Tap Preview can make a tapped step audition its stored notes when selected.

Note Length

- Hold the selected step and turn the encoder.
- Available lengths are:
 - 0%, 25%, 50%, 75%, 100%, 150%, 200%, 250%, 300%, 350%, 400%, 1000%

Playback

- Tempo is the step clock.
- Each step is a 16th note at the current tempo.
- Steps sets the active playback range from 1 to 32.
- Direction choices are:
 - Forward, Backward, Ping-Pong, Random, Brownian, Drunk
- Play Type chooses:
 - MIDI or OB Synth

Menu Items

- Save: saves to the current file.
- Save New: saves as a new file in the selected folder.
- Load: loads a saved sequence.
- Revert: reloads the last saved version of the current sequence.
- File Management:
 - Rename File, Rename Folder, Create Folder, Delete File, Delete Folder
- Steps: active playback length
- Direction: playback order
- Tempo: BPM
- Tap Preview: audition step contents when a step is tapped

- Play Type: MIDI or onboard synth
- Synth Options: opens the shared synth settings page
- Update Firmware: reboots to the firmware update bootloader

Saving And Files

- Sequences are stored under /Sequences in onboard flash.
- The menu title shows the current file name as:
Seq-FILENAME
- If there are unsaved changes, it becomes:
Seq-*FILENAME
- If no file is loaded, the title just says:
Sequencer

Naming Mode

When naming a file or folder, the board shows this entry layout:

```

A B C D E F G H
I J K L M N O P
Q R S T U V W X
Y Z SPC - 1 2 3
<- CANCEL

```

- Press keys to enter characters.
- SPC adds a space.
- <- deletes the previous character.
- CANCEL exits naming without saving.
- Press the encoder to save the name.

Status And Display

- The selected step blinks.
- The overview screen shows 8 steps at a time.
- Empty steps are dark when idle.
- The top title shows the loaded file name and unsaved state.