Autopilot Faq

What Autopilot Can Do

Autopilot is designed to assist with steering, acceleration, and braking on highways and major roads. It helps keep your vehicle centered in its lane and maintains a set distance from the vehicle ahead. When activated, Autopilot can change lanes automatically when you signal, merge onto highways, and navigate complex interchanges with guidance. It operates at speeds up to 130 km/h (80 mph) on roads with clear lane markings.

Autopilot is not a fully autonomous system. It requires your full attention at all times. You must remain ready to take over control at any moment. The system does not detect or respond to all road conditions, such as sudden obstacles, construction zones with temporary signage, or vehicles that stop unexpectedly.

Driver Supervision Requirement

You must keep your hands on the steering wheel at all times when Autopilot is active. The system monitors your engagement through steering torque and wheel movement. If it detects no input for more than 10 seconds, a visual alert appears. After 15 seconds without input, a chime sounds and the system begins to reduce speed. After 30 seconds, Autopilot disengages and the vehicle slows to a stop unless you reengage.

You must watch the road ahead and be prepared to take control at any moment. The system cannot anticipate all hazards. If you are distracted or not paying attention, Autopilot will not compensate. Using Autopilot while drowsy, impaired, or otherwise not fully attentive is unsafe and may violate local laws.

Common Warnings and Alerts

• A yellow steering wheel icon appears if the system detects low steering input. This indicates you need to touch the wheel.

• A red steering wheel icon appears after 15 seconds of inactivity. This means Autopilot will disengage soon.

• A chime sounds after 20 seconds of inactivity. A second chime occurs at 25 seconds.

• If you do not respond after 30 seconds, Autopilot disengages and the vehicle slows to a stop.

• A "Driver Attention" alert appears if the system detects unusual eye movement patterns or lack of head movement during long periods of use.

If you receive multiple attention alerts in a single drive, Autopilot may be temporarily disabled for the remainder of that trip. It will re-enable after a 30-minute cooldown period.

Camera Cleaning and Maintenance

Clean your front and side cameras at least once a month or more frequently in dusty, snowy, or rainy conditions. Use only a soft microfiber cloth and distilled water. Avoid abrasive cleaners, glass cleaners with ammonia, or paper towels.

For the front camera, wipe the windshield area just above the rearview mirror, including the small lens located in the center of the rearview mirror housing. For side cameras, clean the rear quarter panels and side mirrors. If the camera lenses are obscured, Autopilot may not function properly.

After washing your vehicle, allow the cameras to dry completely before using Autopilot. If the system fails to detect lanes or vehicles after cleaning, wait 5 minutes for the sensors to recalibrate. If issues persist, restart the vehicle.

Known Limits and Limitations

• Autopilot cannot detect stationary objects such as stopped emergency vehicles, construction barrels, or debris on the road.

• It may misinterpret lane markings on roads with faded or unclear lines. On roads with no lane markings, Autopilot will not activate.

• The system does not recognize pedestrians or cyclists in certain lighting conditions, such as at night or in heavy rain.

• Autopilot may not respond to sudden lane changes by other vehicles, especially if they occur within 30 meters (100 feet).

• It cannot navigate through toll plazas, roundabouts, or complex intersections with multiple signal phases.

• In low visibility conditions such as fog, heavy rain, or snow, system performance may degrade significantly.

• Autopilot may not detect vehicles turning into your path from side streets at speeds below 20 km/h (12 mph).

• The system does not account for temporary traffic signs or construction zones with non-standard layouts.

• It cannot detect emergency vehicles with flashing lights unless they are moving and within the vehicle’s forward field of view.

Autopilot is designed to assist, not replace, the driver. Always remain in control of your vehicle. Use it only on roads with clear lane markings and in conditions where visibility is good.