Tukang Copilot

Repair Report

#059167958bd0

CAUTION Safety

Fuel and carburetor nearby is flammable, ignition can give high-voltage shock, engine head may be hot with sharp edges. No gas leak, mains wiring or opened engine internals.

Item

Underbone motorcycle air-cooled engine cylinder head area with carburetor

Problem

Honda Beat cranks with the starter but will not fire. Cylinder head, plug cap and carburetor look connected with no obvious break, engine is dusty with oily grime.

Cause worked on

Fouled, wet or worn spark plug giving no spark

Photo with the parts marked (SAM 3.1)



Likely causes

68% Fouled, wet or worn spark plug giving no spark

55% Weak contact in spark plug cap or ignition lead

48% Carburetor fuel delivery blocked - clogged jet or no fuel flow

Before you start, make sure

- ☐ Engine OFF and cool to touch
- ☐ Bike on center stand on flat dry ground
- ☐ Fuel tap closed if fitted

Steps (0/6 verified by camera)

1. Turn ignition OFF, remove key and put bike on center stand on flat ground. Check head is cool with back of hand, do not continue if hot.
   -> ignition key removed, bike upright on center stand, cylinder head cool to touch
2. Wipe dust off plug cap and head with dry rag. Grip rubber cap, twist slightly and pull straight off.
   -> area wiped clean, spark plug cap pulled off and white ceramic plug tip visible
3. Fit 16mm plug socket over plug and turn counter-clockwise by hand. Lift plug out and place on rag.
   -> spark plug removed and placed on rag, empty plug hole visible in cylinder head
4. Screw new or cleaned dry plug in by hand clockwise until snug. Snug only 1/4 turn more with socket.
   -> clean or new spark plug threaded fully into cylinder head, metal base seated with no gap
5. Push spark plug cap firmly onto plug until it clicks. Tug lightly to confirm it stays on.
   -> plug cap pushed fully onto spark plug, no gap, cable routed without kinks
6. Turn ignition ON and try starter for max 5 seconds. Do not hold plug or cap during cranking.
   -> engine running and idling, key in ON position

Engine starts with starter and idles steadily without stalling, plug cap stays firmly seated and there is no strong fuel smell.

Tools

- 16mm spark plug socket wrench	Rp35.000
- Phillips and flat screwdriver set	Rp55.000
- Clean dry rag	Rp10.000

Parts

- Standard scooter spark plug NGK CPR7EA-9 type	Rp28.000
- Spark plug cap / cop busi universal	Rp35.000
- Carburetor cleaner spray can	Rp48.000

Estimated parts cost: Rp111.000 ~45 min

Typical shop price (labour + parts): Rp150.000

Saved by doing it yourself (parts only): Rp39.000

What the AI did

- 0s Scanned your words for hazards (gas, mains, brakes...): clear [code]
- 16s Looked at the photo: Underbone motorcycle air-cooled engine cylinder head area with carburetor, 5 parts located [muse-spark-1.3] 15.9s
- 26s Outlined 5 of 5 parts on your photo (pixel masks) [sam-3.1] 9.9s
- 44s Most likely: Worn or fouled spark plug with no spark (50%), out of 3 causes [muse-spark-1.3] 18.7s
- 44s Only 50% sure (below 60%): asked one question instead of guessing
- 45s Got your answer, re-ran the diagnosis

- 70s Most likely: Fouled, wet or worn spark plug giving no spark (68%), out of 4 causes [muse-spark-1.3] 24.8s
- 96s Planned 6 steps for: Fouled, wet or worn spark plug giving no spark [muse-spark-1.3] 26.0s
- 96s Plan checked by safety rules in code: passed (CAUTION) [code]

Under the hood: models used

- Text safety gate: rules in code
- Look at photo: muse-spark-1.3 15.9s
- Mark parts: sam-3.1 9.9s
- Diagnose: muse-spark-1.3 24.8s
- Plan steps: muse-spark-1.3 26.0s
- Plan safety gate: rules in code

Light repairs only. Prices are estimates. For gas, house wiring, or high voltage, call a professional.

Tukang Copilot
Mechanic brief

Print this page or show it to the workshop so they don't start from zero.

Status

The owner is still on it, no result yet

What was found

Underbone motorcycle air-cooled engine cylinder head area with carburetor
Honda Beat cranks with the starter but will not fire. Cylinder head, plug cap and carburetor look connected with no obvious break, engine is dusty with oily grime.

Seen in the photo: Heavy dust and oily grime on engine, cylinder head and covers, no obvious broken part; Spark plug cap appears seated on spark plug, no visible disconnection; No visible fuel leak, no visible damage to ignition cable in this view; Text overlay at top-left reads 'Sample photo (AI-generated)'

- Fouled, wet or worn spark plug giving no spark (68%): Owner reports starter turns but engine does not fire; Heavy dust and oily grime on cylinder head suggests deferred maintenance; No visible disconnection, so plug itself is most likely weak point
- Weak contact in spark plug cap or ignition lead (55%): Spark plug cap looks seated but old and dusty; Ignition lead looks connected but dusty with age; Morning no-start with crank-no-fire is typical of weak cap connection
- Carburetor fuel delivery blocked - clogged jet or no fuel flow (48%): Carburetor looks complete and dusty with no visible leak; Starter cranks but no firing since morning suggests fuel not reaching cylinder; Carbureted underbone often clogs at pilot jet after sitting
- Clogged air filter or low compression preventing combustion (32%): Heavy dust on engine and cooling cover indicates dusty environment; No visible crack on cylinder head but low compression can still prevent firing; Clogged air filter box would starve engine without visible damage here

Parts marked: 1. spark plug cap, 2. ignition lead, 3. cylinder head, 4. carburetor, 5. engine cooling cover

What was tried

- Being tried now: Fouled, wet or worn spark plug giving no spark

Owner's photos



Photo 1