NORTHSTAR / NDW-240

NORTHSTAR HOME | COMPACT DISHWASHER
QUICK-START & SERVICE MANUAL
Model NDW-240 · Revision 2.1

WELCOME
This manual covers safe installation and basic troubleshooting for the Northstar NDW-240 compact dishwasher. Read all safety notes before servicing. Disconnect power before removing panels.

IN THE BOX
Dishwasher (1), inlet hose (1), drain hose (1), hose clip (1), adjustable leveling feet (4), quick-connect adapter (1).

TOOLS YOU WILL NEED
Adjustable wrench, Phillips screwdriver, spirit level, towel, and a bucket.

SAFETY
WARNING: Always unplug the dishwasher before inspection or repair.
CAUTION: Water may remain in the sump after a cycle. Keep a towel and bucket nearby.
Do not pull the appliance by its hoses. Do not operate with a damaged power cord.

NORTHSTAR / NDW-240

INSTALLATION CHECK

1. Place the unit on a level, stable floor near a grounded outlet and sink connection. Leave at least 5 cm (2 in) of clearance behind the unit.
2. Connect the inlet hose to the cold-water tap. Hand-tighten, then use an adjustable wrench for no more than a quarter turn. Do not overtighten.
3. Secure the drain hose to the sink edge with the supplied hose clip. The hose outlet must be 40–100 cm (16–39 in) above the floor.
4. Adjust the four leveling feet until the spirit level reads even front-to-back and side-to-side.
5. Check both hose connections for leaks before plugging in.

FIRST TEST

Run a short cycle with no dishes. Watch the inlet connection during fill and check beneath the unit after the cycle.

NORTHSTAR / NDW-240

BASIC OPERATION

1. Open the door and slide out the lower rack.
2. Scrape large food scraps from dishes. Do not pre-rinse.
3. Add one dishwasher tablet to the detergent cup and close the lid.
4. Load dishes with soiled surfaces facing the spray arm. Keep the spray arm clear.
5. Push the rack in, close the door, and press Power.
6. Select Normal or Quick, then press Start. The cycle indicator flashes while the cycle is running.

CARE

Clean the filter weekly: unplug the unit, turn the filter counter-clockwise, lift it out, rinse under running water, and reinstall clockwise until it stops. Wipe the door seal with a damp cloth.

REFERENCE

Filter: lower center of wash chamber. Inlet connection: rear upper-left. Drain connection: rear lower-right.

NORTHSTAR / NDW-240

TROUBLESHOOTING

UNIT DOES NOT START

Confirm the plug is in a grounded outlet, the door is fully latched, and Start was pressed after selecting a cycle. If the outlet has no power, contact a qualified electrician.

WATER REMAINS AFTER CYCLE

Check that the drain hose is not kinked and its outlet is between 40–100 cm above the floor. Clean the filter as described on page 3. Place a towel and bucket nearby before disconnecting a hose.

LEAK AT INLET

Stop the cycle and unplug the unit. Close the water tap. Check that the inlet hose washer is seated and the connection is hand-tight plus no more than a quarter turn. Do not continue if leaking persists.

POOR CLEANING

Ensure spray arm can rotate freely, dishes do not block detergent cup, and filter is clean.

If an electrical fault, damaged cord, or persistent leak is present, stop and contact Northstar service. Never remove the sealed pump housing.