/exc3_bcd_tb/in1 0011	0100	0101	0110	0111	1000	1001	1010	1011	1100
/exc3_bcd_tb/out1 0000	0001	0010	0011	0100	0101	0110	0111	1000	1001
0 ps		20000 ps		40000 ps	ı I ı ı'	60000 ps		80000 ps	100000