

Vehicle diagnostic report



Shop Name:
Address:
Phone:
Email:

Owner name: N.K Gupta

License #: BMWF10

VIN: WBAFW32000C283163

Year: 2010.03

Make: BMW

Model: 525d

Odometer: 26895 miles

Vehicle Software Version: V50.54

Diagnostic Application Version: 1.00.039

Test Time: 2021-01-14 17:47:58

Diagnostic path: Automatically Search > Health Report

Inspection Result

Diagnostic Result

Fault (12)

CAS (Car Access System - CAS/FEM/BDC) (5)

Abnormal

93076A Deactivation Of Terminal 15: Upper Startability Limit Reached, But Deactivation Preventer Active Intermittent

93076B Deactivation Of Terminal 30B: Upper Startability Limit Reached Intermittent

93076C Deactivation Of Terminal 30B: Upper Startability Limit Reached, But Deactivation Preventer Or Legal Load/Consumer Active Intermittent

930784 Aerial, Vehicle Interior, Centre Console, Front: Short Circuit, Open Circuit Or Faulty Intermittent

9308B0 Identification Transmitter: Undervoltage, Battery Intermittent

ECM (Engine Control Module - DME/DDE) (3)

Abnormal

29B500 Power Management, Battery Condition: Battery Faulty Permanent

2A0D00 Local Interconnect Network, Bit-Serial Data Interface, Message; Alternator: Missing Permanent

288F00 Power Management: Reduction Or Deactivation Of Individual Electrical Loads/Consumers Intermittent

GWS (Gear Selector Switch) (4)

Abnormal

E09422 Message (Vehicle Condition, 0x3A0) Missing, Gear Selector Switch Receiver, Junction Box Electronics Transmitter Intermittent

E09408 Message (Clamp, 0x12F) Missing, Gear Selector Switch Receiver, Car Access System Transmitter Intermittent

E0940E Message (Vehicle Speed, 0x1A1) Missing, Gear Selector Switch Receiver, Integrated Chassis Management Transmitter Intermittent

E09424 No Message (Data For Drive Train 2, 0x3F9), Receiver GWS, Transmitter DME/DDE Intermittent

ICM (Integrated Chassis Management)/RLM_2L (Tail Light Module, Inner Left)	(1)	Abnormal
	48010F DTC Button, Open Circuit	Intermittent
ABS (Anti-Lock Braking System - DSC)	(2)	Abnormal
	480932 Brake-Fluid Level Too Low	Intermittent
	4809AB DSC Control Unit: Undervoltage	Intermittent
EPB (Electrical Parking Brake - EMF)	(7)	Abnormal
	D39482 Message (Vehicle Identification Number, 0x380) Missing, EMF Receiver, CAS Transmitter	Intermittent
	D394AC No Message (Vehicle Condition, 0x3A0), Receiver EMF, Transmitter JBE	Intermittent
	D394F2 No Message (Kilometre Reading / Range, 0x330), Receiver EMF, Transmitter KOMBI	Intermittent
	D394F8 No Message (Terminals, 0x12F), Receiver EMF, Transmitter CAS	Intermittent
	D396A6 No Message (After-Running Period, Terminal 30 Fault-Controlled, 0x3AC), Receiver EMF, Transmitter JBE	Intermittent
	D396AC No Message (After-Running Period, Voltage Supply, 0x3BE), Receiver EMF, Transmitter CAS	Intermittent
	D39B68 No Message (Brake Temperature, 0x37E), Receiver EMF, Transmitter DSC	Intermittent
JBE/JBBF (Junction-Box Electronics)	(3)	Abnormal
	8020E6 Ignition On: Startability Limit Reached Or Ignition On For A Long Time	Intermittent
	8020E8 Reset Or Deactivation Of Terminal 30F	Intermittent
	802096 Auxiliary Coolant Pump: Short Circuit To Ground	Intermittent
ZGM (Central Gateway Module)	(2)	Abnormal
	801C15 Faulty Sleeping With Active Terminal 30B	Intermittent
	801C20 ZGM: Central Fault Memory Full - No Control-Unit Fault	Permanent
CIC (Car Information Computer)	(1)	Abnormal
	B7F86B CHAMP: Undervoltage	Intermittent
FAS (Seat Module, Driver)	(1)	Abnormal
	8029C0 Switch Block, Driver (R-Coded): Switch Sticking	Permanent
FRM (Footwell Module)	(11)	Abnormal
	800E89 FRM: Startability Limit Reached With Lights Active During Stationary Operation	Intermittent
	800ECB Driver's Door Contact: Short Circuit To Positive Or Open Circuit	Intermittent
	800ECF Passenger's Door Contact: Short Circuit To Positive Or Open Circuit	Intermittent
	800EA5 Operating Unit, Switch Centre For Door (SZT): Signal Button Invalid	Intermittent
	800FB0 Left Exterior Mirror Motor Faulty	Intermittent
	800FB1 Right Exterior Mirror Motor Faulty	Intermittent
	800FD0 Design/Side-Marker Light, Left, Faulty	Permanent
	800F92 Welcome Light, Repeat Interlock, Active	Intermittent

	800F93 Home Lights, Repeat Interlock, Active	Intermittent
	E58C42 Switch Block, Driver's Door: LIN Bus, Communication Fault	Intermittent
	E58C44 Switch Block, Seat Memory, Driver: LIN Bus, Communication Fault	Intermittent
AC (Air Conditioning - IHKA)	(1)	Abnormal
801222 Air Conditioning Compressor: Switch-Off Due To Missing DME/DDE Release		Intermittent
Normal	(13)	
EKPS (Electronic Fuel Pump)/RLM_1L (Tail Light Module, Outer Left)		Normal
TCM (Transmission Control Module - EGS)		Normal
EPS (Electronic Power Steering)		Normal
SRS (Supplemental Inflatable Restraint System - AIRBAG/SGM-SIM)		Normal
SZL (Switch Center, Steering Column)/BATT48 (Battery Electronics 48 V)		Normal
MMC (Multimedia Changer)		Normal
AMP (Amplifier)		Normal
SGE48V (Starter Motor Generator 48 V)		Normal
FZD (Function Center, Roof)		Normal
IC (Instrument Cluster - INSTR)		Normal
PDC (Park Distance Control)		Normal
BFS (Seat Module, Passenger)		Normal
CID (Central Information Display)		Normal