NEXASTORE

Support & Customer Knowledge



SUPPORT GUIDE

NexaBook Laptop Troubleshooting Guide

Practical diagnosis for startup, display, performance and connectivity

NexaStore Knowledge Series • 2026 Edition

1. Start with Safe, Reversible Checks

This guide applies broadly to NexaBook Pro X16, NexaBook AI Studio 16 and NexaBook Developer 14 systems. Exact ports, firmware options and GPU features vary by model, so model-specific manuals remain authoritative for hardware specifications.

Symptom	First checks
Will not power on	Connect known-good charger; disconnect docks/accessories; hold power for 15 seconds; retry.
Powers on, black screen	Increase brightness; disconnect external display; try display-toggle key; perform full shutdown.
Very slow	Check CPU/RAM/disk usage, free storage, background updates and thermal conditions.
Wi-Fi missing	Disable/enable adapter, reboot, verify airplane mode and driver status.
External monitor not detected	Reseat cable/dock, verify input source, test direct USB-C/HDMI connection.
Fan constantly loud	Check workload, blocked vents, ambient temperature and background processes.

2. Startup and Boot

Observation	Action
No LEDs / no fan	Verify AC outlet and charger; remove peripherals; perform power reset.
LEDs present, no image	Test brightness/external display; listen for boot sounds; retry after full shutdown.
Boot loops	Disconnect external devices; use recovery options; note recent driver/update changes.
Storage not found	Do not repeatedly reinstall. Run firmware diagnostics and escalate if drive is absent.
BitLocker/recovery prompt	Use the organization's approved recovery-key process; support must not invent or bypass keys.

3. Performance and Thermal Issues

Issue	Checks
CPU/GPU throttling	Ensure vents are clear; use hard surface; inspect temperatures and power mode.
Low gaming/AI performance	Confirm AC power, performance mode, discrete GPU selection and current supported driver.
High memory usage	Close unused VMs/containers/models; inspect browser/IDE processes; restart if necessary.
Disk nearly full	Remove unused models, caches and container images; preserve user data backups.
Local LLM unexpectedly slow	Verify GPU acceleration, model size/quantization, VRAM usage and thermal state.

4. Display and Docking

Problem	Troubleshooting path
Flickering internal display	Restart graphics driver/OS, test refresh settings, check whether issue appears before OS loads.
Dock display unstable	Update supported dock/graphics firmware; test direct cable; reduce display chain complexity.
Wrong resolution	Verify cable/dock bandwidth and OS display settings.
USB-C display not working	Confirm that the specific USB-C port supports display output for that NexaBook model.

5. When to Stop Troubleshooting

• Stop using the device if there is battery swelling, smoke, burning odor, liquid ingress or unusual heat.

• Do not open the chassis when doing so would violate service terms or when electrical/battery damage is suspected.

• Escalate repeated boot failures, missing storage, display artifacts before OS startup, or persistent hardware diagnostic errors.

• Back up important data before repair or recovery operations whenever the device remains usable.

6. Support-Agent Retrieval Pattern

User question	Knowledge / tool source
'My NexaBook screen flickers'	Retrieve this guide + exact model manual
'Is my laptop still under warranty?'	Warranty entitlement tool, not RAG
'Which GPU does my laptop have?'	Structured product catalog / model manual
'Create a repair ticket'	Authorized support-case tool
'Can I return it instead?'	Order facts + Returns and Refund Policy

Educational notice

This fictional guide is for the NexaStore course case study. Safety-critical symptoms should be handled by qualified service personnel.