Shooting Guide – one spot, one speed

The robot's flywheel and windmill are now consistent (robot logs 30 Oct: every ball left at 1200–1260 t/s). Misses come from **distance and aim**: one speed only lands from one distance. So we tune **one shooting spot** and always shoot from it.

0. Before you start

- Practice HIVE with the **AprilTags on the bottom of the CELLs** (IDs 30–45, printed for practice from the FIRST field resources page). Without them the camera has nothing to see.
- Pick the **alliance that matches the HIVE you shoot at**. AUTO RED / AUTO BLUE sets it on its own; in TeleOp INIT press B / Circle = RED, A / Cross = BLUE. The robot remembers it (even after a restart). **Always read the "Alliance" line in INIT before PLAY** – the camera only looks for that alliance's CELLs.
- Fresh battery (12.5 V or more), 4 balls, tape measure, coloured tape.

1. Pick ONE shooting spot and tape it

1. Choose a spot in front of your alliance's HIVE that drivers can reach quickly and that is not in a lane the other alliance drives through.
2. Pick a comfortable distance – start around **4–6 ft** from the floor under the CELL. The camera sees the tags better when not too far.
3. Put tape on the floor where the **front edge and both sides of the robot** go (an "L" at two corners works well), robot square to the HIVE.
4. Write down where the spot is using things that are the same on every field (tile seams count from the walls, distance from the HIVE frame):

	Our spot (fill in)
Alliance / HIVE side	
Tiles from our alliance wall (count seams)	
Tiles from the audience / rear wall	
Floor distance, camera lens → point under the CELL tags	in
Robot heading (which wall is behind the launcher)	

2. Find the speed: BioBuzz Shot Log

Robot on the tape, square to the HIVE. Select BioBuzz Shot Log, press INIT, then PLAY. D-pad = the + shaped arrows on the left of the controller; in Shot Log it changes the speed being tested.

Button	What it does
Y / Triangle	Flywheel ON / OFF (starts at 1250 t/s)
D-pad UP / DOWN	Speed +50 / −50 t/s (big steps)
D-pad RIGHT / LEFT	Speed +10 / −10 t/s (fine steps)
RB (right bumper)	Fire ONE ball (only when the flywheel is at speed)
Then A / Cross	Ball went IN the CELL
Then B / Circle	MISS
Then Back / Share	Discard (no ball came out)
Triggers	Intake in / out to reload

1. Flywheel ON (Y). Fire 10 balls at **1250**, marking each one IN or MISS.
2. Mostly **SHORT** (hits the front / falls before the CELL) → D-pad UP (+50). Mostly **LONG** (over the back) → D-pad DOWN (−50).
3. When it is close, use RIGHT / LEFT (+/−10) and repeat 10 balls.
4. The Driver Hub shows the hit rate for each speed. Keep the speed with **8 or more of 10 IN**.

CHECK: Do not move the robot between shots – re-check it is on the tape after reloading. Left/right misses are aim, not speed.

Speed (t/s)	IN	MISS short	MISS long	MISS left/right
1250				

DONE WHEN: One speed gives 8/10 or better from the tape. Final speed: _____ t/s

3. Put the speed in the robot

- Tell the programmer (or Copilot) the speed. In **BioBuzzConstants.java**:
- `LAUNCHER_NEAR_VELOCITY` = your speed (TeleOp default, D-pad DOWN = NEAR).
- `AUTO_LAUNCH_VELOCITY` = the same, only if AUTO shoots from about the same distance.
- Rebuild, deploy, then fire 5 balls in TeleOp from the tape to confirm.

3b. Save the SHOT SPOT on the robot (Share button, no code change)

1. Start BioBuzz TeleOp (check the alliance in INIT). Put the robot on the tape, launcher facing the CELL.
2. Set the speed that scored: D-pad DOWN (NEAR), then RIGHT / LEFT until the “Shot speed” line shows your Shot Log speed.
3. Hold X until the bearing settles, release, then press **Back / Share**. The controller rumbles and the screen shows “SHOT SPOT saved: 52 in @ 1275 t/s”.
4. Fire 4 balls to confirm. Not good? Move, re-tune the speed and press Share again – the new save replaces the old one.

RESULT: From now on, **holding X** turns the robot to the CELL, drives it forward/back to the saved distance and sets the saved speed. At the spot the controller rumbles and the screen shows **ON SPOT - FIRE**. The spot is a distance from the HIVE, so it works on both alliances and survives restarts.

CHECK: Share only saves when the camera sees your alliance’s CELL tags (otherwise: “Can’t save the spot”). Pushing the left stick forward/back while holding X takes over the driving.

4. Camera and AIM check: BioBuzz Vision Test

1. Robot on the tape. Select BioBuzz Vision Test, INIT, PLAY. B / Circle switches alliance – pick the HIVE you face.
2. The screen should show your CELL with 2–4 tags and a bearing near 0. Hold X / Square: the robot turns until the bearing settles.
3. In TeleOp the line “HIVE aim” now always shows what the camera sees (cell, tags, bearing, range) – even when you are not pressing X.

CHECK: “no RED CELL tags in view (any tags: 3)” means tags are seen but they belong to the other alliance’s CELL – fix the alliance in INIT. “any tags: 0” means the camera sees no tags at all: check the practice tags, the camera tilt (30° up) and that nothing blocks the view.

DONE WHEN: Your CELL shows with 2+ tags from the tape, and holding X turns the robot onto it.

5. DRIVER RULE (match play)

1. **DRIVE NEAR THE SPOT** – launcher toward our CELL, press Y to pre-spin.
2. **HOLD X** – the robot turns and drives to the saved distance.
3. **WAIT FOR THE RUMBLE** – screen shows ON SPOT - FIRE.
4. **KEEP HOLDING X + HOLD RB** – one ball every ~0.5 s.
5. **RELEASE** RB when empty, then drive away.

No tags seen (no rumble)? Drive onto the taped spot by eye, square up, then RB. Do NOT shoot while moving.

Tip: press Y (pre-spin) while driving to the spot, so the flywheel is already at speed when you stop.

TeleOp button card

D-pad = the + shaped arrow buttons on the LEFT side of the controller. In TeleOp it only changes the SHOT SPEED (how hard the ball is thrown). It does not drive or aim.

D-pad (TeleOp)	What it does	Use it when
UP	FAR preset: 1450 t/s, trim reset to 0	shooting from far away
DOWN	NEAR preset: 1250 t/s (or the speed you tuned), trim reset to 0	shooting from our taped spot – normal choice
RIGHT	+15 t/s (each press)	balls land SHORT (in front of / below the CELL)
LEFT	−15 t/s (each press)	balls go LONG (over / behind the CELL)

The Driver Hub line “Shot speed” always shows it, e.g. `NEAR 1250 +15 = 1265 t/s`. Pressing UP or DOWN clears the +/− trim. The speed stays until you change it; it is used the next time you press RB or Y.

CHECK: D-pad in other programs is different: BioBuzz Shot Log = speed ±50 (UP/DOWN) and ±10 (RIGHT/LEFT); BioBuzz Calibration and Arm Setup = arm position; AUTO INIT = start delay.

Button	Action
Left stick / right stick X	Drive + strafe / turn (intake side = FRONT)
LB (hold)	Precision (slow) drive
RT / LT	Intake IN / OUT (half LT = flower back-out)
RB (hold)	FIRE: spins up and feeds one ball at a time
X / Square (hold)	HIVE aim + drive to the saved SHOT SPOT distance + spot speed; rumbles ON SPOT
Back / Share	Save the SHOT SPOT here (camera distance + current shot speed)
Y / Triangle	Flywheel pre-spin ON / OFF
D-pad UP / DOWN	Shot speed FAR (1450) / NEAR (1250) – see table above
D-pad RIGHT / LEFT	Shot speed +15 / −15 per press
A / Cross	Flower arm DOWN / UP (only when stopped)
B / Circle (hold)	Unjam: windmill slowly backwards
INIT: B / A, Back	Alliance RED / BLUE (remembered; AUTO sets it); diagnostics log on/off