

JEDEC STANDARD

High Bandwidth Memory DRAM (HBM3)

JESD238A

(Revision of JESD238, January 2022)

JANUARY 2023

JEDEC SOLID STATE TECHNOLOGY ASSOCIATION



NOTICE

JEDEC standards and publications contain material that has been prepared, reviewed, and approved through the JEDEC Board of Directors level and subsequently reviewed and approved by the JEDEC legal counsel.

JEDEC standards and publications are designed to serve the public interest through eliminating misunderstandings between manufacturers and purchasers, facilitating interchangeability and improvement of products, and assisting the purchaser in selecting and obtaining with minimum delay the proper product for use by those other than JEDEC members, whether the standard is to be used either domestically or internationally.

JEDEC standards and publications are adopted without regard to whether or not their adoption may involve patents or articles, materials, or processes. By such action JEDEC does not assume any liability to any patent owner, nor does it assume any obligation whatever to parties adopting the JEDEC standards or publications.

The information included in JEDEC standards and publications represents a sound approach to product specification and application, principally from the solid state device manufacturer viewpoint. Within the JEDEC organization there are procedures whereby a JEDEC standard or publication may be further processed and ultimately become an ANSI standard.

No claims to be in conformance with this standard may be made unless all requirements stated in the standard are met.

Inquiries, comments, and suggestions relative to the content of this JEDEC standard or publication should be addressed to JEDEC at the address below, or refer to www.jedec.org under Standards and Documents for alternative contact information.

Published by
©JEDEC Solid State Technology Association 2023
3103 North 10th Street
Suite 240 South
Arlington, VA 22201-2108

JEDEC retains the copyright on this material. By downloading this file the individual agrees not to charge for or resell the resulting material.

PRICE: Contact JEDEC

Printed in the U.S.A.
All rights reserved

PLEASE!

DON'T VIOLATE

THE LAW!

This document is copyrighted by JEDEC and may not be
reproduced without permission.

For information, contact:

JEDEC Solid State Technology Association
3103 North 10th Street
Suite 240 South
Arlington, VA 22201-2107

or refer to www.jedec.org under Standards-Documents/Copyright Information.

This page intentionally left blank

HIGH BANDWIDTH MEMORY DRAM (HBM3)**Contents**

	Pages
1 Scope	1
2 Features	1
3 Organization	2
3.1 Channel Definition	3
3.1.1 Summary of Per-Channel Signals	3
3.1.2 Pseudo Channel	4
3.1.3 Dual Command Interfaces	5
3.2 Channel Addressing	6
3.2.1 Bank Groups.....	7
3.3 Simplified State Diagram	8
4 Initialization	9
4.1 HBM3 Power-up and Initialization Sequence	9
4.2 Controlled Power-off Sequence	11
4.3 Initialization Sequence with Stable Power	12
4.4 Initialization Sequence For Use Of IEEE 1500 Instruction Including Lane Repairs and Channel Disable	12
5 Mode Registers.....	16
6 Operation.....	26
6.1 HBM3 Clocking Overview	26
6.1.1 WDQS-to-CK Alignment Training	28
6.2 HBM3 Data Bus Inversion (DBIac)	30
6.2.1 Data Bus Inversion (DBIac)	30
6.2.1.1 Internal DBIac State with Read.....	31
6.3 Commands.....	34
6.3.1 Command Truth Tables.....	35
6.3.2 Row Commands	37
6.3.2.1 Row No Operation (RNOP) Command.....	37
6.3.2.2 ACTIVATE (ACT) Command.....	38
6.3.2.3 PRECHARGE (PREpb) and PRECHARGE ALL (PREab) Commands	41
6.3.2.4 Rounding Rules for Row Access Timings	45
6.3.2.5 REFRESH Command (REFab).....	46
6.3.2.6 PER-BANK REFRESH Command (REFpb).....	48
6.3.2.7 Refresh Management (RFM).....	52
6.3.2.8 Adaptive Refresh Management (ARFM).....	54
6.3.3 Column Commands.....	56
6.3.3.1 Column No Operation (CNOP).....	56
6.3.3.2 Read Command (RD, RDA)	57
6.3.3.3 Write Command (WR, WRA).....	67
6.3.3.4 Mode Register Set (MRS) Command	75
6.3.4 Power-Mode Commands	77
6.3.4.1 Power-Down (PDE, PDX)	77
6.3.4.2 Self Refresh (SRE, SRX)	83
6.4 Parity	87
6.4.1 Command/Address Parity	87
6.4.2 Data Parity.....	90

Contents (cont'd)

6.5	Clock Frequency Change Sequence	94
6.6	Temperature Compensated Refresh Reporting	94
6.6.1	Temperature Compensated Refresh Trip Points.....	94
6.6.2	Catastrophic Temperature Sensor	94
6.7	Interconnect Redundancy Remapping.....	95
6.7.1	AWORD Remapping	95
6.7.1.1	Row Command Bus – Remapping Table	95
6.7.1.2	Column Command Bus – Remapping Table.....	96
6.7.1.3	AWORD Remapping Examples.....	96
6.7.2	DWORD Remapping	97
6.7.2.1	DWORD Remapping Table	98
6.7.2.2	DWORD Remapping Example	99
6.8	HBM3 Loopback Test Modes	101
6.8.1	HBM3 Polynomial Structure.....	102
6.8.1.1	AWORD MISR Polynomial.....	102
6.8.1.2	DWORD MISR Polynomial.....	103
6.8.2	General Loopback Modes Features and Behavior.....	103
6.8.3	AWORD and DWORD Write MISR Modes	108
6.8.3.1	Test Method for AWORD (Write) MISR Mode	108
6.8.3.2	Test Method for DWORD Write MISR Mode.....	109
6.8.4	AWORD and DWORD Write Register Modes.....	109
6.8.4.1	Test Method for AWORD (Write) Register Mode.....	109
6.8.4.2	Test Method for DWORD Write Register Mode	110
6.8.5	DWORD Read Register Mode	111
6.8.5.1	Test Method for DWORD Read Register Mode	111
6.8.6	DWORD LFSR Mode (Read direction)	112
6.8.6.1	Test Method for DWORD LFSR Mode (Read direction)	112
6.8.7	AWORD and DWORD Write LFSR Compare Modes	113
6.8.7.1	Test method for AWORD (Write) LFSR Compare Mode	114
6.8.7.2	Test Method for DWORD Write LFSR Compare mode	114
6.9	On-die DRAM ECC	115
6.9.1	ECC Overview	115
6.9.2	HBM3 On-die ECC Requirements.....	116
6.9.3	DRAM Fault Isolation Requirements.....	116
6.9.4	Error Check and Scrub (ECS)	116
6.9.5	On-die ECC Transparency Protocol.....	120
6.9.6	ECC Engine Test Mode.....	121
6.10	WOSC	125
6.10.1	WDQS Interval Oscillator	125
6.10.2	tWDQS2DQ_I Offset due to Temperature and Voltage Variation	129
6.11	DCA and DCM.....	130
6.11.1	Duty Cycle Adjuster (DCA).....	130
6.11.2	Duty Cycle Monitor (DCM).....	132
6.12	Self Repair.....	134
7	Operating Conditions	138
7.1	Absolute Maximum DC Rating.....	138
7.2	Recommended DC Operating Condition	138

Contents (cont'd)

7.3	Operating Temperature	139
8	Electrical Characteristics and DQ/CA Rx	140
8.1	Leakage Current	140
8.2	Capacitance	140
8.3	DQ Rx Voltage and Timing	141
8.4	AWORD Signaling	145
8.5	CK and WDQS Input Signaling	145
8.6	Midstack Signaling.....	147
8.7	Transmit Driver Currents	147
8.8	Output Timing Reference Load	147
8.9	Output Voltage Level	148
8.10	Output Rise and Fall Time	148
8.11	Overshoot/Undershoot	149
9	IDD Specification.....	150
9.1	IDD and IPP Specification Parameters and Test Conditions	150
9.2	IDD and IPP Specifications.....	159
9.3	IDD6 Specification.....	159
10	AC Timings	160
11	Package (Die) Specification	167
11.1	Signals	167
11.2	MicroBump Positions.....	169
11.3	HBM3 Stack Height	170
11.4	HBM3 Bump Map.....	170
12	HBM DRAM Assembly	201
13	Test and Boundary Scan.....	201
13.1	Direct Access (DA) Test Port.....	201
13.1.1	DA Test Port Lockout	202
13.2	IEEE Standard 1500	202
13.2.1	Interaction Between DA Test Port and IEEE1500 Test Access Port	202
13.2.2	IEEE1500 Test Access Port I/O Signals	203
13.2.3	IEEE1500 Test Access Port Functional Description.....	203
13.3	Wrapper Data Register (WDR) Types	206
13.3.1	Read Only (R) Wrapper Data Registers	206
13.3.2	Write Only (W) Wrapper Data Registers	206
13.3.3	Read and Write (R/W) Wrapper Data Registers	206
13.3.4	WDR Reset State.....	206
13.4	IEEE1500 Test Access Port Instruction Encodings	207
13.5	Test Instructions	208
13.5.1	BYPASS.....	210
13.5.2	EXTEST_RX and EXTEST_TX	211
13.5.3	HBM_RESET.....	215
13.5.4	MBIST	216
13.5.5	SOFT_REPAIR.....	217
13.5.6	HARD_REPAIR	219
13.5.7	DWORD_MISR	220
13.5.8	AWORD_MISR	222
13.5.9	CHANNEL_ID.....	224

Contents (cont'd)

13.5.10	AWORD_MISR_CONFIG	224
13.5.11	DEVICE_ID	225
13.5.12	TEMPERATURE.....	229
13.5.13	MODE_REGISTER_DUMP_SET	230
13.5.14	READ_LFSR_COMPARE_STICKY	231
13.5.15	SOFT_LANE_REPAIR and HARD_LANE_REPAIR	233
13.5.16	CHANNEL_DISABLE	236
13.5.17	CHANNEL TEMPERATURE.....	237
13.5.18	WOSC_RUN and WOSC_COUNT	240
13.5.19	ECS Error Log.....	241
13.5.20	HS REP CAP.....	243
13.5.21	SELF REP and SELF REP RESULTS.....	244
13.6	Interaction with Mission Mode Operation	246
13.7	IEEE1500 Test Port AC Timing Parameters.....	247
13.8	Boundary Scan	253
	Annex A – (Informative) Differences between JESD238A and JESD238	254

Tables

Table 1 – Single Channel Signal Count	3
Table 2 – Global Signal Count	3
Table 3 – Array Access Timings Counted Individually Per Pseudo Channel	4
Table 4 – HBM3 Channel Addressing	6
Table 5 – Bank Group Assignments.....	7
Table 6 – Command Sequence Affected by Bank Groups	7
Table 7 – Initialization Timing Parameters.....	10
Table 8 – Power Ramp Conditions.....	10
Table 9 – Power Supply Conditions	11
Table 10 – HBM3 Mode Register Overview	17
Table 11 – Mode Register 0 (MR0)	18
Table 12 – Mode Register 1 (MR1)	18
Table 13 – Mode Register 2 (MR2)	19
Table 14 – Mode Register 3 (MR3)	19
Table 15 – Mode Register 4 (MR4)	19
Table 16 – Mode Register 5 (MR5)	20
Table 17 – Mode Register 6 (MR6)	20
Table 18 – Mode Register 7 (MR7)	21
Table 19 – DWORD MISR Read and Write Operations in Loopback Test Mode (MR7 OP0=1).....	22
Table 20 – Mode Register 8 (MR8)	22
Table 21 – Mode Register 9 (MR9)	23
Table 22 – Mode Register 10 (MR10)	23
Table 23 – Mode Register 11 (MR11)	24
Table 24 – Mode Register 12 (MR12)	24
Table 25 – Mode Register 13 (MR13)	24
Table 26 – Mode Register 14 (MR14)	25
Table 27 – Mode Register 15 (MR15)	25
Table 28 – Phase Detector and DERR Signal Behavior	28
Table 29 – DBI(ac) Truth Table	31

Contents (cont'd)

Table 30 – Row Commands Truth Table	35
Table 31 – Column Commands Truth Table.....	36
Table 32 – Options for issuing PREab and PREpb commands	37
Table 33 – Precharge and Auto Precharge Timings	44
Table 34 – Refresh Counter Increments (Example for HBM3 Configurations with 16 Banks)	50
Table 35 – Refresh and Per-Bank Refresh Command Scheduling Requirements	51
Table 36 – Mode Register Definition for Adaptive RFM Levels.....	54
Table 37 – RFM Commands Perceived by HBM3 DRAM	55
Table 38 – Signal Groups for Read Data De-Skew	66
Table 39 – Signal Groups for Write Data De-Skew	74
Table 40 – Pin State Description in Power Down.....	80
Table 41 – Pin State Description in Self Refresh.....	86
Table 42 – Command/Address Parity Function Table.....	87
Table 43 – Data Parity Function Table.....	91
Table 44 – Temperature Compensated Refresh Trip Points.....	94
Table 45 – AWORD - Row Command Bus Remapping.....	95
Table 46 – AWORD - Column Command Bus Remapping	96
Table 47 – Original Lane Assignment - Channel a - AWORD Column Repair.....	96
Table 48 – Remapped Lane Assignment - Channel a - AWORD Column Repair.....	96
Table 49 – Original Lane Assignment - Channel a - AWORD Row Repair	97
Table 50 – Remapped Lane Assignment - Channel a - AWORD Row Repair	97
Table 51 – DWORD Remapping (1 Byte).....	98
Table 52 – Original DWORD Lane Assignment - Channel a – Byte [1:0]	99
Table 53 – Remapped DWORD Lane Assignment - Channel a – Byte [1:0].....	99
Table 54 – MISR Function Table	102
Table 55 – ECS Modes	117
Table 56 – t_{ECSint} per Stack (ECS independent of SID).....	118
Table 57 – Error Overwrite Priority Rules to Handle Multiple Error Logging	119
Table 58 – Transparency Attributes and Their Access/Control Mechanism	120
Table 59 – Severity Encodings on the SEV pins	120
Table 60 – Severity Transmission on READ	120
Table 61 – ECC Engine Test Modes	121
Table 62 – Example of Error Vectors and Corresponding Severity	123
Table 63 – WDQS Oscillator Matching Error Specification	129
Table 64 – DCA Maximum Offset and Step Size.....	130
Table 65 – DCM Measurement Result.....	132
Table 66 – SELF_REP Instruction vs Stack Height	134
Table 67 – SELF_REPAIR Timings	135
Table 68 – SELF_REP – Expected DRAM Behavior When Resources Shared	136
Table 69 – Absolute Maximum DC Ratings.....	138
Table 70 – Recommended DC Operating Condition	138
Table 71 – Operating Temperature.....	139
Table 72 – Input Leakage Current	140
Table 73 – Input/Output Capacitance	140
Table 74 – Input Receiver Voltage Level Specification	142
Table 75 – AWORD Receiver Voltage Level Specification	145
Table 76 – CK and WDQS Input Voltage Level Specification.....	145

Contents (cont'd)

Table 77 – Differential Input Level for WDQS_t, WDQS_c	146
Table 78 – Differential Input Slew Rate Definition for WDQS_t, WDQS_c	146
Table 79 – Midstack Parameter Specification.....	147
Table 80 – Transmit Driver Current Specification	147
Table 81 – Output Voltage Level	148
Table 82 – Overshoot/Undershoot Specification for AWORD and DWORD Signals	149
Table 83 – Basic IDD/IDDQ/IPP/IDDL Measurement Conditions	151
Table 84 – Example of Timings used for IDD Measurement-Loop Pattern.....	153
Table 85 – IDD0 Measurement-Loop Pattern.....	154
Table 86 – IDD4R Measurement-Loop Pattern	155
Table 87 – IDD4W Measurement-Loop Pattern.....	156
Table 88 – IDD5P Measurement-Loop Pattern	157
Table 89 – IDD7 Measurement-Loop Pattern.....	158
Table 90 – IDD and IPP Specification Example.....	159
Table 91 – IDD6 Specification	159
Table 92 – Timings Parameters (Part 1).....	160
Table 93 – Timings Parameters (Part 2).....	162
Table 94 – I/O Signal Description	167
Table 95 – Geometric Parameters of the Staggered MicroBump Pattern	169
Table 96 – HBM3 Stack Height	170
Table 97 – Legend.....	170
Table 98 – HBM3 Bump Map Footprint – Geographical Overview (not to scale)	171
Table 99 – HBM3 Bump Map Footprint : Columns 1 to 36	172
Table 100 – HBM3 Bump Map Footprint : Columns 37 to 74	177
Table 101 – HBM3 Bump Map Footprint : Columns 75 to 90	182
Table 102 – HBM3 Bump Map Footprint : Columns 91 to 118	187
Table 103 – HBM3 Bump Map Footprint : Columns 119 to 148	194
Table 104 – Direct Access (DA) Pin Allocation.....	201
Table 105 – Test Access Port Signal Status	203
Table 106 – IEEE1500 Test Port Signal List and Description	203
Table 107 – WIR Channel Selection Definition	207
Table 108 – Instruction Register Encodings	208
Table 109 – BYPASS Wrapper Data Register.....	210
Table 110 – Wrapper Boundary Register (WBR).....	212
Table 111 – HBM_RESET Wrapper Data Register	215
Table 112 – RESET_n and HBM_RESET Truth Table	216
Table 113 – MBIST Wrapper Data Register.....	216
Table 114 – SOFT_REPAIR Wrapper Data Register`	218
Table 115 – HARD_REPAIR Wrapper Data Register.....	219
Table 116 – DWORD_MISR Wrapper Data Register.....	220
Table 117 – AWORD_MISR Wrapper Data Register.....	223
Table 118 – CHANNEL_ID Wrapper Data Register	224
Table 119 – AWORD_MISR_CONFIG Wrapper Data Register	225
Table 120 – DEVICE_ID Wrapper Data Register.....	226
Table 121 – TEMPERATURE Wrapper Data Register	229
Table 122 – MODE_REGISTER_DUMP_SET Wrapper Data Register	230
Table 123 – READ_LFSR_COMPARE_STICKY Wrapper Data Register	232

Contents (cont'd)

Table 124 – LANE_REPAIR Wrapper Data Register.....	234
Table 125 – CHANNEL_DISABLE Wrapper Data Register	237
Table 126 – CHANNEL_TEMPERATURE Wrapper Data Register.....	238
Table 127 – WOSC_RUN Wrapper Data Register.....	240
Table 128 – WOSC_COUNT Wrapper Data Register	240
Table 129 – ECS Error Log Wrapper Data Register	242
Table 130 – HS REP_CAP Wrapper Data Register	243
Table 131 – SELF REP Wrapper Data Register	245
Table 132 – SELF REP_RESULTS Wrapper Data Register	245
Table 133 – IEEE1500 Port Instruction Interactions	246
Table 134 – IEEE1500 Test Port AC Timings.....	247

Figures

Figure 1 — General Overview of a DRAM Die Stack with Channels	2
Figure 2 — Pseudo Channel Operation.....	5
Figure 3 — Simplified State Diagram.....	8
Figure 4 — Power-up and Initialization.....	11
Figure 5 — HBM3 RESET and Initialization Sequence with Stable Power	12
Figure 6 — Initialization Sequence with Lane Repair or Channel Disable	14
Figure 7 — Initialization Sequence with Channel Disable.....	15
Figure 8 — Aligned WDQS Internal Divider Example	26
Figure 9 — Clocking and Interface Relationship Write to Read Timing.....	27
Figure 10 — High Level Block Diagram Example of Clocking Scheme	27
Figure 11 — DERR Signal Behavior in WDQS-to-CK Alignment Training.....	29
Figure 12 — DBIac Algorithm.....	30
Figure 13 — Example DBIac Logic for Write and Read	31
Figure 14 — Internal DBIac State Reset for Write to Read	32
Figure 15 — Bus Preconditioning and DBI States for Read	33
Figure 16 — RNOP command	38
Figure 17 — ACTIVATE Command.....	39
Figure 18 — Bank and Row Activation Command Cycle	40
Figure 19 — Multiple Bank Activations.....	41
Figure 20 — PRECHARGE (PREpb) Command	42
Figure 21 — PRECHARGE ALL (PREab) Command	42
Figure 22 — REFRESH Command (REFab)	46
Figure 23 — REFRESH Cycle.....	47
Figure 24 — Postponing Refresh Commands (Example)	47
Figure 25 — Per-Bank Refresh Command (REFpb).....	48
Figure 26 — Per-Bank Refresh Command Cycle.....	49
Figure 27 — Sets of Per-Bank Refresh Commands	49
Figure 28 — Refresh Management (RFMab) and Per-Bank Refresh Management (RFMpB) Commands	52
Figure 29 — CNOP Command	56
Figure 30 — READ Command	57
Figure 31 — Clock to RDQS and Data Out Timings	59
Figure 32 — Single Read Burst with BL=8.....	60
Figure 33 — Seamless Read Bursts with BL=8	61

Contents (cont'd)

Figure 34 — Non-Seamless Read Bursts with $t_{CCD}=3$ and $BL=8$	62
Figure 35 — Non-Seamless Read Burst with $t_{CCD}=4$ and $BL=8$	63
Figure 36 — Read to Write	64
Figure 37 — Read to Precharge	65
Figure 38 — Write Command	67
Figure 39 — Clock to WDQS and Data Input Timings	68
Figure 40 — Single Write Burst with $BL=8$	69
Figure 41 — Seamless Write Bursts with $BL=8$	70
Figure 42 — Non-Seamless Write Bursts	71
Figure 43 — Write to Read	72
Figure 44 — Write to Pre-charge	73
Figure 45 — Mode Register Set Command (MRS)	75
Figure 46 — Mode Register Set Timings	76
Figure 47 — Power-Down Entry Command	77
Figure 48 — Power-Down Entry and Exit	79
Figure 49 — READ or READ with Auto Precharge to Power-Down Entry Timing	80
Figure 50 — WRITE or WRITE with Auto Precharge to Power-Down Entry Timing	81
Figure 51 — MODE REGISTER SET to Power-Down Entry Timing	81
Figure 52 — ACTIVATE to Power-Down Entry Timing	82
Figure 53 — REFRESH or PER-BANK REFRESH to Power-Down Entry Timing	82
Figure 54 — PRECHARGE to Power-Down Entry Timing	82
Figure 55 — Self-Refresh Entry Command	83
Figure 56 — Self-Refresh Entry and Exit	85
Figure 57 — Enabling and Disabling Command/Address Parity	87
Figure 58 — Single Command/Address Parity Error	88
Figure 59 — Separated Command/Address Parity Errors	88
Figure 60 — Consecutive Command/Address Parity Errors	89
Figure 61 — Write Parity Errors with $PL = 2$	91
Figure 62 — Write Parity Alignment with $PL = 2$	92
Figure 63 — Write Parity Alignment with $PL = 4$	92
Figure 64 — Read Parity Alignment with $PL = 2$	93
Figure 65 — Read Parity Alignment with $PL = 4$	93
Figure 66 — Example Signal Paths with Lane Repair	100
Figure 67 — MISR Features Block Diagram of HBM3	101
Figure 68 — Example of 4 bit MISR-LFSR implementing $f(x) = X^4 + X^3 + 1$	102
Figure 69 — AWORD MISR Modes Preamble Clock Filter Behavior	107
Figure 70 — DWORD Write MISR Modes Behavior	108
Figure 71 — DWORD Read LFSR Modes Behavior	112
Figure 72 — LFSR Compare Mode Block Diagram	113
Figure 73 — On-die ECC Overview Diagram Example	115
Figure 74 — ECS operation timing	118
Figure 75 — ECS CEs Output Enable Timing for SEV Signaling	121
Figure 76 — The Block Diagram of On-die ECC Engine and Path for ECC Engine Test Mode	122
Figure 77 — Timing Diagram of ECC Engine Test Mode	124
Figure 78 — Oscillator offset ($WOSC_{offset(V)}$)	127
Figure 79 — Oscillator offset ($WOSC_{offset(T)}$)	128
Figure 80 — Duty Cycle Adjuster Range	130

Contents (cont'd)

Figure 81 — Relationship Between WDQS Waveform and DCA Code Change (Example).....	131
Figure 82 — Example Sequence for WDQS Duty Cycle Correction	133
Figure 83 — Self Repair Flowchart	137
Figure 84 — DQ Receiver Mask.....	141
Figure 85 — Across Pin V _{REFD} Voltage Variation.....	141
Figure 86 — DQ to WDQS Timings ($t_{WDQS2DQ_I}$, $t_{DQ2DQtra_I}$ and $t_{DQ2DQter_I}$) at DRAM Pins Referenced from the Internal Latch.....	143
Figure 87 — Read Data Timing Definitions of $t_{DQ2DQtra_O}$, $t_{DQ2DQter_O}$, and $t_{DQSQtra_O}$	144
Figure 88 — CA Single Pulse Amplitude and Pulse Width.....	145
Figure 89 — CK Single Pulse	146
Figure 90 — Differential Input Slew Rate Definition for WDQS_t, WDQS_c	146
Figure 91 — Timing Reference Load	147
Figure 92 — Output Rise and Fall Definition.....	148
Figure 93 — Overshoot, Undershoot Definition.....	149
Figure 94 — Measurement Setup for IDD and IPP Measurements	151
Figure 95 — Staggered MicroBump Pattern	169
Figure 96 — MicroBump Pillar Diameter	169
Figure 97 — DA Port Connection Diagram For Multiple HBM3 DRAM Devices.....	202
Figure 98 — IEEE Std. 1500 Logic Diagram.....	204
Figure 99 — WIR Channel Select Logic Diagram	204
Figure 100 — IEEE1500 Port Operation	205
Figure 101 — RESET_n and HBM_RESET Logic	215
Figure 102 — Registers Associated with Lane Repair Instructions.....	235
Figure 103 — Channel Disable Instruction.....	236
Figure 104 — Example Channel Configuration 1	239
Figure 105 — Example Channel Configuration 2	239
Figure 106 — IEEE1500 Port Input and Output Timings	250
Figure 107 — IEEE1500 EXTEST_RX and EXTEST_TX Instruction Related Timings.....	250
Figure 108 — IEEE1500 SOFT_REPAIR and HARD_REPAIR Instruction Related Timings.....	250
Figure 109 — IEEE1500 Soft_Lane_Repair And Hard_Lane_Repair Instruction Related Timings	251
Figure 110 — IEEE1500 DWORD_MISR / AWORD_MISR Instruction Related Timings	251
Figure 111 — IEEE1500 CHANNEL_ID Instruction Related Timings.....	251
Figure 112 — IEEE1500 MODE_REGISTER_DUMP_SET Instruction Related Timings	252

This page intentionally left blank

HIGH BANDWIDTH MEMORY (HBM3) DRAM

(From JEDEC Board Ballot JCB-22-56, formulated under the cognizance of the JC-42.2 Subcommittee on DRAM Memories, item number 1837.98A).

1 Scope

The HBM3 DRAM is tightly coupled to the host compute die with a distributed interface. The interface is divided into independent channels. Each channel is completely independent of one another. Channels are not necessarily synchronous to each other. The HBM3 DRAM uses a wide-interface architecture to achieve high-speed, low power operation. Each channel interface maintains a 64 bit data bus operating at double data rate (DDR).

2 Features

- 256 bit prefetch per memory read and write access
- BL = 8
- 64 DQ width + ECC/SEV pins support / channel
- Pseudo Channel (PC) mode operation; 32 DQ width for PC mode
- Differential clock inputs (CK_t/CK_c) for command/address
- Double data rate (DDR) command/address. Row Activate commands require one-and-a-half-cycle, all other row commands require a half-cycle except for PDE, SRE with one cycle. Column command require only one cycle
- Semi-independent row and column command interfaces allowing Activates/Precharges to be issued in parallel with Read/Writes
- Data referenced to unidirectional differential data strobes RDQS_t/RDQS_c and WDQS_t/WDQS_c. One strobe pair each per DWORD
- Up to 16 channels / device
- Channel density of 2 Gb to 32 Gb
- 16, 32, 48, or 64 banks per channel; varies by device density / channel
- Bank grouping supported
- 1 KB page size per pseudo channel (PC)
- DBIac support configurable via MRS
- Self refresh modes
- I/O voltage 1.1 V, Tx driver voltage 0.4 V
- DRAM core voltage 1.1 V, independent of I/O voltage
- Unterminated data/address/command/clock interfaces
- Unmatched data interfaces
- Temperature sensor with 2-bit encoded range output

3 Organization

The HBM3 DRAM is optimized for high-bandwidth operation to a stack of multiple DRAM devices across a number of independent interfaces called channels. It is anticipated that each DRAM stack will support up to 16 channels. Figure 1 shows an example stack containing 4 DRAM dies, each die supporting 4 channels. Each die contributes additional capacity and additional channels to the stack (up to a maximum of 16 channels per stack).

Each channel provides access to an independent set of DRAM banks. Requests from one channel may not access data attached to a different channel. Channels are independently clocked, and need not be synchronous.




Figure 1 — General Overview of a DRAM Die Stack with Channels

The DRAM vendor may choose to require an optional interface die that sits at the bottom of the stack and provides signal redistribution and other functions. The vendor may choose to implement many of the logic functions typically found on DRAM die on this logic die. This standard does not explicitly require nor prohibit such a solution.

The division of channels among the DRAM dies within a stack is left to the vendor. Figure 1, with the memory for four channels implemented on each die, is not a required organization. Organizations are permitted where the memory for a single channel is distributed among multiple dies; however, all accesses within a single channel must have the same latency for all accesses. Similarly, vendors may develop products where each memory die can flexibly support 1, 2, 4 or 8 channels – enabling 16-channel configurations with stacks of 4 to 16 dies while keeping all data for a given channel on one die.

Since each channel is independent, much of this standard will describe a single channel. Where signal names are involved, families of signals belonging to a given channel will have the suffix a, b, ..., p for channels a through p. If no suffix is present, the signal(s) being described are generic instances of the various per-channel signals.

3.1 Channel Definition

Each channel consists of an independent command and data interface. RESET_n, IEEE1500 test port and power supply signals are common to all channels. A channel provides access to a discrete pool of memory; no channel may access the memory storage for a different channel. Each channel interface provides an independent interface to a number of banks of DRAM of a defined page size. See Channel Addressing.

3.1.1 Summary of Per-Channel Signals

Table 1 outlines the signals required for each channel, and Table 2 adds global signals that are required once per HBM3 device.

Table 1 — Single Channel Signal Count

Function	Number of Microbumps	Notes
Data	64	DQ[63:0]
Column command/ Address	8	C[7:0]
Row command/ Address	10	R[9:0]
DBI	8	1 DBI per 8 DQs
ECC	4	2 ECC per 32 DQs
SEV	4	2 SEV per 32 DQs
DPAR	2	1 PAR per 32 DQs
APAR	1	1 PAR per AWORD
DERR	2	1 DERR per 32 DQs
Strobe	8	1 RDQS_t/RDQS_c, WDQS_t/WDQS_c per 32 DQs
Clock	2	CK_t/CK_c
AERR	1	AERR per AWORD
Redundant Data	4	RD[3:0]
Redundant Address	1	Redundant row/ column
RFU	1	1 RFU per AWORD
Total	120	

Table 2 — Global Signal Count

Function	Number of Microbumps	Description	Notes
Reset	2	RESET_n	1
Temp	2	TEMP[1:0]	
WRCK	2	IEEE1500 Clock	1
WRST_n	2	IEEE1500 Reset	1
WSI	2	IEEE1500 Serial Input	1
SelectWIR	2	IEEE1500 Select WIR	1
CaptureWR	2	IEEE1500 Capture WR	1
ShiftWR	2	IEEE1500 Shift WR	1
UpdateWR	2	IEEE1500 Update WR	1
WSO	32	2 IEEE1500 Serial Output Per Channels[a:p]	1
CATTRIP	2	Catastrophic Temperature Sensor	1
Total	52		2

NOTE 1 Duplicate microbumps for link redundancy

NOTE 2 Excluding MRFU[1:0] from count

3.1.2 Pseudo Channel

Pseudo channel (PC) divides a channel into two individual sub-channels of 32 bit I/O each, providing 256 bit prefetch per memory read and write access for each pseudo channel.

Both pseudo channels operate semi-independent: they share the channel's row and column command bus as well as CK and R0 inputs, but decode and execute commands individually as illustrated in Figure 2. Address PC is used to direct commands to either to pseudo channel 0 (PC = 0) or pseudo channel 1 (PC = 1). Power-down and self refresh are common to both pseudo channels.

Array access timings as listed in the table below are applicable for each individual pseudo channel. For example, an ACTIVATE to PC0 can be followed by an ACTIVATE to PC1 as shown in Figure 2. However a subsequent ACTIVATE to PC0 can only be done after t_{RRD} (PC0). For commands that are common to both pseudo channels (PDE, PDX, SRE, SRX and MRS) it is required that the respective timing conditions are met by both pseudo channels when issuing that command. Both pseudo channels also share the channel's mode registers.

All I/O signals of DWORD0 are associated with pseudo channel 0, and all I/O signals of DWORD1 with pseudo channel 1.

Table 3 — Array Access Timings Counted Individually Per Pseudo Channel

Array Timing Group	Notes
Row Access Timings	t_{RC} , t_{RAS} , t_{RCDRD} , t_{RCDWR} , t_{RRDL} , t_{RRDS} , t_{FAW} , t_{RTP} , t_{RP} , t_{WR}
Column Access Timings	t_{CCDL} , t_{CCDS} , t_{CCDR} , t_{WTDL} , t_{WTRS} , t_{RTW}
Refresh Timings	t_{RFC} , t_{RFCPB} , t_{RREFD} , t_{REFI} , t_{REFIPB} , t_{RTW}

3.1.2 Pseudo Channel (cont'd)




Figure 2 — Pseudo Channel Operation

3.1.3 Dual Command Interfaces

To enable higher performance, HBM3 DRAMs exploit the increase in available signals in order to provide semi-independent row and column command interfaces for each channel. These interfaces increase command bandwidth and performance by allowing read and write commands to be issued simultaneously with other commands like activates and precharges. See Commands.

3.2 Channel Addressing

Table 4 — HBM3 Channel Addressing

Density per Channel	2 Gb	4 Gb	6 Gb	8 Gb			Note
Density per PC	1 Gb	2 Gb	3 Gb	4 Gb			
Prefetch Size per PC (bits)	256	256	256	256			1, 2
Row Address	RA[12:0]	RA[13:0]	RA[14:0] ⁶	RA[14:0]			
Column Address	CA[4:0]	CA[4:0]	CA[4:0]	CA[4:0]			
Bank Address	BA[3:0]	BA[3:0]	BA[3:0]	BA[3:0]			
Page Size per PC	1 KB	1 KB	1 KB	1 KB			3
Refresh Period	3.9 μ s	3.9 μ s	3.9 μ s	3.9 μ s			
Density Code	0000	0100	1000	1100			8
Configuration ⁴	8 Gb 8High	8 Gb 12High	8 Gb 16High	16 Gb 8High	16 Gb 12High	16 Gb 16High	Note
Density per Channel	4 Gb	6 Gb	8 Gb	8 Gb	12 Gb	16 Gb	
Density per PC	2 Gb	3 Gb	4 Gb	4 Gb	6 Gb	8 Gb	
Prefetch Size per PC (bits)	256	256	256	256	256	256	1, 2
Row Address	RA[12:0]	RA[12:0]	RA[12:0]	RA[13:0]	RA[13:0]	RA[13:0]	
Column Address	CA[4:0]	CA[4:0]	CA[4:0]	CA[4:0]	CA[4:0]	CA[4:0]	
Bank Address	SID, BA[3:0]	SID[1:0] ⁷ , BA[3:0]	SID[1:0], BA[3:0]	SID, BA[3:0]	SID[1:0] ⁷ , BA[3:0]	SID[1:0], BA[3:0]	5
Page Size per PC	1 KB	1 KB	1 KB	1 KB	1 KB	1 KB	3
Refresh Period	3.9 μ s	3.9 μ s	3.9 μ s	3.9 μ s	3.9 μ s	3.9 μ s	
Density Code	0001	0010	0011	0101	0110	0111	8
Configuration ⁴	24 Gb 8High	24 Gb 12High	24 Gb 16High	32 Gb 8High	32 Gb 12High	32 Gb 16High	Note
Density per Channel	12 Gb	18 Gb	24 Gb	16 Gb	24 Gb	32 Gb	
Density per PC	6 Gb	9 Gb	12 Gb	8 Gb	12 Gb	16 Gb	
Prefetch Size per PC (bits)	256	256	256	256	256	256	1, 2
Row Address	RA[14:0] ⁶	RA[14:0] ⁶	RA[14:0] ⁶	RA[14:0]	RA[14:0]	RA[14:0]	
Column Address	CA[4:0]	CA[4:0]	CA[4:0]	CA[4:0]	CA[4:0]	CA[4:0]	
Bank Address	SID, BA[3:0]	SID[1:0] ⁷ , BA[3:0]	SID[1:0], BA[3:0]	SID, BA[3:0]	SID[1:0] ⁷ , BA[3:0]	SID[1:0], BA[3:0]	5
Page Size per PC	1 KB	1 KB	1 KB	1 KB	1 KB	1 KB	3
Refresh Period	3.9 μ s	3.9 μ s	3.9 μ s	3.9 μ s	3.9 μ s	3.9 μ s	
Density Code	1001	1010	1011	1101	1110	1111	8

NOTE 1 Prefetch size and page size reflect the effective addressing along with row and column commands. Both do not include the optional ECC bits as described in Section 3.1.

NOTE 2 The burst order is fixed for Reads and Writes, and the HBM device does not assign column address bits to distinguish between the eight UI of a BL8 burst. A memory controller may internally assign such column address bits but those column address bits are not transmitted to the HBM device.

NOTE 3 Page Size = $2^{\text{COLBITS}} * (\text{Prefetch Size} / 8)$; where COLBITS is the number of column address bits. Page size and prefetch size per pseudo channel in Pseudo Channel. MSB of RA is used to select half of open 2 KB page.

NOTE 4 These configurations are optimized for HBM stacks using 8 or 12 or 16 DRAM dies. The stack height of all other configuration is vendor specific.

NOTE 5 SID, SID0, SID1 act as bank address bits in command execution. Specific AC timing parameters or variations on selected timing parameters may be linked to SID. Table 29 and Table 30 and the vendor data sheets should be consulted for details.

NOTE 6 RA[14:13] = 11 is invalid.

NOTE 7 SID[1:0] = 11 is invalid.

NOTE 8 The density code refers to the encoding of per-channel density in DEVICE_ID Wrapper Data Register, bits[27:24].

3.2.1 Bank Groups

The banks within a device are divided into 4 or 8 or 12 or 16 bank groups. The assignment of banks to bank groups is shown in Table 5.

Different timing parameters are specified depending on whether back-to-back accesses are within the same bank group or across bank groups as shown in Table 6.

Table 5 — Bank Group Assignments

Banks	16 Banks BA[3:0]	32 Banks SID, BA[3:0]	48 Banks SID[1:0], BA[3:0]	64 Banks SID[1:0], BA[3:0]
0 and 3	Group A	Group A	Group A	Group A
4 and 7	Group B	Group B	Group B	Group B
8 to 11	Group C	Group C	Group C	Group C
12 to 15	Group D	Group D	Group D	Group D
16 to 19	N/A	Group E	Group E	Group E
20 to 23		Group F	Group F	Group F
24 to 27		Group G	Group G	Group G
28 to 31		Group H	Group H	Group H
32 to 35		N/A	Group I	Group I
36 to 39			Group J	Group J
40 to 43			Group K	Group K
44 to 47			Group L	Group L
48 to 51		N/A	Group M	
52 to 55			Group N	
56 to 59			Group O	
60 to 63			Group P	

Table 6 — Command Sequence Affected by Bank Groups

Command Sequence	Corresponding Ac Timing Parameter		Notes
	Accesses To Different Bank Groups	Accesses Within Same Bank Group	
ACTIVATE to ACTIVATE	t_{RRDS}	t_{RRDL}	
WRITE to WRITE	t_{CCDS}	t_{CCDL}	
READ to READ	t_{CCDS} or t_{CCDR}	t_{CCDL}	
Internal WRITE to READ	t_{WTRS}	t_{WTRL}	
READ to PRECHARGE	-	t_{RTP}	1

NOTE 1 Parameters t_{RTP} applies only when READ and PRECHARGE go to the same bank.
 NOTE 2 Parameters t_{CCDR} replaces parameter t_{CCDS} when consecutive READs go to banks with different stack IDs (SID).

3.3 Simplified State Diagram

The state diagram provides a simplified illustration of the allowed state transitions and the related commands to control them. The following operations are either not shown or not fully shown in the diagram:

- state transitions involving more than one bank;
- interactions from the use of IEEE1500 instructions to load mode registers or execute test functions;
- the immediate transition from any state to reset state by asserting RESET_n LOW or by loading the IEEE1500 instructions HBM_RESET;
- the ECS and ECC Engine Test Mode operation;
- DCA and DCM;
- Loopback Test Mode;
- WDQS-to-CK Alignment Training

For a complete description of the device behavior, use the information provided in the state diagram along with the command truth tables and AC timing specifications.




Figure 3 — Simplified State Diagram

4 Initialization

To power-up and initialize the HBM3 device into functional operation, the sequence in clause 4.1 must be followed. At any time after the power-up initialization, the HBM3 device may be reset using the sequence in clause. A limited set of IEEE 1500 port instructions may be used within the initialization sequences, as described in clause 4.3.

The interactions between HBM3 functional reset and the IEEE 1500 port reset are as follows (also see clause 13.2):

- Functional reset requires that the IEEE 1500 port also be reset.
- The IEEE 1500 port can be reset at any time without impacting normal operation.
- The IEEE 1500 port may be brought out of reset and a limited set of instructions may be used after a minimum time after RESET_n has been deasserted. See clause 4.3.
- If not needed, the IEEE 1500 port may be left in reset (WRST_n = LOW) during normal operation.

4.1 HBM3 Power-up and Initialization Sequence

HBM3 device must be powered up and initialized in a predefined manner. The following sequence and timing must be satisfied for HBM3 power up and initialization sequence. Also refer to Figure 4.

1. Apply power to the V_{DDC}, V_{DDQ}, V_{DDQL} and V_{PP} supplies following the requirements in the Power Ramp Conditions table. V_{PP} must ramp at the same time or earlier than V_{DDC} and V_{DDQ}. V_{DDC} and V_{DDQ} must ramp simultaneously under the same level. V_{DDC} and V_{DDQ} must ramp at the same time or earlier than V_{DDQL}. During power supply ramp time t_{INIT0}, RESET_n, WRST_n and all other input signals may be in an undefined state (driven LOW or HIGH, or Hi-Z). After T_a in Figure 4 is reached, V_{DDC} and V_{DDQ} must be greater than V_{DDQL}-200 mV.
2. RESET_n and WRST_n must be driven LOW (below 0.2 × V_{DDQ}) before or at the same time when t_{INIT0} expires as shown in Figure 4 (time T_a). All other input signals may be in an undefined state (driven LOW or HIGH, or Hi-Z) at this point. RESET_n must be maintained LOW for a minimum of t_{INIT1} time with stable power. After t_{INIT6} time has elapsed, the HBM3 device drives RDQS_t and RDQS_c to LOW and HIGH static levels, respectively, and AERR, DERR and CATTRIP signals to LOW.
3. A time t_{INIT2} before RESET_n is pulled HIGH, CK_t and CK_c must be driven to static LOW and HIGH levels, respectively.
4. After RESET_n is driven HIGH, R[3:0] must be driven to PDE state (HIGH, LOW, HIGH, LOW) and C[2:0] must be driven to CNOP state (HIGH, HIGH, HIGH) for a t_{INIT7} time before CK clock is toggled. R[9:4] and C[7:3] are allowed to remain in an undefined state. The HBM3 device resets into the precharged power-down state. During t_{INIT3}, the HBM3 device will read and apply internal fuse configuration data and perform I/O driver impedance calibration. At the same time the WRST_n signal may be optionally driven HIGH to enable a subset of the IEEE 1500 instructions (see Initialization Sequence For Use Of IEEE 1500 Instruction Including Lane Repairs and IEEE Standard 1500 clauses). In that case, all other IEEE1500 inputs (WRCK, SelectWIR, ShiftWR, CaptureWR, UpdateWR, WSI) must be driven per IEEE1500 Port Input and Output Timings figure at time t_{INIT2} before WRST_n is pulled HIGH(see IEEE1500 Test Port AC Timing Parameters). CATTRIP data must stay LOW from the end of t_{INIT6} to the end of t_{INIT3} and valid data must start after t_{INIT3}.

4.1 HBM3 Power-up and Initialization Sequence (cont'd)

5. While R[3:0] and C[2:0] remain driven to PDE state as defined in step 4, the CK clock shall be started and stable clocks shall be maintained for minimum of t_{INIT4} time before driving R[3:0] HIGH. Since R[0] of R[3:0] is a synchronous signal, the corresponding setup time to clock (t_{IS}) must be met. Also, RNOP and CNOP commands must be registered (with t_{IS} / t_{IH} satisfied). After R[3:0] are registered HIGH, a minimum t_{INIT5} time must be satisfied before issuing a first MRS command. At or before the time that R[3:0] are driven HIGH, WDQS_t and WDQS_c must be driven to LOW and HIGH static levels, respectively. A stable CK clock shall be maintained except when a channel is in power-down or self refresh state. See Power-Down and Self Refresh clauses for conditions about stopping and re-starting the CK clock.
6. Issue all MRS commands to configure the HBM3 device appropriately for the application setting.
7. The HBM3 device is now ready for normal operation.

Table 7 — Initialization Timing Parameters

Symbol	Description	Min	Max	Unit
t_{INIT0}	Power supply ramp time	0.01	200	ms
t_{INIT1}	RESET_n signal LOW time at power-up (after stable power)	200		μ s
t_{INIT2}	CK_c and CK_t must be driven to HIGH and LOW before RESET_n deassertion	10		ns
t_{INIT3}	Precharged power-down state and WRST_n LOW time after RESET_n deassertion	4		ms
t_{INIT4}	CK clock stable time before R[3:0] HIGH	10		nCK
t_{INIT5}	Idle time before first MRS command	200		ns
t_{INIT6}	RDQS_t, RDQS_c driven valid and AERR, DERR and CATTRIP driven LOW after RESET_n assertion		100	ns
t_{PW_RESET}	RESET_n signal LOW time with stable power	1		μ s
t_{INIT7}	R[3:0] and C[2:0] must be driven to PDE and CNOP before CK clock toggling	2		nCK

Table 8 — Power Ramp Conditions

After	Application Condition
T_0	V_{PP} must be greater than V_{DDC} , V_{DDQ}
	V_{DDC} and V_{DDQ} must be greater than $V_{DDQL} - 200$ mV

NOTE 1 T_0 is the point when any power supply first reaches 300 mV
 NOTE 2 Voltage ramp conditions in this table apply between T_0 and controlled power-off.
 NOTE 3 T_a is the point at which all supply voltages are within their defined ranges.
 NOTE 4 Power ramp duration t_{INIT0} ($T_a - T_0$) must not exceed 200 ms.

4.1 HBM3 Power-up and Initialization Sequence (cont'd)




Figure 4 — Power-up and Initialization

4.2 Controlled Power-off Sequence

For a controlled power-off, the conditions in Table 9 must be met.

While powering off, all input levels must be between V_{SS} and V_{DDQ} or V_{DDQL} during voltage ramp to avoid latch-up.

Table 9 — Power Supply Conditions


Between	Application Condition
T_x and T_z	V_{PP} must be greater than V_{DDC} , V_{DDQ}
	V_{DDC} and V_{DDQ} must be greater than $V_{DDQL} - 200$ mV
NOTE 1 T_x is the point where any power supply drops below the minimum value specified.	
NOTE 2 T_z is the point where all power supplies are below 300 mV. After T_z , the HBM3 device is powered off.	

4.3 Initialization Sequence with Stable Power

Steps 1 and 2 must be satisfied to perform a functional reset when power is kept stable at the HBM3 DRAM. See Figure 5.

1. RESET_n must be driven LOW anytime when a functional reset is needed. All other input signals may be in an undefined state (driven LOW or HIGH, or Hi-Z) at this point except WRST_n and CATTRIP as shown in Figure 5. RESET_n must be maintained LOW for a minimum of t_{PW_RESET}. R[3:0] must be driven to PDE state (HIGH, LOW, HIGH, LOW) and C[2:0] must be driven to CNOP state (HIGH, HIGH, HIGH) for a t_{INIT7} time before CK clock is toggled. R[9:4] and C[7:3] are allowed to remain in an undefined state. Alternately, the IEEE 1500 port HBM3_RESET instruction may be used to perform a re-initialization, with RESET_n continuing to be driven HIGH. Refer to HBM_RESET clause.
2. Follow steps 3 to 6 as described in clause HBM3 Power-up and Initialization Sequence. Note that the CATTRIP output is sticky and not cleared by a functional reset.

A time t_{INIT2} before RESET_n is pulled HIGH, CK_t and CK_c must be driven to static LOW and HIGH levels, respectively. See step 3 of the HBM3 Power-up and Initialization Sequence.



1. CATTRIP will maintain value as the one before reset until end of tINIT3.

□ Don't Care

Figure 5 — HBM3 RESET and Initialization Sequence with Stable Power

4.4 Initialization Sequence For Use Of IEEE 1500 Instruction Including Lane Repairs and Channel Disable

All IEEE 1500 port instructions are allowed after t_{INIT3} without completing the full initialization sequence.

NOTE 1 After EXTEST operations, another RESET_n toggle may be required.

NOTE 2 R[9:0] and C[7:0] mean logical pin name because those pin's physical location will be changed after soft or hard lane repair.

Figure 6 illustrates usage of the EXTEST and SOFT_LANE_REPAIR instructions and Figure 7 the usage of the CHANNEL_DISABLE instruction within the initialization sequence. These sequence may be applied as part of the power-up or stable-power initialization sequence to check for and correct failed connections on the row and column command buses, which must be correctly driven to RNOP and CNOP as part of this initialization sequence. It may also be used to disable a channel before normal operation mode is entered. DWORD lane repairs are also allowed.

1. At time T_a , RESET_n and WRST_n must be driven LOW.
2. After a minimum time t_{INIT1} (if during an initial power-up sequence) or after t_{PW_RESET} (if during a stable power initialization sequence) RESET_n shall be driven HIGH. t_{INIT2} must also be met.
3. After t_{INIT3} , WRST_n is driven HIGH. IEEE 1500 port instructions may now be used. (Note that the WRST_n low pulse width t_{WRSTL} is met since t_{WRSTL} is less than the t_{INIT1} or t_{PW_RESET}). Refer to IEEE1500 Test Port AC Timing Parameters for timing requirements for operating the IEEE 1500 port, including t_{SWRST} . At this point, a defective channel may be disabled; also, defective lane detection and soft lane repair may be executed. EXTEST operations may be applied to identify lanes needing repair. If soft lane repair is needed, SOFT_LANE_REPAIR and HARD_LANE_REPAIR operations can be applied after another RESET_n toggle, which is required after EXTEST instruction operation. An IEEE 1500 port BYPASS instruction should be applied to return all HBM3 signals to their normal functional mode after SOFT_LANE_REPAIR operations. Alternately, WRST_n may be driven LOW.
4. The initialization sequence may then continue per steps 4 to 6 of HBM3 Power-up and Initialization Sequence, as needed.


During the t_{INIT3} period before WRST_n is driven HIGH, the HBM3 device executes various internal configuration operations, including applying hard lane repairs based on previously fused data. Executing soft lane repair instructions after t_{INIT3} overwrites any previously programmed hard lane repair data. It is suggested that the hard lane repair data is read from the HBM3 device and merged in any new lane repairs before applying the new soft lane repair operations. Any applicable IEEE 1500 port instructions timings must be met before continuing to time point T_h , such as t_{SLREP} if a SOFT_LANE_REPAIR instruction has been applied.

The EXTEST instructions are not required before applying the soft lane repair(s). Previously determined needed lane repairs may be applied as part of each initialization event.

A time t_{INIT2} before RESET_n is pulled HIGH, CK_t and CK_c must be driven to static LOW and HIGH levels, respectively. See step 3 of the HBM3 Power-up and Initialization Sequence.

R[3:0] must be driven PDE state and C[2:0] must be driven CNOP state for a t_{INIT7} time.

4.4 Initialization Sequence For Use Of IEEE 1500 Instruction Including Lane Repairs and Channel Disable (cont'd)




NOTE 1 After EXTEST operations, another RESET_n toggle may be required.

NOTE 2 R[9:0] and C[7:0] mean logical pin name because those pin's physical location will be changed after soft or hard lane repair.

Figure 6 — Initialization Sequence with Lane Repair or Channel Disable

4.4 Initialization Sequence For Use Of IEEE 1500 Instruction Including Lane Repairs and Channel Disable (cont'd)



NOTE 1 A disabled channel will turn off all AWORD and DWORD input and output buffers including CK_t/CK_c and WDQS_t/WDQS_c inputs, thus allowing all external signals to float. The CK clock is allowed to be High-Z throughout this initialization sequence.

Figure 7 — Initialization Sequence with Channel Disable

5 Mode Registers

The Mode Registers define the specific mode of operation for the HBM3 DRAM. Sixteen 8-bit wide Mode Registers (MR0 to MR15) are defined as in Table 11 through Table 27. MR10 and MR12 are special mode register and reserved for vendor specific features. Mode Registers are common to both pseudo channels (PC0 and PC1). Reprogramming the Mode Registers does not alter the contents of the memory array.

Mode Registers are programmed via the MODE REGISTER SET (MRS) command and retain the stored information until they are reprogrammed, chip reset, or until the device loses power. Mode Register can also be programmed via the IEEE1500 instruction MODE_REGISTER_DUMP_SET; this instruction can also be used to retrieve the Mode Register content.

Mode Registers must be loaded when all banks are idle and the time tRDMRS from a preceding READ command has elapsed. The controller must wait the specified time tMOD before initiating any subsequent operations. Violating either of these requirements will result in unspecified operation.

No default states are defined for Mode Registers except when otherwise noted. Users therefore must fully initialize all Mode Registers to the desired values upon power-up or after a subsequent chip reset.

When an entire Mode Register is marked as RFU (“Reserved for future use”), then it is considered as not supported by the HBM3 DRAM, and its content is Don’t Care. Reserved states should not be used, as unknown operation or incompatibility with future versions may result. RFU bits in these registers must be programmed to 0.

5 Mode Registers (cont'd)

Table 10 — HBM3 Mode Register Overview

Mode Register		OP7	OP6	OP5	OP4	OP3	OP2	OP1	OP0					
	MA[4:0] ¹													
MR0 (Table 11)	00000	Test Mode (TM)	CA Parity (CAPAR)	Write Parity (WPAR)	Read Parity (RPAR)	RFU	TCSR	Write DBI (WDBI)	Read DBI (RDBI)					
MR1 (Table 12)	00001	Parity Latency (PL)			Write Latency (WL)									
MR2 (Table 13)	00010	Read Latency (RL)												
MR3 (Table 14)	00011	Write Recovery for Auto Pre-charge (WR)												
MR4 (Table 15)	00100	Activate to Precharge (RAS)												
MR5 (Table 16)	00101	RFU			Read to Auto Precharge (RTP)									
MR6 (Table 17)	00110	RFU		Pullup Driver Strength			Pulldown Driver Strength							
MR7 (Table 18)	00111	CATTRIP	RFU	DWORD MISR Control			RFU	DWORD Read Mux Control	DWORD Loopback					
MR8 (Table 20)	01000	RFU		RFM Levels (RFML)		WDQS-to-CK Training (WDQS2CK)	ECS error log auto reset (ECSLOG)	Duty Cycle Monitor (DCM)	DA Port Lockout					
MR9 (Table 21)	01001	ECS error Type and Address Reset (ECSRES)	ECS Multi-bit Error Correction (ECSCEM)	Auto ECS during Self Refresh (ECSSRF)	Auto ECS via REFab (ECSREF)	Error Vector Pattern (ECCVEC)	Error Vector Input Mode (ECCTM)	Severity Reporting (SEVR)	Meta Data (MD)					
MR10 (Table 22)	01010	Reserved for Vendor Specific Features												
MR11 (Table 23)	01011	DCA code for WDQS1 (PC1)				DCA code for WDQS0 (PC0)								
MR12 (Table 24)	01100	Reserved for Vendor Specific Features												
MR13 (Table 25)	01101	RFU												
MR14 (Table 26)	01110	RFU	Reference Voltage for AWORD inputs (VREFCA)					RFU						
MR15 (Table 27)	01111	RFU	Reference Voltage for DWORD inputs (VREFD)					RFU						
NOTE 1 MA4 is a valid mode register address bit that must be set to 0 for the mode registers defined in this table.														

5 Mode Registers (cont'd)

Table 11 — Mode Register 0 (MR0)

Field	Bits	Description	Notes
Test Mode (TM)	OP7	0 – Normal Operation (Default) 1 – Test Mode (Vendor specific): only to be used by the DRAM manufacturer. No functional operation is specified with test mode enabled.	
Command Address Parity (CAPAR)	OP6	0 – Disabled (Default) 1 – Enabled	1
Write Parity (WPAR)	OP5	0 – Disabled 1 – Enabled	2
Read Parity (RPAR)	OP4	0 – Disabled 1 – Enabled	2
RFU	OP3	0	
Temperature Compensated Self Refresh (TCSR)	OP2	0 – Disabled 1 – Enabled (Default)	
Write DBI (WDBI)	OP1	0 – Disabled 1 – Enabled	3
Read DBI (RDBI)	OP0	0 – Disabled 1 – Enabled	3
NOTE 1 Refer to the Command/Address Parity clause for details regarding CA Parity. NOTE 2 Refer to the Data Parity clause for details regarding Write Parity and Read Parity. NOTE 3 Refer to the Data Bus Inversion (DBIac) clause for details regarding WDBI and RDBI.			

Table 12 — Mode Register 1 (MR1)

Field	Bits	Description	Notes
Parity Latency (PL)	OP[7:5]	000 – 0 nCK 001 – 1 nCK 010 – 2 nCK 011 – 3 nCK 100 – 4 nCK All others – Reserved	1, 2
Write Latency (WL)	OP[4:0]	00100 – 4 nCK 00101 – 5 nCK 00110 – 6 nCK ... 01111 – 15 nCK 10000 – 16 nCK All Others - Reserved	1, 3
NOTE 1 All PL and WL values are optional, however the supported min-to-max ranges must be contiguous. NOTE 2 Refer to the Data Parity clause for details regarding Parity Latency (PL) definition and use with write and read operations. NOTE 3 Refer to the WRITE command clause for details regarding the Write Latency (WL) definitions and use.			

5 Mode Registers (cont'd)

Table 13 — Mode Register 2 (MR2)

Field	Bits	Description	Notes
Read Latency (RL)	OP[7:0]	00000100 – 4 nCK 00000101 – 5 nCK 00000110 – 6 nCK ... 00111110 – 62 nCK 00111111 – 63 nCK All others – Reserved	1, 2

NOTE 1 All RL values are optional, however the supported min-to-max ranges must be contiguous.
 NOTE 2 Refer to the READ command clause for details regarding the Read Latency (RL) definitions and use.

Table 14 — Mode Register 3 (MR3)

Field	Bits	Description	Notes
Write Recovery to Auto Precharge (WR)	OP[7:0]	00000100 – 4 nCK 00000101 – 5 nCK 00000110 – 6 nCK ... 00111110 – 62 nCK 00111111 – 63 nCK All others – Reserved	1, 2

NOTE 1 All WR values are optional, however the supported min-to-max range must be contiguous.
 NOTE 2 WR must be programmed with a value greater than or equal to RU{t_{WR}/t_{CK}}, where RU stands for round up, t_{WR} is the analog value from the vendor datasheet and t_{CK} is the operating clock cycle time. If an HBM3 DRAM does not support the mode register definition of t_{WR} in clock cycles, the WR mode register settings will be ignored.

Table 15 — Mode Register 4 (MR4)

Field	Bits	Description	Notes
Activate to Precharge (RAS)	OP[7:0]	00000100 – 4 nCK 00000101 – 5 nCK 00000110 – 6 nCK ... 00111110 – 62 nCK 00111111 – 63 nCK All others – Reserved	1, 2

NOTE 1 All RAS values are optional, however the supported min-to-max range must be contiguous.
 NOTE 2 RAS must be programmed with a value greater than or equal to RU{t_{RAS}/t_{CK}}, where RU stands for round up, t_{RAS} is the analog value from the vendor datasheet and t_{CK} is the operating clock cycle time. If an HBM3 DRAM does not support the mode register definition of t_{RAS} in clock cycles, the RAS mode register settings will be ignored.

5 Mode Registers (cont'd)

Table 16 — Mode Register 5 (MR5)

Field	Bits	Description	Notes
RFU	OP[7:4]	0000	
Read to Auto Pre-charge (RTP)	OP[3:0]	0010 – 2 nCK 0011 – 3 nCK 0100 – 4 nCK ... 1110 – 14 nCK 1111 – 15 nCK All others – Reserved	1, 2

NOTE 1 All RTP values are optional, however the supported min-to-max range must be contiguous.

NOTE 2 RTP must be programmed with a value greater than or equal to $\text{RU}\{\text{tRTP}/\text{tCK}\}$, where RU stands for round up, tRTP is the analog value from the vendor datasheet and tCK is the operating clock cycle time. If an HBM3 DRAM does not support the mode register definition of tRTP in clock cycles, the RTP mode register settings will be ignored.

Table 17 — Mode Register 6 (MR6)

Field	Bits	Description	Notes
RFU	OP[7:6]	00	
Pullup Driver Strength	OP[5:3]	000 – 8 mA 001 – 10 mA 010 – 12 mA (Default) 011 – 14 mA All others – Reserved	1
Pulldown Driver Strength	OP[2:0]	000 – 8 mA 001 – 10 mA 010 – 12 mA (Default) 011 – 14 mA All others – Reserved	1

NOTE 1 Refer to the Transmit Driver Current table for the details.

5 Mode Registers (cont'd)

Table 18 — Mode Register 7 (MR7)

Field	Bits	Description	Notes
CATTRIP	OP7	0 – CATTRIP pin drives a LOW or HIGH depending on CATTRIP sensor output (Default) 1 – CATTRIP pin drives a static HIGH	1
RFU	OP6	0	
DWORD MISR Control	OP[5:3]	The bits are only evaluated if DWORD Loop-back is enabled in OP0 000 – Preset: the DWORD MISR is preset as described in the HBM3 Loopback Test Modes clause, and all DWORD LFSR_COMPARE_STICKY bits are reset to 0. 001 – LFSR mode (READ direction) 010 – Register mode (WRITE and READ directions): DWORD writes are captured directly into the MISR without compression. The MISR will contain the most recent write data. 011 – MISR mode (WRITE direction) 100 – LFSR Compare mode (WRITE direction) All others - Reserved	2, 3
RFU	OP2	0	
DWORD Read Mux Control	OP1	The bit is only evaluated with READ commands and if DWORD Loopback is enabled in OP0 0 – Return data from DWORD MISR (see OP[5:3]) 1 – Return LFSR_COMPARE_STICKY bits (OP[5:3] is ignored)	2, 3
DWORD Loopback	OP0	0 – Disabled (Default) 1 – Enabled: all Writes and Reads will be to/from the MISR. Notes: a) does not require any row activation b) column addresses associated with WRITE and READ commands are ignored	2
NOTE 1 The CATTRIP pin can be asserted to “HIGH” from any of the channels [a:p] MR7 OP7 bit (logic OR). NOTE 2 See HBM3 Loopback Test Modes for DWORD MISR mode features and use. NOTE 3 Refer to Table 19 for details on DWORD MISR operation with WRITE and READ commands.			

5 Mode Registers (cont'd)

Table 19 — DWORD MISR Read and Write Operations in Loopback Test Mode (MR7 OP0=1)

MR7 OP1	MR7 OP[5:3]	DWORD MISR Operation ¹		Comments
		WRITE	READ	
0	000 (Preset)	Write data are ignored	Read the Preset value (clock-like pattern)	Neither Writes nor Reads alter the MISR content
	001 (LFSR)	Write data are ignored	Generate read data from LFSR	Writes do not alter the MISR content
	010 (Register)	MISR stores the second half (UI 4 to 7) or all data (UI 0 to 7) of the most recent Write from register mode, with only (UI 4 to 7) readable via WDR (see note 2)	Read the MISR content (UI 0 to 3 and repeated for UI 4 to 7, or all data (UI 0 to 7) of the most recent Write (see note 2))	Reads do not alter the MISR content
	011 (MISR)	Write data are accumulated in the MISR		
	100 (LFSR Compare)	Write data are compared against data generated by the LFSR		
1	XXX	Write data are ignored	Read sticky error bits	Neither Writes nor Reads alter the MISR content

NOTE 1 See Loopback Test Modes for DWORD MISR and LFSR features and use.

NOTE 2 Depending on implementation, the MISR either stores the second half (UI 4 to 7) or all data (UI 0 to 7) to the most recent Write, and subsequent Reads return either the second half (UI 4 to 7) or all data (UI 0 to 7) to that most recent Write. If a Read shall send identical data regardless of the actual implementation, users should send the same write data on UI 0 to 3 and UI 4 to 7 of the most recent write.

Table 20 — Mode Register 8 (MR8)

Field	Bits	Description	Notes
RFU	OP[7:6]	00	
RFM Levels (RFML)	OP[5:4]	00 – Default Level (RFM may be required or not) 01 – Level A (RFM is required) 10 – Level B (RFM is required) 11 – Level C (RFM is required)	1
WDQS-to-CK Training (WDQS2CK)	OP3	0 – Disabled (Default) 1 – Enabled	2
ECS error log auto reset (ECSLOG)	OP2	0 – Disabled (Default) 1 – Enabled	
Duty Cycle Monitor (DCM)	OP1	0 – Disabled (Default) 1 – Enabled	
DA Port Lockout	OP0	0 – Access to DA port is enabled (Default) 1 – Access to DA port is locked	3

NOTE 1 The support of Adaptive Refresh Management (ARFM) is optional for the DRAM vendor. HBM3 DRAMs not supporting (ARFM) will define these bits as RFU. RAAIMT, RAAMMT and RAADEC values for default RFM level and RFM levels A to C are set by DRAM vendor and can be read via the IEEE1500 DEVICE_ID WDR.

NOTE 2 Refer to the WDQS-to-CK Alignment Training clause for details.

NOTE 3 DA Port Lockout bit is defined for channels a and e only. The bit is RFU for all other channels. Once enabled, the bit can only be cleared by powering off the device. The IEEE1500 MODE_REGISTER_DUMP_SET instruction cannot be used to set or clear the bit, but allows reading the bit.

5 Mode Registers (cont'd)

Table 21 — Mode Register 9 (MR9)

Field	Bits	Description	Notes
ECS Error Type and Address Reset (ECSRES)	OP7	0 – Maintain the ECS error type and address log (Default) 1 – Reset the ECS error type and address log (self-clearing)	1
ECS multi-bit error correction (ECSCEM)	OP6	0 – Correction of multi-bit errors during ECS cycles is disabled 1 – Correction of multi-bit errors during ECS cycles is enabled	
Auto ECS during Self Refresh (ECSSRF)	OP5	0 – Auto ECS during self refresh mode is disabled (Default) 1 – Auto ECS during self refresh mode is Enabled	2
Auto ECS via REFab (ECSREF)	OP4	0 – Auto ECS via REFab command is disabled (Default) 1 – Auto ECS via REFab command is enabled	2, 3
Error Vector Pattern (ECCVEC)	OP3	The bit is only evaluated when ECC Vector Input Mode is enabled in OP2 0 – Codeword 0 (CW0): Data ‘1’ means error bit and data ‘0’ means non-error bit 1 – Codeword 1 (CW1): Data ‘0’ means error bit and data ‘1’ means non-error bit	
Error Vector Input Mode (ECCTM)	OP2	0 – ECC Engine Test Mode is disabled (default) 1 – ECC Engine Test Mode is enabled	
Severity Reporting (SEVR)	OP1	0 – Error severity reporting is disabled and the SEV signals are High-Z 1 – Error severity reporting is enabled. The SEV signals drive error severity information during Reads and otherwise are High-Z.	4
Meta Data (MD)	OP0	0 – ECC signals are disabled. Read and write operations do not include meta data 1 – ECC signals are enabled. Read and write operations include meta data transmitted via ECC pins	
NOTE 1 The bit is self-clearing meaning that it automatically returns back to 0 after the reset function has been issued. NOTE 2 For ECS operation either ECSSRF or ECSREF (or both) must be enabled. NOTE 3 When ECS during REFab is enabled, the host must issue REFab commands at an average rate of t_{ECSint} . NOTE 4 Input data on SEV signals during write operations will be ignored regardless of the SEVR setting.			

Table 22 — Mode Register 10 (MR10)

Field	Bits	Description	Notes
Vendor Specific	OP[7:0]	Vendor Specific	1
NOTE 1 MR10 is reserved for vendor specific features. Refer to the vendor's datasheet for details.			

5 Mode Registers (cont'd)

Table 23 — Mode Register 11 (MR11)

Field	Bits	Description	Notes
DCA code for WDQS1 (PC1)	OP[7:4]	0000 – 0 steps (Default; no correction) 0001 – -1 step 0010 – -2 steps ... 0110 – -6 steps 0111 – -7 steps 1000 – Reserved 1001 – +1 step 1010 – +2 steps ... 1110 – +6 steps 1111 – +7 steps	1, 2
DCA code for WDQS0 (PC0)	OP[3:0]	0000 – 0 steps (Default; no correction) 0001 – -1 step 0010 – -2 steps ... 0110 – -6 steps 0111 – -7 steps 1000 – Reserved 1001 – +1 step 1010 – +2 steps ... 1110 – +6 steps 1111 – +7 steps	1, 2
NOTE 1 Values of 0001 to 0111 decrease the internal WDQS duty cycle, and values of 1001 to 1111 increase the internal WDQS duty cycle. NOTE 2 The step size (in ps) is vendor specific and may be non-linear.			

Table 24 — Mode Register 12 (MR12)

Field	Bits	Description	Notes
Reserved for Vendor Specific Features	OP[7:0]	00000000	1
NOTE 1 MR12 is reserved for vendor specific features. Refer to the vendor's datasheet for details.			

Table 25 — Mode Register 13 (MR13)

Field	Bits	Description	Notes
RFU	OP[7:0]	00000000	

5 Mode Registers (cont'd)

Table 26 — Mode Register 14 (MR14)

Field	Bits	Description	Notes
RFU	OP7	0	
Reference voltage for AWORD inputs (VREFCA)	OP[6:1]	000000 – 0.18 x V _{DDQL} 000001 – 0.19 x V _{DDQL} ... 011111 – 0.49 x V _{DDQL} 100000 – 0.50 x V _{DDQL} (Default) 100001 – 0.51 x V _{DDQL} ... 111110 – 0.80 x V _{DDQL} 111111 – 0.81 x V _{DDQL}	
RFU	OP0	0	
NOTE 1 Refer to the DC and AC Operating Conditions clause for the AWORD input receiver voltage level specification.			

Table 27 — Mode Register 15 (MR15)

Field	Bits	Description	Notes
RFU	OP7	0	
Reference voltage for DWORD inputs (VREFD)	OP[6:1]	000000 – 0.18 x V _{DDQL} 000001 – 0.19 x V _{DDQL} ... 011111 – 0.49 x V _{DDQL} 100000 – 0.50 x V _{DDQL} (Default) 100001 – 0.51 x V _{DDQL} ... 111110 – 0.80 x V _{DDQL} 111111 – 0.81 x V _{DDQL}	
RFU	OP0	0	
NOTE 1 Refer to the DC and AC Operating Conditions clause for the DWORD input receiver voltage level specification.			

6 Operation

6.1 HBM3 Clocking Overview

The HBM device captures commands and addresses on the row and column buses using a differential clock CK_t/CK_c. Both buses operate at double data rate (DDR).

The HBM device has uni-directional differential Write strobes (WDQS_t/WDQS_c) and Read strobes (RDQS_t/RDQS_c) per 32DQ(DWORD). The data bus operates at double data rate (DDR).

HBM3 utilizes two types of clock with different frequencies. The strobe frequency is twice the frequency of the command clock, requiring an HBM3 to have reset-type clock-divider in the WDQS clock tree (Figure 10). By dividing the WDQS, the operation speed of DRAM internal circuits in WDQS domain is reduced to half. The direction of the internal WDQS/2 transition may vary depending on vendor's choice. Command clock and WDQS are generated from the same PLL and RDQS clock is generated from WDQS. WDQS internal divider is initialized to be a pre-defined internal divider state after Self Refresh exit or Power-up or Power down exit sequence. The sum of preamble and postamble for both READ and WRITE operation is required to be an even number so that the internal divider's state, phase of internal WDQS/2, is maintained. Therefore, HBM3 WDQS does not require a specific sync operation before READ and WRITE operations. WDQS starts toggling before starting WRITE or READ operations for reducing ISI. During inactivity, WDQS/ RDQS are required to be static (WDQS/RDQS_t is Low, WDQS/RDQS_c is High). When WRITE training for unmatched DQ/DQS path, DQ should be shifted to align phase to the point where CK and WDQS are in sync.

The following nomenclature is being used throughout this standard:

- a rising CK (or WDQS, RDQS) edge is defined as the crossing of the positive edge of CK_t (or WDQS_t, RDQS_t) and the negative edge of CK_c (or WDQS_c, RDQS_c);
- a falling CK (or WDQS, RDQS) edge is defined as the crossing of the negative edge of CK_t (or WDQS_t, RDQS_t) and the positive edge of CK_c (or WDQS_c, RDQS_c).





Figure 8 — Aligned WDQS Internal Divider Example

6.1 HBM3 Clocking Overview (cont'd)



NOTE 1 tWPRE1 : Write preamble of WDQS, tWPST1 : Write postamble of WDQS

NOTE 2 tWPRE2 : Read preamble of WDQS, tWPST2 : Read postamble of WDQS

NOTE 3 tRPRE : Read preamble of RDQS, tRPST : Read postamble of RDQS

Figure 9 — Clocking and Interface Relationship Write to Read Timing




Figure 10 — High Level Block Diagram Example of Clocking Scheme

6.1.1 WDQS-to-CK Alignment Training

WDQS-to-CK alignment training allows the host to observe the phase offset between the WDQS strobes in both PCs and the CK clock to aid in keeping the phase relationship within the limits given by the t_{DQSS} specification. The WDQS2CK bit in MR8 OP3 is associated with this training mode.

WDQS-to-CK alignment training is required to be performed at least once after device initialization if adherence to the t_{DQSS} timing cannot be guaranteed without performing this alignment training. WDQS-to-CK alignment training is not required if the t_{DQSS} timing is met. An effort to further narrow the WDQS-to-CK phase offset by using this training mode will not improve the stable device operation.

Steps 1 through 7 are required for WDQS-to-CK alignment training:

1. Enter WDQS-to-CK alignment training mode by setting the WDQS2CK bit to 1 and wait t_{MOD}. Commands allowed while in this mode are REFab, REFpb, RFMab, RFMpB, RNOP, CNOP and MRS to exit WDQS-to-CK alignment training. Internal current spikes generated by the use of REFab, REFpb, RFMab and RFMpB commands in this mode may negatively impact the training result. Controllers that cannot account for this impact should avoid use of REFab, REFpb, RFMab and RFMpB commands in this mode.
2. Enable both WDQS0 and WDQS1 strobes; keep both strobes constantly running in order to generate a valid read-out at both phase detectors with each CK clock cycle;
3. Slowly sweep the WDQS0 and WDQS1 phases with respect to the CK clock, and monitor both DERR0 and DERR1 signals for the phase detector's result as shown in Table 28 and Figure 11; each phase detector latches the 0° phase of the internally divided WDQS strobe (0° phase) with each rising CK clock edge and provides the result on the DERR0 signal for WDQS0 and the DERR1 signal for WDQS1 after t_{WDQS2PD};
4. After a minimum of 8 WDQS pulses have been received, the strobes may be halted at any time while WDQS-to-CK alignment training mode is enabled; the phase detector does not provide a valid read-out in this case and its result on the DERR signals should be ignored;
5. The ideal alignment is indicated by the phase detector output transitioning from "early" to "late" when the delay of the WDQS phase is continuously increased;
6. When the phase relationship between WDQS and CK meets the t_{DQSS} specification, stop both WDQS strobes; ensure that the number of WDQS pulses issued while in this training mode is an even number such that the internal WDQS state is back at its reset state once the training has finished. With that, no specific synchronization between CK and WDQS is required for correct write and read operation;
7. Exit WDQS-to-CK alignment training mode by setting the WDQS2CK bit to 0 and wait t_{MOD}.

Table 28 — Phase Detector and DERR Signal Behavior

Internal WDQS/2 (0° Phase) Sampled By CK	WDQS Phase	DERR0 DERR1	Recommended Action
HIGH	Early	HIGH	Increase delay on WDQS
LOW	Late	LOW	Decrease delay on WDQS

6.1.1 WDQS-to-CK Alignment Training (cont'd)




Figure 11 — DERR Signal Behavior in WDQS-to-CK Alignment Training

6.2 HBM3 Data Bus Inversion (DBIac)

6.2.1 Data Bus Inversion (DBIac)

HBM3 DRAMs supports a byte granular Data Bus Inversion (DBIac). The corresponding DBI signal is a DDR I/O and driven or sampled along with the DQs for read and write operations.

The word DBI refers to the internal state of the device unless explicitly noted as DBI signal. The DBIac function can be enabled or disabled independently for writes per MR0 OP1 (WDBI) and for reads per MR0 OP0 (RDBI).

The DBI input is a Don't care and the DBI input receivers are disabled when WDBI is disabled. The DBI output buffers are turned off when RDBI is disabled.




Figure 12 — DBIac Algorithm

Write operation: the HBM3 DRAM inverts write data received on the DQ inputs in case DBI is sampled HIGH, or leaves the write data non-inverted in case DBI is sampled LOW. Note that the ECC inputs are not affected by the DBIac function.

Read operation: the HBM3 DRAM counts the number of DQ signals that are transitioning from the previous state. Note that the ECC and SEV outputs are not affected by DBIac. See Internal DBIac States with Read for bus pre-conditioning. The HBM3 DRAM inverts read data and sets DBI HIGH when the number of transitioning data bits within a byte is greater than 4, or when the number of transitioning data bits within a byte equals 4 and DBI was HIGH; otherwise the HBM3 DRAM does not invert the read data and sets DBI LOW.

6.2.1 Data Bus Inversion (DBIac) (cont'd)

Table 29 — DBI(ac) Truth Table

DQ Charge Count	Previous DBI State	New DBI State	New DQ State
0 to 3	X	LOW	Not inverted
4	LOW	HIGH	Inverted
	HIGH		
5 to 8	X		




Figure 13 — Example DBIac Logic for Write and Read

6.2.1.1 Internal DBIac State with Read

The HBM3 DRAM resets the internal DBIac state to LOW whenever any of the following events occur:

- RESET_n signal de-assertion;
- a MODE REGISTER SET (MRS) command is received;
- a write-to-read bus turnaround;
- Self Refresh exit

For all other events or commands, the internal DBIac state is not reset to LOW and the HBM3 DRAM will use its previous state for DBIac calculation.

First Read Command:

When a first READ command is registered after a DBI reset, the HBM3 DRAM preconditions the bus to LOW prior to read data regardless whether RDBI is enabled or disabled in the mode register, as shown in Figure 14 in case of a write-to-read bus turnaround. The internal state D7 corresponding to the last UI of the read burst is internally stored as a seed value for a subsequent read burst.

The DPAR signal is not included in the DBI calculation and not preconditioned to LOW; its initial state is undefined (LOW or HIGH).

6.2.1.1 Internal DBIac State with Read (cont'd)




Figure 14 — Internal DBIac State Reset for Write to Read

6.2.1.2 Internal DBIac State with Consecutive Read Commands (Seamless and non-seamless)

Once the Read burst is complete, the HBM3 DRAM tri-states all DQ, DBI and ECC output drivers. However, the HBM3 DRAM internally stores the last data-out of the DQ, DBI, ECC and SEV outputs to pre-condition the bus prior to a subsequent read; it also uses the last data-out of the DQ and DBI outputs for DBIac calculation for any subsequent read operation barring a condition to DBI reset. For non-gapless read operations, the HBM3 DRAM pre-conditions all data outputs to the last data-out of the previous burst nominally two WDQS cycles (odd bytes) and one WDQS cycle (even bytes) prior to the first valid data bit as shown in Figure 15.

6.2.1.2 Internal DBIac State with Consecutive Read Commands (Seamless and non-seamless) (cont'd)




Figure 15 — Bus Preconditioning and DBI States for Read

6.3 Commands

The HBM3 DRAM features DDR commands entered on both rising and falling CK clock edges. Row Activate commands require one-and-a-half-cycle and other row commands require only a half-cycle except for PDE and SRE with one cycle. Column commands require only one cycle.

The command interface includes a reserved DDR input signal ARFU which is omitted from subsequent truth tables but required to be driven to a valid signal level along with the other AWORD inputs.

Student

6.3.1 Command Truth Tables

Table 30 — Row Commands Truth Table

Command ⁴	Symbol	Clock Cycle	R0	R1	R2	R3	R4	R5	R6	R7	R8	R9	Notes
Row No Operation	RNOP	R or F	H	H	H	H	V	V	V	V	V	V	1, 2, 3
Activate	ACT	R	L	H	H	PC	SID0 / V	SID1 / V	BA0	BA1	BA2	BA3	1, 2, 3, 5, 6
		F	H	H	RA8	RA9	RA10	RA11	RA12	RA13	RA14 / V	V	
		R	H	H	RA0	RA1	RA2	RA3	RA4	RA5	RA6	RA7	
Precharge	PREPb	R or F	H	L	L	PC	SID0 / V	SID1 / V	BA0	BA1	BA2	BA3	1, 2, 3, 5, 6
Precharge All	PREab	R or F	H	L	H	PC	V	V	V	V	V	V	1, 2, 3, 5
Per-Bank Refresh	REFpb	R	L	L	L	PC	SID0 / V	SID1 / V	BA0	BA1	BA2	BA3	1, 2, 3, 5, 6
All-Bank Refresh	REFab	R	H	H	L	PC	V	V	V	V	L	V	1, 2, 3, 5
Per-Bank Refresh Management	RFMpb	R	L	L	H	PC	SID0 / V	SID1 / V	BA0	BA1	BA2	BA3	1, 2, 3, 5, 6, 7
All-Bank Refresh Management	RFMab	R	H	H	L	PC	V	V	V	V	H	V	1, 2, 3, 5, 7
Power-Down Entry	PDE	R	L	H	L	H	V	V	V	V	V	V	1, 2, 3
		F	L	H	L	H	V	V	V	V	V	V	
Self Refresh Entry	SRE	R	L	H	L	L	V	V	V	V	V	V	1, 2, 3
		F	L	H	L	L	V	V	V	V	V	V	
Power-Down and Self Refresh Exit	PDX/SRX	R	H	H	H	H	V	V	V	V	V	V	1, 2, 8
NOTE 1 BA = Bank Address; RA = Row Address; PC = Pseudo Channel 0 or 1; SID = Stack ID; V = Valid Signal (either H or L, but not floating);													
NOTE 2 R[9:0] must be driven to a valid signal level even if a stack ID address (SID) or row address (RA) is not defined for a specific density. APAR must be driven to a valid signal level even if CA parity is disabled in MR0 OP6.													
NOTE 3 Parity is evaluated on all pins if CA parity is enabled in MR0 OP6.													
NOTE 4 All other command encodings not shown in the table are reserved for future use.													
NOTE 5 PC = 0 selects pseudo channel 0 (PC0), and PC = 1 selects pseudo channel 1 (PC1). The pseudo channel not selected by PC performs a RNOP.													
NOTE 6 The SID bits act as bank address bits in conjunction with ACT, PREpb, REFpb and RFMpb commands, and related timing diagrams shall be interpreted accordingly. All other row commands do not use SID. Refer to the channel addressing table for HBM3 configurations using SID.													
NOTE 7 An HBM3 DRAM not requiring refresh management (RFM) will execute an RNOP command instead of RFMab or RFMpb.													
NOTE 8 No Parity checking at Power-Down Exit or Self Refresh Exit command. The HBM3 device requires RNOP and CNOP commands on Row and Column bus respectively with valid parity if CA parity is enabled during the power-down exit period (txp) and self refresh exit period (txs).													
NOTE 9 ACT is a 1.5 cycle command and another command is not allowed during ACT command.													

6.3.1 Command Truth Tables (cont'd)

Table 31 — Column Commands Truth Table

Command ⁴	Symbol	Clock Cycle	C0	C1	C2	C3	C4	C5	C6	C7	Notes		
Column No Operation	CNOP	R	H	H	H	V	V	V	V	V	1, 2, 3		
		F	V	V	V	V	V	V	V	V			
Read	RD	R	H	L	H	L	PC	SID0 / V	SID1 / V	BA0	1, 2, 3, 5, 6, 7		
		F	BA1	BA2	BA3	CA0	CA1	CA2	CA3	CA4			
Read w/ AP	RDA	R	H	L	H	H	PC	SID0 / V	SID1 / V	BA0	1, 2, 3, 5, 6, 7		
		F	BA1	BA2	BA3	CA0	CA1	CA2	CA3	CA4			
Write	WR	R	H	L	L	L	PC	SID0 / V	SID1 / V	BA0	1, 2, 3, 5, 6		
		F	BA1	BA2	BA3	CA0	CA1	CA2	CA3	CA4			
Write w/ AP	WRA	R	H	L	L	H	PC	SID0 / V	SID1 / V	BA0	1, 2, 3, 5, 6		
		F	BA1	BA2	BA3	CA0	CA1	CA2	CA3	CA4			
Mode Register Set	MRS	R	L	L	L	MA4	OP5	OP6	OP7	MA0	1, 3, 8, 9		
		F	MA1	MA2	MA3	OP0	OP1	OP2	OP3	OP4			
NOTE 1 BA = Bank Address; CA = Column Address; PC = Pseudo Channel 0 or 1; SID = Stack ID; MA = Mode Register Address; V = Valid Signal (either H or L, but not floating).													
NOTE 2 C[7:0] must be driven to a valid signal level even if a stack ID address (SID) is not defined for a specific density, or if parity is disabled in the mode register. APAR must be driven to a valid signal level even if CA parity is disabled in MR0 OP6. C[7:0] are Don't Care when the device is in power-down or self refresh.													
NOTE 3 Parity is evaluated on all pins if CA parity is enabled in MR0 OP6.													
NOTE 4 All other command encodings not shown in the table are reserved for future use.													
NOTE 5 PC = 0 selects pseudo channel 0 (PC0), and PC = 1 selects pseudo channel 1 (PC1). The pseudo channel not selected by PC performs a CNOP.													
NOTE 6 The SID bits act as bank address bits in conjunction with READ and WRITE commands, and related timing diagrams shall be interpreted accordingly. All other column commands do not use SID. Refer to the channel addressing table for HBM3 configurations using SID.													
NOTE 7 HBM3 configurations using the SID specify a timing parameter tccdr for consecutive READs to different SID. Vendor datasheets should be consulted for details.													
NOTE 8 All mode registers are write-only by default using the MRS command.													
NOTE 9 Refer to the HBM3 Mode Register Overview table for MA4 of MRS.													

6.3.1 Command Truth Tables (cont'd)

Table 32 — Options for Issuing PREab and PREpb Commands

Command on Rising Clock Edge	Allowed PREab/PREPb Command(s) on Falling Clock Edge (Same Cycle)		
	Same PC, Same Bank	Same PC, Different Bank	Different PC, Any Bank
RNOP	PREab, PREpb		PREab, PREpb
ACT	--	PREpb	PREab, PREpb
PREab	--	--	PREab, PREpb
PREpb	--	PREpb	PREab, PREpb
REFab	--	--	PREab, PREpb
REFpb	--	PREpb	PREab, PREpb
RFMab	--	--	PREab, PREpb
RFMpb	--	PREpb	PREab, PREpb
PDE, SRE	--		
PDX, SRX	--		

6.3.2 Row Commands

6.3.2.1 Row No Operation (RNOP) Command

The ROW NO OPERATION (RNOP) command is a half-cycle command received on the row command inputs R[9:0] and latched either with the rising or with the falling CK clock edge (or both edges) as shown in Figure 16. RNOP is used to instruct the HBM3 device to perform a NOP as row command; this prevents unwanted row commands from being registered during idle or wait states. Operations already in progress are not affected.

Row commands other than RNOP are defined either as half-cycle or as one-and-a-half-cycle commands that begin and end on a rising CK clock edge. These commands must be padded with RNOP on the falling CK clock edge of the same cycle. As an alternative, some row commands may be paired with PRECHARGE or PRECHARGE ALL commands on the falling CK clock edge instead of RNOP, with the specific conditions for these commands being explicitly described for each row command.

Parity is evaluated with the RNOP command when the parity calculation is enabled in the Mode Register.

RNOP is assumed for the R[9:0] inputs on subsequent timing diagrams unless other row commands are explicitly shown.

6.3.2.1 Row No Operation (RNOP) Command (cont'd)




Figure 16 — RNOP command


6.3.2.2 ACTIVATE (ACT) Command

Before a READ or WRITE command can be issued to a bank, a row in that bank must be opened. This is accomplished via the ACTIVATE command, which selects both the bank and the row to be activated. Once a row is open, a READ or WRITE command could be issued to that row, subject to the t_{RCD} specification.

The ACTIVATE command is a one-and-a-half-cycle command received on the row command inputs R[9:0] and latched with the rising and falling CK clock edges as shown in Figure 17. The command must be followed either by RNOP, PRECHARGE or PRECHARGE ALL on the falling CK clock edge of the second clock cycle. Note that a PRECHARGE ALL in that case must be for the other pseudo channel. A PRECHARGE command could be to any bank in the other pseudo channel as well as to a different bank in the same pseudo channel. In all cases the timing requirements for issuing these commands must be met.

The actual bank and row activation is initiated with the second rising CK clock edge of the ACTIVATE command; therefore all relevant timing parameters refer to this second rising CK clock edge as shown in Figures 17 and 18.

6.3.2.2 ACTIVATE (ACT) Command (cont'd)



NOTE 1 BA = Bank Address; PC = Pseudo Channel 0 or 1; RA = Row Address; SID = Stack ID; V = Valid (H or L)

Figure 17 — ACTIVATE Command


Parity is evaluated with the ACTIVATE command when the parity calculation is enabled in MR0 OP6.

A subsequent ACTIVATE command to another row in the same bank can only be issued after the previous row has been closed (precharged). The minimum time interval between successive ACTIVATE commands to the same bank is defined by trc, as shown in Figure 18. A minimum time tras must have elapsed between opening and closing a row. The figure also shows two cases of tras timings and command slots of the PRECHARGE command


A subsequent ACTIVATE command to another bank can be issued while the first bank is being accessed, which results in a reduction of total row access overhead. The minimum time interval between successive ACTIVATE commands to different banks is defined by trrd. The row remains active until a PRECHARGE command (or READ or WRITE command with Auto Precharge) is issued to the bank.

6.3.2.2 ACTIVATE (ACT) Command (cont'd)

Case1 : tRAS timing met at rising CK clock edge



Case2 : tRAS timing met at falling CK clock edge



NOTE 1 BAx = bank address x; RAy,z = row addresses y,z; CAN = column address n.

NOTE 2 The PRECHARGE command shown could also be a PRECHARGE ALL command.


NOTE 3 tRCD = trCDRD or trCDWR, depending on command; tRFC = tRFCab or tRFCpb, depending on command.

NOTE 4 The reference for tXP and tXS timings is the first clock cycle of an ACTIVATE command, and the reference for tRFC and tMOD timing is the second clock cycle of an ACTIVATE command.

Figure 18 — Bank and Row Activation Command Cycle

6.3.2.2.1 Bank Restrictions

There is a need to limit the number of bank activations in a rolling window to ensure that the instantaneous current supplying capability of the device is not exceeded. To reflect the short term current supply capability, the parameter tFAW (four activate window) is defined: no more than 4 banks may be activated in a rolling tFAW window. Converting to clocks is done by dividing tFAW (ns) by tCK (ns) and rounding up to next integer value. As an example of the rolling window, if (tFAW/tCK) rounds up to 25 clocks, and an ACTIVATE command is issued at clock T0, no more than three further ACTIVATE commands may be issued at clocks T1 through T24 as illustrated in Figure 19.



NOTE 1 t_{RRD} = t_{RRDS} or t_{RRDL}, depending on accessed banks.

NOTE 2 Refer to the “REFRESH and PER-BANK REFRESH Command Scheduling Requirements” table for timing restrictions between all combinations of ACTIVATE and PER-BANK REFRESH commands.

Figure 19 — Multiple Bank Activations


6.3.2.3 PRECHARGE (PREpb) and PRECHARGE ALL (PREab) Commands

The PRECHARGE (PREpb) and PRECHARGE ALL (PREab) commands are half-cycle commands received on the row command inputs R[9:0] and latched either with the rising or with the falling CK clock edge as shown in Figure 20 and Figure 21. The commands are used to deactivate the open row in a particular bank (PREpb) or the open rows in all banks (PREab). The bank(s) will be in idle state and available for a subsequent row access a specified time t_{RP} after the PRECHARGE command is issued.

The fact that both are half-cycle commands and defined on both the rising and the falling CK clock edges allows to issue one PREpb or PREab command on the rising CK clock edge and a second PREpb or PREab command on the falling CK clock edge of the same cycle and thus deactivate the open row in two different banks or even all banks in both pseudo channels within a single clock cycle, provided the t_{PPD} timing has been met. It is pointed out that the t_{RP} timing is always referenced from the CK clock edge on which the PREpb or PREab command is issued.


Parity is evaluated with the PRECHARGE and PRECHARGE ALL commands when the parity calculation is enabled in MR0 OP6.

6.3.2.3 PRECHARGE (PREpb) and PRECHARGE ALL (PREab) Commands (cont'd)



NOTE 1 BA = Bank Address; PC = Pseudo Channel 0 or 1; SID = Stack ID; V = Valid (H or L)

Figure 20 — PRECHARGE (PREpb) Command



NOTE 1 BA = Bank Address; PC = Pseudo Channel 0 or 1; SID = Stack ID; V = Valid (H or L)

Figure 21 — PRECHARGE ALL (PREab) Command

Input R2 determines whether one or all banks are to be precharged. In case where only one bank is to be precharged, bank addresses {SID[1:0], BA[3:0]} select the bank. Otherwise the bank addresses are treated as “Don’t Care”.

Once a bank has been precharged, it is in the idle state and must be activated prior to any READ or WRITE command being issued to that bank. A PRECHARGE command is allowed if there is no open row in that bank (idle state), or if the previously open row is already in the process of precharging. However, the precharge period shall be determined by the most recent PRECHARGE command issued to the bank.

6.3.2.3.1 AUTO PRECHARGE

Auto Precharge is a feature which performs the same individual-bank precharge function described in Figures 20 and 21, but without requiring an explicit PRECHARGE command. Auto Precharge is nonpersistent meaning that it is enabled or disabled along for each individual READ or WRITE command.

For read bursts an auto precharge of the bank and row that is addressed with the READ command begins RTP clock cycles after the READ command was issued or after RAS has been met, with RTP as programmed in clock cycles in MR6 OP[3:0] and RAS as programmed in clock cycles in the RAS field of Mode Register MR4 OP[7:0].

For write bursts an auto precharge of the bank and row that is addressed with the WRITE command begins (WL + 2 + WR) clock cycles after the WRITE command was issued or after RAS has been met, with WR as programmed in clock cycles in MR3 OP[7:0] and RAS as programmed in clock cycles in MR4 OP[7:0].

Auto Precharge ensures that the precharge is initiated at the earliest valid stage within a burst. The user must not issue another command to the same bank until the precharge (t_{RP}) is completed. This is determined as if an explicit PRECHARGE command was issued at the earliest possible time, as described for READ or WRITE commands. A precharge resulting from a READ or WRITE with Auto Precharge may occur in parallel with an explicit PRECHARGE (or PRECHARGE ALL) command. It is pointed out that an auto precharge is internally always issued with a rising CK clock edge, while explicit PRECHARGE (or PRECHARGE ALL) commands are supported on both clock edges.

6.3.2.3.1 AUTO PRECHARGE (cont'd)**Table 33 — Precharge and Auto Precharge Timings**

From Command	To Command	Minimum Delay Between "From Command" to "To Command"	Unit	Note
READ	PRECHARGE (same bank)	t _{RTP}	nCK	
	PRECHARGE (different bank)	0	nCK	4
	PRECHARGE ALL	t _{RTP}	nCK	
	WRITE or WRITE w/ AP (any bank)	t _{RTW}	ns	
	READ or READ w/ AP (any bank)	t _{CCD}	nCK	5
READ with AP	PRECHARGE ALL	t _{RTP}	nCK	
	PRECHARGE (different bank)	0	nCK	4
	ACTIVATE or PER BANK REFRESH (same bank)	RTP + RU(t _{RP} /t _{CCK})	nCK	2, 8
	WRITE or WRITE w/ AP (same bank)	Illegal		
	WRITE or WRITE w/ AP (different bank)	t _{RTW}	ns	
	READ or READ w/ AP (same bank)	Illegal		
WRITE	PRECHARGE (same bank)	WL + 2 + RU(t _{WR} /t _{CCK})	nCK	2, 6
	PRECHARGE (different bank)	0	nCK	4
	PRECHARGE ALL	WL + 2 + RU(t _{WR} /t _{CCK})	nCK	2, 6
	WRITE or WRITE w/ AP (any bank)	t _{CCD}	nCK	5
	READ w/ AP (same bank)	WL + 2 + MAX[RU(t _{WR} /t _{CCK}) - t _{RTP} , t _{WTR}]	nCK	2, 6, 7
	READ (same bank)	WL + 2 + t _{WTR}	nCK	6, 7
	READ or READ w/ AP (different bank)	WL + 2 + t _{WTR}	nCK	6, 7
WRITE with AP	PRECHARGE ALL	WL + 2 + RU(t _{WR} /t _{CCK})	nCK	2, 6
	PRECHARGE (different bank)	0	nCK	4
	ACTIVATE or PER BANK REFRESH (same bank)	WL + 2 + WR + RU(t _{RP} /t _{CCK})	nCK	2, 6, 8
	WRITE or WRITE w/ AP (same bank)	Illegal		
	WRITE or WRITE w/ AP (different bank)	t _{CCD}	nCK	5
	READ or READ w/ AP (same bank)	Illegal		
PRECHARGE	PRECHARGE (any bank)	t _{PPD}	nCK	3
	PRECHARGE ALL	t _{PPD}	nCK	3
PRECHARGE ALL	PRECHARGE or PRECHARGE ALL	t _{PPD}	nCK	3
NOTE 1 A command issued during the minimum delay time is illegal. NOTE 2 RU = round up to next integer. NOTE 3 A PRECHARGE command is allowed if there is no open row in that bank (idle state), or if the previously open row is already in the process of precharging. However, the precharge period shall be determined by the most recent PRECHARGE command issued to the bank. NOTE 4 READ or WRITE and PRECHARGE commands may be issued simultaneously. NOTE 5 t _{CCD} could either be t _{CCDS} or t _{CCDL} ; for READs, t _{CCD} could also be t _{CCDR} . NOTE 6 WL = write latency. NOTE 7 t _{WTR} could either be t _{WTRS} or t _{WTRL} . NOTE 8 Even if t _{RP} is satisfied from PREab command, t _{RP} generated from previous WRA or RDA (Write or Read with Auto-precharge) should also be satisfied.				

6.3.2.4 Rounding Rules for Row Access Timings

The HBM3 DRAM allows the PRECHARGE (PREpb) and PRECHARGE ALL (PREab) commands to be issued on both rising and falling CK clock edges, as e.g., illustrated in the Bank and Row Activation Command Cycle figure. To let a system take advantage of this flexibility in command scheduling, it is required to adapt the rounding rules for related row access timings.

Traditionally, basic row access timings are converted into clock cycles using the formula $NX\bar{X} = RU(tXX/tCK)$, with XX representing either RAS, RTP, WR or RP parameters. This formula rounds the analog timings up to the next integer such that the subsequent command can be issued on the next rising clock edge that meets the analog value.

For HBM3 DRAM, this formula is replaced by $NX\bar{X} = 0.5 \times RU(2 \times tXX/tCK)$, which rounds analog timings to the next rising or following clock edge that meets the analog value. The result may be the same as with the traditional formula, or 0.5nCK less. The formula may be applied to row timings tRAS, tRTP, tWR and tRP, only. If rounding the tRP timing results in a falling edge as the command slot for a subsequent row access command, it is required to add 0.5nCK to the result because all such row commands following a row precharge can be issued on a rising clock edge only.


Examples:

- $tRAS = 33 \text{ ns}$, $tCK = 0.7 \text{ ns}$; $NRAS = 0.5 \times RU(2 \times tRAS/tCK) = 0.5 \times RU(2 \times 33/0.7) = 0.5 \times RU(94.29) = 47.5$. Conclusion: When the ACTIVATE command was issued at T0, the earliest possible slot for a PRECHARGE command is at T47.5 (falling clock edge).
- $tRP = 15 \text{ ns}$, $tCK = 0.7 \text{ ns}$; $NRP = 0.5 \times RU(2 \times tRP/tCK) = 0.5 \times RU(2 \times 15/0.7) = 0.5 \times RU(42.85) = 21.5$. Conclusion: When the PRECHARGE command was issued at T0 (rising edge), the earliest possible slot for a subsequent ACTIVATE command is at T22, because the falling edge at T21.5 is not supported for an ACTIVATE command and 0.5nCK must be added to the result. However, when the PRECHARGE command was issued at T0.5 (falling edge), the earliest possible slot for a subsequent ACTIVATE command is again at T2.

6.3.2.5 REFRESH Command (REFab)

The (all-bank) REFRESH command is used during normal operation of the HBM3 device. The command is a half-cycle command received on the row command inputs R[9:0] and latched with the rising CK clock edge as shown in Figure 22. The command must be followed either by RNOP, PRECHARGE or PRECHARGE ALL on the falling CK clock edge of the same cycle. Note that PRECHARGE and PRECHARGE ALL commands in this case must be for the other pseudo channel and the timing requirements for issuing these commands must be met. The REFRESH command also requires a CNOP command on the column command inputs C[7:0], unless the column command is for the other pseudo channel.

Parity is evaluated with the REFRESH command when the parity calculation is enabled in the Mode Register.




NOTE 1 PC = Pseudo Channel 0 or 1; V = Valid (H or L)

Figure 22 — REFRESH Command (REFab)

The REFRESH command is nonpersistent, so it must be issued each time a refresh is required. A minimum time t_{RFCab} is required between two REFRESH commands or a REFRESH command and any subsequent access command after the refresh operation. All banks must be precharged with t_{RP} -satisfied prior to the REFRESH command. The banks are in idle state after completion of the REFRESH command.

The refresh addressing is generated by an internal refresh controller. This makes the address bits “Don’t Care” during a REFRESH command.

6.3.2.5 REFRESH Command (REFab) (cont'd)



NOTE 1 Only RNOP and CNOP commands are allowed after a REFRESH command until t_{RFCab} has expired.

NOTE 2 The maximum time interval between two REFRESH commands is $9 \times t_{REFI}$.

Figure 23 — REFRESH Cycle

The HBM3 DRAM requires REFab cycles at an average periodic interval of $t_{REFI}(\text{MAX})$. To allow for improved efficiency in scheduling and switching between tasks, some flexibility in the absolute refresh interval is provided. A maximum of eight REFRESH commands can be postponed during operation of the device, meaning that at no point in time more than a total of eight REFRESH commands are allowed to be postponed. In case that eight REFRESH commands are postponed in a row, the resulting maximum interval between the surrounding REFRESH commands is limited to $9 \times t_{REFI}$ (see Figure 24). At any given time, a maximum of 9 REFRESH commands can be issued within t_{REFI} .

This flexibility to postpone refresh commands also extends to REFPb commands (see REFPb). The maximum interval between refreshes to a particular bank is limited to $9 \times t_{REFI}$. At any given time, a maximum of 9 REFPb commands to a particular bank can be issued within t_{REFI} .





Figure 24 — Postponing Refresh Commands (Example)

Self refresh mode may be entered with a maximum of eight REFRESH commands being postponed. After exiting self refresh mode with one or more REFRESH commands postponed, additional REFRESH commands may be postponed to the extent that the total number of postponed REFRESH commands (before and after the self refresh) will never exceed eight. During self refresh mode, the number of postponed REFRESH commands does not change.

6.3.2.6 PER-BANK REFRESH Command (REFpb)

The PER-BANK REFRESH command (REFpb) provides an alternative solution for the refresh of the HBM3 device. The command initiates a refresh cycle on a single bank while accesses to other banks including writes and reads are not affected. PER-BANK REFRESH is a half-cycle command received on the row command inputs R[9:0] and latched with the rising CK clock edge as shown in Figure 25. The command must be followed either by RNOP, PRECHARGE or PRECHARGE ALL on the falling CK clock edge of the same cycle. Note that a PRECHARGE ALL must be for the other pseudo channel. A PRECHARGE command could be to any bank in the other pseudo channel as well as to a different bank in the same pseudo channel. In all cases the timing requirements for issuing these commands must be met.

Parity is evaluated with the PER-BANK REFRESH command when the parity calculation is enabled in the Mode Register.




NOTE 1 BA = Bank Address; PC = Pseudo Channel 0 or 1; SID = Stack ID; V = Valid (H or L)

Figure 25 — Per-Bank Refresh Command (REFpb)

The PER-BANK REFRESH command is nonpersistent, so it must be issued each time a refresh is required. A minimum time t_{RRD} is required between an ACTIVATE command and a PER-BANK REFRESH command to a different bank. A minimum time t_{RREFD} is required between any two PER-BANK REFRESH commands (see below for an exception requiring t_{RFCpb}), and between a PER-BANK REFRESH command and an ACTIVATE command to a different bank as shown in Figure 26. A minimum time t_{RFCpb} is required between a PER-BANK REFRESH command and an access command to the same bank that follows. The bank to be refreshed must be precharged with t_{RP} satisfied prior to the PER-BANK REFRESH command. The bank is in idle state after completion of the PER-BANK REFRESH command.

6.3.2.6 PER-BANK REFRESH Command (REFpb) (cont'd)



NOTE 1 $B_{An,x,y,z}$ = bank address n,x,y,z; $RA_{a,b,c}$ = row address a,b,c.

NOTE 2 t_{RRD} timing must be met between ACTIVATE commands and REFpb commands to different banks.

NOTE 3 t_{RREFD} timing must be met between consecutive REFpb commands to different banks, and between a REFpb command followed by an ACTIVATE command to the different bank.

NOTE 4 t_{RFCpb} timing must be met between a REFpb command followed by an ACTIVATE command to the same bank.

Figure 26 — Per-Bank Refresh Command Cycle

The row address for each bank is provided by internal refresh counters. This makes the row address bits “Don’t Care” during PER-BANK REFRESH commands.

Rules for issuing PER-BANK REFRESH commands to the banks apply to each SID individually. A PER-BANK REFRESH command to one of the 16 banks per SID can be issued in any order. After all banks within an SID have been refreshed using the PER-BANK REFRESH command and after waiting for at least t_{RFCpb} , the controller can issue another set of PER-BANK REFRESH commands in the same or different order. However, it is illegal to send another PER-BANK REFRESH command to a bank unless all banks within an SID have been refreshed using the PER-BANK REFRESH command. The controller must track the bank being refreshed by the PER-BANK REFRESH command.

A PER-BANK REFRESH command and/or REFRESH MANAGEMENT command must not be issued during t_{RFCpb} succeeding the last PER-BANK REFRESH (REFpb #N) of a single cycle as shown in Figure 27.

The bank count is synchronized between the controller and the HBM3 DRAM by resetting the bank count to zero. Synchronization can occur upon exit from reset state or by issuing a REFRESH or SELF REFRESH ENTRY command. Both commands may be issued at any time even if a preceding sequence of PER-BANK REFRESH commands has not completed cycling through all banks.




Figure 27 — Sets of Per-Bank Refresh Commands

6.3.2.6 PER-BANK REFRESH Command (REFpb) (cont'd)

The average rate of PER-BANK REFRESH commands tREFIpb depends on the bank count N and can be calculated by the following formula:

$$tREFIpb = tREFI / N$$

The example in Table 34 (for HBM3 configurations with 16 banks) shows two full sets of REFpb commands with the bank counter reset to 0 and the refresh counter incremented after 16 REFpb commands each. The third set of REFpb commands is interrupted by the REFab command which resets the bank counter to 0 and performs refreshes to all banks indicated by the refresh counter.

Table 34 — Refresh Counter Increments (Example for HBM3 Configurations with 16 Banks)

Count	Sub-Count	Command	Bank Address	Refresh Bank	Bank Counter	Refresh Counter	
0	0	Reset REFRESH or SELF REFRESH ENTRY command		To 0			
1	1	REFpb	000	0	0 to 1	n	
2	2	REFpb	0001	1	1 to 2		
3	3	REFpb	0010	2	2 to 3		
4	4	REFpb	0011	3	3 to 4		
...				
15	15	REFpb	1110	14	14 to 15		
16	16	REFpb	1111	15	15 to 0		
17	1	REFpb	0100	4	0 to 1	n + 1	
18	2	REFpb	0111	7	1 to 2		
19	3	REFpb	1011	11	2 to 3		
20	4	REFpb	0110	6	3 to 4		
...				
31	15	REFpb	1100	12	14 to 15	n + 2	
32	16	REFpb	0001	1	15 to 0		
33	1	REFpb	0010	2	0 to 1		
34	2	REFpb	1001	9	1 to 2		
35	3	REFpb	0000	0	2 to 3		
36	0	REFab	V	all	To 0	n + 2	
37	1	REFpb	1010	10	0 to 1		
38	2	REFpb	0101	5	1 to 2		
...				

6.3.2.6 PER-BANK REFRESH Command (REFpb) (cont'd)

Table 35 — Refresh and Per-Bank Refresh Command Scheduling Requirements

From Command	To Command	Minimum Delay Between “From Command” to “To Command”	Note
REFRESH	REFRESH	t_{RFCab}	
	PER-BANK REFRESH (any bank)	t_{RFCab}	
	REFRESH MANAGEMENT	t_{RFCab}	
	PER-BANK REFRESH MANAGEMENT (any bank)	t_{RFCab}	
	ACTIVATE	t_{RFCab}	
PER-BANK REFRESH	REFRESH	t_{RFCpb}	
	PER-BANK REFRESH (different bank)	t_{RREFD}	
	PER-BANK REFRESH (any bank)	t_{RFCpb}	3
	REFRESH MANAGEMENT	t_{RFCpb}	
	PER-BANK REFRESH MANAGEMENT (different bank)	t_{RREFD}	
	PER-BANK REFRESH MANAGEMENT (any bank)	t_{RFCpb}	4
	ACTIVATE (same bank)	t_{RFCpb}	
	ACTIVATE (different bank)	t_{RREFD}	1
REFRESH MANAGEMENT	REFRESH	t_{RFCab}	
	PER-BANK REFRESH (any bank)	t_{RFCab}	
	REFRESH MANAGEMENT	t_{RFCab}	
	PER-BANK REFRESH MANAGEMENT (any bank)	t_{RFCab}	
	ACTIVATE	t_{RFCab}	
PER-BANK REFRESH MANAGEMENT	REFRESH	t_{RFCpb}	
	PER-BANK REFRESH (same bank)	t_{RFCpb}	
	PER-BANK REFRESH (different bank)	t_{RREFD}	
	REFRESH MANAGEMENT	t_{RFCpb}	
	PER-BANK REFRESH MANAGEMENT (same bank)	t_{RFCpb}	
	PER-BANK REFRESH MANAGEMENT (different bank)	t_{RREFD}	
	ACTIVATE (same bank)	t_{RFCpb}	
	ACTIVEATE (different bank)	t_{RREFD}	1
ACTIVATE	REFRESH	t_{RC}	2
	PER-BANK REFRESH (same bank)	t_{RC}	2
	PER-BANK REFRESH (different bank)	t_{RRD}	1
	REFRESH MANAGEMENT	t_{RC}	2
	PER-BANK REFRESH MANAGEMENT (same bank)	t_{RC}	2
	PER-BANK REFRESH MANAGEMENT (different bank)	t_{RRD}	1

NOTE 1 t_{FAW} parameter must be observed as well.

NOTE 2 A bank must be in the idle state with t_{RP} satisfied before it is refreshed.

NOTE 3 t_{RFCpb} parameter must be observed when the first REFpb command completes a set of 16 per-bank refresh operations within an SID and the second REFpb command initiates the next set of 16 per-bank refresh operations within an SID.

NOTE 4 t_{RFCpb} parameter must be observed when the REFpb command completes a set of 16 per-bank refresh operations within an SID and the following RFMpb command operations.

6.3.2.7 Refresh Management (RFM)


Periods of high DRAM activity may require additional refresh commands to protect the integrity of the stored data. The requirement for additional Refresh Management (RFM) is indicated in the RFM field of the DEVICE_ID WDR (see Table 120): RFM = 0 indicates that no additional refresh is needed beyond the refreshes specified in the REFRESH clause of the standard; RFM = 1 indicates additional DRAM refresh management is required.

A suggested implementation of refresh management by the controller monitors ACTIVATE commands issued per bank to the device. This activity can be monitored as a rolling accumulated ACTIVATE (RAA) count. Each ACTIVATE command will increment the RAA count by 1 for the individual bank receiving the ACTIVATE command.

When the RAA count reaches a DRAM vendor specified Initial Management Threshold (RAAIMT), which is indicated by the HBM3 DRAM in the RAAIMT field of the DEVICE_ID WDR (see Table 120), additional refresh management is needed. Executing a refresh management command allows additional time for the HBM3 DRAM to manage refresh internally. The RFM operation can be initiated to all banks with the (all-bank) REFRESH MANAGEMENT (RFMab) command, or to a single bank with the PER-BANK REFRESH MANAGEMENT (RFMpB) command.

The encoding of RFM related commands RFMab and RFMpB is shown in Figure 28. Both half-cycle commands are received on the R[9:0] inputs and latched with the rising CK clock edge. They must be followed either by RNOP, PRECHARGE or PRECHARGE ALL on the falling CK clock edge of the same cycle. Note that a PRECHARGE ALL must be for the other pseudo channel. In case of a PER-BANK REFRESH MANAGEMENT command a PRECHARGE command could be to any bank in the other pseudo channel as well as to a different bank in the same pseudo channel. In all cases the timing requirements for issuing these commands must be met.

An HBM3 DRAM not requiring refresh management will ignore RFMab and RFMpB commands and execute an RNOP command instead.



NOTE 1 BA = Bank Address; PC = Pseudo Channel 0 or 1; SID = Stack ID; V = Valid (H or L)

Figure 28 — Refresh Management (RFMab) and Per-Bank Refresh Management (RFMpB) Commands

6.3.2.7 Refresh Management (RFM) (cont'd)

The RFMab and RFMp_b command scheduling shall meet the same minimum separation requirements as those for the REFab and REFpb commands, respectively (see REFRESH Command (REFab) and PER-BANK REFERSH Command (REFpb) clause). The RFMab command period is the same as the REFab command period (t_{RFCab}), and the RFMp_b command period is the same as the REFpb command period (t_{RFCpb}). The requirement for REFpb commands to be issued to all banks in a rolling fashion does not apply to RFMp_b commands.

A PER-BANK REFRESH command and/or REFRESH MANAGEMENT command must not be issued during t_{RFCpb} succeeding the last PER-BANK REFRESH (REFpb #N) of a single cycle as shown in Figure 26.

When an RFM command is issued to the HBM3 DRAM, the RAA counter in any bank receiving the command can be decremented by the RAAIMT value, down to a minimum RAA value of 0 (no negative or “pull-in” of RFM commands is allowed). Issuing an RFMab command allows the RAA count in all banks to be decremented by the RAAIMT value. Issuing an RFMp_b command allows the RAA count only in the bank selected by {SID[1:0], BA[3:0]} to be decremented by the RAAIMT value.

RFM commands are allowed to accumulate or “postpone”, but the RAA counter shall never exceed a vendor specified RAA Maximum Management Threshold (RAAMMT), which is indicated by the HBM3 DRAM in the RAAMMT field of the DEVICE_ID WDR (see Table 120). If the RAA counter reaches RAAMMT, no additional ACTIVATE commands are allowed to the bank until one or more REF or RFM commands have been issued to reduce the RAA counter below the maximum value.

An RFM command does not replace the requirement for the controller to issue periodic REF commands to the HBM3 DRAM, nor does an RFM command affect internal refresh counters. The RFM commands are bonus time for the HBM3 DRAM to manage refresh internally. However, issuing a REF command also allows decrementing the RAA counter by a value indicated the RAA_CNT_DEC field of the DEVICE_ID WDR (see Table 120). Hence, any periodic REF command issued to the HBM3 DRAM allows the RAA counter of the banks being refreshed to be decremented by that value. Issuing an REFab command allows the RAA count in all banks to be decremented by that value. Issuing an REFpb command allows the RAA count only in the bank selected by {SID[1:0], BA[3:0]} to be decremented by that value.

The per-bank RAA count values may be reset to 0 when the HBM3 DRAM is held in self refresh for at least t_{RAASRF} time. No decrement to the per-bank RAA count values is allowed for entering or exiting self refresh and when the HBM3 DRAM is held in self refresh for less than t_{RAASRF} time.

6.3.2.8 Adaptive Refresh Management (ARFM)

HBM3 DRAMs optionally support a refresh management mode called Adaptive Refresh Management (ARFM). The HBM3 DRAM indicates the support of ARFM via the ARFM bit in the IEEE1500 DEVICE_ID WDR. Since RFM related parameters RAAIMT, RAAMMT and RAADEC are read-only, the ARFM mode allows the controller flexibility to choose additional (lower) RFM threshold settings called “RFM Levels”. The RFM levels permit alignment of the controller-issued RFM commands with the DRAM internal management of these commands. MR8 OP[5:4] select the RFM level as shown in Table 36.

Table 36 — Mode Register Definition for Adaptive RFM Levels

MR8 OP[5:4]	RFM Level	RFM Requirement	RAAIMT	RAAMMT	RAA Decrement per REF Command	Notes
00	Default	Default	RAAIMT	RAAMMT	RAADEC	1
01	Level A	RFM is required	RAAIMT_A	RAAMMT_A	RAADEC_A	
10	Level B	RFM is required	RAAIMT_B	RAAMMT_B	RAADEC_B	
11	Level C	RFM is required	RAAIMT_C	RAAMMT_C	RAADEC_C	

NOTE 1 RAAIMT, RAAMMT and RAADEC values are set by DRAM vendor in the IEEE1500 DEVICE_ID WDR.

The Adaptive RFM mode inherits the RAA counting and decrement attributes of the standard RFM mode, while using the alternate RAAIMT, RAAMMT and RAADEC values for the selected RFM level. Increasing the RFM level results in increased need for RFM commands. Level C is highest RFM level. The alternate RAAIMT, RAAMMT and RAADEC values for RFM level A to C can be retrieved from the corresponding fields of the IEEE1500 DEVICE_ID WDR.

Setting the bits in MR8 OP[5:4] to something other than the default "00" will select one of the RFM levels A, B or C. The host shall decrement the Rolling Accumulated ACT (RAA) count to 0, either with RFM or pending REF commands, prior to making a change to the ARFM level.

It is required to set the same RFM level on all channels of the HBM3 DRAM.

Adaptive RFM also allows an HBM3 DRAM shipped with 'RFM not required' (RFM bit in IEEE1500 DEVICE_ID WDR = 0) to override that initial setting and enable RFM by programming a non-default ARFM level. The HBM3 DRAM internally manages the change to treat the RFM command as an RFM command in this special override case as shown in Table 37.

6.3.2.7 Adaptive Refresh Management (ARFM) (cont'd)

Table 37 — RFM Commands Perceived by HBM3 DRAM

Command	Bit in DEVICE_ID WDR		RFM Level MR8 OP[5:4]	Command Perceived by HBM3 DRAM	Notes	
	RFM	ARFM				
RFMab / RFMpib	0 (RFM not required)	0 (ARFM not supported)	00	RNOP		
			01, 10 or 11	Illegal	1	
		1 (ARFM supported)	00	RNOP		
	1 (RFM required)	0 (ARFM not supported)	01, 10 or 11	RFMab / RFMpib	2	
			00	RFMab / RFMpib		
		1 (ARFM supported)	00, 01, 10 or 11	RFMab / RFMpib		
NOTE 1 These cases are marked as ‘Illegal’ because HBM3 DRAMs not supporting Adaptive RFM do not support the selection of an ARFM level via MR8 OP[:4] and therefore define these bits as RFU which implies that the only supported setting for these bits is 00.						
NOTE 2 Adaptive RFM enables an HBM3 DRAM shipped with RFM = 0 (RFM not required) to override the initial setting and enable Adaptive RFM by programming a non-default RFM level.						

6.3.3 Column Commands

The column commands consist of CNOP, Read, Read with Auto Precharge, Write, Write with Auto Precharge, MRS. The column commands utilize C[7:0] inputs. All column commands are transmitted in a single clock cycle.

6.3.3.1 Column No Operation (CNOP)

The COLUMN NO OPERATION (CNOP) command is a 1-cycle command as shown in Figure 29 and is used to instruct the HBM3 DRAM to perform a NOP as the column command; this prevents unwanted column commands from being registered during idle or wait states. Operations already in progress are not affected.

Parity is evaluated with the CNOP command when the parity calculation is enabled in the Mode Register.

CNOP is assumed for the C[7:0] inputs on subsequent timing diagrams unless other column commands are explicitly shown.





Figure 29 — CNOP Command

6.3.3.2 Read Command (RD, RDA)

A read burst is initiated with a READ command; READ is an one-cycle command received on the column command inputs C[7:0] and latched with the rising and falling CK clock edges as shown in Figure 30. The bank, PC, SID and column addresses are provided with the READ command and auto precharge is either enabled or disabled for that access.

Parity is evaluated with the READ command when CA parity is enabled in the Mode Register.



NOTE 1 BA = Bank Address; CA = Column Address; SID = Stack ID; PC = Pseudo Channel 0 or 1;
NOTE 2 EN AP = Enable Auto Precharge; DIS AP = Disable Auto Precharge

Figure 30 — READ Command

The length of the burst initiated with a READ command is eight. The column address is unique for the burst eight. There is no interruption nor truncation of read bursts.

The read latency (RL) is defined from the rising CK edge on which the READ command is issued to the rising CK edge from which the t_{DQSS} delay is measured, and the RL field of MR2 OP[7:0] (see Table 13). The first valid data is available $RL \times t_{CK} + t_{DQSS} + t_{WDQS2DQ_O} + t_{DQSQ}$ after the rising CK edge when the READ command was issued.

The write strobe(WDQS) is the source to trigger read data (DQ, DBI, ECC, SEV) and the read data strobe. The output drivers are enabled and begin driving either HIGH or LOW nominally two RDQS pulses (odd bytes) and one RDQS pulses (even bytes) prior to the first valid data bit. Bus pre-condition is Low regardless of RDBI enabled and disabled modes on a first READ command.

The output drivers will drive Hi-Z nominally one-half of RDQS pulse or less after the completion of the burst provided no other READ command has been issued.

6.3.3.2 Read Command (RD, RDA) (cont'd)

The write data strobe should be provided with a fixed four-pulse preamble and fixed two-pulse postamble before the read data strobe start to toggle because RDQS is generated from WDQS. The first WDQS edge occurs $(RL-2) \times t_{CK} + t_{DQSS}$. The read data strobe provides a fixed two-pulse preamble and fixed two-pulse postamble; the first RDQS edge occurs $(RL-1) \times t_{CK} + t_{DQSS} + t_{WDQS2DQ_O}$ after the rising CK edge when the READ command was issued. The first data bit of the read burst is synchronized with the third rising edge of the RDQS strobe. Each subsequent data-out is edge-aligned with the data strobe. Timings for the data strobe are measured relative to the cross point of RDQS_t and its complement, RDQS_c.

6.3.3.2.1 Clock to Write Data Strobe Timings

The Write Data Strobe(WDQS) to Clock(CK) relationship is shown in Figure 31. Related parameters:

- t_{DQSS} (min/max) describes the allowed range for rising or falling WDQS edge relative to CK.
- t_{DQSS} is the actual position of a WDQS edge relative to CK.
- t_{WQSH} describes the WDQS HIGH pulse width
- t_{WQSL} describes the WDQS LOW pulse width

6.3.3.2.2 Write Data Strobe and Data Out Timings

The Write Data Strobe to Read Data Strobe(RDQS) relationship is shown in Figure 31. Related parameters:


- $t_{WDQS2DQ_O}$ (min/max) describes the allowed range for a rising or falling RDQS edge relative to WDQS.
- $t_{WDQS2DQ_O}$ is the actual position of a RDQS edge relative to WDQS.
- t_{QSH} describes the RDQS HIGH pulse width.
- t_{QSL} describes the RDQS LOW pulse width.
- t_{LZ} (min/max) describe the allowed range for the data output Hi-Z to low impedance transition relative to WDQS.
- t_{HZ} (min/max) describe the allowed range for the data output low impedance to Hi-Z transition relative to WDQS.

6.3.3.2.3 Read Data Strobe and Data Out Timings

The Read Data Strobe(RDQS) to Data Out(DQ, ECC, SEV, DBI) relationship is shown in Figure 31. Related parameters:

- t_{DQSQ} describes the latest valid transition of any associated DQ or ECC or SEV or DBI pin for both rising and falling RDQS edges.
- t_{QH} describes the earliest invalid transition of any associated DQ or ECC or SEV or DBI pin for both rising and falling RDQS edges.
- t_{QW} describes the valid data output window of any associated DQ or ECC or SEV or DBI pin for both rising and falling RDQS edges.
- t_{DQ2DQ} describes Read DQ to DQ skew of any associated DQ or ECC or SEV or DBI pin for both rising and falling RDQS edges.

6.3.3.2.3 Read Data Strobe and Data Out Timings (cont'd)



NOTE 1 twdqs2dq_o may span multiple clock periods.

NOTE 2 A burst length of 8 is shown.

NOTE 3 Early/late data transition of a DQ or SEV or ECC or DBI can vary within a burst.

NOTE 4 Da...a+7 = data-out for READ command a.

D = last data-out from previous READ command (not if first READ after reset, MRS, self refresh or write-to-read).


NOTE 5 twpre2 = Read preamble for WDQS, twpst2 = Read postamble for WDQS

NOTE 6 trpre = Read preamble for RDQS, trpst = Read postamble for RDQS

Figure 31 — Clock to RDQS and Data Out Timings

6.3.3.2.4 Read Operation

Single read bursts are shown in Figure 32 for BL=8.



NOTE 1 BAx = bank address x; CAA = column address a.

NOTE 2 RL = 6 is shown as an example.

NOTE 3 DATA = DQ[31:0]. DBI[3:0], ECC[1:0]. SEV[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2]. SEV[3:2] for PC1.
WDQS_t/_c is WDQS0_t/_c for PC0, and WDQS1_t/_c for PC1.

RDQS_t/_c is RDQS0_t/_c for PC0, and RDQS1_t/_c for PC1.

NOTE 4 Da...a+7 = data-out for READ command a.

D = last data-out from previous READ command (not if first REA D after reset, MRS, self refresh or write-to-read).


NOTE 5 twdqs2dq_o = 0 and nominal tqw is shown for illustration purposes.

NOTE 6 RDBI could be on or off and is controlled with MRO OP0.

Figure 32 — Single Read Burst with BL=8

6.3.3.2.4 Read Operation (cont'd)

Data from any read burst may be concatenated with data from a subsequent READ command. A continuous flow of data can be maintained as shown in Figure 33. The first data element from the new burst follows the last element of a completed burst. The new READ command should be issued after the previous READ command according to the t_{CCD} timing. If that READ command is to another idle bank then an ACTIVATE command must precede the READ command and t_{RCDRD} also must be met.



NOTE 1 BAx = bank address x; CAa,b = column address a,b.

NOTE 2 RL = 6 is shown as an example.

NOTE 3 DATA = DQ[31:0].DBI[3:0], ECC[1:0].SEV[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2].SEV[3:2] for PC1.
WDQS_t/_c is WDQS0_t/_c for PC0, and WDQS1_t/_c for PC1.

RDQS_t/_c is RDQS0_t/_c for PC0, and RDQS1_t/_c for PC1.

NOTE 4 Da, Da+1..Da+7, Db, Db+1..Db+7 = output data for READ commands a,b.

D = last data-out from previous READ command (not if first READ after reset, MRS, self refresh or write-to-read).

NOTE 5 twqs2dq_o = 0 and nominal tqw is shown for illustration purposes.


NOTE 6 RDBI could be on or off and is controlled with MR0 OP0.

Figure 33 — Seamless Read Bursts with BL=8

6.3.3.2.4 Read Operation (cont'd)

Examples of non-seamless read bursts are shown in Figure 34 for $t_{CCD}=3$ and Figure 35 for $t_{CCD}=4$. The RDQS pulse at clock edge T8 in Figure 34 represents the read postamble of the first read burst as well as the read preamble of the second read burst. The chosen t_{CCD} value leads to a continuous series of RDQS pulses over both read bursts, and the data bus does not return to Hi-Z between the read bursts (for odd bytes), and the last data out of the first read burst ($Da+7$) is re-driven at the RDQS at clock edge T8+a half (for even bytes) preceding the second read burst.

With $t_{CCD}=4$ as shown in Figure 35 the timing of each of the two read bursts is identical to a single read burst as shown in Figure 32. The data bus returns to Hi-Z between the read bursts, and the last data out of the first read burst ($Da+7$) is re-driven at the RDQS pulse at clock edge T9 (for odd bytes) and T9+a half (for even bytes) preceding the second read burst.



NOTE 1 BAx = bank address x; CAa,b = column address a,b.

NOTE 2 RL = 6, $t_{CCD} = 3$ are shown as an example.

NOTE 3 DATA = DQ[31:0], DBI[3:0], ECC[1:0], SEV[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2], SEV[3:2] for PC1. WDQS_t/_c is WDQS0_t/_c for PC0, and WDQS1_t/_c for PC1.

RDQS_t/_c is RDQS0_t/_c for PC0, and RDQS1_t/_c for PC1.

NOTE 4 Da, Da+1..Da+7, Db, Db+1..Db+7 = output data for READ commands a,b.


D = last data-out from previous READ command (not if first READ after reset, MRS, self refresh or write-to-read).

NOTE 5 twqs2dq_o = 0 and nominal tqw is shown for illustration purposes.

NOTE 6 RDBI could be on or off and is controlled with MRO OP0.

Figure 34 — Non-Seamless Read Bursts with $t_{CCD}=3$ and $BL=8$

6.3.3.2.4 Read Operation (cont'd)



NOTE 1 BAx = bank address x; CAa,b = column address a,b.

NOTE 2 RL = 6, tCCD = 4 are shown as an example.

NOTE 3 DATA = DQ[31:0], DBI[3:0], ECC[1:0], SEV[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2], SEV[3:2] for PC1.
WDQS_{t/c} is WDQS0_{t/c} for PC0, and WDQS1_{t/c} for PC1.

RDQS_{t/c} is RDQS0_{t/c} for PC0, and RDQS1_{t/c} for PC1.

NOTE 4 Da, Da+1..Da+7, Db, Db+1..Db+7 = output data for READ commands a,b.

D = last data-out from previous READ command (not if first READ after reset, MRS, self refresh or write-to-read).


NOTE 5 twdqs2dq_o = 0 and nominal tqw is shown for illustration purposes.

NOTE 6 RDBI could be on or off and is controlled with MRO OP0.

Figure 35 — Non-Seamless Read Burst with tCCD=4 and BL=8

6.3.3.2.4 Read Operation (cont'd)

A WRITE can be issued any time after a READ command as long as the bus turnaround time t_{RTW} is met as shown in Figure 36. If that WRITE command is to another idle bank, then an ACTIVATE command must precede the WRITE command and t_{RCDWR} also must be met.



NOTE 1 BAx = bank address x; CAa = column address a.

NOTE 2 RL=6 and WL=5 are shown as examples.

NOTE 3 DATA = DQ[31:0], DBI[3:0], ECC[1:0], SEV[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2], SEV[3:2] for PC1. WDQS_{t/c} is WDQS0_{t/c} for PC0, and WDQS1_{t/c} for PC1.

RDQS_{t/c} is RDQS0_{t/c} for PC0, and RDQS1_{t/c} for PC1.

NOTE 4 Da...a+7 = data-out for READ command a.

D = last data-out from previous READ command (not if first READ after re set, MRS, self refresh or write-to-read).

NOTE 5 Db...b+7 = data-in for WRITE command b.

NOTE 6 twdqs2dq_o = 0 and nominal tqw is shown for illustration purposes.


NOTE 7 trtw is not a device limit but determined by the system bus turnaround time.

NOTE 8 RDBI and WDBI could be on or off. RDBI is controlled with MR0 OP0, and WDBI is controlled with MR0 OP1.

Figure 36 — Read to Write

6.3.3.2.4 Read Operation (cont'd)

A PRECHARGE can be issued t_{RTP} after the READ command as shown in Figure 37. After the PRECHARGE command, a subsequent ACTIVATE command to the same bank cannot be issued until t_{RP} is met.



NOTE 1 BAx = bank address x; CAa = column address a.

NOTE 2 RL = 6 is shown as an example.

NOTE 3 DATA = DQ[31:0], DBI[3:0], ECC[1:0], SEV[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2], SEV[3:2] for PC1. WDQS_{t_c} is WDQS0_{t_c} for PC0, and WDQS1_{t_c} for PC1.

RDQS_{t_c} is RDQS0_{t_c} for PC0, and RDQS1_{t_c} for PC1.

NOTE 4 Da...a+7 = data-out for READ command a.

D = last data-out from previous READ command (not if first READ after reset, MRS, self refresh or write-to-read).

NOTE 5 twdqs2dq_o = 0 and nominal tqw is shown for illustration purposes.

NOTE 6 trtp = 1 nCK is shown as an example. trtp = trtpl when bank groups are enabled and the PRECHARGE command accesses the same bank; otherwise trtp = trtps.

NOTE 7 RDBI could be on or off and is controlled with MRO OP0.

Figure 37 — Read to Precharge

6.3.3.2.5 Per-Signal-Group for Read De-Skew

The internal WDQS clock tree is optimized for lowest signal skew among signals within a group as outlined in Table 38 . The grouping is aligned with the physical location of signals in a DWORD (see HBM3 Ballout) with no lane being repaired.

Each group contains 6 to 8 signals. The internal WDQS clock tree however compensates the different loading by e.g., adding dummy loads. The per-group de-skew is also deterministic and not frequency dependent. A larger signal skew should be expected between different groups. A per-group de-skew is recommended to achieve the largest signaling margin for read data.

In this context, RDQS_t and RDQS_c are treated as regular out signals within group T4.


Table 38 — Signal Groups for Read Data De-Skew

Group	Signal List (DWORD0)	Signal List (DWORD1)
T0	DQ0, DQ1, DQ2, DQ8, DQ9, DQ10, ECC0, ECC1	DQ32, DQ33, DQ34, DQ40, DQ41, DQ42, ECC2, ECC3
T1	DQ3, DQ4, DQ11, DQ12, RD0, DPAR0	DQ35, DQ36, DQ43, DQ44, RD2, DPAR1
T2	DQ5, DQ6, DQ7, DQ13, DQ14, DQ15, DBI0, DBI1	DQ37, DQ38, DQ39, DQ45, DQ46, DQ47, DBI4, DBI5
T3	DQ16, DQ17, DQ18, DQ24, DQ25, DQ26, SEV0, SEV1	DQ48, DQ49, DQ50, DQ56, DQ57, DQ58, SEV2, SEV3
T4	DQ19, DQ20, DQ27, DQ28, RD1, RDQS0_t, RDQS0_c	DQ51, DQ52, DQ59, DQ60, RD3, RDQS1_t, RDQS1_c
T5	DQ21, DQ22, DQ23, DQ29, DQ30, DQ31, DBI2, DBI3	DQ53, DQ54, DQ55, DQ61, DQ62, DQ63, DBI6, DBI7

6.3.3.3 Write Command (WR, WRA)

A Write burst is initiated with a WRITE command. WRITE is a one-cycle command received on the column command inputs C[7:0] and latched with the rising and falling CK clock edges as shown in Figure 38. The bank, PC, SID and column addresses are provided with the WRITE command and auto precharge is either enabled or disabled for that access.

Parity is evaluated with the WRITE command when CA parity is enabled in MR0 (Table 11).



NOTE 1 BA = Bank Address; CA = Column Address; SID = Stack ID; PC = Pseudo Channel 0 or 1;
NOTE 2 EN AP = Enable Auto Precharge; DIS AP = Disable Auto Precharge

Figure 38 — Write Command

The length of the burst initiated with a WRITE command is eight. The column address is unique for this burst of eight. There is no interruption nor truncation of write bursts.

The write latency (WL) is defined from the rising CK edge on which the WRITE command is issued to the rising CK edge from which the t_{DQSS} delay is measured, and the WL field of MR1 OP[4:0]. The first valid data must be driven $WL \times t_{CK} + t_{DQSS}$ after the rising CK edge when the WRITE command was issued.

The write data strobe provides a fixed two-pulse preamble and two-pulse postamble; the first WDQS edge must be driven $(WL-1) \times t_{CK} + t_{DQSS}$ after the rising CK edge when the WRITE command was issued.

The HBM3 uses an un-matched WDQS-DQ path, so WDQS must stay within t_{DQSS} and the DQ can be trained to stay center aligned to the WDQS with satisfying t_{DIVW}. The DQ-data must be held for t_{DIVW} (data input valid window) and the WDQS can be periodically trained to stay center aligned to DQ in the t_{DIVW} window to compensate for timing changes due to temperature and voltage variation. Burst data is captured by the HBM on successive edges of WDQS until the burst length is complete. Pin timings for the data strobe are measured relative to the cross point of WDQS_t and its complement, WDQS_c.

6.3.3.3.1 Clock to Write Data Strobe Timings

The clock to write data strobe (WDQS) relationship is shown in Figure 39. Related parameters:

- $t_{DQSS}(\min/\max)$ describes the allowed range for a rising or falling WDQS edge relative to CK.
- t_{DQSS} is the actual position of a WDQS edge relative to CK.
- t_{WQSH} describes the WDQS HIGH pulse width.
- t_{WQSL} describes the WDQS LOW pulse width.

6.3.3.3.2 Write Data Strobe and Data In Timings

The write data strobe (WDQS) to data in relationship is shown in Figure 39. Related parameters:

- $t_{WDQS2DQ_I}$ describes the allowed range for a DQ to a rising or falling WDQS edge.
- t_{DIVW} describes allowed range for receiver minimum setup/hold time for sampling at DQ.
- V_{DIVW} describes allowed range for receiver voltage peak to peak size.





Figure 39 — Clock to WDQS and Data Input Timings

6.3.3.3.3 Write Operation

Single write bursts are shown in Figure 40.



NOTE 1 BAx = bank address x; CAa = column address a.

NOTE 2 WL = 4 is shown as an example.

NOTE 3 DATA = DQ[31:0], DBI[3:0], ECC[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2] for PC1.
DPAR = DPAR 0 for PC0 and DPAR1 for PC1 (if applicable).

WDQS_t_c is WDQS0_t_c for PC0, and WDQS1_t_c for PC1..

NOTE 4 Da...Da+7 = data-in for WRITE command a.


NOTE 5 tqss = 0 is shown for illustration purposes.

NOTE 6 WDBI could be on or off and is controlled with MR0 OP1.

Figure 40 — Single Write Burst with BL=8

6.3.3.3.3 Write Operation (cont'd)

Data from any write burst may be concatenated with data from a subsequent WRITE command. A continuous flow of data can be maintained as shown in Figure 41. The first data element from the new burst follows the last element of a completed burst. The new WRITE command should be issued after the previous WRITE command according to the t_{CCD} timing. If that WRITE command is to another idle bank then an ACTIVE command must precede the WRITE command and t_{RCDWR} also must be met.



NOTE 1 BAx = bank address x; CAa = column address a.

NOTE 2 WL = 4 is shown as an example.

NOTE 3 $t_{CCD} = t_{CCDS}$ when bank groups is disabled or the second WRITE is to a different bank group, otherwise $t_{CCD}=t_{CCDL}$.

NOTE 4 DATA = DQ[31:0], DBI[3:0], ECC[1:0] for PC0 and DQ[63:32], DBI[7:4], ECC[3:2] for PC1.

DPAR = DPAR0 for PC0 and DPAR1 for PC1 (if applicable).

WDQS_t/_c is WDQS0_t/_c for PC0 and WDQS1_t/_c for PC1.

NOTE 5 Da...Da+7 = data-in for WRITE command a, Db...Db+7 = data-in for WRITE command b


NOTE 6 $t_{DQSS} = 0$ And $t_{CCDS} = 2$ are shown for illustration purposes.

NOTE 7 WDBI could be on or off and is controlled with MR0 OP1.

Figure 41 — Seamless Write Bursts with BL=8

6.3.3.3.3 Write Operation (cont'd)

Examples of non-seamless write bursts are shown in Figure 42.



NOTE 1 BAx = bank address x; CAa = column address a.

NOTE 2 WL = 4 is shown as an example.

NOTE 3 tCCD = tCCDS when bank groups is disabled or the second WRITE is to a different bank group, otherwise tCCD=tCCDL.

NOTE 4 DATA = DQ[31:0], DBI[3:0], ECC[1:0] for PC0 and DQ[63:32], DBI[7:4], ECC[3:2] for PC1.

DPAR = DPAR0 for PC0 and DPAR1 for PC1 (if applicable).

WDQS_t/_c is WDQS0_t/_c for PC0, and WDQS1_t/_c for PC1.

NOTE 5 Da..Da+7 = data-in for WRITE command a, Db..Db+7 = data-in for WRITE command b.


NOTE 6 tDQSS = 0 And tCCDS = 3 are shown for illustration purposes.

NOTE 7 WDBI could be on or off and is controlled with MR0 OP1.

Figure 42 — Non-Seamless Write Bursts

6.3.3.3.3 Write Operation (cont'd)

A READ can be issued any time after a WRITE command as long as the bus turnaround time t_{WTR} is met as shown in Figure 43. If that READ command is to another idle bank, then an ACTIVATE command must precede the READ command and t_{RCDRD} also must be met. The bus is preconditioned for the first read burst by being driven LOW two RDQS pulses (Odd bytes) and one RDQS pulse (Even bytes) prior to the first valid data element of the read burst regardless whether RDBI is enabled in MR0 or not.



NOTE 1 $\text{BAX} = \text{bank address } x; \text{CAa,b} = \text{column address a,b.}$

NOTE 2 $WL = 4$ and $RL = 6$ are shown as examples.

NOTE 3 DATA = DQ[31:0], DBI[3:0], ECC[1:0], SEV[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2], SEV[3:2] for PC1.
DPAR = DPAR0 for PC0 and DPAR1 for PC1 (if applicable).

WDQS_{t/c} is WDQS0_{t/c} for PC0 and WDQS1_{t/c} for PC1.

RDQS_{t/c} is RDQS0_{t/c} for PC0 and RDQS1_{t/c} for PC1.

NOTE 4 Da...Da+7 = data-in for WRITE command b. Db...Db+7 = data-out for READ command a.

NOTE 5 $t_{WDQS2DQ_O}$, $t_{DQSS} = 0$ and nominal t_{QW} is shown for illustration purposes.

NOTE 6 $t_{WTR} = t_{WTRL}$ when bank groups is enabled and both WRITE and READ access banks in the same bank group, otherwise $t_{WTR} = t_{WTRS}$.


NOTE 7 WDBI could be on or off and is controlled with MR0 OP1.

NOTE 8 READ operation shown with RDBI enabled. RDBI is enabled/disabled with MR0 OPO.

Figure 43 — Write to Read

6.3.3.3.3 Write Operation (cont'd)

The write recovery time t_{WR} must have elapsed before a PRECHARGE command can be issued to that bank as shown in Figure 44; the t_{WR} interval begins with the completion of the write burst at $WL + BL/4$ clock cycles after the WRITE command was issued. Also, t_{RAS} must be met when the PRECHARGE is issued. After the PRECHARGE command, a subsequent ACTIVATE command to the same bank cannot be issued until t_{RP} is met.



NOTE 1 BAx = bank address x; CAA = column address a.

NOTE 2 WL = 4 is shown as an example.

NOTE 3 DATA = DQ[31:0], DBI[3:0], ECC[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2] for PC1.
DPAR = DPAR0 for PC0 and DPAR1 for PC1 (if applicable).

WDQS_{t/c} is WDQS0_{t/c} for PC0 and WDQS1_{t/c} for PC1

NOTE 4 Da...Da+7 = data-in for WRITE command a.

NOTE 5 tDQSS = 0 is shown for illustration purposes.

NOTE 6 WDBI could be on or off and is controlled with MR0 OP1.

Figure 44 — Write to Pre-charge

6.3.3.3.4 Per-Signal-Group for Write De-Skew

The internal WDQS clock tree is optimized for lowest signal skew among signals within a group as outlined in Table 39. The grouping is aligned with the physical location of signals in a DWORD (see HBM3 Ballout) with no lane being repaired.

Each group contains 5 to 8 signals. The internal WDQS clock tree however compensates the different loading by e.g., adding dummy loads. The per-group de-skew is also deterministic and not frequency dependent. A larger signal skew should be expected between different groups. A per-group de-skew is recommended to achieve the largest signaling margin for write data.


Table 39 — Signal Groups for Write Data De-Skew

Group	Signal List (DWORD0)	Signal List (DWORD1)
T0	DQ0, DQ1, DQ2, DQ8, DQ9, DQ10, ECC0, ECC1	DQ32, DQ33, DQ34, DQ40, DQ41, DQ42, ECC2, ECC3
T1	DQ3, DQ4, DQ11, DQ12, RD0, DPAR0	DQ35, DQ36, DQ43, DQ44, RD2, DPAR1
T2	DQ5, DQ6, DQ7, DQ13, DQ14, DQ15, DBI0, DBI1	DQ37, DQ38, DQ39, DQ45, DQ46, DQ47, DBI4, DBI5
T3	DQ16, DQ17, DQ18, DQ24, DQ25, DQ26	DQ48, DQ49, DQ50, DQ56, DQ57, DQ58
T4	DQ19, DQ20, DQ27, DQ28, RD1	DQ51, DQ52, DQ59, DQ60, RD3
T5	DQ21, DQ22, DQ23, DQ29, DQ30, DQ31, DBI2, DBI3	DQ53, DQ54, DQ55, DQ61, DQ62, DQ63, DBI6, DBI7

6.3.3.4 Mode Register Set (MRS) Command

The MODE REGISTER SET (MRS) command is a 1-cycle command as shown in Figure 45 and is used to load the Mode Registers of the HBM3 DRAM. The command is received on the column command inputs C[7:0] and requires an RNOP command on the row command inputs R[9:0].

Inputs MA[4:0] select one of the sixteen Mode Registers, and inputs OP[7:0] determine the opcode to be loaded. Refer to the Mode Registers clause for the register definition.



NOTE 1 MA = Mode Register Address; OP = Opcode; V = Valid (H or L)

Figure 45 — Mode Register Set Command (MRS)

The MODE REGISTER SET (MRS) command can only be issued when all banks are idle, the time t_{RDMRS} from a preceding READ command has elapsed, and the time t_{WRMRS} from a preceding WRITE command has elapsed. The MRS command cycle time t_{MRD} is required to complete the write operation to the Mode Register and is the minimum time required between two MRS commands. The MRS command to Non-MRS command delay, t_{MOD} , is required by the HBM3 DRAM to update the features, and is the minimum time required from an MRS command to a non-MRS command excluding RNOP and CNOP.

Parity is evaluated with the MODE REGISTER SET command when CA parity has already been enabled in the Mode Register prior to this MODE REGISTER SET command. When CA parity is enabled by a MODE REGISTER SET command, the HBM3 DRAM requires all subsequent commands including RNOP and CNOP to be issued with correct parity until t_{MOD} has expired for the MODE REGISTER SET command that disables CA parity.

6.3.3.4 Mode Register Set (MRS) Command (cont'd)




Figure 46 — Mode Register Set Timings

6.3.4 Power-Mode Commands

6.3.4.1 Power-Down (PDE, PDX)

HBM3 devices enter Power-down with a Power-down Entry command as shown in Figure 47.




Figure 47 — Power-Down Entry Command

Power-down Entry must not be issued when read or write operations are in progress on either PC. A read operation is completed when the last data element including parity (when enabled) and RDQS postamble has been transmitted on the outputs. A write operation is completed when the last data element including parity (when enabled) has been written to the memory array with t_{WR} satisfied; for writes with auto-precharge, the number of clock cycles programmed in the mode register for WR must have elapsed instead.

Power-down Entry can be issued while any other operations such as row activation, precharge, auto precharge, or refresh are in progress, but the power-down IDD specification will not apply until such operations are complete.

If power-down occurs when all banks are idle, this mode is referred to as precharge power-down; if power-down occurs when there is a row active in any bank, this mode is referred to as active power-down.

To ensure that there is enough time to internally process the power-down entry, POWER DOWN ENTRY and CNOP commands have to be maintained for t_{CPDED} period. Also, the CK clock must be held stable for t_{CPDDE} cycle.

6.3.4.1 Power-Down (PDE, PDX) (cont'd)

Once t_{CPDED} and t_{CKPDE} have been met, the pins shall have the following states (see Table 40):

- The RESET_n and R0 receiver remains active; RESET_n = HIGH and R0 = LOW must be maintained to keep the HBM3 DRAM in power-down;
- The CK clock receiver remains active. The clock may be stopped with CK_t and CK_c being driven to static LOW and HIGH levels, respectively; in that case the clock must be stable again with $t_{CH(min)}$ and $t_{CL(min)}$ satisfied at least t_{CKPDX} cycles prior to power-down exit;
- WDQS_t = static LOW and WDQS_c = static HIGH levels must be maintained, respectively;
- RDQS_t and RDQS_c continue driving static LOW and HIGH levels, respectively;
- AERR, DERR continue driving static LOW levels;
- TEMP and CATTRIP continue driving valid HIGH or LOW levels;
- All other input and output buffers are deactivated.

No refresh operations are performed in power-down mode. The maximum duration in power-down mode is limited by the refresh requirements of the device.

While in power-down the device will maintain the internal DBI state for the DBI(ac) calculation when DBI is enabled in the Mode Register. The device will also continue driving RDQS_t and RDQS_c to LOW and HIGH static levels, respectively, and TEMP and CATTRIP to valid HIGH or LOW levels.


Power-down is synchronously exited when R0 is registered HIGH (in conjunction with CNOP commands). A valid executable command may be applied t_{XP} cycles later. The minimum power-down duration is specified by t_{PD} .

If CA parity is enabled, parity is evaluated for the POWER-DOWN ENTRY command. The HBM3 device requires PDE and CNOP commands with valid parity for the entire t_{CPDED} period, while it will suspend parity checking after power-down entry and drive AERR to a static LOW. DERR remains LOW as there are no data bursts in progress at this time.

Parity is not evaluated for the POWER-DOWN EXIT command. The HBM3 device requires RNOP and CNOP commands with valid parity for the entire t_{XP} period, while within t_{XP} period it will resume parity checking and indicating parity errors on AERR. DERR remains LOW as there are no data bursts in progress at this time.

Power-down is entered when R[3:0] are registered HIGH, LOW, HIGH, LOW along with CNOP commands as shown in Figure 48. PDE and CNOP commands are required for t_{CPDED} period after power-down entry.

6.3.4.1 Power-Down (PDE, PDX) (cont'd)



- NOTE 1 Only PDE and CNOP commands are allowed during tCPDED period. PDX, RNOP and CNOP commands are allowed during tXP periods.
- NOTE 2 Write bursts must have been completed with tWRPDE (or tWRAPDE in the case of write with auto pre-charge) satisfied prior to power-down entry.
- NOTE 3 Read bursts must have been completed with tRPDPE satisfied prior to power-down entry.
- NOTE 4 Address inputs are "Don't Care" for power-down entry and exit.
- NOTE 5 AERR, DERR are driven LOW when parity check is suspended during power-down. Signals are shown with tPARAC=0 and tPARDQ=0 for illustration purpose.
- NOTE 6 The CK clock may be stopped during power-down as shown, or toggling.
- NOTE 7 tCKPDE means valid CK clocks required after first power-down entry.
- NOTE 8 tCKPDX means valid CK clocks required before power-down exit.
- NOTE 9 Second PDE and third PDE after first PDE are treated as a RNOP and does not issue a power down entry.


Figure 48 — Power-Down Entry and Exit

6.3.4.1 Power-Down (PDE, PDX) (cont'd)

Table 40 — Pin State Description in Power Down

Pin Group	Pin State
RESET_n	H
CK_t, CK_c	L/H or Toggling
R0	L
R[9:1]	X
C[7:0]	X
APAR, ARFU	X
AERR	L
DQ, DBI, ECC, SEV, DPAR	X
WDQS_t, WDQS_c	L/H
RDQS_t, RDQS_c	L/H
DERR	L
TEMP, CATTRIP	V

NOTE 1 For the pin state description, the following definitions apply:
a) "L" is defined as "LOW", and "H" is defined as "HIGH"
b) "X" is defined as "Don't Care", and "V" is defined as "Valid"




NOTE 1 PRE indicates the internal auto-precharge for RDA commands.

NOTE 2 BL = 8, RL = 6 and PL = 1 are shown as examples.

NOTE 3 R0 must be used for command except for PDE or address until the end of the read burst operation.

Figure 49 — READ or READ with Auto Precharge to Power-Down Entry Timing

6.3.4.1 Power-Down (PDE, PDX) (cont'd)



NOTE 1 PRE indicates the internal auto-precharge for WRA commands.

NOTE 2 BL = 8, WL = 4 and PL = 1 are shown as examples.

NOTE 3 R0 must be used for address until the end of the write burst operation.

NOTE 4 twr is the analog value used with WR commands.

NOTE 5 nWR is the number of clock cycles programmed for WR in the Mode Register and used with WRA commands.

Figure 50 — WRITE or WRITE with Auto Precharge to Power-Down Entry Timing





Figure 51 — MODE REGISTER SET to Power-Down Entry Timing

6.3.4.1 Power-Down (PDE, PDX) (cont'd)



NOTE 1 Upon power-down entry the clock must be kept active for the number of clock cycles programmed for RAS in the Mode Register.

Figure 52 — ACTIVATE to Power-Down Entry Timing




Figure 53 — REFRESH or PER-BANK REFRESH to Power-Down Entry Timing




Figure 54 — PRECHARGE to Power-Down Entry Timing

6.3.4.2 Self Refresh (SRE, SRX)

Self refresh can be used to retain data in the HBM3 device, even if the rest of the system is powered down. When in the self refresh mode, the HBM3 device retains data without external clocking. The command is received on the row command inputs R[9:0] as shown in Figure 55 and requires a CNOP command on the column command inputs C[7:0].




Figure 55 — Self-Refresh Entry Command

Self refresh entry is only allowed when all banks in both pseudo channels are precharged with tRP satisfied, the last data elements from a preceding READ command have been pushed out ($t_{RD SRE}$), or t_{MOD} from a preceding MODE REGISTER SET command is met. PDE and CNOP commands are required after entering self refresh mode until t_{CPDED} is met.

Once the SELF REFRESH-ENTRY command is registered, R0 must be held LOW to keep the device in self refresh mode. For proper self refresh operation, all power supply pins (VDDC, VDDQ, VPP, VDDQL) must be at valid levels. The HBM3 device initiates a minimum of one internal refresh within t_{CKSR} period once it enters self refresh mode.

The clocks are internally disabled during self refresh operation to save power. The minimum time that the HBM3 device must remain in self refresh mode is t_{CKSR} . The user may halt the external clock or change the external clock frequency t_{CKSRE} after self refresh entry is registered. However, the clock must be restarted and stable t_{CKSRX} before the device can exit self refresh operation.

To ensure that there is enough time to internally process the self refresh entry, POWER DOWN ENTRY and CNOP commands have to be maintained for t_{CPDED} period following the SELF REFRESH ENTRY command. Also, the CK clock must be held stable for t_{CKSRE} cycle.

Once t_{CPDED} and t_{CKSRE} have been met, the pins shall have the following states (see Table 41):

6.3.4.2 Self Refresh (SRE, SRX) (cont'd)

- The RESET_n and R0 receiver remains active; RESET_n = HIGH and R0 = LOW must be maintained to keep the HBM3 DRAM in self refresh;
- The CK clock receiver is disabled; the clock may be stopped, or the clock frequency may be changed; MRS required to set after t_{XSMRST} in case of frequency changed; the clock must be stable again with t_{CH(min)} and t_{CL(min)} satisfied at least t_{CCLKSRX} cycles prior to self refresh exit;
- WDQS_t = static LOW and WDQS_c = static HIGH levels must be maintained, respectively;
- RDQS_t and RDQS_c continue driving static LOW and HIGH levels, respectively;
- AERR, DERR continue driving static LOW levels;
- TEMP and CATTRIP continue driving valid HIGH or LOW levels;
- All other input and output buffers are deactivated.


If CA parity is enabled, parity is evaluated for the SELF REFRESH ENTRY command. The HBM3 device requires PDE and CNOP commands with valid parity for the entire t_{CPDED} period, while it will suspend parity checking after self refresh entry and drive AERR to a static LOW. DERR remains LOW as there are no data bursts in progress at this time.

Parity is not evaluated for the SELF REFRESH EXIT command. The HBM3 device requires RNOP and CNOP commands with valid parity for the entire t_{XS} period, while within t_{XS} period it will resume parity checking and indicating parity errors on AERR. DERR remains LOW as there are no data bursts in progress at this time.

The procedure for exiting self refresh requires a sequence of events. First, the CK clock must be stable prior to R0 going back HIGH. A delay of at least t_{XS} must be satisfied before a valid command can be issued to the device to allow for completion of any internal refresh in progress.

Upon exit from self refresh, the HBM3 device can be put back into self refresh mode after waiting at least t_{XS} period.

6.3.4.2 Self Refresh (SRE, SRX) (cont'd)



- NOTE 1 Only PDE and CNOP commands are allowed during t_{CPDED} period. Only RNOP and CNOP commands are allowed during t_{XS} periods, except for MRS commands which are allowed t_{XSMRS}(or t_{XMSRF} when in case of frequency changed), t_{XSMRSF} can be required longer than t_{XS} after self-refresh exit.
- NOTE 2 Write bursts must have been completed with t_{RP} satisfied prior to self-refresh entry.
- NOTE 3 Read bursts must have been completed with t_{RDSSRE} satisfied prior to self-refresh entry.
- NOTE 4 Address inputs are "Don't Care" for self-refresh entry and exit.
- NOTE 5 AERR, DERR are driven LOW when parity check is suspended during self-refresh. Signals are shown with t_{PARAC}=0 and t_{PARDQ}=0 for illustration purpose.
- NOTE 6 PDE commands after SRE are treated as a RNOP and does not issue a power down entry.

Figure 56 — Self-Refresh Entry and Exit

6.3.4.2 Self Refresh (SRE, SRX) (cont'd)

Table 41 — Pin State Description in Self Refresh

Pin Group	Pin State
RESET_n	H
CK_t, CK_c	X
R0	L
R[9:1]	X
C[7:0]	X
APAR, ARFU	X
AERR	L
DQ, DBI, ECC, SEV, DPAR	X
WDQS_t, WDQS_c	L/H
RDQS_t, RDQS_c	L/H
DERR	L
TEMP, CATTRIP	V
NOTE 1 For the pin state description, the following definitions apply: a) "L" is defined as "LOW", and "H" is defined as "HIGH" b) "X" is defined as "Don't Care", and "V" is defined as "Valid"	

6.4 Parity

6.4.1 Command/Address Parity

The HBM3 DRAM includes a command/address parity checking function controlled by the CAPAR bit in MR0 OP6. The function is disabled by default. The APAR input and AERR output are associated with the function. APAR is enabled only when the function is enabled.

If enabled, the parity is calculated every CK clock cycle separately on both the rising and falling CK clock edges over input signals R[9:0], C[7:0], ARFU and APAR as summarized in Table 42. The AERR output indicates whether a parity error has occurred or not on either the rising or falling CK clock edge (or both edges). The HBM3 DRAM executes commands regardless of command/address parity errors.


Table 42 — Command/Address Parity Function Table

INPUTS	Sum of Inputs Received HIGH	AERR
R[9:0], C[7:0], ARFU, APAR	Even	LOW
	Odd	HIGH

NOTE 1 See Command Truth Tables for command and device state exceptions.

The HBM3 DRAM may begin to check parity on the next clock cycle following the MODE REGISTER SET command that enables the parity checking function; it will have the parity check enabled latest when t_{MOD} has expired after that MODE REGISTER SET command. The HBM3 DRAM therefore requires all subsequent commands including RNOP and CNOP to be issued with correct parity until when t_{MOD} has expired for the MODE REGISTER SET command that disables the parity calculation. See also the Power-Down and Self Refresh clauses. AERR is driven LOW by the HBM3 DRAM at reset.

For every parity error, AERR is driven HIGH for 1 t_{CK}, t_{PARAC} after the corresponding cycle of the error inputs. In the case of consecutive errors, the AERR signal will stay HIGH during the next cycle. The parity function should not be disabled within t_{PARAC} after an access command.




NOTE 1 For illustration purpose, t_{PARAC} is shown with 0 t_{CK} digital and 0 ns analog output delay.

NOTE 2 See Power-Down and Self Refresh clauses for details on disabling and enabling parity check in conjunction with power-down and self refresh entry and exit.

Figure 57 — Enabling and Disabling Command/Address Parity

6.4.1 Command/Address Parity (cont'd)


Figure 58 illustrates a single parity error occurrence on the R inputs. In this case, the error occurs at the rising edge of the first cycle of the ACTIVATE command at time T0. After t_{PARAC}, AERR is driven HIGH for 1 t_{CLOCK} and then LOW since no subsequent errors occur.



NOTE 1 For illustration purpose, t_{PARAC} is shown with 2 t_{CLOCK} digital and 0 ns analog output delay.
NOTE 2 MR0 OP6 shall be maintained as 1 for at least t_{PARAC} after the access command.

Figure 58 — Single Command/Address Parity Error

Figure 59 illustrates parity error occurrences on the R and the C inputs. In this case, the error occurs at the falling edge of the first cycle of the ACTIVATE command at time T0. After t_{PARAC}, AERR is driven HIGH for 1 t_{CLOCK} and then LOW for 1 t_{CLOCK}. Since an error also occurs in T2 at both the rising and the falling edges of the READ or WRITE command, the AERR is again driven HIGH for 1 t_{CLOCK} and then LOW since no subsequent errors occur.




NOTE 1 For illustration purpose, t_{PARAC} is shown with 2 t_{CLOCK} digital and 0 ns analog output delay.
NOTE 2 MR0 OP6 shall be maintained as 1 for at least t_{PARAC} after the access command.

Figure 59 — Separated Command/Address Parity Errors

6.4.1 Command/Address Parity (cont'd)

Figure 60 illustrates consecutive parity error occurrences on the R and the C inputs during the T0, T1, and T2 cycles and either the rising, the falling or both clock edges. Due to the common AERR output, parity error occurrences on both interfaces are indistinguishable.



NOTE 1 For illustration purpose, tPARAC is shown with 2 tck digital and 0 ns analog output delay.
NOTE 2 MR0 OP6 shall be maintained as 1 for at least tPARAC after the access command.

Figure 60 — Consecutive Command/Address Parity Errors

6.4.2 Data Parity

The HBM3 DRAM includes a data parity checking function for writes controlled by the WPAR bit in MR0 OP5, and a data parity generation function for reads controlled by the RPAR bit in MR0 OP4. Both WPAR and RPAR functions are disabled by default. There is one DPAR bidirectional DDR I/O and one DERR output signal per DWORD associated with the function. The DPAR input is enabled with WPAR during writes, and the DPAR output is enabled with RPAR during reads, otherwise DPAR is disabled.

The data parity function includes a programmable parity latency PL between the corresponding data and the DPAR signal. PL is programmed in MR1 OP[7:5], and is the same for writes and reads. The corresponding DPAR signal will be received and sent PL cycles later. The WDQS and RDQS strobes will have additional strobe cycles with the same preamble and postambles to accommodate the latching of the delayed DPAR signal at both ends. Examples of reads and writes with DQ parity enabled can be found in the Write Command and Read Command clauses. The DRAM vendor's datasheet shall be consulted for the range of supported PL values.

On read transactions, the HBM3 DRAM generates parity and transmits the parity on the DPAR signal along with the corresponding data on DQ, DBI, and ECC.

On write transactions, the HBM3 DRAM compares the DPAR input with the corresponding data received on DQ, DBI and ECC inputs as summarized in Table 43. The parity calculation is performed separately for each UI of a write burst.

If an error occurs in any single or in multiple UIs within one clock cycle of a write burst (D0 ... D3 or D4 ... D7), DERR is driven HIGH for 1 tCK, t_{PARDQ} after the corresponding cycle of error inputs. The t_{PARDQ} interval for errors occurring during the first clock cycle of a write burst begins (WL + PL) clock cycles after the WRITE command was issued. In case of errors within the first and the second clock cycle of a write burst, DERR will stay HIGH during the next cycle. DERR is driven LOW by the HBM3 DRAM at reset.

When an error occurs, the HBM3 DRAM does not block the write data. The HBM3 DRAM completes the write transaction to the array as normal.

WPAR should not be disabled within (WL + PL + t_{PARDQ} + 2 tCK) after the WRITE command in order to not create a conflict with any ongoing parity operation. For the same reason RPAR should not be disabled within t_{RDMRS} after the READ command.


As outlined in Table 43, meta data received and sent via the ECC signals are included in the parity check and parity generation only when these signals are enabled by the MD bit in MR9 OP0. Similarly, the DBI signals are included in the parity check and parity generation only when these signals are enabled by the WDBI and RDBI bits in MR0 OP[1:0]. The SEV signals are not included in the parity check or parity generation.

6.4.2 Data Parity (cont'd)

Table 43 — Data Parity Function Table

CONFIGURATION		INPUTS		Sum of Inputs Received HIGH	DERR
MD (MR9 OP0)	WDBI or RDBI (MR0 OP[1:0])	DWORD0	DWORD1		
Enabled	Enabled	DQ[31:0], ECC[1:0], DBI[3:0], DPAR0	DQ[63:32], ECC[3:2], DBI[7:4], DPAR1	Even	LOW
				Odd	HIGH
	Disabled	DQ[31:0], ECC[1:0], DPAR0	DQ[63:32], ECC[3:2], DPAR1	Even	LOW
				Odd	HIGH
Disabled	Enabled	DQ[31:0], DBI[3:0], DPAR0	DQ[63:32], DBI[7:4], DPAR1	Even	LOW
				Odd	HIGH
	Disabled	DQ[31:0], DPAR0	DQ[63:32], DPAR1	Even	LOW
				Odd	HIGH
NOTE 1 The DBI inputs are disabled and excluded from the parity check when WDBI is disabled in MR0 OP1. The DBI outputs are disabled and excluded from the parity generation when RDBI is disabled in MR0 OP0. The ECC I/Os are disabled and excluded from the parity check and parity generation when MD is disabled in MR0 OP3.					

Figure 61 illustrates data parity error occurrences on two seamless write bursts. In this example errors occur in the second (D1), third (D2), sixth (D5) and seventh (D6) UI of the first write burst, and in the fifth (P4) and sixth (P5) UI of the DPAR input of the second write burst. After tPARDQ, DERR is driven HIGH for 2 tCK at T5 and T6, then driven LOW for 1 tCK and again driven HIGH for 1 tCK at T8.



NOTE 1 D0 ... D7 = data-in for WRITE command (BL8 burst). P0 ... P7 = parity-in for WRITE command.

NOTE 2 DATA = DQ[31:0], DBI[3:0], ECC[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2] for PC1. WDQS_{0..1}_c is WDQS0_{..1}_t_c for PC0, and WDQS1_{..1}_t_c for PC1.

NOTE 3 Two seamless bursts are shown, with parity errors in the second (D1), third (D2), sixth (D5) and seventh (D6) UI of the first write burst, and in the fifth (P4) and sixth (P5) UI of the DPAR input of the second write burst.

NOTE 4 PL=2 is assumed.

NOTE 5 The parity check is performed separately for the first clock cycle (UI = D0 ... D3) and the second clock cycle (UI = D4 ... D7) of a BL8 burst.


NOTE 6 tPARDQ is shown with 2 tCK digital and 0 ns analog output delay.

NOTE 7 WDBI could be on or off and is controlled with MR0 OP1. WDBI shall be maintained enabled for at least tPARDQ after the access command.

Figure 61 — Write Parity Errors with PL = 2

6.4.2 Data Parity (cont'd)

Examples of single write bursts with write data parity enabled are shown in Figure 62 — Write Parity Alignment with PL = 2 and Figure 63 — Write Parity Alignment with PL = 4. With PL= 2, four additional WDQS pulses are received at cycles T8 and T9 to latch the DPAR input.



NOTE 1 D0 ... D7 = data-in for WRITE command (BL8 burst). P0 ... P7 = parity-in for WRITE command.


NOTE 2 DATA = DQ[31:0], DBI[3:0], ECC[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2] for PC1. WDQS_t/_c is WDQS0_t/_c for PC0, and WDQS1_t/_c for PC1.

NOTE 3 WL = 6 and PL=2 is assumed.

NOTE 4 WDBI could be on or off and is controlled with MR0 OP1.

Figure 62 — Write Parity Alignment with PL = 2

With PL = 4, the WDQS postamble for the write data at cycle T8 is immediately followed by the WDQS preamble for the write parity data at cycle T9, resulting in continuous WDQS pulses over the write data and data parity bursts.



NOTE 1 D0 ... D7 = data-in for WRITE command (BL8 burst). P0 ... P7 = parity-in for WRITE command.

NOTE 2 DATA = DQ[31:0], DBI[3:0], ECC[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2] for PC1. WDQS_t/_c is WDQS0_t/_c for PC0, and WDQS1_t/_c for PC1.

NOTE 3 WL = 6 and PL=4 is assumed.


NOTE 4 WDBI could be on or off and is controlled with MR0 OP1.

Figure 63 — Write Parity Alignment with PL = 4

Examples of single read bursts with read data parity enabled are shown in Figure 64 – Read Parity Alignment with PL = 2 and Figure 65 – Read Parity Alignment with PL = 4. The DPAR output is

6.4.2 Data Parity (cont'd)

preconditioned over half a clock cycle like for the even data bytes. With PL = 2 four additional WDQS and RDQS pulses for DPAR are received and returned at cycles T12 and T13.



NOTE 1 D0 ... D7 = data-out for READ command (BL8 burst). P0 ... P7 = parity-out for READ command.


NOTE 2 DATA = DQ[31:0], DBI[3:0], ECC[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2] for PC1. RDQS_{t/c} is RDQS0_{t/c} for PC0, and RDQS1_{t/c} for PC1. WDQS_{t/c} is WDQS0_{t/c} for PC0, and WDQS1_{t/c} for PC1.

NOTE 3 RL = 10 and PL=2 is assumed.

NOTE 4 RDBI could be on or off and is controlled with MR0 OP0.

Figure 64 — Read Parity Alignment with PL = 2

With PL = 4, the WDQS postamble for the read data at cycle T12 overlaps with the WDQS preamble for the read parity data. The RDQS postamble for the read data at cycle T12 is immediately followed by the RDQS preamble for the read parity data at cycle T13, both resulting in continuous WDQS and RDQS pulses over the read data and data parity bursts.



NOTE 1 D0 ... D7 = data-out for READ command (BL8 burst). P0 ... P7 = parity-out for READ command.

NOTE 2 DATA = DQ[31:0], DBI[3:0], ECC[1:0] for PC0, and DQ[63:32], DBI[7:4], ECC[3:2] for PC1. RDQS_{t/c} is RDQS0_{t/c} for PC0, and RDQS1_{t/c} for PC1. WDQS_{t/c} is WDQS0_{t/c} for PC0, and WDQS1_{t/c} for PC1.

NOTE 3 RL = 10 and PL=4 is assumed.

NOTE 4 RDBI could be on or off and is controlled with MR0 OP0.

Figure 65 — Read Parity Alignment with PL = 4

6.5 Clock Frequency Change Sequence

Clock Frequency changes can occur during self refresh mode only. When the CK clock is stopped after self refresh entry, it can be restarted at a different frequency. If the change in clock-rate requires changes to configuration parameters, MRS commands immediately prior to or after self refresh mode may be required.

6.6 Temperature Compensated Refresh Reporting

6.6.1 Temperature Compensated Refresh Trip Points

The HBM3 DRAM provides temperature compensated refresh related information to the controller via an encoding on the TEMP[1:0] pins. The gray-coded encoding as in Table 44 defines the required refresh rate as determined by the hottest device in the stack to maintain data integrity. The reported refresh rate is updated when the junction temperature exceeds the vendor specific trip-point levels appropriate for each refresh rate. Vendor datasheets should be consulted for the absolute temperature trip points for each encoding.

Table 44 — Temperature Compensated Refresh Trip Points

TEMP[1:0]	Refresh Rate	Temperature Trip Point
00	1 x tREFI	Vendor Specific
01	0.5 x tREFI	
11	0.25 x tREFI	
10	Reserved	

6.6.2 Catastrophic Temperature Sensor

The CATTRIP sensor logic detects if the junction temperature of any die in the HBM3 stack exceeds a catastrophic trip-point level. The level is set by the DRAM vendor to a value below the temperature that would result in permanent damage of the device. If the junction temperature anywhere in the stack exceeds that catastrophic trip-point level, the HBM3 device will drive the CATTRIP pin to HIGH.

The CATTRIP output is sticky in that device power-off is required to clear the CATTRIP output to LOW. Sufficient time should be allowed for the device to cool after a CATTRIP event. See HBM3 Power-Up and Initialization Sequence for the initialization of the CATTRIP pin.

The circuits associated with the CATTRIP pin will operate correctly even if the catastrophic trip-point level has been exceeded, and regardless of whether the external or internal clocks have stopped. The functionality of CATTRIP can be verified by writing a “1” to MR7 OP7 to force CATTRIP to HIGH, and “0” to set CATTRIP back to LOW.

6.7 Interconnect Redundancy Remapping

The HBM3 DRAM supports interconnect lane remapping to help improve SIP assembly yield and recover functionality of the HBM3 stack. The SOFT_LANE_REPAIR and HARD_LANE_REPAIR instructions are used to perform lane remapping. Lane remapping is independent for each channel.

SOFT_LANE_REPAIR and HARD_LANE_REPAIR instructions can only be issued as part of the device initialization and before normal memory operation has commenced, e.g., before the CK clock has started to toggle.

The HBM DRAM can be programmed to retain the remapped lane information even when power is completely removed from the HBM stack.

6.7.1 AWORD Remapping

There is one redundant AWORD lane per channel to either repair one lane in the row command bus or one lane in the column command bus. APAR and ARFU are associated with the column command bus repair as shown in Table 46. CK_c, CK_t, and AERR signals cannot be remapped. After a lane is remapped, the input buffer associated with the broken lane is turned off and the input buffer associated with the redundant bump (RA) is turned on. All functionalities are preserved with row or column bus lane remapping.

6.7.1.1 Row Command Bus – Remapping Table

Table 45 — AWORD - Row Command Bus Remapping

Description	Register Encoding	R1	R2	R3	R0	R4	R5	R6	R7	R8	R9	RA
Repair Lane 0	0001	XX	R1	R2	R3	R0	R4	R5	R6	R7	R8	R9
Repair Lane 1	0010	R1	XX	R2	R3	R0	R4	R5	R6	R7	R8	R9
Repair Lane 2	0011	R1	R2	XX	R3	R0	R4	R5	R6	R7	R8	R9
Repair Lane 3	0000	R1	R2	R3	XX	R0	R4	R5	R6	R7	R8	R9
Repair Lane 4	0100	R1	R2	R3	R0	XX	R4	R5	R6	R7	R8	R9
Repair Lane 5	0101	R1	R2	R3	R0	R4	XX	R5	R6	R7	R8	R9
Repair Lane 6	0110	R1	R2	R3	R0	R4	R5	XX	R6	R7	R8	R9
Repair Lane 7	0111	R1	R2	R3	R0	R4	R5	R6	XX	R7	R8	R9
Repair Lane 8	1000	R1	R2	R3	R0	R4	R5	R6	R7	XX	R8	R9
Repair Lane 9	1001	R1	R2	R3	R0	R4	R5	R6	R7	R8	XX	R9
Reserved	1010 to 1110	R1	R2	R3	R0	R4	R5	R6	R7	R8	R9	RA
Default – No Repair	1111	R1	R2	R3	R0	R4	R5	R6	R7	R8	R9	RA
NOTE 1 XX = Lane is remapped												

6.7.1.2 Column Command Bus – Remapping Table

Table 46 — AWORD - Column Command Bus Remapping

Description	Register Encoding	C0	C1	C2	C3	C4	C5	C6	C7	APAR	ARFU	RA
Repair Lane 0	0000	XX	C0	C1	C2	C3	C4	C5	C6	C7	APAR	ARFU
Repair Lane 1	0001	C0	XX	C1	C2	C3	C4	C5	C6	C7	APAR	ARFU
Repair Lane 2	0010	C0	C1	XX	C2	C3	C4	C5	C6	C7	APAR	ARFU
Repair Lane 3	0011	C0	C1	C2	XX	C3	C4	C5	C6	C7	APAR	ARFU
Repair Lane 4	0100	C0	C1	C2	C3	XX	C4	C5	C6	C7	APAR	ARFU
Repair Lane 5	0101	C0	C1	C2	C3	C4	XX	C5	C6	C7	APAR	ARFU
Repair Lane 6	0110	C0	C1	C2	C3	C4	C5	XX	C6	C7	APAR	ARFU
Repair Lane 7	0111	C0	C1	C2	C3	C4	C5	C6	XX	C7	APAR	ARFU
Repair Lane 8	1000	C0	C1	C2	C3	C4	C5	C6	C7	XX	APAR	ARFU
Repair Lane 9	1001	C0	C1	C2	C3	C4	C5	C6	C7	APAR	XX	ARFU
Reserved	1010 to 1110	C0	C1	C2	C3	C4	C5	C6	C7	APAR	ARFU	RA
Default – No Repair	1111	C0	C1	C2	C3	C4	C5	C6	C7	APAR	ARFU	RA
NOTE 1 XX = Lane is remapped												

6.7.1.3 AWORD Remapping Examples

As an example, Ca4 is the broken lane in the Column Command bus with no broken lanes on the Row Command bus. The lane is remapped by programming Channel a's LANE REPAIR WDR bits AWORD_CA[3:0] to 4h and AWORD_RA[3:0] to Fh.

Table 47 — Original Lane Assignment - Channel a - AWORD Column Repair

	ARFUa		Ca7		Ca5		Ca4		Ca2		Ca0
RAa		APARA		Ca6		CKa_t		Ca3		Ca1	
	Ra9		Ra7		CKa_c		Ra4		Ra3		Ra1
AERRa		Ra8		Ra6		Ra5		Ra0		Ra2	

Table 48 — Remapped Lane Assignment - Channel a - AWORD Column Repair

	APARA		Ca6		Ca4		XX		Ca2		Ca0
ARFUa		Ca7		Ca5		CKa_t		Ca3		Ca1	
	Ra9		Ra7		CKa_c		Ra4		Ra3		Ra1
AERRa		Ra8		Ra6		Ra5		Ra0		Ra2	

6.7.1.3 AWORD Remapping Examples (cont'd)

In a second example, Ra0 is the broken lane in the Row Command bus with no broken lanes on the Column Command bus. The lane is remapped by programming Channel a's LANE REPAIR WDR bits AWORLD_RA[3:0] to 0h and AWORLD_CA[3:0] to Fh.

Table 49 — Original Lane Assignment - Channel a - AWORLD Row Repair

	ARFUa		Ca7		Ca5		Ca4		Ca2		Ca0
RAa		APARA		Ca6		CKa_t		Ca3		Ca1	
	Ra9		Ra7		CKa_c		Ra4		Ra3		Ra1
AERRa		Ra8		Ra6		Ra5		Ra0		Ra2	

Table 50 — Remapped Lane Assignment - Channel a - AWORLD Row Repair

	ARFUa		Ca7		Ca5		Ca4		Ca2		Ca0
RA9		APARA		Ca6		CKa_t		Ca3		Ca1	
	Ra8		Ra6		CKa_c		Ra0		Ra3		Ra1
AERRa		Ra7		Ra5		Ra4		XX		Ra2	

6.7.2 DWORD Remapping

HBM3 supports remapping of one broken data bus lane per double byte. Two adjacent bytes (e.g., DQ[15:0], DQ[31:16], DQ[47:32], DQ[63:48]) are treated as a pair (double byte), but each double byte is treated independently.

After a lane is remapped, the input buffer associated with the broken lane is turned off and the output driver is tri-stated; the input buffer associated with the redundant lane (RD) is additionally turned on and the output driver is activated.

It is required to program “1111b” for the intact byte within the double byte while the remapping for the broken lane in the other byte is encoded according to the table.

DBI functionality is preserved as long as the Mode Register setting for DBI function is enabled. There is no impact on the Data Parity function. WDQS_c, WDQS_t, RDQS_c, RDQS_t, PAR and DERR signals cannot be remapped.

During Reads, the RD output drivers are enabled along with the DQ, DBI and ECC/SEV lanes of the physical byte the lane is located in: RD0 and RD2 are located within even bytes and thus enabled one clock cycle prior to the first valid data bit, and RD1 and RD3 are located within odd bytes and thus enabled two clock cycles prior to the first valid data bit.

6.7.2.1 DWORD Remapping Table

Table 51 — DWORD Remapping (1 Byte)

Description	Register Encoding	ECC0 (ECC1/ SEV0/ SEV1)	DQ0 (DQ8/ DQ16/ DQ24)	DQ1 (DQ9/ DQ17/ DQ25)	DQ2 (DQ10/ DQ18/ DQ26)	DQ3 (DQ11/ DQ19/ DQ27)	DQ4 (DQ12/ DQ20/ DQ28)	DQ5 (DQ13/ DQ21/ DQ29)	DQ6 (DQ14/ DQ22/ DQ30)	DQ7 (DQ15/ DQ23/ DQ31)	DBI0 (DBI1/ DBI2/ DBI3)	RD0 (RD0/ RD1/ RD1)
Repair Lane 0	0000	XX	ECC0	DQ0	DQ1	DQ2	DQ3	DQ4	DQ5	DQ6	DQ7	DBI0
Repair Lane 1	0001	ECC0	XX	DQ0	DQ1	DQ2	DQ3	DQ4	DQ5	DQ6	DQ7	DBI0
Repair Lane 2	0010	ECC0	DQ0	XX	DQ1	DQ2	DQ3	DQ4	DQ5	DQ6	DQ7	DBI0
Repair Lane 3	0011	ECC0	DQ0	DQ1	XX	DQ2	DQ3	DQ4	DQ5	DQ6	DQ7	DBI0
Repair Lane 4	0100	ECC0	DQ0	DQ1	DQ2	XX	DQ3	DQ4	DQ5	DQ6	DQ7	DBI0
Repair Lane 5	0101	ECC0	DQ0	DQ1	DQ2	DQ3	XX	DQ4	DQ5	DQ6	DQ7	DBI0
Repair Lane 6	0110	ECC0	DQ0	DQ1	DQ2	DQ3	DQ4	XX	DQ5	DQ6	DQ7	DBI0
Repair Lane 7	0111	ECC0	DQ0	DQ1	DQ2	DQ3	DQ4	DQ5	XX	DQ6	DQ7	DBI0
Repair Lane 8	1000	ECC0	DQ0	DQ1	DQ2	DQ3	DQ4	DQ5	DQ6	XX	DQ7	DBI0
Repair Lane 9	1001	ECC0	DQ0	DQ1	DQ2	DQ3	DQ4	DQ5	DQ6	DQ7	XX	DBI0
Reserved	1010 to 1110	ECC0	DQ0	DQ1	DQ2	DQ3	DQ4	DQ5	DQ6	DQ7	DBI0	RD0
Default – No Repair	1111	ECC0	DQ0	DQ1	DQ2	DQ3	DQ4	DQ5	DQ6	DQ7	DBI0	RD0

NOTE 1 XX = Lane is remapped
 NOTE 2 DWORD0 and DWORD0_BYTEx are shown as an example
 NOTE 3 ECC is associated with DWORD0_BYTEx, DWORD0_BYTE1, DWORD1_BYTEx and DWORD1_BYTE1
 NOTE 4 SEV is associated with DWORD0_BYTEx, DWORD0_BYTE3, DWORD1_BYTE2 and DWORD1_BYTE3

6.7.2.2 DWORD Remapping Example

As an example, ECCa0 is a broken lane for byte 0 while all lanes for byte 1 are intact. The lane is remapped as illustrated in Table 53 by programming channel a's LANE REPAIR WDR bits DWORD0_BYTEn[3:0] to 0h and bits DWORD0_BYTEn[3:0] to Fh.

Table 52 — Original DWORD Lane Assignment - Channel a – Byte [1:0]

	DQa7		DQa5		RDa0		DQa3		DQa1		ECCa0
DBIa0		DQa6		DQa4		PARa0		DQa2		DQa0	
	VDDQL		VDDQL		VDDQL		VDDQL		VDDQL		VDDQL
DBIa1		DQa14		DQa12		WDQS _a 0_t		DQa10		DQa8	
	DQa15		DQa13		WDQS _{a_c}		DQa11		DQa9		ECCa1

Table 53 — Remapped DWORD Lane Assignment - Channel a – Byte [1:0]

	DQa6		DQa4		DBIa0		DQa2		DQa0		XX
DQa7		DQa5		DQa3		PARa0		DQa1		ECCa0	
	VDDQL		VDDQL		VDDQL		VDDQL		VDDQL		VDDQL
DBIa1		DQa14		DQa12		WDQS _a 0_t		DQa10		DQa8	
	DQa15		DQa13		WDQS _{a_c}		DQa11		DQa9		ECCa1

The circuit diagram in Figure 66 illustrates the DQ lane remapping in more detail. Physical micro-bump DQ3 will be connected to internal logical DQ3 input and output paths when the DQ3 lane is not remapped; with remapping the internal DQ3 input and output paths would be routed to the physical DQ4 micro-bump.

6.7.2.2 DWORD Remapping Example (cont'd)




Figure 66 — Example Signal Paths with Lane Repair

6.8 HBM3 Loopback Test Modes

A Multiple-input Shift Register (MISR) / Linear Feedback Shift Register (LFSR) circuit is defined within the HBM3 AWORD and DWORD I/O blocks. These circuits are intended for testing and training the link between the Host and the HBM3 device. Referring to Figure 67, each byte within a DWORD implements a 40-bit MISR/LFSR circuit, comprised of WDQS 2-cycles Rise and Fall 4-bits for each of the eight DQs plus DBI and ECC/SEV signals. Respective Q0, Q1, Q2, Q3 indicate half WDQS cycle for each one signal within each byte of a DWORD implement. The BL0 to BL3 of HBM3 are matched with the Q0 to Q3 in the front two WDQS cycles and the BL4 to BL7 of HBM3 are matched with the Q0 to Q3 in the next two WDQS cycles. In operation, the MISR/LFSR circuits operate independently across the bytes. The AWORD implements a 38-bit MISR/LFSR circuit comprised of CK DDR Rise and Fall bits for the 18 row and column command bits, plus ARFU. When the MISR registers are read via the IEEE 1500 port DWORD_MISR instruction, the four bytes per DWORD (160-bits) for the two DWORDs within a channel are serially shifted out, for a total of 320-bits. The 38-bit AWORD MISR content is read via the AWORD_MISR instruction. See

Table 116 and Table 117 for the bit-orders for these MISR registers.

The term MISR modes collectively refers to all of the modes - LFSR mode, Register mode, MISR mode, and LFSR Compare mode. AWORD MISR modes and DWORD MISR modes refer to all of the modes defined for the specific bus.




Figure 67 — MISR Features Block Diagram of HBM3

6.8.1 HBM3 Polynomial Structure

Figure 68 provides an example of a 4-bit Galois type MISR/LFSR structure that implements the following polynomial:

$$f(x) = X^4 + X^3 + 1$$

The example circuit and function table are for illustration only, and this circuit's modes are not fully representative of the actual DWORD and AWORD MISR definitions as outlined below. For example, the circuit shown in Figure 68 implements a reset function, while the AWORD and DWORD MISRs instead implement a preset function, where specific bits are set to logic 1.




Figure 68 — Example of 4 bit MISR-LFSR Implementing $f(x) = X^4 + X^3 + 1$

Table 54 — MISR Function Table

M1	M0	Function
0	0	Reset
0	1	LFSR
1	0	Register
1	1	MISR

6.8.1.1 AWORD MISR Polynomial

The HBM3 AWORD MISR structure is a 38-bit MISR/LFSR with the following polynomial:

$$f(x) = X^{38} + X^6 + X^5 + X + 1$$

The AWORD MISR may be serially accessed via the AWORD_MISR IEEE 1500 port instruction. See Table 117 for the AWORD MISR wrapper data register bit order.

6.8.1.2 DWORD MISR Polynomial

The DWORD MISR structure is a 40-bit MISR/LFSR per byte with the following polynomial:

$$f(x) = X^{40} + X^{38} + X^{21} + X^{19} + 1$$

Note that when the DWORD MISRs are accessed via the DWORD_MISR IEEE 1500 port instructions that all of the individual byte MISRs within a channel are concatenated into a 320-bit wrapper data register. See

Table 116 for the DWORD MISR bit order.

6.8.2 General Loopback Modes Features and Behavior

This clause addresses features and behaviors that generally apply to all of the MISR modes.

- a) **Entering the MISR modes** – MISR modes may be enabled after tINIT3 within the initialization sequence; they may also be entered any time after completing the initialization (see Initialization). DWORD MISR modes are controlled via Mode Register 7 (see Table 18), while AWORD MISR modes are controlled via the IEEE 1500 port AWORD MISR CONFIG instruction. AWORD and DWORD MISR modes cannot be used simultaneously since the DWORD MISR modes are driven via READ and WRITE commands on the AWORD bus.
- b) **Entering and exiting AWORD MISR modes** – HBM3 allows the AWORD MISR modes to be utilized on one or more channels while the other channels continue to operate normally. After normal initialization, to enter the AWORD MISR modes on a given channel the host must put the HBM3 channel into either precharge power-down or self refresh modes. Self refresh mode may be used in order to retain memory content while using the AWORD MISR modes, as needed. AWORD MISR modes may also be enabled after tINIT4 within the initialization sequence. Enabling the AWORD MISR modes re-enables the AWORD I/O buffers that are normally disabled in power-down and self refresh modes, which may result in increased current draw over the IDD2P, IDD2P0 and IDD6x specifications. If returning to normal operation is not required, the host may assert an initialization sequence per clause Initialization after operating the AWORD MISR modes. The sequence for entering AWORD MISR modes, and then exiting back to normal operation is as follows:
 - 1) At any time after initializing the HBM3 enter the all banks idle state.
 - 2) Enter either the precharge power-down state or the self refresh state. R0 = LOW while in these states.
 - 3) Stop toggling CK (CK_t = LOW, CK_c = HIGH).
 - 4) Enable/enter and operate the AWORD MISR modes (AWORD_MISR_CONFIG Enable = 1 - On). Finish these operations with CK stopped (CK_t = LOW, CK_c = HIGH) and R0 = LOW.
 - 5) Disable the AWORD MISR modes and follow the Power-Down (PDE, PDX) or Self Refresh (SRE, SRX) exit procedures.
 - 6) When using the AWORD MISR modes after tINIT3 within the initialization sequence, power-down or self refresh entry and exit does not apply.

If the DRAM is not required to continue with mission mode operation after AWORD MISR test, there is no requirement on row/column command bus and the precharge power-down state or the self refresh state after loopback test. The AWORD MISR modes (AWORD_MISR_CONFIG Enable bit) can be reset by WRST_n during a subsequent initialization sequence.

6.8.2 General Loopback Modes Features and Behavior (cont'd)

c) **Entering and exiting DWORD MISR modes** – HBM3 allows the DWORD MISR modes to be utilized on one or more channels while the other channels continue to operate normally. After normal initialization (see Initialization), to enter the DWORD MISR modes on a given channel the host must put the HBM3 channel into the all banks idle, enable the DWORD MISR modes (MR7 Loopback Enable = 1 - Enable; see Table 18), and then enter precharge power-down or self refresh. Self refresh may be used in order to retain memory content while using the DWORD MISR modes, as needed. Enabling the DWORD MISR modes before entering precharge power-down or self refresh keeps the AWORD and DWORD I/O buffers enabled, and may result in increased current draw over the IDD2P, IDD2P0 and IDD6x specifications. DWORD MISR modes may also be enabled after t_{INIT3} within the initialization sequence. Also see items f) and h) for related DWORD MISR modes configuration setting. On the column command bus only READ (RD), WRITE (WR), and Column No Operation (CNOP) commands may be issued which operate the DWORD MISR modes, MR15 MRS commands may be issued to set the DWORD VREF (VREFD), and MR7 MRS commands may be issued to select the DWORD MISR modes. On the row command bus only R0 = static LOW may be issued. The sequence for entering DWORD MISR modes, and then exiting back to normal operation is as follows:

- 1) At any time after initializing the HBM3, enter the all banks idle state.
- 2) Set all configuration mode registers as needed for use in the DWORD MISR modes (see items h), k), and n)).
- 3) Set MR7 DWORD Loopback Enable = 1 - Enable, and then wait t_{MOD} .
- 4) Enter either precharge power-down or self refresh. R0 = LOW while in these states.
- 5) Select and operate the DWORD MISR modes via MR7 settings (Row command input requires RNOP with R0=L to keep power-down or self refresh status during MR7 setting) and sending RD, WR, and CNOP commands. After completing DWORD MISR operations, send CNOP commands.
- 6) Follow the power-down exit (PDX) or self refresh exit (SRX) procedures.
- 7) Set MR7 DWORD Loopback Enable = 0 - Disable, and then wait t_{MOD} before continuing normal operation.

MRS commands are not supported until after t_{INIT5} in the initialization sequences; therefore, to configure and control the mode registers for DWORD MISR modes usage after t_{INIT3} the MODE_REGISTER_DUMP_SET instruction must be used. The sequence for entering and operating the DWORD MISR modes after t_{INIT3} in the initialization sequence is as follows:

- 1) Start CK with PD and CNOP on the command busses.
- 2) Using MODE_REGISTER_DUMP_SET sets all configuration mode registers as needed for use in the DWORD MISR modes (see items f) and h)), set MR7 DWORD Loopback Enable = 1 - Enable, and then wait t_{MOD} .
- 3) Select and operate the DWORD MISR modes via MR7 settings (using MODE_REGISTER_- DUMP_SET) and sending RD, WR, and CNOP commands.
- 4) After completing DWORD MISR operations, send CNOP commands, set MR7 DWORD Loopback Enable = 0 - Disable using MODE_REGISTER_DUMP_SET, then wait t_{MOD} .
- 5) CK clocking may be stopped if desired.

6.8.2 General Loopback Modes Features and Behavior (cont'd)

- 6) Proceed to other IEEE 1500 instructions, or proceed with the initialization sequence from Figure 6, time Td.

If the DRAM is not required to continue with mission mode operation after DWORD MISR test, there is no requirement to follow the power-down or self refresh procedures and set MR7 DWORD Loopback Enable = 0 - Disable. The Loopback Enable bit can be reset by a subsequent initialization sequence with RESET_n = LOW.

- d) **Command decode is disabled in AWORD MISR modes** - When AWORD MISR modes are enabled the traffic sent on the AWORD bus is not limited to valid commands. To prevent undefined states and operations, when AWORD MISR modes are enabled (AWORD MISR CONFIG Enable = 1 - On), command decoding is disabled.
- e) **With lane repairs the MISR bit positions remain with their logical signals** - The MISR bits are associated with their logic signals, not the physical microbumps (see Figure 66). For example, if DQ3 has been repaired (which routes the DQ3 data to the DQ4 microbump) the data received on the DQ4 microbump is routed to the DQ3 MISR bits. Effectively, the behaviors for all MISR modes are unchanged - all 10 bits of the byte are captured in the MISR in the same bit locations, as if no lane repair were active.
- f) **HBM3 DBI, and ECC/SEV logic circuits are not functional in the DWORD MISR modes** - The DBI and ECC/SEV signals are treated as pure data signals. Their raw values are captured, compared, or sent without regard to their normal bus inversion or ECC functional meaning.
 - It is required to enable Write DBIac and Read DBIac in MR0 in order to enable the I/O buffers on the DBI signals. A value of 0 is internally assumed for all DBI write data in case WDBI is disabled.
 - Regardless whether meta data and severity reporting are enabled in MR9 or not, setting MR7 DWORD Loopback Enable = 1 will enable the ECC/SEV signal's I/O buffers. Note that the SEV signals are bidirectional I/Os in loopback test mode only.
 - The host may write DBI encoded or non-encoded data to the HBM3. In MISR mode or Register mode, the raw data received from the host will be directly captured (not DBI decoded) to the MISR register.
 - For LFSR Compare mode to match, the host must send the LFSR generated raw data on all 10 signals of the byte without write DBI encoding. The HBM3 will not DBI decode the received data, and thus the host must send the raw LFSR data in order for LFSR Compare to match.
 - For LFSR mode, the HBM3 will generate non-DBI encoded read data.

6.8.2 General Loopback Modes Features and Behavior (cont'd)

- g) **DWORD read path parity traffic generation** - In DWORD LFSR mode (Read direction) and Read Register mode, the HBM3 parity logic is not active and the MR0 DQ Bus Read Parity settings has no effect. To generate traffic on the DWORD parity signal a copy of a nearby DQ signal is produced on the Parity signal. Logical signals DQ2, DQ34 are sent on the respective DWORD block parity DPAR0, DPAR1 signals, irrespective of any lane repairs. The parity signals are driven with the DQ data without any additional cycle delay - effectively with Parity Latency = 0. A suggested host-side implementation is to use signature register circuits for checking the validity of the received parity signal. When reading back the LFSR_COMPARE_STICKY error bits, the parity signal output is unspecified.
- h) **AWORD and DWORD write parity checking** - In AWORD and DWORD Register mode, MISR mode, and LFSR Compare mode the HBM3 parity evaluation logic is active and outputs results on AERR after t_{PARAC} and DERR after t_{PARDQ} , respectively (if enabled in MR0, see Table 11). The MR1 Parity Latency setting (see Table 12) must be set to a vendor implementation-specific supported PL value, which may be interface speed specific. The HBM3 device will process write parity per the PL setting and protocol, including any required additional WDQS cycles. A suggested host-side implementation is to use signature register circuits for checking the correctness of the AERR and DERR signals. It is also suggested that the host generate data on the DWORD Parity signals in order to exercise these signal paths and logic.
- i) **Preset state AAAA₁₆ and 2AAA₁₆** - The Preset state for the DWORD MISR registers is AAAA₁₆, which initializes the Rise bit for each signal to 1'b1 and the Fall bit to 1'b0. This is a useful state for producing an alternating 0/1/0/1/0/1/0/1 pattern on all 10 bits associated with a DWORD byte when put into DWORD read Register mode (burst length 8). This basic pattern may be used by the host for RDQS eye centering. READ commands from the DWORD_MISR are supported in Preset state. WRITE and READ commands to and from the DWORD_MISR do not change the DWORD_MISR content in this mode. The AWORD MISR register is also preset to the same 0/1 pattern (0x2AAA₁₆ for the 38-bit polynomial) for implementation consistency; although the AWORD cannot be enabled to drive this data pattern back to the host. Any non-zero initialization pattern is sufficient for all of the MISR modes; however, an initial pattern of all zeroes is a stuck-at-zero state for the DWORD LFSR mode. The Preset state may be overridden using the Write Register modes (see AWORD and DWORD Write Register Modes).
- j) **DWORD MISR registers are writeable via IEEE 1500** - The normal intended method for writing the DWORD MISR registers are through the functional interface (see Test Method for DWORD Write MISR mode). The values of the DWORD MISR registers may also be written using the DWORD_MISR IEEE 1500 port instruction. This feature enables setting alternate seed values.
- k) **DWORD read and write latencies must be set properly** - READ and WRITE commands are used to generate DWORD MISR modes traffic. Normal mode DWORD read and write protocol is followed using the latency settings, as supported by the operating frequency being used.
- l) **DWORD Write preamble and post-amble clocks adhere to the normal protocol** - For DWORD write MISR modes (Register mode, MISR mode, and LFSR Compare mode), the host is expected to send WDQS preamble and postamble clocks, and the HBM3 samples the DWORD data, consistent with the write protocols defined in the clause entitled Write Command (WR, WRA).

6.8.2 General Loopback Modes Features and Behavior (cont'd)

- m) **DWORD Read preamble and post-amble clocks adhere to the normal protocol** - For DWORD Read Register mode, LFSR mode (Read direction), and when returning the LFSR_COMPARE_STICKY bits, the HBM3 will produce RDQS preamble and postamble clocks, and send DWORD data, consistent with the read protocols defined in the clause entitled Read Command (RD, RDA).
- n) **AWORD MISR modes preamble clock filter** - In the AWORD MISR modes, the host is expected to stop CK toggling, enable the desired AWORD MISR mode, and then start sending CK toggles and AWORD data. To avoid timing impairment on the CK startup cycle, the HBM3 will treat the first received CK cycle as a preamble clock cycle and not process the data on the AWORD signals in MISR or Register mode, nor compare them in LFSR Compare mode. The MISR block will keep its state unchanged during filter cycle. The first clock cycle filter circuit is enabled by setting AWORD_MISR_CONFIG MODE = 2'b00 - Preset. The first data sampled by the HBM3 is on the second CK clock cycle. Only the very first CK clock cycle will be filtered - if the host were to stop and restart CK clocking while remaining in an AWORD MISR mode (without applying another Preset), the AWORD data will be sampled on the startup clock cycle, with possible CK edge timing impairment.




Figure 69 — AWORD MISR Modes Preamble Clock Filter Behavior

- o) **Cycles processed in the MISR modes** - AWORD MISR modes rely on stopping CK clocks before and after the test sequence. All AWORD cycles sent to the HBM3 after the filtered preamble clock cycle are processed into the MISR (MISR mode and Register mode) or compared (LFSR Compare mode), including the last cycle before CK is stopped. An even number of AWORD cycles – not counting the filtered preamble cycle – provides that the test results is the same regardless of the specific AWORD MISR implementation. For DWORD MISR modes, all valid data cycles written to the HBM3 are processed into the MISR (MISR mode and Register mode) or compared (LFSR Compare mode) while the DWORD MISR modes are enabled, consistent with the DWORD write protocol and write latency setting. Data pin signal states during preamble and post-amble cycles are not processed into the MISR. For example, if 10 non-seamless Burst Length = 8 write operations are sent to the HBM3 in DWORD MISR mode a total of 80 data bit times (UI) will be processed into the MISR.

6.8.3 AWORD and DWORD Write MISR Modes

When the AWORD or DWORD MISR modes are active, the data on the AWORD or DWORD data signals is received based on the CK or WDQS clocks respectively, and compressed in the MISR circuits. The host is in complete control of the number of data cycles that are sent, and if successfully received by the HBM3 the values captured in the respective MISRs will be repeatable and deterministic. Figure 70 illustrates the behavior for DWORD MISR mode (Write direction).




Figure 70 — DWORD Write MISR Modes Behavior

6.8.3.1 Test Method for AWORD (Write) MISR Mode

- a) After the required HBM3 initialization, the host issues either precharge power-down or self refresh mode ($R0 = \text{LOW}$) and stops sending CK clocks to the HBM3 ($CK_t = \text{LOW}$, $CK_c = \text{HIGH}$).
- b) Initialize the AWORD MISR by setting the AWORD_MISR_CONFIG Enable = 1'b1 - On and AWORD_MISR_CONFIG MODE = 2'b00 - Preset. The Preset operation also enables the preamble clock filter circuit.
- c) Enable the AWORD MISR mode by setting AWORD_MISR_CONFIG Mode = 2'b11 - MISR mode.
- d) The host sends three or more CK clock cycles and data on the AWORD signals. The first received CK clock cycle is discarded as a preamble clock by the HBM3 and shall be followed by an even number of clock cycles. The HBM3 clocks the received data into the AWORD MISR and evaluates parity, if enabled. The ending clock state applied by the host is $CK_t = \text{LOW}$, $CK_c = \text{HIGH}$.
- e) The host reads the MISR content via the IEEE 1500 AWORD_MISR instruction.

6.8.3.2 Test Method for DWORD Write MISR Mode

- a) Initialize the test sequence by setting MR7 DWORD Loopback Enable = 1'b1 - Enable and presetting the MISR registers by setting the DWORD MISR Control = 3'b000 - Preset. The controller can load the DWORD MISR registers with an alternate seed value via the functional interface or IEEE 1500 (see AWORD and DWORD Write Register Modes and DWORD_MISR IEEE1500 port instruction).
- b) Enable DWORD MISR mode by setting MR7 DWORD MISR Control = 3'b011 - MISR mode.
- c) The host sends one or more DWORD write cycles following the write latency and burst length setting and following the normal write protocol. The HBM3 clocks the received data into the DWORD MISRs and evaluates parity, if enabled.
- d) The host reads the MISR content via the IEEE 1500 DWORD_MISR instruction. The MISR content is also readable via the functional interface (see DWORD Read Register Mode).

6.8.4 AWORD and DWORD Write Register Modes

When the AWORD or DWORD Register modes are active, the data on the AWORD or DWORD data signals are received based on the CK or WDQS clocks respectively, and stored directly into the respective MISR registers without compression. Effectively the MISR register operates as a 2-bit storage register for AWORD and as a 4-bit storage register for DWORD. On rising CK or WDQS edges the signal states on the AWORD or DWORD bus respectively are stored in the Rising bits within the MISR registers, and on falling CK or WDQS edges the bus signal states are stored in the Falling bits within the MISR registers. If the host sends multiple DDR cycles to the HBM3, the MISRs will contain the last 2-bit per AWORD MISR cycle and 4-bit per DWORD MISR cycle, if successfully received by the HBM3.

The Register modes are intended for basic, quick link testing and training, and for initializing the DWORD MISR seed values.

6.8.4.1 Test Method for AWORD (Write) Register Mode

- a) After the required HBM3 initialization, the host issues either precharge power-down or self refresh mode (R0 = LOW) and stops sending CK clocks to the HBM3 (CK_t = LOW, CK_c = HIGH).
- b) Initialize the AWORD MISR by setting the AWORD_MISR_CONFIG Enable = 1'b1 - On and AWORD_MISR_CONFIG MODE = 2'b00 - Preset. The Preset operation enables the preamble clock filter circuit.
- c) Enable the AWORD Register mode by setting AWORD_MISR_CONFIG MODE = 2'b10 – Register mode.
- d) The host sends two or more CK clock cycles and data on the AWORD signals. The first received CK clock cycle is discarded as a preamble clock by the HBM3. The HBM3 clocks the raw received data into the AWORD MISR register without MISR compression and evaluates parity, if enabled. The ending clock state applied by the host is CK_t = LOW, CK_c = HIGH. The last clocked DDR cycle data is retained in the AWORD MISR register.
- e) The host reads the MISR content via the IEEE 1500 AWORD_MISR instruction.

6.8.4.1 Test Method for AWORD (Write) Register Mode (cont'd)

Note that the AWORD write register mode cannot practically be used to apply an alternate seed value into the AWORD MISR register. In clause 6.8.4.1 step d, the preamble clock filter circuit is exercised and cleared. At this point while it is allowed for the host to then stop sending AWORD cycles, set the AWORD_MISR_CONFIG MODE to MISR mode or LFSR Compare mode, and then send additional AWORD cycles, there may be timing impairment for the beginning of the second set of AWORD cycles.

The preamble clock filter circuit cannot be re-enabled for these additional AWORD cycles without applying the AWORD MISR Preset function, which would also overwrite the alternate seed value applied by the AWORD write register operation. There is no expected application value for using an alternate MISR seed value for the AWORD MISR functions since the AWORD bus is receive-only.

6.8.4.2 Test Method for DWORD Write Register Mode

- a) Enable DWORD Register mode by setting MR7 DWORD Loopback Enable = 1'b1 - Enable and DWORD MISR Control = 3'b010 - Register mode. A Preset is not required prior to using Register mode.
- b) The host sends one or more DWORD write cycles following the write latency and burst length setting and following the normal write protocol. The HBM3 clocks the raw received data into the DWORD MISR registers without MISR compression and evaluates parity, if enabled. The last clocked DDR cycle data is retained in the DWORD MISR registers.
- c) The host reads the MISR content via the IEEE 1500 DWORD_MISR instruction. The MISR content is also readable via the functional interface (see DWORD Read Register Mode).

6.8.5 DWORD Read Register Mode

The content of various DWORD MISR mode related registers may be read over the functional interface, assuming that the read path with the host is properly trained (or used for read path training). The MR7 DWORD Read Mux Control bit field is used to select the data source. The host issues read commands and the HBM3 responds following the read command protocol (such as read latency and burst length) and timing (such as pre and post-amble clocks) per clause Read Command (RD, RDA).

Intended uses for the various read data sources include the following:

- Reading the sticky error bits after an LFSR Compare mode test sequence (DWORD Read Mux Control = 1'b1 - Return LFSR_COMPARE_STICKY) - Sticky error data is a single data bit per signal and is output as static values on the interface for the full read burst length.
- NOTE: When using the LFSR mode (see DWORD Read LFSR Mode) set the DWORD Read Mux Control = 1'b0 - Return data from DWORD MISR registers.
- Reading a basic clock pattern on all or select signals for DWORD read link training (DWORD Read Mux Control = 1'b0 - Return data from DWORD MISR registers) - Which signals toggle may be set with the Preset mode or a DWORD Register write (see AWORD and DWORD Write Register Modes).
- Reading the MISR registers final values at the end of a MISR mode test sequence (DWORD Read Mux Control = 1'b0 - Return data from DWORD MISR registers) - The results of a MISR mode test sequence may be read back on the functional interface, or via the IEEE 1500 port DWORD_MISR instruction. The MISR content is sent on UI 0 - 3 and then repeated on UI 4 – 7, or all data(UI 0 to 7) of the most recent Write depending on vendor's implementation (see Table 18 DWORD MISR Read and Write Operations in Loopback Test Mode).

6.8.5.1 Test Method for DWORD Read Register Mode

- a) Enable the test mode and select the desired read-back register by setting MR7 DWORD Loopback Enable = 1'b1 - Enable, DWORD MISR Control = 3'b010 - Register mode, and DWORD Read Mux Control = 0.
- b) The host sends one or more DWORD read commands. The HBM3 responds following the read latency and burst length setting and following the normal read protocol.

6.8.6 DWORD LFSR Mode (Read direction)

When in DWORD LFSR mode (Read direction), the HBM3 generates DWORD data from the LFSR in response to read commands issued by the host. LFSR data is generated consistent with only the valid UIs of the read protocol. Read Preamble and post-amble RDQS clocks are generated consistent with the read protocol. The first data cycle generated will be the LFSR initial state, based on Preset or an alternate seed value if loaded. Figure 71 illustrates the behavior for DWORD LFSR mode (Read direction).

NOTE: There is no AWORD LFSR mode since the AWORD bus cannot source data to the host.




Figure 71 — DWORD Read LFSR Modes Behavior

6.8.6.1 Test Method for DWORD LFSR Mode (Read direction)

- Initialize the test sequence by setting MR7 DWORD Loopback Enable = 1'b1 - Enable and presetting the MISR registers by setting the DWORD MISR Control = 3'b000 - Preset. The controller can load the DWORD MISR registers with an alternate seed value via the functional interface or IEEE 1500 (see AWORD and DWORD Write Register Modes and DWORD_MISR IEEE 1500 port instruction).
- Enable DWORD LFSR mode by setting MR7 DWORD MISR Control = 3'b001 - LFSR mode and DWORD Read Mux Control = 1'b0 - Return data from DWORD MISR registers.
- The host sends one or more DWORD read commands. The HBM3 responds following the read latency and burst length setting and following the normal read protocol, with data produced from the LFSR. A suggested host-side implementation is to use signature register circuits for checking the validity of the received data.

6.8.7 AWORD and DWORD Write LFSR Compare Modes

The LFSR Compare modes enable direct identification of failing signal connections between the Host and HBM3. It is assumed that the Host implements LFSR data generators that match the lengths and polynomials of the HBM3 LFSRs, and that the Host and HBM3 LFSRs start and run in synch. The LFSRs generate data on each signal, and the compare circuitry checks for matching data for each data unit interval (UI). Any mismatch between the data received at the HBM3 inputs (based on the respective CK or WDQS clocking) and the data predicted by the HBM3 LFSR will set the sticky error bit for the respective signals. The first data cycle expected from the host and compared by the HBM3 will be the LFSR initial state, based on Preset or an alternate seed value if loaded.

Once a miscompare is found on a signal, its sticky error bit is set (1'b1) for the remainder of the test sequence. The sticky error bits may be read via the IEEE 1500 port READ_LFSR_COMPARE_STICKY instruction or via the functional interface (see DWORD Read Register Mode). AWORD sticky error bits are only readable via the IEEE 1500 port. The sticky error bits are reset (1'b0) via the MR7 DWORD MISR Control = 3'b000 - Preset, or IEEE 1500 AWORD_MISR_CONFIG MODE = 2'b00 - Preset.

Figure 72 illustrates the system-level configuration for LFSR Compare mode.




Figure 72 — LFSR Compare Mode Block Diagram

Note that data produced on the DWORD Parity signals from the host to the HBM3 is an implementation suggestion for exercising the parity signal paths and HBM3 input timing and logic. The host-side implementation for parity signal generation is not specified. This figure also illustrates that a host-driven logical signal is compared with the matching logical signal data by the HBM3 compare circuit, regardless of any active lane repairs which may shift the physical signal routing. The AWORD LFSR Compare circuit matches the DWORD circuit except for the non-existent Parity signals.

6.8.7.1 Test method for AWORD (Write) LFSR Compare Mode

- a) After the required HBM3 initialization, the host issues either precharge power-down or self refresh mode ($R_0 = \text{LOW}$) and stops sending CK clocks to the HBM3 ($\text{CK}_t = \text{LOW}$, $\text{CK}_c = \text{HIGH}$).
- b) Initialize the AWORD MISR (LFSR) register by setting the AWORD_MISR_CONFIG Enable = 1'b1 - On and AWORD_MISR_CONFIG MODE = 2'b00 - Preset. The Preset operation also clears the AWORD per-signal sticky error bits and enables the preamble clock filter circuit. The host-side LFSR data generator should also be initialized to the same value.
- c) Enable the AWORD LFSR Compare mode by setting AWORD_MISR_CONFIG MODE = 2'b01 - LFSR Compare mode.
- d) The host sends two or more CK clock cycles with LFSR-generated data on the AWORD signals. The first received CK clock cycle is discarded as a preamble clock by the HBM3. The HBM3 LFSR predicts expected AWORD data per cycle from the host, based on matching LFSR polynomials and starting seeds in the host and HBM3. Any mismatches set sticky error for the respective signal. Parity is evaluated, if enabled. The ending clock state applied by the host is $\text{CK}_t = \text{LOW}$, $\text{CK}_c = \text{HIGH}$.
- e) The host reads the Sticky error bits to determine which signals failed. The bits are readable via the IEEE 1500 port READ_LFSR_COMPARE_STICKY instruction.

6.8.7.2 Test Method for DWORD Write LFSR Compare mode

- a) Initialize the DWORD LFSR (MISR) registers by setting MR7 DWORD Loopback Enable = 1'b1 - Enable and DWORD MISR Control = 3'b000 - Preset. The Preset operation also clears the DWORD per-signal sticky error bits. The controller can load the DWORD MISR registers with an alternate seed value via the functional interface or IEEE 1500 (see AWORD and DWORD Write Register Modes and DWORD_MISR IEEE1500 port instruction). The host-side LFSR data generator should also be preset-initialized to the same value.
- b) Enable DWORD LFSR Compare mode by setting MR7 DWORD MISR Control = 3'b100 – LFSR Compare mode.
- c) The host sends one or more DWORD write cycles with LFSR-generated data on the DWORD signals following the write latency and burst length setting and following the normal write protocol. The HBM3 LFSRs predict expected DWORD data per cycle from the host, based on matching LFSR polynomials and starting seeds in the host and HBM3. Any mismatches set sticky error for the respective signal. Parity is evaluated, if enabled.
- d) The host reads the sticky error bits to determine which signals failed. The bits are readable via the IEEE 1500 port READ_LFSR_COMPARE_STICKY instruction. The sticky error bits are also readable via the functional interface (see DWORD Read Register Mode).

6.9 On-die DRAM ECC

6.9.1 ECC Overview

The HBM3 device uses a symbol-based on-die ECC, read/write meta-data (MD) bits, an error scrubbing mechanism, an error transparency protocol, interface transmission parity, and fault isolation limits to achieve a high level of system RAS.

HBM3 ECC features:

- Minimum 304b codeword
 - 256b+16b user data access size
 - Symbol-based on-die ECC
 - Symbol size is implementation specific
- On-die ECC real-time transparency
 - Two pins per PC transmit error severity
 - SBE signaled only after SBE threshold exceeded
- Automated on-die error scrubbing mechanism
 - Auto-ECS during REFab operation has MR for enable/disable
 - Auto-ECS during SRF has MR for enable/disable
 - MR bit to enable correction of CEm during ECS
 - Errors are only logged during ECS
- Single bit READ and WRITE data interface parity
 - DQ, DBI, and ECC bits included in parity calculation
 - SEV transparency bits not included in parity calculation

An overview of an example HBM3 on-die ECC engine is shown in Figure 73.




Figure 73 — On-die ECC Overview Diagram Example

6.9.2 HBM3 On-die ECC Requirements

On-die ECC Engine:

HBM3 devices shall implement on-die symbol-based ECC.

HBM3 on-die ECC has a codeword size dependent on symbol size error correction capability. The data-word and example check-bits of the codeword are as follows:

- Data-word: 272b (256b data per PC + 16b meta data per PC)
- On-die ECC check-bits: Implementation specific (e.g., 32b assuming 16b single symbol correction)

The 272b user data consists of 256b transmitted over 32 DQ pins x BL8 and 16b transmitted over 2 ECC pins x BL8.

On reads the DRAM corrects all errors that are less than or equal to a single symbol size and within the symbol boundary before returning the data to the memory controller. The DRAM shall not write the corrected data back to the array during a read cycle.

On writes the DRAM computes the check bits and writes the data and check bits to the array.

In the case of interface MD bits being disabled via MR9 OP0, the DRAM may assume any value for the 16b of the ECC data-word corresponding to the MD bits. The DRAM can only guarantee valid array MD bits if written while interface MD function is enabled. The ECC engine treatment of the MD bits is not affected by the disabling of the interface MD setting.

The specific ECC H-matrix used, the symbol size, and the number of codewords are implementation specific.

6.9.3 DRAM Fault Isolation Requirements

Fault isolation is the management of errors caused by various faults to be isolated within certain boundaries regardless of the od-ECC operation.

The fault isolation boundaries will be chosen in accordance with the ECC symbol size to maximize the correction capability of multi-bit faults. The design must guarantee that the most common multi-bit fault modes will create errors constrained to a correctable symbol-size or fewer bits.

6.9.4 Error Check and Scrub (ECS)

The HBM3 device will implement an Auto ECS function. Auto ECS will use on-die ECC and operate in the background during REFab and SRF periods. The ECS mode allows the DRAM to internally read, detect errors, correct errors, and write back corrected data bits to the array (scrub errors) while providing transparency. Any errors corrected by on-die ECC during Auto ECS must be logged in the transparency registers according to the rules described in this clause.

6.9.4 Error Check and Scrub (ECS) (cont'd)

During Auto ECS, the internal Read-Modify-Write cycle will:

1. Read the entire code-word(s) from the DRAM array.
2. If the ECC engine detects a single-bit error, the error will be corrected, and code-word(s) will be written back to DRAM.
3. If the ECC engine detects a correctable multi-bit error, the error will be corrected, and code-word(s) will be written back to DRAM. CEm during ECS can be enabled/disabled by MR9 OP6.
4. If an error is detected in the code-word(s) and is uncorrectable, the bits in the code-word(s) will not be modified. The code-word(s) must not be written back to DRAM.
5. If the ECC engine detects no error, the DRAM may choose to write the resultant code-word(s) back to DRAM or not.

ECS related MR control:

Table 55 — ECS Modes

ECS Mode	Mode Register Value (Default All Disabled)
Auto ECS via REFab	MR9 OP4, 1 = Enabled, 0 = Disabled
Auto ECS during Self Refresh	MR9 OP5, 1 = Enabled, 0 = Disabled
CEm during ECS	MR9 OP6, 1 = Enabled, 0 = Disabled
ECS Error Type and Address Reset	MR9 OP7, 1 = Reset (Self Clearing), 0 = Maintain
ECS Error Log Reset with Log Read-out	MR8 OP2 1 = Enabled, 0 = Disabled
NOTE 1 REFab used for ECS will count toward refresh credit.	
NOTE 2 When ECS during REFab is enabled, the host must issue REFab commands at an average rate of t_{ECSint} .	

The internal Error Check and Scrub Log status for error type and address is initialized either by a device RESET or by manually writing a “1” to MR9 OP7.

ECS modes MR9 OP[6:4] defined in Table 55 shall be programmed during DRAM initialization and shall not be changed once the first ECS operation occurs unless followed by an ECS reset, otherwise an unknown operation could result during subsequent ECS operations.

The DRAM can only guarantee valid ECS operations if array bits are written to prior to executing ECS operations, thus enabling DRAM to calculate the proper parity bits.

6.9.4 Error Check and Scrub (ECS) (cont'd)

ECS related timing parameters:

The ECS operation timing is shown in Figure 74.




Figure 74 — ECS Operation Timing

- t_{ECSC} : Max time for HBM3 to complete ECS operation
- t_{ECSint} : Average ECS interval to cover all codewords in a specified period of t_{ECS} (e.g., 24h)
- t_{ECS} : Period of time to complete ECS on all codeword
- ERRTH: Vendor specific filter threshold of ERRCNT used for transparency. No CEs will be logged or transmitted on SEV pins until $ERRCNT > ERRTH$

In order to complete a full Error Check and Scrub within the recommended t_{ECS} (e.g., 24 hours), the average periodic interval of ECS operations (t_{ECSint}) is 86,400 seconds divided by the total number of codewords as described in Table 56. The number of ECS operations is configuration dependent.

Table 56 — t_{ECSint} per Stack (ECS Independent of SID)

Configuration	16 Gb x 4/ 8/ 12/ 16	24 Gb x 4/ 8/ 12/ 16	32 Gb x 4/ 8/ 12/ 16
GB per device	8/ 16/ 24/ 32 GB	12/ 24/ 36/ 48 GB	16/ 32/ 48/ 64 GB
Gb per PC	2 Gb	3 Gb	4 Gb
304b code-words per PC per SID	2^{23}	$2^{23} * 1.5$	2^{24}
t_{ECSint} [ms] per PC	10.300	6.866	5.150

In order for the HBM3 to perform ECS operations when in ECS Mode, the host needs to issue periodic REFab commands. The maximum average spacing between REFab commands for the DRAM to complete the automatic scrub within the recommended t_{ECS} (e.g., 24 hours) is t_{ECSint} . Meeting this REFab requirement allows the DRAM to perform the ECS operations without placing additional restrictions on refresh mode usage, i.e., all bank/per-bank refresh or normal mode refresh, while in ECS mode. REFab commands issued in excess of required by the DRAM for ECS operations (one per t_{ECSint}) may be used by the DRAM for normal refresh operation.

6.9.4 Error Check and Scrub (ECS) (cont'd)

ECS related logging: The registers are allocated per PC and SID accessible via the IEEE 1500 interface.

1. When the on-die ECC detects an error, the DRAM address of the error must be logged in the form of Bank, Row, Column, Error Type Severity
2. The error is logged within t_{ECS} and accessible via IEEE 1500

The priority of error logging is defined in Table 57.

Table 57 — Error Overwrite Priority Rules to Handle Multiple Error Logging

Previous Error	Current Error			
	NE	CEs	CEm	UE
NE (No error)	None	Update	Update	Update
CEs (Corrected single-bit error)	Maintain	Update	Update	Update
CEm (Corrected multi-bit error)	Maintain	Maintain	Update	Update
UE (Uncorrectable error)	Maintain	Maintain	Maintain	Update

NOTE 1 Logging of newest error may be lost in case of a simultaneous reset and new ECS error
 NOTE 2 In the case of MR8 OP2 = 1, reset of ECS error log can only be guaranteed when captured WDR of ECS error log is valid

Reset of ECS Error Log:

A reset of the ECS error log clears all VALID bits of the ECS_ERROR_LOG WDR to 0b and the error priority log to “NE” (no error). There are three independent methods for clearing the error log:

- The host may issue device RESET
- The host may issue a log reset according to MR9 OP7
- The host may configure MR8 OP2 ECS error log auto-reset, in which case the error log will be reset upon read of the error log

Error Counting:

The number of CEs are counted during ECS in order to control whether the severity information of CEs is conveyed on the SEV pins during READ operations. Error counting assumes one codeword covering each access.

- ERRCNT == number of error events accumulated during ECS
- ERRCNT is independently maintained per PC and SID
- CEs count as one event toward ERRCNT
- CEm and UE do not count toward ERRCNT
- If more than one codeword is used, a CEs in both codewords counts as a CEm
- ERRCNT will be incremented a maximum of one for any codeword size

Reset of ERRCNT:

Automatic reset internally by HBM3 after each t_{ECS}

6.9.5 On-die ECC Transparency Protocol

An HBM3 device must provide transparency of actions by the on-die ECC engine. The specific information to be conveyed and the method of conveyance is given in Table 58.

Table 58 — Transparency Attributes and their Access/Control Mechanism

Attribute	Operation	Transparency Mechanism
Real-time severity metadata	RD/RDA	Two SEV pins per PC
Logging address and severity of an error	ECS	IEEE1500 register

Severity Metadata: The severity of an error denotes the outcome of the on-die ECC processing over a codeword(s) during a READ operation. The severity information is conveyed on the SEV pins together with the data transfer on the DQ pins. Severity transmission will use the encoding shown in the Table 59 for each BL8 transaction.

Table 59 — Severity Encodings on the SEV Pins

Severity	Pin	Burst Position							
		0	1	2	3	4	5	6	7
NE	SEV[0]	0	0	0	0	0	0	0	0
	SEV[1]	0	0	0	0	0	0	0	0
CEs	SEV[0]	0	0	0	0	1	1	1	1
	SEV[1]	0	0	0	0	0	0	0	0
CEm	SEV[0]	0	0	0	0	1	1	1	1
	SEV[1]	0	0	0	0	1	1	1	1
UE	SEV[0]	0	0	0	0	0	0	0	0
	SEV[1]	0	0	0	0	1	1	1	1

Severity Metadata Signaling Control: The HBM3 device includes a mode register MR9 OP1 to enable or disable the severity metadata signaling by the HBM3 device.

Table 60 — Severity Transmission on READ

On-die ECC Severity	NE	CEs	CEm	UE
Severity on SEV[1:0]	NE	NE if ERRCNT <= ERRTH CEs if previous or current ERRCNT > ERRTH	CEm	UE

6.9.5 On-die ECC Transparency Protocol (cont'd)

The CEs output enable timing for SEV is shown in Figure 75.




Figure 75 — ECS CEs Output Enable Timing for SEV Signaling

6.9.6 ECC Engine Test Mode

HBM3 devices provide ECC engine testing method of the on-die ECC engine only, not error access into the core. The outcome of the error injection is reported according to the transparency protocol.

Table 61 — ECC Engine Test Modes

Selection by MRS	ECC Engine Test Mode
ECC Engine Test Mode (MR9 OP2)	0 – Normal Operation (Default) 1 – ECC Engine Test Mode
Error Vector Patterns (MR9 OP3)	0 – CW0 (Codeword0) Data ‘1’ means error bit and Data ‘0’ means non-error bit 1 – CW1 (Codeword1) Data ‘0’ means error bit and Data ‘1’ means non-error bit

While in the ECC engine test mode in Table 61,

1. WR will function as an error injection command, Write DQ data is error injection pattern (CW0 or CW1 by MR9 OP3)
2. RD will function as an outcome output command, Read DQ/ECC/SEV data is the outcome of ECC engine test

6.9.6 ECC Engine Test Mode (cont'd)

The following sequence must be satisfied to perform a functional On-die ECC engine test mode of HBM3 DRAM. See Figure 76 and Table 62.

1. The HBM3 device registers Mode Register Set command (MRS) by MR9 OP[3:2] for the entry of On-die ECC engine test mode in Table 61. Error severity reporting must be enabled via the SEVR bit in MR9 OP1. The MD bit in MR9 OP0 must be set according to the user's desire to include the ECC signals in this test or not.
2. As an example in Table 62 — Example of Error Vectors and Corresponding Severity for the engine test, write “1” as Error and “0” as NE(No Error) in the case of CW0 mode. The symbol boundary is vendor specific, and output and severity information are determined according to the error type injected by the host.
3. To check the result of engine test, read the output after t_{WTR} .
 - A. The DQs will show the correction data as ALL “0” when the DATA is CEs or CEm in the case of CW0. Also, the output will show the values as written data when the DATA is UE case.
 - B. The BL[7:4] of SEV[1:0] pins will indicate NE, CEs, CEm and UE. CEs severity information can be real-time signaling via SEV[1:0]. During ECC engine test, #ERRTH value is ignored.
4. Repeat the 2, 3, 4 sequence and the operation for the engine test after t_{RTW} .
 - A. E.g.) Mode entry - WR-RD - WR-RD - WR-RD - ...

In this case, a single WR must be followed by a single RD.

The mapping between DQ/ECC and DATA[271:0] is vendor specific. When the MRS bit is enabled, the core is not accessed, and the data pattern is interpreted as an error vector. When HBM3 is in the ECC Engine Test Mode, it does not guarantee data retention and the only allowed commands are CNOP, WR, RD, and MRS to disable this test mode.




Figure 76 — The Block Diagram of On-die ECC Engine and Path for ECC Engine Test Mode


6.9.6 ECC Engine Test Mode (cont'd)

Table 62 — Example of Error Vectors and Corresponding Severity

Severity	Error Vector Pattern (MR9 OP3)	Error Vector Input[271:0] (Write data)	Error Vector Output[271:0] (Read data)	Severity (SEV[1:0])	Note
NE	CW0	0000...00000000	0000...00000000	NE	1
	CW1	1111...11111111	1111...11111111		2
CEs	CW0	1000...00000000	0000...00000000	CEs	1
		... 0000...00000001	... 0000...00000000		2
	CW1	0111...11111111	1111...11111111		1
		... 1111...11111110	... 1111...11111111		2
CEm	CW0	0000...00001111	0000...00000000	CEm	1, 3
		... 1111...00000000	... 0000...00000000		2, 3
	CW1	1111...11110000	1111...11111111		
UE	CW0 or 1	None of the above	Not specified	UE	

NOTE 1 CW0 indicates that 1 means the error bit and 0 means normal bit.
 NOTE 2 CW1 indicates that 0 means the error bit and 1 means normal bit.
 NOTE 3 CEm is limited to a symbol.

6.9.6 ECC Engine Test Mode (cont'd)



- NOTE 1 WRITE and READ address must be the same for ECC Engine Test Mode.
- NOTE 2 WRITE and READ commands don't require a preceding ACT command for ECC Engine Test Mode.
- NOTE 3 No other commands are allowed except CNOP and MRS to disable ECC Engine Test mode.
- NOTE 4 WL = 4 and RL = 6 are shown as an example.
- NOTE 5 DATA = DQ[31:0], DBI[3:0], ECC[1:0], SEV[1:0] for PC0 and DATA = DQ[63:32], DBI[7:4], ECC[3:2], SEV[3:2] for PC1.
WDQS_{t/c} = WDQS0_{t/c} for PC0 and WDQS1_{t/c} for PC1.
RDQS_{t/c} = RDQS0_{t/c} for PC0 and RDQS1_{t/c} for PC1.
- NOTE 6 Da, ..., Da+7 = data-in for WRITE command. Db, ..., Db+7 = data-out for READ command.
- NOTE 7 twdqs2dq_o, tqss = 0 and nominal tqw are shown for illustration purposes.
- NOTE 8 twtr should be twtrl by both WRITE and READ access banks in the same bank group for ECC Engine Test Mode.
- NOTE 9 WDBI and RDBI could be on or off. WDBI is controlled with MR0 OP1 and RDBI is controlled with MR0 OP0.
- NOTE 10 WDBI and RDBI off are recommended for output of ECC Engine Test Mode. (see Table 62 — Example of Error Vectors and Corresponding Severity)
- NOTE 11 SEVR on is mandatory to verify on-die ECC transparency.
- NOTE 12 It is recommended that the MD bit is evaluated and the ECC signals are not included with MD on.
- NOTE 13 The WRITE and READ commands do not require a preceding ACT command in this test mode.

Figure 77 — Timing Diagram of ECC Engine Test Mode

6.10 WOSC

6.10.1 WDQS Interval Oscillator

As voltage and temperature change on the HBM3 DRAM, the WDQS clock tree delay will shift and may require re-training. The HBM3 DRAM includes an internal WDQS clock-tree oscillators to measure the amount of delay over a given time interval (determined by the controller), allowing the controller to compare the trained delay value to the delay value seen at a later time. The WDQS Interval Oscillator (“oscillator”) will provide the controller with important information regarding the need to re-train, and the magnitude of potential error. The oscillator is not associated with any channel and operates fully independent of any channel’s operating frequency or state (e.g., bank active, bank idle, power-down, or self refresh). Also, no CK, WDQS or WRCK clock is required while the oscillator is counting. The oscillator is disabled by default upon power-up.

The IEEE1500 instructions WOSC_RUN and WOSC_COUNT are associated with the oscillator. Setting the WOSC_START_STOP bit in the WOSC_RUN Wrapper Data Register to 1 will start an internal ring oscillator that counts the number of times a signal propagates through a copy of the WDQS clock tree. The oscillator is stopped by setting the WOSC_START_STOP bit back to 0. The maximum count is $2^{24} - 1$, and the longest run time for the oscillator to not overflow the counter can be calculated as follows:

$$\text{Longest Run Time Interval} = 2^{24} * t_{\text{RX_DQS2DQ}}(\text{min})$$

The validity of the clock count is indicated by the WOSC_COUNT_VALID bit in the WOSC_COUNT Wrapper Data Register. The default state of 0 indicates an invalid count. The state is also set to 0 when the oscillator is started. When the oscillator stops, the WOSC_COUNT_VALID bit is set to 1 to indicate a valid count, and the result of the counter is stored in the WOSC_COUNT_VALUE field of the WOSC_COUNT WDR. The WOSC_COUNT_VALID bit will remain 0 (invalid) if the counter overflows (2^{24} or more cycles) or if the oscillator is interrupted by pulling RESET_n to LOW. On the other hand, pulling WRST_n to LOW does not impact the oscillator's operation. After the oscillator stops the host may issue the WOSC_COUNT instruction to read out the count.

The controller may adjust the accuracy of the result by running the oscillator for shorter (less accurate) or longer (more accurate) duration. The accuracy of the result for a given temperature and voltage is determined by the following equation:

$$\text{WDQS Oscillator Granularity Error} = \frac{2 * (\text{WDQS delay})}{\text{Run Time}}$$

Where:

- Run Time = total time between the oscillator starting and automatically stopping
- WDQS delay = the value of the WDQS clock tree delay [$t_{\text{RX_DQS2DQ}}(\text{min/max})$]

Additional matching error must be included, which is the difference between WDQS training circuit and the actual WDQS clock tree across voltage and temperature. The matching error is vendor specific.

Therefore, the total accuracy of the WDQS Oscillator counter is given by:

$$\text{WDQS Oscillator Accuracy} = 1 - \text{Granularity Error} - \text{Matching Error}$$

6.10.1 WDQS Interval Oscillator (cont'd)

Example: If the total time between start and stop is 100 ns, and the maximum WDQS clock tree delay is 400 ps [$t_{RX_DQS2DQ}(\max)$], then the WDQS Oscillator Granularity Error is:

$$\text{WDQS Oscillator Granularity Error} = \frac{2 * (0.4 \text{ ns})}{100 \text{ ns}} = 0.8\%$$

This equates to a granularity timing error of 3.2ps.

Assuming a circuit Matching Error of 5.5 ps across voltage and temperature, then the accuracy is:

$$\text{WDQS Oscillator Accuracy} = 1 - \frac{3.2 + 5.5}{400} = 97.8\%$$

Example: Running the WDQS Oscillator for a longer period improves the accuracy. If the total time between start and stop is 250 ns, and the maximum WDQS clock tree delay is 400ps [$t_{RX_DQS2DQ}(\max)$], then the WDQS Oscillator Granularity Error is:

$$\text{WDQS Oscillator Granularity Error} = \frac{2 * (0.4 \text{ ns})}{250 \text{ ns}} = 0.32\%$$

This equates to a granularity timing error of 1.28ps.

Assuming a circuit Matching Error of 5.5 ps across voltage and temperature, then the accuracy is:

$$\text{WDQS Oscillator Accuracy} = 1 - \frac{1.28 + 5.5}{400} = 98.3\%$$

6.10.1 WDQS Interval Oscillator (cont'd)

The WDQS Interval Oscillator matching error is defined as the difference between the WDQS training circuit (interval oscillator) and the actual WDQS clock tree across voltage and temperature.

Parameters:

- t_{RX_DQS2DQ} : Actual WDQS clock tree delay
- $t_{WDQSosc}$: Training circuit (interval oscillator) delay
- $WOSC_{Offset(V)}$: Average delay difference over voltage
- $WOSC_{Offset(T)}$: Average delay difference over temp
- $WOSC_{Match(V)}$: WDQS oscillator matching error over voltage
- $WOSC_{Match(T)}$: WDQS oscillator matching error over temp




Figure 78 — Oscillator Offset ($WOSC_{offset(V)}$)

$WOSC_{Match(V)}$:

$$WOSC_{Match(V)} = [t_{RX_DQS2DQ(V)} - t_{WDQSosc(V)} - WOSC_{offset(V)}]$$

$t_{DQSosc(V)}$:

$$t_{WDQSosc(V)} = \frac{\text{Runtime}}{2 * \text{Count}}$$

6.10.1 WDQS Interval Oscillator (cont'd)




Figure 79 — Oscillator Offset ($WOSC_{offset(T)}$)

$WOSC_{Match(T)}$:

$$WOSC_{Match(T)} = [t_{RX_DQS2DQ(T)} - t_{WDQSosc(T)} - WOSC_{offset(T)}]$$

$t_{WDQSosc(T)}$:

$$t_{WDQSosc(T)} = \frac{\text{Runtime}}{2 * \text{Count}}$$

6.10.1 WDQS Interval Oscillator (cont'd)

Table 63 — WDQS Oscillator Matching Error Specification

Parameter	Symbol	Min	Max	Unit	Notes
WDQS Oscillator Matching Error: voltage variation	WOSC _{Match(V)}			ps	1, 2, 3, 5
WDQS Oscillator Matching Error: temperature variation	WOSC _{Match(T)}			ps	1, 2, 3, 5
WDQS Oscillator Offset for voltage variation	WOSC _{offset(V)}			ps	2, 5
WDQS Oscillator Offset for temperature variation	WOSC _{offset(T)}			ps	2, 5

NOTE 1 The WOSC_{Match} is the matching error per between the actual WDQS and WDQS interval oscillator over voltage or temp.
 NOTE 2 This parameter will be characterized or guaranteed by design.
 NOTE 3 The input stimulus for trx_DQS2DQ will be consistent over voltage and temp conditions.
 NOTE 4 trx_DQS2DQ(V, or T) delay will be the average of WDQS to DQ delay over the runtime period.
 NOTE 5 The matching error and offset of the oscillator came from WDQS Interval oscillator.
 NOTE 6 These parameters are defined per device.

6.10.2 tWDQS2DQ_I Offset Due to Temperature and Voltage Variation

As temperature and voltage change on the HBM3 DRAM, the WDQS clock tree will shift and may require retraining. The oscillator is usually used to measure the amount of delay over a given time interval (determined by the controller), allowing the controller to compare the trained delay value to the delay value seen at a later time. The tWDQS2DQ_I offset due to temperature and voltage variation specification can be used for instances when the oscillator cannot be used to control the tWDQS2DQ_I.

6.11 DCA and DCM

6.11.1 Duty Cycle Adjuster (DCA)

HBM3 DRAMs support a Duty Cycle Adjuster (DCA) that allows the memory controller to adjust the DRAM internally generated WDQS to compensate for a systemic duty cycle error on WDQS. The DCA is located before the WDQS divider or equivalent (see High Level Block Diagram Example of Clocking Scheme Figure 10). The DCA will affect the WDQS duty cycle for both Write and Read operations.

A separate DCA is provided for each WDQS (See Table 23):

- the DCA for WDQS0 (PC0) is controlled via MR11 OP[3:0];
- the DCA for WDQS1 (PC1) is controlled via MR11 OP[7:4];

A range of -7 steps to +7 steps is supported as shown in Figure 80 and changes the effective internal WDQS duty cycle as follows:

- a positive value increases the effective twQSH time and decreases the effective twQLS time;
- a negative value decreases the effective twQSH time and increases the effective twQLS time.

The use of the DCA is optional for the memory controller and is not supported at CK clock frequencies lower than f_{CKDCA} ; at those frequencies it is required to disable the DCA by setting the DCA code to the default value (0000).

A duty cycle adjustment, with or without a duty cycle monitor sequence, shall be performed prior to WDQS-to-CK Alignment Training.

An example of the effect of a DCA code change to the WDQS duty cycle is shown in Figure 81. The maximum offset and step are given in Table 64.





Figure 80 — Duty Cycle Adjuster Range

Table 64 — DCA Maximum Offset and Step Size

Parameter	Min	Max	Unit	Notes
Duty cycle adjuster maximum offset	15	35	ps	1, 2
Duty cycle adjuster single step size	2	5	ps	1, 3

Note 1 The values are guaranteed by design.
Note 2 The parameter describes the absolute maximum offset from step 0 to step +7 or from step 0 to step -7.
Note 3 The single step size reflects the non-linearity of each step.

6.11.1 Duty Cycle Aligner (DCA) (cont'd)



NOTE 1 Refer to the AC Timings clause for the definition of twQSH, twQSL and twDQS.

Figure 81 — Relationship between WDQS Waveform and DCA Code Change (Example)

6.11.2 Duty Cycle Monitor (DCM)

The HBM3 DRAM includes a Duty Cycle Monitor (DCM) that allows the memory controller to observe the DRAM internal WDQS clock tree duty cycle distortion.

The DCM is controlled via MR8 OP1 (see Table 20). Once DCM is enabled by setting MR8 OP1 to 1, the DCM will start the WDQS duty cycle distortion measurement and provide the result on DERR0 for DWORD0 (PC0) and on DERR1 for DWORD1 (PC1) after waiting at least t_{DCMM} time. An even number of continuous WDQS pulses will be required for the complete duration of the measurement cycle, from the MRS command that initiates the measurement until the t_{DCMM} timing has been met. The result will remain valid until the DCM is disabled by setting MR8 OP1 back to 0. The DERR outputs will then return to their default state latest after t_{MOD} has elapsed.

Commands allowed while in this mode are REFab, REFpb, RFMab, RFMpB, RNOP, CNOP, and MRS to disable the duty cycle monitor. Internal current spikes generated by the use of REFab, REFpb, RFMab and RFMpB commands in this mode may negatively impact the training result. Controllers that cannot account for this impact should avoid use of REFab, REFpb, RFMab and RFMpB commands in this mode.

The DCM is not supported at CK clock frequencies lower than fCKDCA, as in the case of DCA.

Table 65 — DCM Measurement Result


WDQS Duty Cycle	Result (DERR0, DERR1)	Notes
< 50%	LOW	1
$\geq 50\%$	HIGH	

NOTE 1 The result is valid a time t_{DCMM} after enabling DCM

The following example command sequence may be used for WDQS duty cycle adjustment (see also Figure 82):

1. Enable both WDQS strobes;
2. Enable DCM and wait for t_{DCMM} ;
3. Observe the measurement result via DERR0 and DERR1 outputs;
4. Disable DCM and wait for t_{MOD} ; DERR0 and DERR1 outputs return to their default state;
5. Issue an MRS command to set an appropriate DCA codes for both WDQS strobes and wait for t_{MOD} ;
6. Repeat steps 2 to 5 as needed;
7. Perform WDQS-to-CK alignment training.

6.11.2 Duty Cycle Monitor (DCM) (cont'd)



NOTE 1 The host may send continuous WDQS pulses throughout the whole duty cycle adjustment procedure, in addition to the required WDQS pulses as shown in the figure.

Figure 82 — Example Sequence for WDQS Duty Cycle Correction

6.12 Self Repair

The HBM3 DRAM supports self repair to help improve SIP assembly yield or to achieve a high level of system reliability by scanning for and repairing failures in the DRAM during the initialization process.

The IEEE1500 instructions SELF_REP and SELF_REP_RESULTS are associated with the HBM3 self repair functionality. Self repair is initiated by setting WIR [7:0] to ‘1Ah’ which loads the SELF_REP instruction. Since the instruction works on 8 channels at a time, WIR [12:8] must be set to ‘1Ch’ or ‘1Dh’ to select one half of the channels to run on. A parallel operation of Self Repair on both groups of 8 channels is not supported. SELF_REP clock source can be WRCK as a direct clock source or reference clock source or an internal clock mode independent of WRCK and independent of any I/O functional clocks.

Setting REP_TYPE field, bits[3:2], of the SELF_REP instruction to ‘11b’ will instruct the DRAM to start the first phase of the self repair process which is ‘self-test’ to identify any hard failures. The SELF_REP instruction works on one SID at a time and must be run on each SID separately by using the SID_SELECT field, bits [5:4]. The number of SELF_REP instructions required to check all channels and SIDs is listed in Table 66. The SELFR_REF_RATE field, bits [7:6], must be set by the host to control temperature compensated refresh rate.

Table 66 — SELF_REP Instruction vs Stack Height

Stack Height	SID	Min # SELF_REP Instructions to Cover all 16 Channels
4H	SID0	2
8H	SID0, SID1	4
12H	SID0, SID1, SID2	6
16H	SID0, SID1, SID2, SID3	8

The ‘self-test’ will use vendor specific pattern(s) that detect hard failures in the HBM3 DRAM. Once the ‘self-test’ phase is complete the DRAM will proceed to the ‘auto-repair’ phase. The ‘auto-repair’ automatically repairs failed address(es) from the ‘self-test’ phase with the number of failed addresses repaired vendor specific.

SELF_REP may be issued any time after the device has been properly initialized, specifically t_{INIT3} has been met and the DRAM is in the all banks idle state. Since the SELF_REP instruction operates on 8 channels at a time as selected by WIR[12:8], the 8 channels identified in 1Ch and 1Dh must be in the all banks idle state. See the vendor specification for the mapping of channels for 1Ch and 1Dh.

During the self repair process the host can poll the DRAM for status using the SR_PROGRESS field of the SELF_REP instruction. The DRAM will report whether the “self-test” is in progress, the “auto-repair” is in progress or the self repair process has completed or not running. The SELF_REP instruction must be kept in the WIR during this time.

Once the self repair process is complete, the SELF_REP_RESULTS instruction can be issued to read out the results. The DRAM will report the results for each SID and will indicate whether; i) fails remain, ii) unrepairable fails remain; iii) SELF_REP should be run again; or iv) Self Repair has not run since INIT or no fails remain after most recent run.

6.12 Self Repair (cont'd)

If after running both the ‘self-test’ and ‘auto-repair’ phases the results indicate that fails remain, the SELF REP instruction can be issued to run only the ‘auto-repair’ phase to repair additional fails by setting the REP_TYPE to ‘10b’. With REP_TYPE set to ‘10b’ the DRAM will repair additional row addresses from the previous ‘self-test’. If additional fails remain, the host can continue to issue SELF_REP instructions with REP_TYPE=‘10b’, followed by SELF_REP_RESULTS, until the DRAM reports ‘00b’ to indicate that there are no fails remaining. If the DRAM reports ‘11b’, this is an indication to the host to run SELF_REP again with either REP_TYPE set to ‘01b’ (‘self-test only) or ‘11b’ (self-test and auto-repair) to load internal fail addresses from the ‘self -test’ phase.

With REP_TYPE set to ‘01b’, the SELF_REPAIR instruction will only run the ‘self-test’ phase and the host can check the results after completion to decide next steps.

If the host runs the ‘auto-repair’ only without previously having run the ‘self-test’ phase, then the SELF_REP_RESULTS instruction will report ‘00b’ as there are no failing address(es).

If the DRAM reports “Unrepairable fails remain” on a channel, this indicates that there are not enough repair elements remaining to repair failed addresses latched during the ‘self-test’ phase. The host can decide whether to run self repair again to repair other channels or complete the repair process.

Once the self repair process is complete, the host must issue a reset of the DRAM by driving RESET_n to low and then following the Initialization Sequence with Stable power.

The host is able to cancel the self repair in progress by using the SELF_REP instruction with REP_TYPE set to ‘00b’, however only the “self-test” phase can be cancelled. The SR_PROGRESS field of the SELF_REP will be set to ‘00b’ and the host must wait t_{SELF_CANCEL} before any additional SELF repair. If no further repair is needed, the host must reset the DRAM.

If the host does not use the polling to determine completion then the following timing parameters will indicate the completion of the REP_TYPE.

Table 67 — SELF_REPAIR Timings

Parameter	REP_TYPE	Phase	Min/Max	Unit
t_{SELF_HEAL}	11b	Self-test and Auto-repair	Max	s
t_{SELF_REP}	10b	Auto-repair	Max	s
t_{SELF_NR}	01b	Self-test	Max	s
t_{SELF_CANCEL}	00b	Self-test cancel time	Max	μ s

Self repair resources are vendor specific. The Self repair resources can be shared with the hard/soft repair resources if the DRAM supports two or more resources per bank. The SHARED REP RES field of the DEVICE_ID indicates whether the DRAM supports separate or shared resources. If the DRAM shares the resources the host can use the HS REP CAP instruction to tell how many resources are available for self repair. When resources shared, any repairs done by self repair will update the resources per bank. The number of repair done by the DRAM per SELF_REP instruction is vendor specific.

6.12 Self Repair (cont'd)

If the DRAM shares resources with self repair, the DRAM must not use all the available resources in a bank. One resource per bank must be left for the host to perform soft repair. If the host desires to allow self repair to use all of the shared resources then the SHARED_OVERRIDE field can be set to '1b'. If the resources are not shared the SHARED_OVERRIDE field will be ignored. Before any self repair, the host is recommended to clear any soft repairs using the undo function on the channels the host plans to run self repair, or a chip reset. Failure to do so could result in the DRAM using the shared resources and operation is then not guaranteed, including loss of data. After the self repair is complete the host can perform soft repairs after checking if resources are available. Table 68 illustrates the expected behavior of the DRAM and the expected SEL REP RESULTS when SHARED_OVERRIDE is set to '0' and '1'.

Table 68 — SELF REP – Expected DRAM Behavior When Resources Shared

Case	Resource vs Fails	Examples						
		Resource(s) before SELF REP	Fails	Override (0 = default)	DRAM behavior	Results	Resource(s) after SELF REP	Subsequent Hard/ Soft repair
1	Resources < Fails	1	2	0 (No)	No repair	Unrepairable fails remain	1	Yes
				1 (Yes)	Auto-repair	Unrepairable fails remain	0	No
2	Resources = Fails	2	2	0 (No)	No repair	Unrepairable fails remain	2	Yes
				1 (Yes)	Auto-repair(s) ¹	No fails remain (Fails remain) ²	0 (1) ³	No (Yes) ³
3	Resources > Fails	3	2	0 (No)	Auto-repair(s) ¹	No fails remain (Fails remain) ²	1 (2) ⁴	Yes
				1 (Yes)	Auto-repair(s) ¹	No fails remain (Fails remain) ²	1 (2) ⁴	Yes
NOTE 1 The number of repairs per SELF REP instruction is vendor specific. NOTE 2 If the DRAM does 1 repair per SELF REP then after the initial SELF REP the DRAM will report 'fails remain' and the host will need to issue a second SELF REP to repair the other fail so that the results are 'no fails remain'. If the DRAM repairs both fails in one SELF REP instruction then the results will be 'no fails remain'. NOTE 3 If the DRAM only does 1 repair per SELF REP, the host has the option to do no further repair and leave the remaining resource for soft repair or use up the one remaining resource with an additional SELF REP. If the DRAM does more than 1 repair per SELF REP then the host cannot do subsequent soft repair. NOTE 4 For Case 3, the number of resources repaired depends on whether the initial SELF REP repairs 1 fail or both.								

6.12 Self Repair (cont'd)

Figure 83 provides a flow chart showing the 3 flows for REP_TYPE field of the SELF_REP instruction.




Figure 83 — Self Repair Flowchart

7 Operating Conditions

7.1 Absolute Maximum DC Rating

Table 69 — Absolute Maximum DC Ratings

Parameter	Symbol	Rating	Unit	Notes
Voltage on V_{DDC} relative to V_{SS}	V_{DDC}	-0.3 to 1.4	V	1, 2
Voltage on V_{DDQ} relative to V_{SS}	V_{DDQ}	-0.3 to 1.4	V	1, 2
Voltage on V_{DDQL} relative to V_{SS}	V_{DDQL}	-0.3 to 0.8	V	1, 2
Voltage on V_{PP} relative to V_{SS}	V_{PP}	-0.3 to 2.1	V	1, 2
Voltage on any signal pin relative to V_{SS}	V_{IN}, V_{OUT}	-0.3 to 1.4	V	1, 2
Storage Temperature	$T_{STORAGE}$		°C	1, 2
NOTE 1	Stresses greater than those listed under “Absolute Maximum Ratings” may cause permanent damage to the device. This is a stress rating only and functional operation of the device at these or any other conditions above those indicated in the operational clauses of this standard is not implied. Exposure to absolute maximum rating conditions for extended periods may affect reliability.			
NOTE 2	See HBM3 Power-up and Initialization Sequence for the relationship between the power supplies.			
NOTE 3	Storage temperature is the case surface temperature on the center/top side of the HBM3 device. For the Measurement conditions, please refer to JESD51-2 standard.			

7.2 Recommended DC Operating Condition

Table 70 — Recommended DC Operating Condition

Parameter	Symbol	Minimum	Typical	Maximum	Unit	Notes
Core Supply Voltage	V_{DDC}	1.067	1.1	1.177	V	1, 2
I/O Supply Voltage	V_{DDQ}	1.067	1.1	1.177	V	1, 2
Supply Voltage for TX Driver Output Stage	V_{DDQL}	0.38	0.4	0.44	V	2
Pump Voltage	V_{PP}	1.746	1.8	1.95	V	2
NOTE 1	V_{DDC} and V_{DDQ} supplies are independent of each other and must not be tied together internally on the HBM3 DRAM					
NOTE 2	The voltage ranges are defined at the HBM3 DRAM micropillars. DC bandwidth is limited to 20 MHz.					

7.3 Operating Temperature

Table 71 — Operating Temperature

Parameter	Symbol	Minimum	Maximum	Unit	Notes
Operating Temperature	T _N			°C	1
Operating Temperature (Optional)	T _E			°C	1, 2

NOTE 1 The operating temperature refers to the junction temperature of all memory die(s) and the optional logic die of the HBM3 DRAM. The host is required to monitor the operating temperature via the IEEE1500 test port instructions TEMPERATURE and CHANNEL_TEMPERATURE. The host is also required to monitor the CATTRIP output that signals if the junction temperature of any die in the HBM3 DRAM exceeds a catastrophic trip-point level that could result in permanent damage of the device.

NOTE 2 HBM DRAM may require additional Refresh cycle. Refer to vendor datasheet.

8 Electrical Characteristics and DQ/CA Rx

8.1 Leakage Current

Table 72 — Input Leakage Current

Parameter	Symbol	Minimum	Max	Unit	Notes
Input leakage current for AWORD and DWORD inputs	I _{L1}	-5	5	µA	1
Input leakage current for AWORD and DWORD outputs and I/O signals	I _{L2}	-15	15	µA	1
NOTE 1 Any input $0V \leq V_{IN} \leq V_{DDQL}$. (All inputs pins including IEEE1500 not under test = 0V)					

8.2 Capacitance

Table 73 — Input/Output Capacitance

Parameter	Symbol	Min	Max	Unit	Notes
Input/Output Capacitance – DQs, DBI, DPAR, ECC, SEV	C _{IO}		0.5	pF	1
Input Capacitance – Row and pF Column Address	C _{ADDR}		0.5	pF	1
Input/Output Capacitance – Read Strobe	C _{RDQS}		0.5	pF	1
Input Capacitance – Write Strobe	C _{WDQS}		0.5	pF	1
Input Capacitance – Clock	C _{CK}		0.5	pF	1
Input/Output Capacitance – DERR, AERR	C _{ERROR}		0.5	pF	1
NOTE 1 This parameter is not subject to production test.					

8.3 DQ Rx Voltage and Timing




Figure 84 — DQ Receiver Mask

The DQ input receiver mask for voltage and timing is shown in Figure 84 is applied per pin. The DQ Rx mask (V_{DIVW} , t_{DIVW}) defines the area the input signal must not encroach in order for the DQ input receiver to successfully capture an input signal with a BER of lower than TBD. The mask is a receiver property.

$V_{cent_DQ(pin_mid)}$ is defined as the midpoint between the largest V_{cent_DQ} voltage level and the smallest V_{cent_DQ} voltage level across all DQ pins for a given DRAM TBD (Determined by DRAM V_{REFD} training granularity, i.e., component/channel/DWORD) level. Each DQ V_{cent} is defined by the center, i.e., widest opening, of the cumulative data input eye as depicted in Figure 85. This clarifies that any DRAM TBD level variation must be accounted for within the DQ Rx mask.





Figure 85 — Across Pin V_{REFD} Voltage Variation

8.3 DQ Rx Voltage and Timing (cont'd)

Table 74 — Input Receiver Voltage Level Specification

Parameter	Symbol	Speed Bin										Unit	Notes		
		4.8 Gbps		5.2 Gbps		5.6 Gbps		6.0 Gbps		6.4 Gbps					
		Min	Max	Min	Max	Min	Max	Min	Max	Min	Max				
DQ Rx Mask voltage p-p	V _{DIVW}		120		120		120		120		120	mV	1, 2		
Input Slew Rate over V _{DIVW}	SR _{IN_DIVW}	1	7	1	7	1	7	1	7	1	7	V/ns	3		
Rx single pulse amplitude	V _{IHLDQ_AC}	190		190		190		190		190		mV	4		
NOTE 1	DQ Rx mask voltage and timing parameters are applied per pin and includes DRAM DQ to WDQS voltage AC noise impact for frequencies > 20 MHz at a fixed temperature on a die.														
NOTE 2	DQ Rx mask voltage V _{DIVW} has to be centered around V _{cent_DQ(pin_mid)} .														
NOTE 3	Input slew rate over V _{DIVW} mask centered at V _{cent_DQ(pin_mid)} .														
NOTE 4	DQ single input pulse amplitude into the receiver has to meet or exceed V _{IHLDQ_AC} at any point over the total UI. No timing requirement above level. V _{IHLDQ_AC} is the peak to peak voltage centered around V _{cent_DQ(pin_mid)} such that V _{IHL_AC} /2 min has to be met both above and below V _{cent_DQ(pin_mid)} .														

8.3 DQ Rx Voltage and Timing (cont'd)



NOTE 1 DQx and DQy are in the same data de-skewing group (Ta) in a DWORD.

NOTE 2 DQx represents the max $t_{WDQS2DQx_I}$ in group Ta, and DQy represents the min $t_{WDQS2DQy_I}$ in group Ta, in this example.

NOTE 3 $t_{WDQS2DQc_I}$ represents the max $t_{WDQS2DQ_I}$ and $t_{WDQS2DQb_I}$ represents the min $t_{WDQS2DQ_I}$ in a DWORD, where Ta, Tb, and Tc are signals in each de-skewing group in this example. $t_{WDQS2DQa_I}$ represents the reference of $t_{WDQS2DQ_I}$ for comparison in this example.

NOTE 4 Timing different between $t_{WDQS2DQx_I}$ and $t_{WDQS2DQy_I}$ represents the max $t_{DQ2DQtra_I}$, in this example.


NOTE 5 Timing different between $t_{WDQS2DQy_I}$ and $t_{WDQS2DQc_I}$ represents the max $t_{DQ2DQter_I}$, in this example.

NOTE 6 Refer to Table 38 for the signals that belong to each signal group.

Figure 86 — DQ to WDQS Timings ($t_{WDQS2DQ_I}$, $t_{DQ2DQtra_I}$, and $t_{DQ2DQter_I}$) at DRAM Pins Referenced from the Internal Latch

8.3 DQ Rx Voltage and Timing (cont'd)

All of the timing terms in DQ to WDQS_t are measured from the WDQS_t/WDQS_c to the center midpoint of the t_{DIVW} window taken at the V_{DIVW} voltage levels centered around V_{cent_DQ(pin_mid)}. In Figure 87, the timings at the pins are referenced with respect to all DQ signal groups center aligned to the DRAM internal latch. The data to data offset in write de-skew group, t_{DQ2DQtra_I}, is defined as the difference between the min and max t_{WDQS2DQ_I} for a given de-skew group. The data to data offset in different write de-skew group, t_{DQ2DQter_I}, is defined as the difference between the min and max t_{WDQS2DQ_I} for a given DWORD. t_{WDQS2DQ_O} is defined as the WDQS to read data and RDQS offset.



- NOTE 1 $t_{DQ2DQtra_O}$ is defined at the same input pattern for all DQ in the same de-skew group signals.
- NOTE 2 $t_{DQ2DQter_O}$ is defined at the skew between de-skew group signals (T_a, T_b in this example) at the latest valid transition of the associated DQ pins. $t_{WDQS2DQx_O}$ represents the min $t_{WDQS2DQ_O}$ and $t_{WDQS2DQy_O}$ represents the max $t_{WDQS2DQ_O}$, in this example.
- NOTE 3 $t_{DQSQtra_O}$ is defined at the skew between RDQS to the last valid transition of the DQ pins in de-skew group T4.

Figure 87 — Read Data Timing Definitions of $t_{DQ2DQtra_O}$, $t_{DQ2DQter_O}$, and $t_{DQSQtra_O}$

8.4 AWORD Signaling

Table 75 — AWORD Receiver Voltage Level Specification

Parameter	Symbol	Min	Max	Unit	Notes
Input HIGH Voltage	V_{IHCA}	$V_{REFCA} + 0.1$		V	1, 3
Input LOW Voltage	V_{ILCA}		$V_{REFCA} - 0.1$	V	1, 3
Command/Address Rx single pulse amplitude	V_{IHLCA_AC}	240		mV	2, 3
NOTE 1 V_{REFCA} based input receiver enabled (see MR14). For C, R, ARFU and APAR inputs.					
NOTE 2 CA single input pulse amplitude into the receiver has to meet or exceed V_{IHL_AC} at any point over the total UI. No timing requirement above level. V_{IHLCA_AC} is the peak to peak voltage centered around $V_{DDQL}/2$ such that $V_{IHLCA_AC}/2$ min has to be met both above and below $V_{DDQL}/2$.					
NOTE 3 Parameter is applied to all speed bins.					




Figure 88 — CA Single Pulse Amplitude and Pulse Width

8.5 CK and WDQS Input Signaling

Table 76 — CK and WDQS Input Voltage Level Specification

Parameter	Symbol	Min	Max	Unit	Notes
CK clock Input Differential Input Voltage	V_{IDCK}	160		mV	1, 7
CK clock Differential Input Cross-point Voltage	V_{IXCK}	$V_{DDQL}/2 - 40\text{mV}$	$V_{DDQL}/2 + 40\text{mV}$	V	2, 7
WDQS Differential Input Voltage	V_{IDWDQS}	150		mV	3, 7
WDQS Differential Input Cross-point Voltage	V_{IXWDQS}	$V_{DDQL}/2 - 30\text{mV}$	$V_{DDQL}/2 + 30\text{mV}$	V	4, 7
RDQS Differential Output Cross-point Voltage	V_{OXRDQS}	$V_{DDQL}/2 - \text{TBD}$	$V_{DDQL}/2 + \text{TBD}$	V	5, 6, 7
WDQS Differential Input Slew Rate	SR_WDQS	TBD	TBD	V/ns	7
NOTE 1 V_{IDCK} is the magnitude of the difference between the input level on CK_t and the input level on CK_c.					
NOTE 2 The input reference level for timings referenced to CK is the point at which CK_t and CK_c cross.					
NOTE 3 V_{IDWDQS} is the magnitude of the difference between the input level on WDQS_t and the input level on WDQS_c.					
NOTE 4 The input reference level for timings referenced to WDQS is the point at which WDQS_t and WDQS_c cross.					
NOTE 5 Includes VDDQL, VDDQ AC noise impact of TBD mV (pk-pk) at the DRAM supply microbumps; AC noise includes system PDN impact.					
NOTE 6 This parameter is guaranteed by design at the DRAM micropillars with Output Timing reference load and Read DBI enabled.					
NOTE 7 Parameter is applied to all speed bins.					

8.5 CK and WDQS Input Signaling (cont'd)




Figure 89 — CK Single Pulse

Table 77 — Differential Input Level for WDQS_t, WDQS_c

Parameter	Symbol	Min	Unit	Notes
WDQS Differential Input High	V_{IHdiff_WDQS}	TBD	mV	
WDQS Differential Input Low	V_{ILdiff_WDQS}	TBD	mV	

Table 78 — Differential Input Slew Rate Definition for WDQS_t, WDQS_c

Description	From	To	Defined by
WDQS Differential Input Slew Rate for Rising Edge (WDQS_t – WDQS_c)	V_{ILdiff_WDQS}	V_{IHdiff_WDQS}	$ V_{ILdiff_WDQS} - V_{IHdiff_WDQS} / T_{Rdiff}$
WDQS Differential Input Slew Rate for Falling Edge (WDQS_t – WDQS_c)	V_{IHdiff_WDQS}	V_{ILdiff_WDQS}	$ V_{ILdiff_WDQS} - V_{IHdiff_WDQS} / T_{Fdiff}$




Figure 90 — Differential Input Slew Rate Definition for WDQS_t, WDQS_c

8.6 Midstack Signaling

Table 79 — Midstack Parameter Specification

Parameter	Symbol	Min	Max	Unit	Notes
Input HIGH Voltage for RESET_n and WRST_n, WRCK, SELECTWIR, SHIFTWR, CAPTUREWR, UPDATEWR and WSI inputs	V _{IHR}	0.7 x V _{DDQ}		V	1
Input LOW Voltage for RESET_n and WRST_n, WRCK, SELECTWIR, SHIFTWR, CAPTUREWR, UPDATEWR and WSI inputs	V _{ILR}		0.2 x V _{DDQ}	V	1
Output HIGH Voltage for CATTRIP, TEMP and WSO outputs	V _{OHR}	0.7 x V _{DDQ}		V	
Output LOW Voltage for CATTRIP, TEMP and WSO outputs	V _{OLR}		0.3 x V _{DDQ}	V	
NOTE 1 CMOS input receivers. For RESET_n, WRST_n, WRCK, SELECTWIR, SHIFTWR, CAPTUREWR, UPDATEWR, and WSI inputs.					


8.7 Transmit Driver Currents

HBM3 drivers have programmable current settings with 20% accuracy. Driver targets, in mA, are shown in Table 80.

Table 80 — Transmit Driver Current Specification

Nominal (mA)	Min (mA)	Max (mA)	Notes
8.0	6.4	9.6	2
10.0	8.0	12.0	2
12.0	9.6	14.4	2
14.0	11.2	16.8	1, 2
NOTE 1 Implementation optional for devices not supporting 6.4 Gbps.			
NOTE 2 Transmit driver current is based on measurement of 0.5 x VDDQL			

8.8 Output Timing Reference Load



NOTE C = C_{TOTAL} - C_{IO}; where C_{TOTAL} = 2.50 pF


Figure 91 — Timing Reference Load

8.9 Output Voltage Level

Table 81 — Output Voltage Level

Parameter	Symbol	Min	Max	Unit	Notes
Output HIGH Voltage	V_{OH}	$V_{DDQL}/2 + 60 \text{ mV}$		V	
Output LOW Voltage	V_{OL}		$V_{DDQL}/2 - 60 \text{ mV}$	V	

8.10 Output Rise and Fall Time



NOTE $T_R = \{ C_{TOTAL} \times (V_{OH} - V_{OL}) \} / I$; $T_F = \{ C_{TOTAL} \times (V_{OH} - V_{OL}) \} / I$;
Where I = Transmit Drive Current in mA.

Figure 92 — Output Rise and Fall Definition

8.11 Overshoot/Undershoot

Table 82 — Overshoot/Undershoot Specification for AWORD and DWORD Signals

Parameter	4.8 Gbps	5.2 Gbps	5.6 Gbps	6.0 Gbps	6.4 Gbps	Unit	Notes
Maximum peak amplitude allowed for overshoot area	0.12	0.12	0.12	0.12	0.12	V	
Maximum peak amplitude allowed for undershoot area	0.12	0.12	0.12	0.12	0.12	V	
Maximum overshoot area above V_{DDQL}	13	12	11	10	9	mV-ns	
Maximum undershoot area below V_{SS}	13	12	11	10	9	mV-ns	




Figure 93 — Overshoot, Undershoot Definition

9 IDD Specification

9.1 IDD and IPP Specification Parameters and Test Conditions

This clause defines operating current measurement conditions and loop pattern.

- I_{DD} currents are measured as time-averaged currents with all V_{DDC} microbumps of the HBM3 device under test tied together.
- I_{PP} currents use the same definitions as I_{DD} except that the current on the V_{PP} supply is measured. All V_{PP} microbumps of the HBM3 device under test are tied together for I_{PP} current measurements.
- I_{DDQ} currents are measured as time-averaged currents with all V_{DDQ} microbumps of the HBM3 device under test tied together are not included in the measurements. Instead, DRAM vendors shall provide simulated values using the I_{DD4R} measurement-loop pattern as defined in Table 83.
- I_{DDQL} currents are measured as time-averaged currents with all V_{DDQL} microbumps of the HBM3 device under test tied together. Output reference load C_{TOTAL} is 2.5 pF, and the simulated load driving current can be added to the I_{DDQL} if vendor uses no load for this measurement.
- I_{DD} , I_{DDQ} , I_{DDQL} , and I_{PP} measurements are taken with all channels of the HBM3 device simultaneously executing the same pattern. However, values in the vendor's datasheet shall be given per channel.

For IDD measurements, the following definitions apply:

- “0” and “LOW” are defined as $V_{IN} \leq V_{IL}(\text{max})$;
- “1” and “HIGH” are defined as $V_{IN} \geq V_{IH}(\text{min})$;
- WL, RL, RAS, and RTP are programmed to appropriate values;
- DBIac is enabled for Reads and Writes;
- SEV and parity are disabled;
- MD is enabled in MR9;
- CNOP/RNOP commands and all address inputs are stable during idle command cycles;
- Some I_{DD} Measurement-Loop pattern use high order address bits RA14 and RA13 which are not defined for all densities. In those cases the respective undefined address bit(s) shall be kept LOW.
- Basic I_{DD} Measurement Conditions are described in Table 83.
- I_{DD} Measurements are done after properly initializing the HBM3 device. This includes the pre-load of the memory array with data pattern used with I_{DD4R} measurements.
- The I_{DD} Measurement-Loop patterns shall be executed at least once before actual I_{DD} measurement is started.
- For timing parameters used with I_{DD} Measurement-Loop pattern: $nRC = tRC/tCK$; $nRAS = tRAS/tCK$, $nRP = tRP/tCK$, and $nRFC = tRFC/tCK$. If not already an integer, round up to the next integer.

9.1 IDD and IPP Specification Parameters and Test Conditions (cont'd)




Figure 94 — Measurement Setup for IDD and IPP Measurements

Table 83 — Basic IDD/DDQ/IPP/DDQL Measurement Conditions

Parameter/Condition	Symbol
One Bank Activate Precharge Current: $t_{CK} = t_{CK}(\min)$; t_{RC} , t_{RAS} and t_{RP} as defined in Table 84; R and C inputs are HIGH between valid commands; DQ, ECC and DBI inputs are LOW; bank and row addresses with ACT and PRE commands as defined in Table 85.	I_{DD0} , I_{DDQ0} , I_{PP0} , I_{DDQL0}
Precharge Power-down Current: Device in Precharge Power-Down is issued; $t_{CK} = t_{CK}(\min)$; all banks are idle; R0 input is LOW; R[9:1] and C inputs are HIGH; DQ, ECC and DBI inputs are LOW	I_{DD2P} , I_{DDQ2P} , I_{PP2P} , I_{DDQL2P}
Precharge Power-down Current with clock stop: Device in Precharge Power-Down is issued; CK_t is LOW; CK_c is HIGH; all banks are idle; R0 input is LOW; R[9:1] and C inputs are HIGH; DQ, ECC and DBI inputs are LOW	I_{DD2P0} , I_{DDQ2P0} , I_{PP2P0} , $I_{DDQL2P0}$
Precharge Standby Current: $t_{CK} = t_{CK}(\min)$; all banks are idle; R and C inputs are HIGH; DQ, ECC and DBI inputs are LOW	I_{DD2N} , I_{DDQ2N} , I_{PP2N} , I_{DDQL2N}
Active Power-down Current: Device in Active Power-Down is issued; $t_{CK} = t_{CK}(\min)$; one bank is active; R0 input is LOW; R[9:1] and C inputs are HIGH; DQ, ECC and DBI inputs are LOW	I_{DD3P} , I_{DDQ3P} , I_{PP3P} , I_{DDQL3P}
Active Power-down Current with clock stop: Device in Active Power-Down is issued; CK_t is LOW; CK_c is HIGH; one bank is active; R0 input is LOW; R[9:1] and C inputs are HIGH; DQ, ECC and DBI inputs are LOW	I_{DD3P0} , I_{DDQ3P0} , I_{PP3P0} , $I_{DDQL3P0}$
Active Standby Current: $t_{CK} = t_{CK}(\min)$; one bank is active; R and C inputs are HIGH; DQ, ECC and DBI inputs are LOW	I_{DD3N} , I_{DDQ3N} , I_{PP3N} , I_{DDQL3N}

Table 83 — Basic IDD/IDDQ/IPP/IDDQL Measurement Conditions (cont'd)

Parameter/Condition	Symbol
Read Burst Current: $t_{CK} = t_{CK}(\min)$; all banks activated; continuous read burst across bank groups as defined in Table 86; $I_{OUT} = 0\text{mA}$; $C_{total} = 2.5\text{ pF}$	I_{DD4R} , I_{DDQ4R} , I_{PP4R} , I_{DDQL4R}
Write Burst Current: $t_{CK} = t_{CK}(\min)$; all banks activated; continuous write burst across bank groups as defined in Table 87.	I_{DD4W} , I_{DDQ4W} , I_{PP4W} , I_{DDQL4W}
All-bank Refresh Burst Current: $t_{CK} = t_{CK}(\min)$; t_{RFCab} as defined Table 84; R and C inputs are HIGH between valid commands; DQ, ECC and DBI inputs are LOW	I_{DD5B} , I_{DDQ5B} , I_{PP5B} , I_{DDQL5B}
Per-bank Refresh Burst Current: $t_{CK} = t_{CK}(\min)$; Use t_{RFCpb} and t_{RREFD} as defined in Table 84; R and C inputs are HIGH between valid commands; DQ, ECC and DBI inputs are LOW; The order of bank is sequential from BK0 to BK15 with sequential SID.	I_{DD5P} , I_{DDQ5P} , I_{PP5P} , I_{DDQL5P}
Self Refresh Current: R0 input is LOW; R[9:1] and C inputs are LOW; DQ, ECC and DBI inputs are LOW	I_{DD6} , I_{DDQ6} , I_{PP6} , I_{DDQL6}
All-Bank Interleave Read Current: One bank in each of the 4 bank groups activated and precharged at $t_{RC}(\min)$ as defined in Table 89; continuous read burst across bank groups; $C_{total}=2.5\text{ pF}$	I_{DD7} , I_{DDQ7} , I_{PP7} , I_{DDQL7}
Reset Low Current: RESET_n is LOW; CK_t, CK_c, WDQS_t, WDQS_c are LOW; R and C inputs are LOW; DQ, ECC and DBI inputs are LOW; Note: Reset low current reading is valid once power is stable and RESET_n has been LOW for at least 1ms	I_{DD8} , I_{DDQ8} , I_{PP8} , I_{DDQL8}

9.1 IDD and IPP Specification Parameters and Test Conditions (cont'd)

Table 84 — Example of Timings Used for IDD Measurement-Loop Pattern

Parameter			Value	Unit
t_{RC}			48	ns
t_{RAS}			33	ns
t_{RP}			15	ns
t_{RREFD}			8	ns
t_{RFCpb}			200	ns
t_{RFCab}	8 Gb/die	8-High	4 Gb / channel	260
		12-High	6 Gb / channel	310
		16-High	8 Gb / channel	350
	16 Gb/die	4-High	4 Gb / channel	260
		8-High	8 Gb / channel	350
		12-High	12 Gb / channel	410
NOTE 1 DRAM vendors may decide to use different values for t_{RAS} and t_{RP} ; however, $n_{RAS} + n_{RP} = n_{RC}$ must be achieved. $n_{RAS} = RU(t_{RAS}/t_{CK})$, $n_{RP} = RU(t_{RP}/t_{CK})$, $n_{RFCpb} = RU(t_{RFCpb}/t_{CK})$, $n_{RREFD} = RU(t_{RREFD}/t_{CK})$. If not already an integer, round up to the next integer.				

9.1 IDD and IPP Specification Parameters and Test Conditions (cont'd)

Table 85 — IDD0 Measurement-Loop Pattern

Sub-Loop	Cycle Number	Row Command	Column Command	Bank Address (BA[3:0])	Row Address (RA[14:0])	Col. Address (CA[4:0])					
0	0	ACT – PC0	CNOP	00h	05555h	0Ah					
	1		CNOP			0Ah					
	2	ACT – PC1	CNOP	00h	05555h	0Ah					
	3		CNOP			0Ah					
	4	RNOP	CNOP	00h	05555h	0Ah					
	...	Repeat pattern until cycle (nRAS)									
	nRAS + 1	PRE – PC0	CNOP	00h	05555h	0Ah					
	nRAS + 2	RNOP	CNOP	00h	05555h	0Ah					
	nRAS + 3	PRE – PC1	CNOP	00h	05555h	0Ah					
	nRAS + 4	RNOP	CNOP	00h	05555h	0Ah					
	...	Repeat pattern until cycle (nRC – 1)									
1	nRC	repeat sub-loop 0 pattern until cycle ($2 \times nRC - 1$); use BA = 05h and RA = 02AAAh instead									
2	2 x nRC	repeat sub-loop 0 pattern until cycle ($3 \times nRC - 1$); use BA = 02h and RA = 05555h instead									
3	3 x nRC	repeat sub-loop 0 pattern until cycle ($4 \times nRC - 1$); use BA = 07h and RA = 02AAAh instead									
4	4 x nRC	repeat sub-loop 0 pattern until cycle ($5 \times nRC - 1$); use BA = 01h and RA = 05555h instead									
5	5 x nRC	repeat sub-loop 0 pattern until cycle ($6 \times nRC - 1$); use BA = 06h and RA = 02AAAh instead									
6	6 x nRC	repeat sub-loop 0 pattern until cycle ($7 \times nRC - 1$); use BA = 03h and RA = 05555h instead									
7	7 x nRC	repeat sub-loop 0 pattern until cycle ($8 \times nRC - 1$); use BA = 04h and RA = 02AAAh instead									
8 to 15	for 16-bank devices: repeat sub-loops 0 to 7 pattern; use BA3 = 1 instead, maintain SID[1:0] = 00										
16 to 31	for 8-High,12-High and 16-High devices: repeat sub-loops 0,1 and 2 pattern; use SID[1:0] = 01 instead										
32 to 47	for 12-High and 16-High devices: repeat sub-loops 0,1 and 2 pattern; use SID[1:0] = 10 instead										
48 to 63	for 16-High devices: repeat sub-loops 0,1 and 2 pattern; use SID[1:0] = 11 instead										

9.1 IDD and IPP Specification Parameters and Test Conditions (cont'd)

Table 86 — IDD4R Measurement-Loop Pattern

Sub-Loop	Cycle Number	Row Command	Column Command	Row Bank Address (BA[3:0])	Col. Bank Address (BA[3:0])	Row Address (RA[14:0])	Col. Address (CA[4:0])	Data Pattern (1 Byte)							
0	0	RNOP	READ – PC0	02h	00h	05555h	0Ah	Pattern A							
	1	RNOP	READ – PC1	02h	00h	05555h	0Ah	Pattern A							
	2	RNOP	READ – PC0	02h	04h	05555h	15h	Pattern B							
	3	RNOP	READ – PC1	02h	04h	05555h	15h	Pattern B							
	4	RNOP	READ – PC0	02h	08h	05555h	1Ah	Pattern A							
	5	RNOP	READ – PC1	02h	08h	05555h	1Ah	Pattern A							
	6	RNOP	READ – PC0	02h	0Ch	05555h	05h	Pattern B							
	7	RNOP	READ – PC1	02h	0Ch	05555h	05h	Pattern B							
	8	RNOP	READ – PC0	06h	04h	02AAAh	0Ah	Pattern A							
	9	RNOP	READ – PC1	06h	04h	02AAAh	0Ah	Pattern A							
	10	RNOP	READ – PC0	06h	08h	02AAAh	15h	Pattern B							
	11	RNOP	READ – PC1	06h	08h	02AAAh	15h	Pattern B							
	12	RNOP	READ – PC0	06h	0Ch	02AAAh	1Ah	Pattern A							
	13	RNOP	READ – PC1	06h	0Ch	02AAAh	1Ah	Pattern A							
	14	RNOP	READ – PC0	06h	00h	02AAAh	05h	Pattern B							
	15	RNOP	READ – PC1	06h	00h	02AAAh	05h	Pattern B							
	16	RNOP	READ – PC0	0Ah	08h	05555h	0Ah	Pattern A							
	17	RNOP	READ – PC1	0Ah	08h	05555h	0Ah	Pattern A							
	18	RNOP	READ – PC0	0Ah	0Ch	05555h	15h	Pattern B							
	19	RNOP	READ – PC1	0Ah	0Ch	05555h	15h	Pattern B							
	20	RNOP	READ – PC0	0Ah	00h	05555h	1Ah	Pattern A							
	21	RNOP	READ – PC1	0Ah	00h	05555h	1Ah	Pattern A							
	22	RNOP	READ – PC0	0Ah	04h	05555h	05h	Pattern B							
	23	RNOP	READ – PC1	0Ah	04h	05555h	05h	Pattern B							
	24	RNOP	READ – PC0	0Eh	0Ch	02AAAh	0Ah	Pattern A							
	25	RNOP	READ – PC1	0Eh	0Ch	02AAAh	0Ah	Pattern A							
	26	RNOP	READ – PC0	0Eh	00h	02AAAh	15h	Pattern B							
	27	RNOP	READ – PC1	0Eh	00h	02AAAh	15h	Pattern B							
	28	RNOP	READ – PC0	0Eh	04h	02AAAh	1Ah	Pattern A							
	29	RNOP	READ – PC1	0Eh	04h	02AAAh	1Ah	Pattern A							
	30	RNOP	READ – PC0	0Eh	08h	02AAAh	05h	Pattern B							
	31	RNOP	READ – PC1	0Eh	08h	02AAAh	05h	Pattern B							
1		repeat sub-loop 0 pattern; use RBA0 = 1 and CBA0 = 1 instead, maintain SID[1:0]=00													
2		repeat sub-loop 0 and 1 pattern; use RBA1 = 0 and CBA1 = 1 instead, maintain SID[1:0]=00 RNOP, CNOP 2-cycle before SID change to meet TCCDR													
3		for 8-High,12-High and 16-High devices: repeat sub-loops 0,1 and 2 pattern; use SID[1:0] = 01 instead													
4		for 12-High and 16-High devices: repeat sub-loops 0,1 and 2 pattern; use SID[1:0] = 10 instead													
5		for 16-High devices: repeat sub-loops 0,1 and 2 pattern; use SID[1:0] = 11 instead													
Note 1 Pattern A for a Byte (BL0 to BL7) : 00h, 3Ch, F0h, 69h, AAh, FFh, C3h, 55h															
Note 2 Pattern B for a Byte (BL0 to BL7) : F0h, A5h, 96h, 0Fh, C3h, 55h, CCh, 5Ah															
Note 3 Vendors may provide IDD4/7 values based on worse toggle patterns reflecting internal bus architecture															

9.1 IDD and IPP Specification Parameters and Test Conditions (cont'd)

Table 87 — IDD4W Measurement-Loop Pattern

Sub-Loop	Cycle Number	Row Command	Column Command	Row Bank Address (BA[3:0])	Col. Bank Address (BA[3:0])	Row Address (RA[14:0])	Col. Address (CA[4:0])	Data Pattern (1 Byte)							
0	0	RNOP	WRITE – PC0	02h	00h	05555h	0Ah	Pattern A							
	1	RNOP	WRITE – PC1	02h	00h	05555h	0Ah	Pattern A							
	2	RNOP	WRITE – PC0	02h	04h	05555h	15h	Pattern B							
	3	RNOP	WRITE – PC1	02h	04h	05555h	15h	Pattern B							
	4	RNOP	WRITE – PC0	02h	08h	05555h	1Ah	Pattern A							
	5	RNOP	WRITE – PC1	02h	08h	05555h	1Ah	Pattern A							
	6	RNOP	WRITE – PC0	02h	0Ch	05555h	05h	Pattern B							
	7	RNOP	WRITE – PC1	02h	0Ch	05555h	05h	Pattern B							
	8	RNOP	WRITE – PC0	06h	04h	02AAAh	0Ah	Pattern A							
	9	RNOP	WRITE – PC1	06h	04h	02AAAh	0Ah	Pattern A							
	10	RNOP	WRITE – PC0	06h	08h	02AAAh	15h	Pattern B							
	11	RNOP	WRITE – PC1	06h	08h	02AAAh	15h	Pattern B							
	12	RNOP	WRITE – PC0	06h	0Ch	02AAAh	1Ah	Pattern A							
	13	RNOP	WRITE – PC1	06h	0Ch	02AAAh	1Ah	Pattern A							
	14	RNOP	WRITE – PC0	06h	00h	02AAAh	05h	Pattern B							
	15	RNOP	WRITE – PC1	06h	00h	02AAAh	05h	Pattern B							
	16	RNOP	WRITE – PC0	0Ah	08h	05555h	0Ah	Pattern A							
	17	RNOP	WRITE – PC1	0Ah	08h	05555h	0Ah	Pattern A							
	18	RNOP	WRITE – PC0	0Ah	0Ch	05555h	15h	Pattern B							
	19	RNOP	WRITE – PC1	0Ah	0Ch	05555h	15h	Pattern B							
	20	RNOP	WRITE – PC0	0Ah	00h	05555h	1Ah	Pattern A							
	21	RNOP	WRITE – PC1	0Ah	00h	05555h	1Ah	Pattern A							
	22	RNOP	WRITE – PC0	0Ah	04h	05555h	05h	Pattern B							
	23	RNOP	WRITE – PC1	0Ah	04h	05555h	05h	Pattern B							
	24	RNOP	WRITE – PC0	0Eh	0Ch	02AAAh	0Ah	Pattern A							
	25	RNOP	WRITE – PC1	0Eh	0Ch	02AAAh	0Ah	Pattern A							
	26	RNOP	WRITE – PC0	0Eh	00h	02AAAh	15h	Pattern B							
	27	RNOP	WRITE – PC1	0Eh	00h	02AAAh	15h	Pattern B							
	28	RNOP	WRITE – PC0	0Eh	04h	02AAAh	1Ah	Pattern A							
	29	RNOP	WRITE – PC1	0Eh	04h	02AAAh	1Ah	Pattern A							
	30	RNOP	WRITE – PC0	0Eh	08h	02AAAh	05h	Pattern B							
	31	RNOP	WRITE – PC1	0Eh	08h	02AAAh	05h	Pattern B							
1		repeat sub-loop 0 pattern; use RBA0 = 1 and CBA0 = 1 instead, maintain SID[1:0]=00													
2		repeat sub-loop 0 and 1 pattern; use RBA1 = 0 and CBA1 = 1 instead, maintain SID[1:0]=00													
3		for 8-High,12-High and 16-High devices: repeat sub-loops 0,1 and 2 pattern; use SID[1:0] = 01 instead													
4		for 12-High and 16-High devices: repeat sub-loops 0,1 and 2 pattern; use SID[1:0] = 10 instead													
5		for 16-High devices: repeat sub-loops 0,1 and 2 pattern; use SID[1:0] = 11 instead													
Note 1 Pattern A for a Byte (BL0 to BL7) : 00h, 3Ch, F0h, 69h, AAh, FFh, C3h, 55h															
Note 2 Pattern B for a Byte (BL0 to BL7) : F0h, A5h, 96h, 0Fh, C3h, 55h, CCh, 5Ah															
Note 3 Vendors may provide IDD4/7 values based on worse toggle patterns reflecting internal bus architecture															

9.1 IDD and IPP Specification Parameters and Test Conditions (cont'd)

Table 88 — IDD5P Measurement-Loop Pattern

Sub-Loop	Cycle Number	Row Command	Column Command	Row Bank Address (SID[1:0], BA[3:0])
0	0	PER-BANK REFRESH – PC0	CNOP	00h, 00h
	1	RNOP	CNOP	N/A
	2	PER-BANK REFRESH – PC1	CNOP	00h, 00h
	3	RNOP	CNOP	N/A
	...	repeat RNOP until cycle (nRREFD-1)		
1	nRREFD	repeat sub-loop 0 pattern until cycle (2 x nRREFD-1); use BA=05h instead		
2	2 x nRREFD	repeat sub-loop 0 pattern until cycle (3 x nRREFD-1); use BA=02h instead		
3	3 x nRREFD	repeat sub-loop 0 pattern until cycle (4 x nRREFD-1); use BA=07h instead		
4	4 x nRREFD	repeat sub-loop 0 pattern until cycle (5 x nRREFD-1); use BA=01h instead		
5	5 x nRREFD	repeat sub-loop 0 pattern until cycle (6 x nRREFD-1); use BA=06h instead		
6	6 x nRREFD	repeat sub-loop 0 pattern until cycle (7 x nRREFD-1); use BA=03h instead		
7	7 x nRREFD	repeat sub-loop 0 pattern until cycle (8 x nRREFD-1); use BA=04h instead		
	repeat sub-loops 0 to 7 pattern; use BA3=1 instead			
	for 4-High devices: wait for (nRFCpb - 15 x nRREFD) for all other devices: repeat sub-loops 0 to 15 pattern; use SID[1:0] = 01h instead			
	for 12-High and 16-High devices: repeat sub-loops 0 to 15 pattern; use SID[1:0] = 02h instead			
	for 16-High devices: repeat sub-loops 0 to 15 pattern; use SID[1:0] = 03h instead			

NOTE 1 nRFCpb = RU(tRFCpb/tCK), nRREFD = RU(tRREFD/tCK). If not already an integer, round up to the next integer.

9.1 IDD and IPP Specification Parameters and Test Conditions (cont'd)

Table 89 — IDD7 Measurement-Loop Pattern

Sub-Loop	Cycle Number	Row Command	Column Command	Row Bank Address (BA[3:0])	Col. Bank Address (BA[3:0])	Row Address (RA[14:0])	Col. Address (CA[4:0])	Data Pattern (1 Byte)							
0	0	ACT – PC0	READ – PC0	02h	00h	05555h	0Ah	Pattern A							
	1		READ – PC1		00h		0Ah	Pattern A							
	2	ACT – PC1	READ – PC0	02h	04h	05555h	15h	Pattern B							
	3		READ – PC1		04h		15h	Pattern B							
	4	RNOP	READ – PC0	02h	08h	05555h	1Ah	Pattern A							
	5	RNOP	READ – PC1	02h	08h	05555h	1Ah	Pattern A							
	6	RNOP	READ – PC0	02h	0Ch	05555h	05h	Pattern B							
	7	RNOP	READ – PC1	02h	0Ch	05555h	05h	Pattern B							
	8	ACT – PC0	READ – PC0	06h	04h	02AAAh	0Ah	Pattern A							
	9		READ – PC1		04h		0Ah	Pattern A							
	10	ACT – PC1	READ – PC0	06h	08h	02AAAh	15h	Pattern B							
	11		READ – PC1		08h		15h	Pattern B							
	12	RNOP	READ – PC0	06h	0Ch	02AAAh	1Ah	Pattern A							
	13	RNOP	READ – PC1	06h	0Ch	02AAAh	1Ah	Pattern A							
	14	RNOP	READ – PC0	06h	00h	02AAAh	05h	Pattern B							
	15	RNOP	READ – PC1	06h	00h	02AAAh	05h	Pattern B							
	16	ACT – PC0	READ – PC0	0Ah	08h	05555h	0Ah	Pattern A							
	17		READ – PC1		08h		0Ah	Pattern A							
	18	ACT – PC1	READ – PC0	0Ah	0Ch	05555h	15h	Pattern B							
	19		READ – PC1		0Ch		15h	Pattern B							
	20	RNOP	READ – PC0	0Ah	00h	05555h	1Ah	Pattern A							
	21	RNOP	READ – PC1	0Ah	00h	05555h	1Ah	Pattern A							
	22	RNOP	READ – PC0	0Ah	04h	05555h	05h	Pattern B							
	23	RNOP	READ – PC1	0Ah	04h	05555h	05h	Pattern B							
	24	ACT – PC0	READA – PC0	0Eh	0Ch	02AAAh	0Ah	Pattern A							
	25		READA – PC1		0Ch		0Ah	Pattern A							
	26	ACT – PC1	READA – PC0	0Eh	00h	02AAAh	15h	Pattern B							
	27		READA – PC1		00h		15h	Pattern B							
	28	RNOP	READA – PC0	0Eh	04h	02AAAh	1Ah	Pattern A							
	29	RNOP	READA – PC1	0Eh	04h	02AAAh	1Ah	Pattern A							
	30	RNOP	READA – PC0	0Eh	08h	02AAAh	05h	Pattern B							
	31	RNOP	READA – PC1	0Eh	08h	02AAAh	05h	Pattern B							
1		repeat sub-loop 0 pattern; use RBA0 = 1 and CBA0 = 1 instead, maintain SID[1:0]=00													
2		repeat sub-loop 0 and 1 pattern; use RBA1 = 0 and CBA1 = 1 instead, maintain SID[1:0]=00 RNOP, CNOP 2-cycle before SID change to meet tCCDR													
3		for 8-High,12-High and 16-High devices: repeat sub-loops 0,1 and 2 pattern; use SID[1:0] = 01 instead													
4		for 12-High and 16-High devices: repeat sub-loops 0,1 and 2 pattern; use SID[1:0] = 10 instead													
5		for 16-High devices: repeat sub-loops 0,1 and 2 pattern; use SID[1:0] = 11 instead													
NOTE 1 Pattern A for a Byte (BL0 to BL7) : 00h, 3Ch, F0h, 69h, AAh, FFh, C3h, 55h															
NOTE 2 Pattern B for a Byte (BL0 to BL7) : F0h, A5h, 96h, 0Fh, C3h, 55h, CCh, 5Ah															
NOTE 3 Vendors may provide IDD4/7 values based on worse toggle patterns reflecting internal bus architecture															

9.2 IDD and IPP Specifications

IDD and IPP values are valid for the full operating range of voltage and temperature unless otherwise noted.

Table 90 — IDD and IPP Specification Example

Symbol	Speed Bin		Unit	Notes
	IDD (Max)	IPP (Max)		
IDD0			mA	
IDD2P			mA	
IDD2P0			mA	
IDD2N			mA	
IDD3P			mA	
IDD3P0			mA	
IDD3N			mA	
IDD4R			mA	
IDD4W			mA	
IDD5B			mA	
IDD5P			mA	
IDD6x	See Separate Table		mA	
IDD7			mA	
IDD8			mA	

9.3 IDD6 Specification

Table 91 — IDD6 Specification

Symbol	Temperature Range	Value	Unit	Notes
IDD6N	0°C - T _N		mA	2, 3, 7
IDD6E (Optional)	0°C - T _E		mA	1, 3, 4, 7
IDD6R (Optional)	0°C - T _R		mA	3, 5, 7
IDD6A (Optional)	0°C - T _a		mA	3, 5, 6
	T _b - T _y (optional)		mA	3, 5, 6
	T _z - T _{OPERmax}		mA	3, 5, 6, 8
NOTE 1	Max. values for IDD currents considering worst case conditions of process, temperature and voltage.			
NOTE 2	Applicable for MR0 settings OP2=0.			
NOTE 3	Supplier data sheets include a max value.			
NOTE 4	IDD6E is only specified for devices which support the Extended Temperature Range feature.			
NOTE 5	IDD6A is only specified for devices which support the Temperature Controlled Self Refresh feature enabled by MR0 with OP2=1.			
NOTE 6	The number of discrete temperature ranges supported and the associated T _a - T _z , and T _{OPERmax} values are supplier/design specific. Temperature ranges are intended to denote the nominal trip points for the internal temperature sensor to bracket discrete self refresh rates internal to the DRAM. Refer to supplier datasheet for more information.			
NOTE 7	T _R represents the temperature used to reflect the current consumed in a typical room temperature environment.			
NOTE 8	T _{OPERmax} represents the max temperature supported by the DRAM when TCSR is enabled.			

10 AC Timings

Table 92 — Timings Parameters (Part 1)

Parameter	Symbol	Speed Bin ²										Unit	Notes		
		4.8 Gbps/pin		5.2 Gbps/pin		5.6 Gbps/pin		6.0 Gbps/pin		6.4 Gbps/pin					
		Min	Max	Min	Max	Min	Max	Min	Max	Min	Max				
CK Timings															
CK clock frequency	f _{CK}	50	1200	50	1300	50	1400	50	1500	50	1600	MHz			
CK clock period	t _{CK}	0.833	20	0.769	20	0.714	20	0.667	20	0.625	20	ns	4		
Absolute CK clock differential HIGH-level width	t _{CH}	0.45	0.55	0.45	0.55	0.45	0.55	0.45	0.55	0.45	0.55	t _{CK}	40		
Absolute CK clock differential LOW-level width	t _{CL}	0.45	0.55	0.45	0.55	0.45	0.55	0.45	0.55	0.45	0.55	t _{CK}	40		
Command and Address Input Timings															
Command and address input setup time based on VIH/VIL	t _{IS}	92		85		79		73		69		ps	5		
Command and address input hold time based on VIH/VIL	t _{IH}	92		85		79		73		69		ps	5		
Command and address single pulse width	t _{CIPW}	292		269		250		233		219		ps	27		
Data Input Timings															
WDQS clock period	t _{WDQS}	0.416	10	0.385	10	0.357	10	0.333	10	0.312	10	ns	41		
Average WDQS differential input HIGH pulse width	t _{WQSH(avg)}	0.47	0.53	0.47	0.53	0.47	0.53	0.47	0.53	0.47	0.53	t _{WDQS}	42		
Average WDQS differential input LOW pulse width	t _{WQSL(avg)}	0.47	0.53	0.47	0.53	0.47	0.53	0.47	0.53	0.47	0.53	t _{WDQS}	42		
Absolute WDQS differential input HIGH pulse width	t _{WQSH(abs)}	0.45	0.55	0.45	0.55	0.45	0.55	0.45	0.55	0.45	0.55	t _{WDQS}	43		
Absolute WDQS differential input LOW pulse width	t _{WQSL(abs)}	0.45	0.55	0.45	0.55	0.45	0.55	0.45	0.55	0.45	0.55	t _{WDQS}	43		
Rx single pulse width	t _{DIPW}	0.55		0.55		0.55		0.55		0.55		UI	27		
Rx Timing Window with PSII	t _{DIVW}	0.30		0.30		0.30		0.30		0.30		UI			
WDQS to write data offset	t _{WDQS2DQ_I}	300	900	300	900	300	900	300	900	300	900	ps	33,34, 45		
WDQS to write data offset voltage variation for write	t _{WDQS2DQ_I_VOLT}		0.8		0.8		0.8		0.8		0.8	ps/ mV	34,46		
WDQS to write data offset temperature variation for write	t _{WDQS2DQ_I_TEMP}		0.4		0.4		0.4		0.4		0.4	ps/C	34,46, 47		

Table 92 — Timings Parameters (Part 1) (cont'd)

Parameter	Symbol	Speed Bin ²										Unit	Notes		
		4.8 Gbps/pin		5.2 Gbps/pin		5.6 Gbps/pin		6.0 Gbps/pin		6.4 Gbps/pin					
		Min	Max	Min	Max	Min	Max	Min	Max	Min	Max				
Data Input Timings (cont'd)															
DQ to DQ skew (intra-byte) for write	tDQ2DQtra_I			10		10		10		10		10	ps		
DQ to DQ skew (inter-byte) for write	tDQ2DQter_I			30		30		30		30		30	ps		
Data Output Timings															
RDQS differential output HIGH	tQSH	twQSH(abs) - 0.08		twQSH(abs) - 0.08		twQSH(abs) - 0.08		twQSH(abs) - 0.08		twQSH(abs) - 0.08		twDQS	6,38		
RDQS differential output LOW	tQLS	twQSL(abs) - 0.08		twQSL(abs) - 0.08		twQSL(abs) - 0.08		twQSL(abs) - 0.08		twQSL(abs) - 0.08		twDQS	6,39		
DQ output hold time from DQS	tQH	Min(tQSH , tQLS)		Min(tQSH , tQLS)		Min(tQSH , tQLS)		Min(tQSH , tQLS)		Min(tQSH , tQLS)		twDQS	6		
DQ output window per pin	tQW	Min(tQSH , tQLS) - 0.07		Min(tQSH , tQLS) - 0.07		Min(tQSH , tQLS) - 0.07		Min(tQSH , tQLS) - 0.07		Min(tQSH , tQLS) - 0.07		UI	6		
RDQS to DQ skew in Byte T4	tDQSQtra			20		20		20		20		20	ps		
DQ to DQ skew (intra-byte) for read	tDQ2DQtra_O			10		10		10		10		10	ps		
DQ to DQ skew (inter-byte) for read	tDQ2DQter_O			30		30		30		30		30	ps		
WDQS to read data and RDQS offset	tWDQS2DQ_O	0.6	2.5	0.6	2.5	0.6	2.5	0.6	2.5	0.6	2.5	ns	6,33,3 5		
WDQS to read data offset voltage variation for read	tWDQS2DQ_O _VOLT			2.5		2.5		2.5		2.5		2.5	ps/ mV		
WDQS to read data offset temperature variation for read	tWDQS2DQ_O _TEMP			1.0		1.0		1.0		1.0		1.0	ps/C		
DQ, DBI high impedance to low impedance time from WDQS	tLZ	Min: tWDQS2DQ_O(min) - tQH(min) Max: tWDQS2DQ_O(max) + tDQSQtra(max)										ns	6		
DQ, DBI low impedance to high impedance time from WDQS	tHZ	Min: tWDQS2DQ_O(min) Max: tWDQS2DQ_O(max) + tDQSQtra(max)										ns	6		

10 AC Timings (cont'd)**Table 93 — Timings Parameters (Part 2)**

Parameter ^{1,3}	Symbol	Values		Unit	Notes
		MIN	MAX		
Row Access Timings					
ACTIVATE to ACTIVATE command period	t _{RC}		-	ns	
ACTIVATE to PRECHARGE command period	t _{RAS}		9 x t _{REFI}	ns	7
ACTIVATE to READ command delay	t _{RCDRD}		-	ns	
ACTIVATE to WRITE command delay	t _{RCDWR}		-	ns	
ACTIVATE to ACTIVATE or PER BANK REFRESH bank B command delay same bank group	t _{RRDL}		-	ns	8
ACTIVATE to ACTIVATE or PER BANK REFRESH bank B command delay different bank group	t _{RRDS}		-	ns	9
Four bank activate window	t _{FAW}		-	ns	10
READ to PRECHARGE command delay same bank	t _{RTP}		-	nCK	11, 32
PRECHARGE command period	t _{RP}		-	ns	
WRITE recovery time	t _{WR}		-	ns	32
Auto precharge write recovery + precharge time	t _{DAL}	-	-	nCK	12
PRECHARGE to PRECHARGE delay same pseudo channel	t _{PPD}	2		nCK	
Rolling Accumulated ACTIVATE count	RAA			-	
Column Access Timings					
RD/WR bank A to RD/WR bank B command delay same bank group	t _{CCDL}	Max (4, 2.5 ns/tck)	-	nCK	13, 14
RD/WR bank A to RD/WR bank B command delay different bank group	t _{CCDS}	2	-	nCK	15, 16
RD SID A to RD SID B command delay	t _{CCDR}		-	nCK	17
Internal WRITE to READ command delay same bank group	t _{WTRL}		-	nCK	13
Internal WRITE to READ command delay different bank group	t _{WTRS}		-	nCK	15
READ to WRITE command delay	t _{RTW}		-	ns	18
Power-Down Timings					
POWER-DOWN ENTRY to EXIT time	t _{PD}	t _{CPDED} + 6 x tck	9 x t _{REFI}	ns	
POWER-DOWN EXIT time	t _{XP}	MAX(10 x tck, 7.5)	-	ns	
Valid CK clocks required after POWER-DOWN ENTRY	t _{CKPDE}	RU(t _{CPDED} / tck) + 1		nCK	
Valid CK clocks required before POWER-DOWN EXIT	t _{CKPDX}	5		nCK	
Command path disable delay	t _{CPDED}	MAX(5 x tck, 7.5)	-	ns	
ACTIVATE to POWER-DOWN ENTRY command delay	t _{ACTPDE}	1	-	nCK	19
PRECHARGE(rising CK edge) to POWER-DOWN ENTRY command delay	t _{PRPDER}	1	-	nCK	
PRECHARGE(falling CK edge) to POWER-DOWN ENTRY command delay	t _{PRPDEF}	1.5	-	nCK	
REFRESH to POWER-DOWN ENTRY command delay	t _{REFPDE}	1	-	nCK	19
PER BANK REFRESH to POWER-DOWN ENTRY command delay	t _{REFPBDE}	1	-	nCK	19

Table 93 — Timings Parameters (Part 2) (cont'd)

Parameter ^{1,3}	Symbol	Values		Unit	Notes			
		MIN	MAX					
Power-Down Timings (cont'd)								
MODE REGISTER SET to POWER-DOWN ENTRY command delay	tMRSPDE	tMOD(min)	-	nCK				
READ or READ w/ AP to POWER-DOWN ENTRY command delay	tRDPDE	RL + PL + 2 + RU(tDQSS(max) + tWDQS2DQ_O (max) / tCK)	-	nCK				
WRITE to POWER-DOWN ENTRY command delay	tWRPDE	WL + PL + 3 + RU(tWR / tCK)	-	nCK	20			
WRITE with AP to POWER-DOWN ENTRY command delay	tWRAPDE	WL + PL + 3 + WR	-	nCK	21			
Self Refresh Timings								
SELF REFRESH ENTRY to EXIT time	tCKSR	tCPDED + 6 x tCK	-	ns				
Valid CK clocks required after SELF REFRESH ENTRY	tCKSRE	RU(tcpded / tCK) + 1		nCK				
Valid CK clocks required before SELF REFRESH or POWER-DOWN EXIT	tCKSRX	5		nCK				
READ or READ w/ AP to SELF REFRESH ENTRY command delay	tRDSRE	RL + PL + 3	-	nCK				
Exit self refresh command delay	txs	MAX(10 x tCK, tRFC(min) + 10)	-	ns				
Exit self refresh to MODE REGISTER SET command delay	txSMRS	MAX(10 x tCK, 15)	-	ns				
Exit self refresh to MODE REGISTER SET command delay after frequency change	txSMRSF		-	ns				
Refresh Timings								
Minimum time in self refresh for per-bank RAA count to be reset to 0	tRAASRF		-	ns	29			
REFRESH command period	8 Gb/die	4-High	2 Gb / channel	tRFCab	TBD	-	ns	22
		8-High	4 Gb / channel		260	-		
		12-High	6 Gb / channel		310			
		16-High	8 Gb / channel		350	-		
	16 Gb/die	4-High	4 Gb / channel		260	-		
		8-High	8 Gb / channel		350	-		
		12-High	12 Gb / channel		410	-		
		16-High	16 Gb / channel		450	-		
	24 Gb/die	4-High	6 Gb / channel		310			
		8-High	12 Gb / channel		410	-		
		12-High	18 Gb / channel		450	-		
		16-High	24 Gb / channel		TBD	-		
	32 Gb/die	4-High	8 Gb / channel		TBD			
		8-High	16 Gb / channel		TBD	-		
		12-High	24 Gb / channel		TBD			
		16-High	32 Gb / channel		TBD	-		

Table 93 — Timings Parameters (Part 2) (cont'd)

Parameter ^{1,3}	Symbol	Values		Unit	Notes
		MIN	MAX		
Refresh Timings (cont'd)					
PER BANK REFRESH command period (same bank)	tRFCpb	TBD	-	ns	28
		200	-		
		240	-		
		TBD	-		
PER BANK REFRESH command period (different bank) and PER BANK REFRESH to ACTIVATE (different bank) command delay	tREFD	MAX(3 x tck, 8)	-	ns	
Average periodic refresh interval for REFRESH command	tREFI	-	3.9	μs	23
Average periodic refresh interval for PER BANK REFRESH command	tREFIp _b	-	tREFI / 16	μs	22, 24
		-	tREFI / 32	μs	
		-	tREFI / 48	μs	
		-	tREFI / 64	μs	
WDQS-to-CK Timings					
WDQS/2 (0° phase) rising edge to CK rising edge delay	tDQSS	Max (-200ps, -0.2tCK)	Min (200 ps, 0.2tCK)	ps/tCK	
WDQS-to-CK phase search range during WDQS-to-CK alignment training	tWDQS2CK	-0.4	0.4	tCK	
CK clock to phase detector output delay in WDQS-to-CK alignment training mode	tWDQS2PD			ns	
Miscellaneous Timings					
MODE REGISTER SET command update delay	tMOD		-	nCK	
MODE REGISTER SET command cycle time	tMRD		-	nCK	
MODE REGISTER SET command from a preceding READ command	tRDMRS	RL + PL + 2 + RU(tDQSS(max) + tWDQS2DQ_O (max)/tCK)		nCK	
Internal WRITE to MODE REGISTER SET command delay	tWRMRS	MAX(RU(tWR + tRP)/tCK), (PL + RU(tPARDQ/tCK), 6)	-	nCK	
Interval VREFD offset single step settling time	tVREFD		-	ns	
Interval VREFD offset full range settling time	tFVREFD		-	ns	
ADD/CMD parity error output delay	tPARAC			ns	25
Write data parity error output delay	tPARDQ			ns	26
Write preamble for WDQS	tWPRE1	2		tWDQS	
Read preamble for WDQS	tWPRE2	4		tWDQS	
Write postamble for WDQS	tWPST1	2		tWDQS	
Read postamble for WDQS	tWPST2	2		tWDQS	
Read preamble for RDQS	tRPRE	2		tWDQS	
Read postamble for RDQS	tRPST	2		tWDQS	
CK clock frequency with DCA enabled	fCKDCA	1200	-	MHz	36
Duty Cycle Monitor Measurement time	tDCMM	1	-	μs	37

Table 93 — Timings Parameters (Part 2) (cont'd)

Parameter ^{1,3}	Symbol	Values		Unit	Notes
		MIN	MAX		
NOTE 1					AC timing parameters apply to each channel of the HBM3 device independently. No timing parameters are specified across channels, and all channels operate independently of each other.
NOTE 2					Speed bins are shown as examples. Vendors may define different speed bins; in this case it is recommended to scale the values for the related timing parameters.
NOTE 3					All parameters assume proper device initialization.
NOTE 4					Parameter tck is calculated as the average clock period across any consecutive 1,000 cycle window, where each clock period is calculated both from rising CK edge to rising CK edge, and falling CK edge to falling CK edge.
NOTE 5					Parameter is based on V _{IHCA} and V _{ILCA} .
NOTE 6					Parameter is measured with Output Timing reference load and Read DBI enabled.
NOTE 7					For Reads and Writes with auto precharge enabled, the device will hold off the internal precharge until t _{RAS(min)} has been satisfied or the number of clock cycles as programmed for RAS in MR4 have elapsed.
NOTE 8					Parameter applies when consecutive commands access the same bank group.
NOTE 9					Parameter applies when consecutive commands access different bank groups.
NOTE 10					No more than 4 ACTIVATE or PER BANK REFRESH commands are allowed within t _{FAW} period.
NOTE 11					Parameter applies when READ and PRECHARGE commands access the same bank.
NOTE 12					t _{DAL} = (t _{WR} /t _{Clock}) + (t _{RP} /t _{Clock}). For each of the terms, if not already an integer, round up to the next integer.
NOTE 13					Parameter applies consecutive commands access the same bank group.
NOTE 14					t _{CCDL} parameter is applied when seamless consecutive Write or Read commands access to the banks in the same bank group.
NOTE 15					Parameter applies when consecutive commands access different bank groups.
NOTE 16					t _{CCDS} is either for seamless consecutive READ or seamless consecutive WRITE commands.
NOTE 17					t _{CCDR} is a parameter for 8,12,16-High HBM devices that is used for seamless consecutive READ commands between different stack IDs (SID) instead of t _{CCDS} . The t _{CCDR(min)} value is vendor specific and a range of t _{CCDS} + 1 to 2nCK is supported. The t _{CCDR(min)} is dependent on the operation frequency. The vendor datasheet should be consulted for details. For seamless WRITE commands the normal t _{CCDS} parameter applies. t _{CCDR} does not apply to DWORD MISR operations when DWORD Loopback is enabled in MR7.
NOTE 18					t _{RTW} is not a DRAM device limit but determined by the system bus turnaround time. Avoid bus contention by setting t _{RTW} (min) = (RL + BL/4 - WL + 0.5) × t _{Clock} + t _{WDQS2DQ_O(max)} - t _{WDQS2DQ_O(min)} , and round up to the next integer.
NOTE 19					Upon entering power-down the CK clock may be stopped after the number of clock cycles as programmed for RAS in MR4.
NOTE 20					t _{WR} is defined in ns. For calculation of t _{WRPDE} round up t _{WR} /t _{Clock} to the next integer.
NOTE 21					WR in clock cycles as programmed in MR3.
NOTE 22					Density is given per channel.
NOTE 23					A maximum of 8 consecutive REFRESH commands can be posted to an HBM3 device, meaning that the maximum absolute interval between any REFRESH command and the next REFRESH command is 9 × t _{REFI} .
NOTE 24					t _{REFIPB} = t _{REFI} / N; N = no. of banks.
NOTE 25					t _{PARAC} may be specified as an analog delay or as a combination of n clock cycles and an analog delay. The nominal AERR HIGH time in case of a parity error is 1 nCK.
NOTE 26					t _{PARDQ} may be specified as an analog delay or as a combination of n clock cycles and an analog delay. The nominal DERR HIGH time in case of a parity error is 1 nCK.
NOTE 27					t _{CIPW} is based on V _{REFCA} level, and t _{DIPW} is based on V _{REFDQ} level.

Table 93 — Timings Parameters (Part 2) (cont'd)

Parameter ^{1,3}	Symbol	Values		Unit	Notes
		MIN	MAX		
NOTE 28	Density is given per die.				
NOTE 29	Parameter applies only to HBM3 DRAMs that require the use of Refresh Management (RFM).				
NOTE 32	PRECHARGE and PRECHARGE ALL commands can be issued on a rising or a falling CK edge. For corresponds to the internal WR or RTP, add 0.5 tCK to the number of clock cycles defined for RTP with reference to tRTP or the number of clock cycles calculated to WR using RU(twr/tck).				
NOTE 33	PVT variation is included.				
NOTE 34	The minimum-to-maximum range does not exceed 400 ps. The vendor's datasheet shall be consulted for the minimum and maximum values.				
NOTE 35	The minimum-to-maximum range does not exceed 1.5 ns. The vendor's datasheet shall be consulted for the minimum and maximum values.				
NOTE 36	Parameter fCKDCA applies when a duty correction code other than the default 0000 is programmed in the mode register.				
NOTE 37	tDCMM is measured from the MRS command that enables the duty cycle measurement until the measurement result is valid.				
NOTE 38	tQSH describes the instantaneous differential output high pulse width on RDQS_t – RDQS_c as it measures the next falling edge from an arbitrary rising edge. tQSH edge measurement is based on zero voltage.				
NOTE 39	tQLS describes the instantaneous differential output low pulse width on RDQS_t – RDQS_c as it measures the next rising edge from an arbitrary falling edge. tQLS edge measurement is based on zero voltage.				
<p style="text-align: center;">Differential Output Voltage: $t(t) = RDQS_t - RDQS_c$</p>					
NOTE 40	$t_{CH(\text{abs})}$ is the absolute instantaneous clock high pulse width, as measured from one rising edge to the following falling edge. $t_{CL(\text{abs})}$ is the absolute instantaneous clock low pulse width, as measured from one falling edge to the following rising edge.				
NOTE 41	Parameter twDQS is calculated as the average write clock period across any consecutive 200 cycle window, where each clock period is calculated both from rising CK edge to rising CK edge, and falling CK edge to falling CK edge.				
NOTE 42	$twQSH_{(\text{avg})}$ is defined as the average high pulse width, as calculated across any consecutive 200 high pulses. $twQLS_{(\text{avg})}$ is defined as the average low pulse width, as calculated across any consecutive 200 low pulses.				
NOTE 43	$twQSH_{(\text{abs})}$ is the absolute instantaneous write clock high pulse width, as measured from one rising edge to the following falling edge. $twQLS_{(\text{abs})}$ is the absolute instantaneous write clock low pulse width, as measured from one falling edge to the following rising edge.				
NOTE 45	twDQS2DQ_I max delay variation as a function of the DC voltage variation for VDDQ. It includes VDDQ AC noise impact for frequencies > 20 MHz and max voltage of TBDmVpk-pk from DC to 20 MHz at a fixed temperature on the package.				
NOTE 46	Actual values could be positive or negative numbers depending on design implementation and process.				
NOTE 47	The parameter is referenced to IEEE1500 TEMPERATURE readout. See clause 13.5.12 TEMPERATURE.				

11 Package (Die) Specification

11.1 Signals

Table 94 — I/O Signal Description

Signals	Type	Description
CK[a:p]_t, CK[a:p]_c	Input	Clock: CK_t and CK_c are differential clock inputs. Row and column command and address inputs are latched on the rising and falling edges of CK.
C[a:p][7:0]	Input	Column command and address: the command code, bank and column address for Write and Read operations and the mode register address and code to be loaded with MODE REGISTER SET commands are received on the C[7:0] inputs.
R[a:p][9:0]	Input	Row command and address: the command code, bank and row address for Activate, Precharge and Refresh commands are received on the R[9:0] inputs.
ARFU[a:p]	Input	Reserved for future use: unused microbumps in AWORD.
APAR[a:p]	Input	Command / address parity: one parity signal per AWORD. APAR is associated with C[7:0], R[9:0] and ARFU.
DQ[a:p][63:0]	I/O	Data Input/Output: 64-bit data bus. DQ[31:0] represents the 32-bit data bus of PC0 and DQ[63:32] represents the 32-bit data bus of PC1.
DBI[a:p][7:0]	I/O	Data Bus Inversion: DBI0 is associated with DQ[7:0], DBI1 is associated with DQ[15:8], ..., and DBI7 is associated with DQ[63:56].
ECC[a:p][3:0]	I/O	ECC: ECC0, ECC1 are associated with DQ[31:0]. ECC2, ECC3 are associated with DQ[63:32].
SEV[a:p][3:0]	I/O	SEV: SEV0, SEV1 are associated with DQ[31:0]. SEV2, SEV3 are associated with DQ[63:32].
DPAR[a:p][1:0]	I/O	Data Parity: one data parity signal per DWORD. DPAR0 is associated with DQ[31:0] and DPAR1 is associated with DQ[63:32].
DERR[a:p][1:0]	Output	Data parity error: one data parity error bit per DWORD. DERR0 is associated with DQ[31:0] and DERR1 is associated with DQ[63:32].
AERR[a:p]	Output	Address parity error. One address parity error bit for row and column address and command per AWORD.
WDQS[a:p][1:0]_t, WDQS[a:p][1:0]_c	Input	Write Data Strobe: WDQS_t and WDQS_c are differential strobe inputs. One WDQS pair per DWORD. WDQS0 is associated with DQ[31:0] and WDQS1 is associated with DQ[63:32].
RDQS[a:p][1:0]_t, RDQS[a:p][1:0]_c	Output	Read Data Strobe: RDQS_t and RDQS_c are differential strobe outputs. Read output data are sent on the rising and falling edges of RDQS. One RDQS pair per DWORD. RDQS0 is associated with DQ[31:0] and RDQS1 is associated with DQ[63:32].
DA[39:0]	I/O	Direct Access Input/Output: These pins are provided for direct access test. They must be routed directly to an external package I/O pin. The function is defined by the memory vendor.

Table 94 — I/O Signal Description (cont'd)

Signals	Type	Description
RESET_n	Input	Reset: RESET_n LOW asynchronously initiates a full chip reset of the HBM3 device.
NC		No connect pad: electrically isolated
WRCK	Input	IEEE-1500 Wrapper Serial Port Clock
WRST_n	Input	IEEE-1500 Wrapper Serial Port Reset
SelectWIR	Input	IEEE-1500 Wrapper Serial Port Instruction Register Select
ShiftWR	Input	IEEE-1500 Wrapper Serial Port Shift
CaptureWR	Input	IEEE-1500 Wrapper Serial Port Capture
UpdateWR	Input	IEEE-1500 Wrapper Serial Port Update
WSI	Input	IEEE-1500 Wrapper Serial Port Data
WSO[a:p]	Output	IEEE-1500 Wrapper Serial Port Data Out
RD[a:p][3:0]	I/O	Redundant microbumps in DWORD
RA[a:p]	Input	Redundant command and address microbump in AWORD
MRFU[1:0]		Reserved for future use, unused microbumps in mid-stack region
NOBUMP		Depopulated pad: reserved as test pad for probing
TEMP[1:0]	Output	DRAM Temperature Report
CATTRIP	Output	DRAM Catastrophic Temperature Report
VSS	Supply	Ground
VDDC, VDDQ, VPP, VDDQL	Supply	Power supply
NOTE 1 Index [a:p] represents the channel indicator “a” to “p” of the HBM device. Signal names including the channel indicators are used whenever more than one channel and/or pseudo channel is referenced, as e.g., with the HBM3Ballout. The channel indicators are omitted whenever features and functions common to all channels and/or all pseudo channels are described		
NOTE 2 HBM3 devices supporting less than 16 channels are allowed to have input/output buffers physically present at the pins associated with the unavailable channels, however these input/output buffers will be disabled. The host shall leave those pins floating. The availability of each channel [a:p] has to be coded in IEEE1500 DEVICE_ID Wrapper Data Register bits [23:8].		
NOTE 3 All power supply microbumps defined in Table 98 to Table 103 must be present and connected with their respective power nets even if the related channel is not present or marked non-working.		

11.2 MicroBump Positions

The MicroBump array of the DRAM stack employs a staggered pattern as depicted in Figure 95, where a ‘staggered’ bump is located halfway between major row and column, hence its location is determined by $X/2$ and $Y/2$. Table 95 shows geometric parameters of the Staggered MicroBump pattern. Parameter P_{Min} is the minimum bump pitch anywhere in the MicroBump field; for chosen X and Y parameters.




Figure 95 — Staggered MicroBump Pattern

Table 95 — Geometric Parameters of the Staggered MicroBump Pattern

Label	Nominal Value	Description
X	96 um	Horizontal pitch of two adjacent MicroBumps
Y	110 um	Vertical pitch of two adjacent MicroBumps
P_{Min}	73 um	Minimum pitch of the bump field
D	28 um	MicroBump diameter
S		Bump-to-bump air gap; $S = P_{\text{Min}} - D$

The HBM3 bump matrix is defined as shown in subsequent tables. Please refer to MO-349 for device dimensions.




Figure 96 — MicroBump Pillar Diameter

11.2 MicroBump Positions (cont'd)

Footprint consists of 161 rows with a pitch of Y/2 and 148 columns with a pitch of X/2. The overall array size is $(147 \times X/2 + D) \times (160 \times Y/2 + D) = 7084.0 \mu\text{m} \times 8828.0 \mu\text{m}$. The ball matrix is center aligned with the die. The ball array center is the origin of the ball location coordinates. Ball A1 is located at the top left at $X = -3528.0 \mu\text{m}$, $Y = +4400.0 \mu\text{m}$.

11.3 HBM3 Stack Height

Table 96 — HBM3 Device Dimensions

Parameter	Symbol	Configuration	Minimum	Nominal	Maximum	Unit	Notes		
Width	X			10.975		mm	3		
Length	Y			10.975		mm			
Height	Z	4-High	695	720	745	μm	1,2		
		8-High	695	720	745	μm			
		12-High	695	720	745	μm			
		16-High	TBD	TBD	TBD	μm			
NOTE 1 The configuration refers to the number of memory dies in the stack. The stack may include an additional base (interface) die.									
NOTE 2 Refer to MO-349 for related package drawings.									
NOTE 3 Refer to MO-349 for X and Y dimension min/max tolerances and related package drawings.									

11.4 HBM3 Bump Map

A geographical overview of the HBM3 bump matrices is provided in Table 98 for Footprint, and the detailed bump matrices are provided in Table 99 thru Table 103

Due to space constraints these tables use abbreviations for specific functions as given in Table 97. The orientation of the ballout shown is the bottom view looking at the microbumps.

HBM3 devices supporting less than 16 channels must have all microbumps physically present as shown in the following tables.

Table 97 — Legend

VPP	A	VSS	D
NC	B	VDDC	E
No Bump	C	VDDQ	M
		VDDQL	N

11.4 HBM3 Bump Map (cont'd)

Table 98 — HBM3 Bump Map Footprint – Geographical Overview (not to scale)

		See Table 96			See Table 97		See Table 98		See Table 99			See Table 100			147, 148				
Columns		1, 2	3 ... 20	21 ... 36	37 ... 51	52 ... 74	75 ... 90	91 ... 104	105 ... 118	119 ... 132	133 ... 146								
R o w s	A ... K	Mechanical Bumps Power Supply Region	Depopulated micropillar area dedicated for (optional) probe pads	Direct Access Test Port	Upper Left Power Supply Region	Upper Right Power Supply Region	Upper Right Power Supply Region								Mechanical Bumps				
	L ... AD						DWORD0 Channel m	DWORD0 Channel i	DWORD0 Channel e	DWORD0 Channel a									
	AE ... AK						AWORD Channel m	AWORD Channel i	AWORD Channel e	AWORD Channel a									
	AL ... BD						DWORD1 Channel m	DWORD1 Channel i	DWORD1 Channel e	DWORD1 Channel a									
	BE ... BV						DWORD0 Channel n	DWORD0 Channel j	DWORD0 Channel f	DWORD0 Channel b									
	BW ... CD						AWORD Channel n	AWORD Channel j	AWORD Channel f	AWORD Channel b									
	CE ... CT						DWORD1 Channel n	DWORD1 Channel j	DWORD1 Channel f	DWORD1 Channel b									
	CU, CV						Reset, IEEE1500 Port, Temperature, etc...												
	CW ... DC					Lower Left Power Supply Region	DWORD1 Channel o	DWORD1 Channel k	DWORD1 Channel g	DWORD1 Channel c									
	DD, DE						AWORD Channel o	AWORD Channel k	AWORD Channel g	AWORD Channel c									
	DF ... DU						DWORD0 Channel o	DWORD0 Channel k	DWORD0 Channel g	DWORD0 Channel c									
	DW ... EC						DWORD1 Channel p	DWORD1 Channel l	DWORD1 Channel h	DWORD1 Channel d									
	ED ... EU						AWORD Channel p	AWORD Channel l	AWORD Channel h	AWORD Channel d									
	EV ... FL						DWORD0 Channel p	DWORD0 Channel l	DWORD0 Channel h	DWORD0 Channel d									
	FM ... FU						Lower Right Power Supply Region												
	FV ... GL																		
	GM ... HA																		

11.4 HBM3 Bump Map (cont'd)

Table 99 — HBM3 Bump Map Footprint : Columns 1 to 36

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36
A	B	C	D	D	C	D	C	D	E	C	D	E	D	C	D	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C				
B	B	D	C	D	D	C	D	C	E	D	C	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
C	B	C	D	D	D	C	D	C	E	C	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
D	B	D	C	D	C	D	D	C	E	E	D	C	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
E	B	C	D	D	D	C	D	C	E	C	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
F	B	D	C	D	D	C	D	C	E	D	C	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
G	B	C	D	D	D	C	D	C	E	C	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
H	B	D	C	D	D	C	D	C	E	D	C	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
J	B	C	D	D	C	D	D	C	E	C	D	E	C	D	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
K	B	D	C	D	D	C	D	C	E	D	C	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
L	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
M	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
N	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
P	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
R	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
T	B	D	C	D	D	C	D	C	E	D	C	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
U	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
V	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
W	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
Y	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AA	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AB	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AC	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AD	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AE	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AF	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AG	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AH	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AJ	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AK	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AL	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AM	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AN	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AP	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AR	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AT	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AU	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AV	B	D	C	D	D	C	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AW	B	C	D	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					
AY	B	D	C	D	C	D	D	C	E	C	D	E	D	C	E	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C					

Table 99 — HBM3 Bump Map Footprint : Columns 1 to 36 (cont'd)

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36
BA	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C		C	
BB		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
BC	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
BD		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
BE	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
BF		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
BG	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
BH		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
BJ	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
BK		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
BL	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
BM		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
BN	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
BP		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
BR	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
BT		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
BU	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
BV		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
BW	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
BY		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
CA	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
CB		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
CC	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
CD		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
CE	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
CF		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
CG	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
CH		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
CJ	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
CK		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
CL	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
CM		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
CN	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
CP		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
CR	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
CT		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		

Table 99 — HBM3 Bump Map Footprint : Columns 1 to 36 (cont'd)

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36
CU	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
CV		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
CW	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
CY		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
DA	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
DB		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
DC	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
DD		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
DE	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			

Table 99 — HBM3 Bump Map Footprint : Columns 1 to 36 (cont'd)

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36
DF	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
DG	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
DH	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
DJ	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
DK	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
DL	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
DM	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
DN	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
DP	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
DR	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
DT	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
DU	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
DV	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
DW	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
DY	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
EA	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
EB	B			D		C		D		D		C		E		D		C		F		C		C		C		C		C		C		C		
EC	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
ED	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
EE	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
EF	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
EG	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
EH	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
EJ	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
EK	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
EL	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
EM	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
EN	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
EP	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
ER	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
ET	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
EU	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
EV	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
EW	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
EV	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
FA	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
FB	B			D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
FC	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			

Table 99 — HBM3 Bump Map Footprint : Columns 1 to 36 (cont'd)

	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36
FD		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
FE	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
FF		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
FG	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
FH		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
FJ	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
FK		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
FL	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
FM		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
FN	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
FP		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
FR	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
FT		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
FU	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
FV		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
FW	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
FY		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
GA	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
GB		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
GC	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
GD		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
GE	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
GF		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
GG	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
GH		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
GJ	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
GK		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
GL	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
GM		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
GN	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
GP		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
GR	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
GT		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
GU	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
GV		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
GW	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			
GY		B		D		C		D		D		C		E		D		C		E		C		C		C		C		C		C		C		
HA	B		C		D		D		C		D		E		C		D		E		C		C		C		C		C		C		C			

11.4 HBM3 Bump Map (cont'd)

Table 100 — HBM3 Bump Map Footprint : Columns 37 to 74

	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74
A	D	C		E		D		C		E		D		C		E		D		C	A	D	C		E		D	C	N	D								
B		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							
C	D		C		E		D		C		E		D		C		E		D	C	A	D	C		E		D	C	N	C	D							
D		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							
E	D		C		E		D		C		E		D		C		E		D	C	A	A	D	C		E		D	C	N	D							
F		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							
G	D		C		E		D		C		E		D		C		E		D	C	A	A	D	C		E		D	C	N	D							
H		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							
J	D		C		E		D		C		E		D		C		E		D	C	A	A	D	C		E		D	C	N	D							
K		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							
L	D		C		E		D		C		E		D		C		E		D	C	A	A	D	C		E		D	C	N	D							
M		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							
N	D		C		E		D		C		E		D		C		E		D	C	A	A	D	C		E		D	C	N	D							
P		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							
R	D		C		E		D		C		E		D		C		E		D	C	A	A	D	C		E		D	C	N	D							
T		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							
U	D		C		E		D		C		E		D		C		E		D	C	A	A	D	C		E		D	C	N	D							
V		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							
W	D		C		E		D		C		E		D		C		E		D	C	A	A	D	C		E		D	C	N	D							
Y		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	C	N	D							
AA	D		C		E		D		C		E		D		C		E		D	C	A	A	D	C		E		D	C	N	D							
AB		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							
AC	D		C		E		D		C		E		D		C		E		D	C	A	A	D	C		E		D	C	N	D							
AD		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							
AE	D		C		E		D		C		E		D		C		E		D	C	A	A	D	C		E		D	C	N	D							
AF		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							
AG	D		C		C		C		C		C		C		C		E		D	C	A	A	D	C		E		D	C	N	D							
AH		D		B		C		B		B		C		B		E		C		D	A	C	D	E		C		D	N	C	D							
AJ	D		C		B		B		C		B		C		C		E		D	C	A	A	D	C		E		D	C	N	D							
AK		D		C		C		C		C		C		C		E		C		D	A	C	D	E		C		D	N	C	D							
AL	D		C		D		E		C		D		E		C		E		D	C	A	A	D	C		E		D	C	N	D							
AM		D		D		C		E		D		C		E		C		D		A	C	D	E		C		D	N	C	D								
AN	D		C		D		E		C		D		E		C		E		D	C	A	A	D	C		E		D	C	N	D							
AP		D		D		C		E		D		C		E		C		D		A	C	D	E		C		D	N	C	D								
AR	D		C		C		C		C		C		C		C		E		D	C	A	A	D	C		E		D	C	N	D							
AT		D		DA0		C		DA1		B		C		B		E		C		D	A	C	D	E		C		D	N	C	D							
AU	D		C		DA0		DA1		C		B		B		C		E		D	C	A	A	D	C		E		D	C	N	D							
AV		D		C		C		C		C		C		C		E		C		D	A	C	D	E		C		D	N	C	D							
AW	D		C		E		D		C		E		D		C		E		D	C	A	A	D	C		E		D	N	C	D							
AY		D		E		C		D		E		C		D		E		C		D	A	C	D	E		C		D	N	C	D							

Table 100 — HBM3 Bump Map Footprint : Columns 37 to 74 (cont'd)

	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74
BA	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C	N	D			
BB		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		N	C	D				
BC	D		C		C		C		C		C		C		C		E		D		C		A		C		D		E		D		C	N	D			
BD	D		DA2		C		DA3		DA4		C		DA5		E		C		D		A		C		D		E		C		D		N	C	D			
BE	D		C		DA2		DA3		C		DA4		DA5		C		E		D		C		A		C		D		E		D		C	N	D			
BF	D		C		C		C		C		C		C		E		C		D		A		C		D		E		C		D		N	C	D			
BG	D		C		D		E		C		D		E		C		E		D		C		A		D		C		E		D		C	N	D			
BH	D		D		C		E		D		C		E		C		E		D		A		C		D		E		C		D		N	C	D			
BJ	D		C		D		E		C		D		E		C		E		D		C		A		D		C		E		D		C	N	D			
BK	D		D		C		E		D		C		E		C		E		C		D		A		C		D		E		C		D	N	C	D		
BL	D		C		C		C		C		C		C		C		E		D		C		A		D		C		E		D		C	N	D			
BM	D		DA6		C		DA7		DA8		C		DA9		E		C		D		A		C		D		E		C		D		N	C	D			
BN	D		C		DA6		DA7		C		DAS		DA9		C		E		D		C		A		D		C		E		D		C	N	D			
BP	D		C		C		C		C		C		C		C		E		C		D		A		C		D		E		C		D	N	C	D		
BR	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C	N	D			
BT	D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N	C	D			
BU	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C	N	D			
BV	D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N	C	D			
BW	D		C		C		C		C		C		C		C		E		D		C		A		D		C		E		D		C	N	D			
BV	D		DA10		C		DA11		DA12		C		DA13		E		C		D		A		C		D		E		C		D		N	C	D			
CA	D		C		DA10		DA11		C		DA12		DA13		C		E		D		C		A		D		C		E		D		C	N	D			
CB	D		C		C		C		C		C		C		C		E		C		D		A		C		D		E		C		D	N	C	D		
CC	D		C		D		E		C		D		E		C		E		D		C		A		D		C		E		D		C	N	D			
CD	D		D		C		E		C		D		E		C		E		C		D		A		C		D		E		C		D	N	C	D		
CE	D		C		D		E		C		D		E		C		E		D		C		A		D		C		E		D		C	N	D			
CF	D		D		C		E		D		C		E		C		E		D		A		C		D		E		C		D		N	C	D			
CG	D		C		C		C		C		C		C		C		E		D		C		A		D		C		E		D		C	N	D			
CH	D		DA14		C		DA15		DA16		C		DA17		E		C		D		A		C		D		E		C		D		N	C	D			
CJ	D		C		DA14		DA15		C		DA16		DA17		C		E		D		C		A		D		C		E		D		C	N	D			
CK	D		C		C		C		C		C		C		C		E		C		D		A		C		D		E		C		D	N	C	D		
CL	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C	N	D			
CM	D		E		C		D		E		C		D		E		C		D		C		A		C		D		E		C		D	N	C	D		
CN	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C	N	D			
CP	D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N	C	D			
CR	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C	N	D			
CT	D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N	C	D			

Table 100 — HBM3 Bump Map Footprint : Columns 37 to 74 (cont'd)

	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74
CU	D		C		E		D		C		E		D		C		C		C		C		C		C		C		C		C		C		C			
CV		D		E		C		D		E		C		D		C		C		C		C		C		C		C		C		C		C				
CW	D		C		E		D		C		E		D		C		C		C		C		C		C		C		C		C		C					
CY		D		E		C		D		E		C		D		C		C		C		C		C		C		C		C		C		C				
DA	D		C		E		D		C		E		D		C		C		C		C		C		C		C		C		C		C					
DB		D		E		C		D		E		C		D		C		C		C		C		C		C		C		C		C						
DC	D		C		E		D		C		E		D		C		C		C		C		C		C		C		C		C		C					
DD		D		E		C		D		E		C		D		C		C		C		C		C		C		C		C		C						
DE	D		C		E		D		C		E		D		C		C		C		C		C		C		C		C		C		C					

Table 100 — HBM3 Bump Map Footprint : Columns 37 to 74 (cont'd)

	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74
DF	D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D	N	C	D				
DG	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D	C	N	D				
DH	D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D	N	C	D				
DJ	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D	C	N	D				
DK	D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D	N	C	D				
DL	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D	C	N	D				
DM	D		C		C		C		C		C		C		C		E		C		D		A		C		D		E		C		D	N	C	D		
DN	D		C		DA18		DA19		C		DA20		DA21		C		E		D		C		A		D		C		E		D		C	N	D			
DP	D		DA18		C		DA19		DA20		C		DA21		E		C		D		A		C		D		E		C		D	N	C	D				
DR	D		C		C		C		C		C		C		C		E		D		C		A		D		C		E		D	C	N	D				
DT	D		D		C		E		D		C		E		E		C		D		A		C		D		E		C		D	N	C	D				
DU	D		C		D		E		C		D		E		C		E		D		C		A		D		C		E		D	C	N	D				
DV	D		D		C		E		D		C		E		E		C		D		A		C		D		E		C		D	N	C	D				
DW	D		C		D		E		C		D		E		C		E		D		C		A		D		C		E		D	C	N	D				
DY	D		C		C		C		C		C		C		C		E		C		D		A		C		D		E		C		D	N	C	D		
EA	D		C		DA22		DA23		C		DA24		DA25		C		E		D		C		A		D		C		E		D		C	N	D			
EB	D		DA22		C		DA23		DA24		C		DA25		E		C		D		A		C		D		E		C		D	N	C	D				
EC	D		C		C		C		C		C		C		C		E		D		C		A		D		C		E		D	C	N	D				
ED	D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D	N	C	D				
EE	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D	C	N	D				
EF	D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D	N	C	D				
EG	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D	C	N	D				
EH	D		C		C		C		C		C		C		C		E		C		D		A		C		D		E		C		D	N	C	D		
EJ	D		C		DA26		DA27		C		DA28		DA29		C		E		D		C		A		D		C		E		D		C	N	D			
EK	D		DA26		C		DA27		DA28		C		DA29		E		C		D		A		C		D		E		C		D	N	C	D				
EL	D		C		C		C		C		C		C		C		E		D		C		A		D		C		E		D	C	N	D				
EM	D		D		C		E		D		C		E		E		C		D		A		C		D		E		C		D	N	C	D				
EN	D		C		D		E		C		D		E		C		E		D		C		A		D		C		E		D	C	N	D				
EP	D		D		C		E		D		C		E		E		C		D		A		C		D		E		C		D	N	C	D				
ER	D		C		D		E		C		D		E		C		E		D		C		A		D		C		E		D	C	N	D				
ET	D		C		C		C		C		C		C		C		E		C		D		A		C		D		E		C		D	N	C	D		
EU	D		C		DA30		DA31		C		DA32		DA33		C		E		D		C		A		D		C		E		D		C	N	D			
EV	D		DA30		C		DA31		DA32		C		DA33		E		C		D		A		C		D		E		C		D	N	C	D				
EW	D		C		C		C		C		C		C		C		E		D		C		A		D		C		E		D	C	N	D				
EW	D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D	N	C	D				
FA	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D	C	N	D				
FB	D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D	N	C	D				
FC	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D	C	N	D				

Table 100 — HBM3 Bump Map Footprint : Columns 37 to 74 (cont'd)

	37	38	39	40	41	42	43	44	45	46	47	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74
FD		D		C		C		C		C		C		C		E		C		D		A		C		D		E		C		N		C		D		
FE	D		C		DA34		DA35		C		DA36		DA37		C		E		D		C		A		D		C		E		D		C		N		D	
FF		D		DA34		C		DA35		DA36		C		DA37		E		C		D		A		C		D		E		C		D		C		D		
FG	D		C		C		C		C		C		C		C		E		D		C		A		C		D		E		D		C		N		D	
FH		D		D		C		E		D		C		E		E		C		D		A		C		D		E		C		D		C		D		
FJ	D		C		D		E		C		D		E		C		E		D		C		A		D		C		E		D		C		N		D	
FK		D		D		C		E		D		C		E		E		C		D		A		C		D		E		C		D		N		C		D
FL	D		C		D		E		C		D		E		C		E		D		C		A		D		C		E		D		C		N		D	
FM		D		C		C		C		C		C		C		E		C		D		A		C		D		E		C		D		N		C		D
FN	D		C		DA38		DA39		C		B		B		C		E		D		C		A		D		C		E		D		C		N		D	
FP		D		DA38		C		DA39		B		C		B		E		C		D		A		C		D		E		C		D		N		C		D
FR	D		C		C		C		C		C		C		C		E		D		C		A		D		C		E		D		C		N		D	
FT		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
FU	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	
FV		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
FW	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	
FY		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
GA	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	
GB		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
GC	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	
GD		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
GE	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	
GF		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
GG	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	
GH		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
GJ	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	
GK		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
GL	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	
GM		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
GN	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	
GP		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
GR	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	
GT		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
GU	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	
GV		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
GW	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	
GY		D		E		C		D		E		C		D		E		C		D		A		C		D		E		C		D		N		C		D
HA	D		C		E		D		C		E		D		C		E		D		C		A		D		C		E		D		C		N		D	

11.4 HBM3 Bump Map (cont'd)

Table 101 — HBM3 Bump Map Footprint : Columns 75 to 90

	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90
A	C		E		D		C		E		D		C		E	
B		E		C	D			E		C	D		E		C	
C	C		E		D		C		E		D		C		E	
D		E		C	D			E		C	D		E		C	
E	C		E		D		C		E		D		C		C	
F		E		C	D			E		C	D		C		C	
G	C		E		D		C		E		C		C		C	
H		E		C	D			E		C		C		C		C
J	C		E		D		C		E		C		C		M	
K		E		C	D			E		C		C		M		C
L	C		E		D		C		E		D		C		M	
M		E		C	D			E		C	D		C		C	
N	C		E		D		C		E		D		C		C	
P		E		C	D			E		C		C		C		C
R	C		E		D		C		E		C		C		C	
T		E		C	D			E		C		C		M		C
U	C		E		D		C		E		C		C		M	
V		E		C	D			E		C	D		M		C	
W	C		E		D		C		E		D		C		C	
Y		E		C	D			E		C	D		C		C	
AA	C		E		D		C		E		C		C		C	
AB		E		C	D			E		C		C		C		C
AC	C		E		D		C		E		C		C		M	
AD		E		C	D			E		C		C		M		C
AE	C		E		D		C		E		D		C		M	
AF		E		C	D			E		C	D		C		C	
AG	C		E		D		C		E		D		C		C	
AH		E		C	D			E		C		C		C		C
AJ	C		E		D		C		E		C		C		M	
AK		E		C	D			E		C		C		M		C
AL	C		E		D		C		E		D		C		M	
AM		E		C	D			E		C	D		C		C	
AN	C		E		D		C		E		D		C		C	
AP		E		C	D			E		C		C		C		C
AR	C		E		D		C		E		C		C		C	
AT		E		C	D			E		C		C		M		C
AU	C		E		D		C		E		C		C		M	
AV		E		C	D			E		C	D		M		C	
AW	C		E		D		C		E		D		C		C	
AY		E		C	D			E		C	D		C		C	

Table 101 — HBM3 Bump Map Footprint : Columns 75 to 90 (cont'd)

	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90
BA	C		E		D		C		E		C		C		C	
BB		E		C	D		E		C		C		C		C	
BC	C		E	D		C		E		C		C		M		
BD		E		C	D		E		C		C		M		C	
BE	C		E	D		C		E		D		C		M		
BF		E		C	D		E		C		D		C		C	
BG	C		E	D		C		E		D		C		C		
BH		E		C	D		E		C		C		C		C	
BJ	C		E	D		C		E		C		C		C		
BK		E		C	D		E		C		C		M		C	
BL	C		E	D		C		E		C		C		M		
BM		E		C	D		E		C		D		M		C	
BN	C		E	D		C		E		D		C		C		
BP		E		C	D		E		C		D		C		C	
BR	C		E	D		C		E		C		C		C		
BT		E		C	D		E		C		C		C		C	
BU	C		E	D		C		E		C		C		M		
BV		E		C	D		E		C		C		M		C	
BW	C		E	D		C		E		D		C		M		
BY		E		C	D		E		C		D		C		C	
CA	C		E	D		C		E		D		C		C		
CB		E		C	D		E		C		C		C		C	
CC	C		E	D		C		E		C		C		M		
CD		E		C	D		E		C		C		M		C	
CE	C		E	D		C		E		D		C		M		
CF		E		C	D		E		C		D		C		C	
CG	C		E	D		C		E		D		C		C		
CH		E		C	D		E		C		C		C		C	
CJ	C		E	D		C		E		C		C		C		
CK		E		C	D		E		C		C		M		C	
CL	C		E	D		C		E		C		C		M		
CM		E		C	D		E		C		D		M		C	
CN	C		E	D		C		E		D		C		C		
CP		E		C	D		E		C		D		C		C	
CR	C		E	D		C		E		C		C		C		
CT		E		C	D		E		C		C		C		C	

Table 101 — HBM3 Bump Map Footprint : Columns 75 to 90 (cont'd)

	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90
CU	C		C		C		C		C		C		C		C	
CV		C		C		C		C		C		C		C		C
CW	C		C		C		C		C		C		C		C	
CY		C		C		C		C		C		C		C		C
DA	C		C		C		C		C		C		C		C	
DB		C		C		C		C		C		C		C		C
DC	C		C		C		C		C		C		C		C	
DD		C		C		C		C		C		C		C		C
DE	C		C		C		C		C		C		C		C	

Table 101 — HBM3 Bump Map Footprint : Columns 75 to 90 (cont'd)

	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90
DF		E		C		D		E		C		C		C		C
DG	C		E		D		C		E		C		C		C	
DH		E		C	D		E		C		D		C		C	
DJ	C		E		D		C		E		D		C		C	
DK		E		C	D		E		C		D		M		C	
DL	C		E		D		C		E		C		C		M	
DM		E		C	D		E		C		C		M		C	
DN	C		E		D		C		E		C		C		C	
DP		E		C	D		E		C		C		C		C	
DR	C		E		D		C		E		D		C		C	
DT		E		C	D		E		C		D		C		C	
DU	C		E		D		C		E		D		C		M	
DV		E		C	D		E		C		C		M		C	
DW	C		E		D		C		E		C		C		M	
DY		E		C	D		E		C		C		C		C	
EA	C		E		D		C		E		D		C		C	
EB		E		C	D		E		C		D		C		C	
EC	C		E		D		C		E		D		C		M	
ED		E		C	D		E		C		C		M		C	
EE	C		E		D		C		E		C		C		M	
EF		E		C	D		E		C		C		C		C	
EG	C		E		D		C		E		C		C		C	
EH		E		C	D		E		C		D		C		C	
EJ	C		E		D		C		E		D		C		C	
EK		E		C	D		E		C		D		M		C	
EL	C		E		D		C		E		C		C		M	
EM		E		C	D		E		C		C		M		C	
EN	C		E		D		C		E		C		C		C	
EP		E		C	D		E		C		C		C		C	
ER	C		E		D		C		E		D		C		C	
ET		E		C	D		E		C		D		C		C	
EU	C		E		D		C		E		D		C		M	
EV		E		C	D		E		C		C		M		C	
EW	C		E		D		C		E		C		C		M	
EY		E		C	D		E		C		C		C		C	
FA	C		E		D		C		E		C		C		C	
FB		E		C	D		E		C		D		C		C	
FC	C		E		D		C		E		D		C		C	

Table 101 — HBM3 Bump Map Footprint : Columns 75 to 90 (cont'd)

	75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	
FD		E		C		D		E	C		D		M		C		
FE	C		E		D		C		E	C		C		M			
FF		E		C		D		E	C		C		M		C		
FG	C		E		D		C		E	C		C		C			
FH		E		C		D		E	C		C		C		C		
FJ	C		E		D		C		E		D		C		C		
FK		E		C		D		E	C		D		C		C		
FL	C		E		D		C		E		D		C		M		
FM		E		C		D		E	C		C		M		C		
FN	C		E		D		C		E	C		C		M			
FP		E		C		D		E	C		C		C		C		
FR	C		E		D		C		E		D		C		C		
FT		E		C		D		E	C		D		C		C		
FU	C		E		D		C		E		D		C		M		
FV		E		C		D		E	C		C		M		C		
FW	C		E		D		C		E		C		C		M		
FY		E		C		D		E		C		C		C		C	
GA	C		E		D		C		E	C		C		C		C	
GB		E		C		D		E	C		D		C		C		
GC	C		E		D		C		E		D		C		C		
GD		E		C		D		E	C		D		M		C		
GF	C		E		D		C		E	C		C		M		C	
GG		E		C		D		E	C		C		C		C		
GH		E		C		D		E	C		C		C		C		
GJ	C		E		D		C		E		D		C		C		
GK		E		C		D		E	C		D		C		C		
GL	C		E		D		C		E		D		C		M		
GM		E		C		D		E	C		C		M		C		
GN	C		E		D		C		E	C		C		M			
GP		E		C		D		E	C		C		C		C		
GR	C		E		D		C		E	C		C		C		C	
GT		E		C		D		E	C		D		C		C		
GU	C		E		D		C		E		D		C		C		
GV		E		C		D		E	C		D		E		C		
GW	C		E		D		C		E		D		C		E		
GV		E		C		D		E	C		D		E		C		
HA	C		E		D		C		E		D		C		E		

11.4 HBM3 Bump Map (cont'd)

Table 102 — HBM3 Bump Map Footprint : Columns 91 to 118

	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118
A	D		C		E		D		C		E		D		C		E		D		C		E		D		C	
B		D		E		C		D		E		C		D		E		D		E		C		D		D		E
C	D		C		E		D		C		E		D		C		E		D		C		E		D		C	
D		D		E		C		D		E		C		D		E		C		D		E		C		D		E
E	D		C		E		D		C		E		D		C		E		D		C		E		D		C	
F		D		E		C		D		E		C		D		E		C		D		E		C		D		E
G	C		C		C		C		C		C		C		C		C		C		C		C		C		C	
H		N		N		N		N		N		N		N		N		N		N		N		N		N		N
J	C		C		C		C		C		C		C		C		C		C		C		C		C		C	
K	M		M		M		M		M		M		M		M		M		M		M		M		M		M	

Table 102 — HBM3 Bump Map Footprint : Columns 91 to 118 (cont'd)

	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118	
L	D		D		D		D		D		D		D		D		D		D		D		D		D		D		
M		C		DQm7		DQm5		RDm0		DQm3		DQm1		ECCm0		C		DQ17		DQ15		RD0		DQ13		DQ11		ECC10	
N	C		DBIm0		DQm6		DQm4		DPARm0		DQm2		DQm0		C		DEB10		DQ16		DQ14		DPAR10		DQ12		DQ10		
P		N		N		N		N		N		N		N		N		N		N		N		N		N			
R	C		DBIm1		DQm14		DQm12		WDQSm0_t		DQm10		DQm8		C		DEB11		DQ14		DQ12		WDQSi0_t		DQ10		DQ15		
T		C		DQm15		DQm13		WDQSm0_c		DQm11		DQm9		ECCm1		C		DQ15		DQ13		WDQSi0_c		DQ11		DQ19		ECC11	
U	M		M		M		M		M		M		M		M		M		M		M		M		M		M		
V		D		D		D		D		D		D		D		D		D		D		D		D		D			
W	C		DBIm2		DQm22		DQm20		RDQSm0_t		DQm18		DQm16		C		DEB12		DQ122		DQ120		RDQSi0_t		DQ18		DQ16		
Y		C		DQm23		DQm21		RDQSm0_c		DQm19		DQm17		SEVm0		C		DQ123		DQ121		RDQSi0_c		DQ19		DQ17		SEV10	
AA	N		N		N		N		N		N		N		N		N		N		N		N		N		N		
AB		C		DQm31		DQm29		RDm1		DQm27		DQm25		SEVm1		C		DQ131		DQ129		RD1		DQ127		DQ125		SEV11	
AC	C		DBIm3		DQm30		DQm28		DERRm0		DQm26		DQm24		C		DEB13		DQ130		DQ128		DERR10		DQ126		DQ124		
AD		M		M		M		M		M		M		M		M		M		M		M		M		M			
AE	D		D		D		D		D		D		D		D		D		D		D		D		D		D		
AF		C		ARFUm		Cm7		Cm5		Cm4		Cm2		Cm0		C		ARFU1		C17		Ci5		Ci4		C12		C10	
AG	C		RAm		APARm		Cm6		CKm_t		Cm3		Cm1		C		RAi		APARi		Ci6		CKi_t		Ci3		Ci1		
AH		C		Rm9		Rm7		CKm_c		Rm4		Rm3		Rm1		C		Ri9		Ri7		CKi_c		Ri4		Ri3		Ri1	
AJ	C		AERRm		Rm8		Rm6		Rm5		Rm0		Rm2		C		AERRi		Ri8		Ri6		Ri5		Ri0		Ri2		
AK		M		M		M		M		M		M		M		M		M		M		M		M		M			
AL	D		D		D		D		D		D		D		D		D		D		D		D		D		D		
AM		C		DQm39		DQm37		RDm2		DQm35		DQm33		ECCm2		C		DQ139		DQ137		RD2		DQ135		DQ133		ECC12	
AN	C		DBIm4		DQm38		DQm36		DPARm1		DQm34		DQm32		C		DEB14		DQ138		DQ136		DPAR1		DQ134		DQ132		
AP		N		N		N		N		N		N		N		N		N		N		N		N		N			
AR	C		DBIm5		DQm46		DQm44		WDQSm1_t		DQm42		DQm40		C		DEB15		DQ146		DQ144		WDQSi1_t		DQ142		DQ140		
AT		C		DQm47		DQm45		WDQSm1_c		DQm43		DQm41		ECCm3		C		DQ147		DQ145		WDQSi1_c		DQ143		DQ141		ECC13	
AU	M		M		M		M		M		M		M		M		M		M		M		M		M		M		
AV		D		D		D		D		D		D		D		D		D		D		D		D		D			
AW	C		DBIm6		DQm54		DQm52		RDQSm1_t		DQm50		DQm48		C		DEB16		DQ154		DQ152		RDQSi1_t		DQ150		DQ148		
AV		C		DQm55		DQm53		RDQSm1_c		DQm51		DQm49		SEVm1		C		DQ155		DQ153		RDQSi1_c		DQ151		DQ149		SEV12	
BA	N		N		N		N		N		N		N		N		N		N		N		N		N		N		
BB		C		DQm53		DQm61		RDm3		DQm59		DQm57		SEVm3		C		DQ163		DQ161		RD3		DQ159		DQ157		SEV13	
BC	C		DBIm7		DQm62		DQm60		DERRm1		DQm58		DQm56		C		DEB17		DQ162		DQ160		DERR11		DQ158		DQ156		
BD		M		M		M		M		M		M		M		M		M		M		M		M		M			

Table 102 — HBM3 Bump Map Footprint : Columns 91 to 118 (cont'd)

	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118	
BE	D		D		D		D		D		D		D		D		D		D		D		D		D		D		
BF	C		DQu7		DQu5		RDu0		DQu3		DQu1		ECCu0		C		DQj7		DQj5		RDj0		DQj3		DQj1		ECCj0		
BG	C		DBIn0		DQu6		DQu4		DPARu0		DQu2		DQu0		C		DBIj0		DQj6		DQj4		DPARj0		DQj2		DQj0		
BH	N		N		N		N		N		N		N		N		N		N		N		N		N		N		
BJ	C		DBIn1		DQu14		DQu12		WDQSj0_t		DQu10		DQu8		C		DBIj1		DQj14		DQj12		WDQSj0_t		DQj10		DQj8		
BK	C		DQu15		DQu13		WDQSj0_c		DQu11		DQu9		ECCu1		C		DQj15		DQj13		WDQSj0_c		DQj11		DQj9		ECCj1		
BL	M		M		M		M		M		M		M		M		M		M		M		M		M		M		
BM	D		D		D		D		D		D		D		D		D		D		D		D		D		D		
BN	C		DBIn2		DQu22		DQu20		RDQSj0_t		DQu18		DQu16		C		DBIj2		DQj22		DQj20		RDQSj0_t		DQj18		DQj16		
BP	C		DQu23		DQu21		RDQSj0_c		DQu19		DQu17		SEVn0		C		DQj23		DQj21		RDQSj0_c		DQj19		DQj17		SEVj0		
BR	N		N		N		N		N		N		N		N		N		N		N		N		N		N		
BT	C		DQu31		DQu29		RDu1		DQu27		DQu25		SEVn1		C		DQj31		DQj29		RDj1		DQj27		DQj25		SEVj1		
BU	C		DBIn3		DQu30		DQu28		DERRu0		DQu26		DQu24		C		DBIj3		DQj30		DQj28		DERRj0		DQj26		DQj24		
BV	M		M		M		M		M		M		M		M		M		M		M		M		M		M		
BW	D		D		D		D		D		D		D		D		D		D		D		D		D		D		
BY	C		ARFu0		Cn7		Cn5		Cn4		Cn2		Cn0		C		ARFUj		Cj7		Cj5		Cj4		Cj2		Cj0		
CA	C		RAu		APARu		Cn6		CKu_t		Cn3		Ca1		C		RAj		APARj		Cj6		CKj_t		Cj3		Cj1		
CB	C		Rn9		Rn7		CKu_c		Rn4		Rn3		Rn1		C		Rj9		Rj7		CKj_c		Rj4		Rj3		Rj1		
CC	C		AFRRn		Rn8		Rn6		Rn5		Rn0		Rn2		C		AERRj		Rj8		Rj6		Rj5		Rj0		Rj2		
CD	M		M		M		M		M		M		M		M		M		M		M		M		M		M		
CE	D		D		D		D		D		D		D		D		D		D		D		D		D		D		
CF	C		DBIn4		DQu39		DQu37		RDu2		DQu35		DQu33		ECCu2		C		DQj39		DQj37		RDj2		DQj35		DQj33		ECCj2
CG	C		DBIn4		DQu35		DQu36		DPARu1		DQu34		DQu32		C		DBIj4		DQj38		DQj36		DPARj1		DQj34		DQj32		
CH	N		N		N		N		N		N		N		N		N		N		N		N		N		N		
CJ	C		DBIn5		DQu45		DQu44		WDQSj1_t		DQu42		DQu40		C		DBIj5		DQj46		DQj44		WDQSj1_t		DQj42		DQj40		
CK	C		DQu47		DQu45		WDQSj1_c		DQu43		DQu41		ECCu3		C		DQj47		DQj45		WDQSj1_c		DQj43		DQj41		ECCj3		
CL	M		M		M		M		M		M		M		M		M		M		M		M		M		M		
CM	D		D		D		D		D		D		D		D		D		D		D		D		D		D		
CN	C		DBIn6		DQu54		DQu52		RDQSj1_t		DQu50		DQu48		C		DBIj6		DQj54		DQj52		RDQSj1_t		DQj50		DQj48		
CP	C		DQu55		DQu53		RDQSj1_c		DQu51		DQu49		SEVn2		C		DQj55		DQj53		RDQSj1_c		DQj51		DQj49		SEVj2		
CR	N		N		N		N		N		N		N		N		N		N		N		N		N		N		
CT	C		DQu63		DQu61		RDu3		DQu59		DQu57		SEVn3		C		DQj63		DQj61		RDj3		DQj59		DQj57		SEVj3		
CU	C		DBIn7		DQu62		DQu60		DERRu1		DQu58		DQu56		C		DBIj7		DQj62		DQj60		DERRj1		DQj58		DQj56		
CV	M		M		M		M		M		M		M		M		M		M		M		M		M		M		

Table 102 — HBM3 Bump Map Footprint : Columns 91 to 118 (cont'd)

	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118
CW	D		D		D		D		D		D		D		D		D		D		D		D		D		D	
CY		C		MRFU0		CATTRIP		CATTRIP		WS0o		WS0o		WS0m		WS0m		WS0k		WS0k		WS0i		WS0i		WS0g		WS0g
DA	M		M		M		M		M		M		M		M		M		M		M		M		M		M	
DB		C		MRFU1		TEMP1		TEMP0		WS0p		WS0p		WS0u		WS0u		WS0l		WS0l		WS0j		WS0j		WS0h		WS0h
DC	D		D		D		D		D		D		D		D		D		D		D		D		D		D	

Student

Table 102 — HBM3 Bump Map Footprint : Columns 91 to 118 (cont'd)

	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118
DD	M		M		M		M		M		M		M		M		M		M		M		M		M		M	
DE	C		DBI ₀₇		DQ ₀₆₂		DQ ₀₆₀		DERR ₀₁		DQ ₀₅₈		DQ ₀₅₆		C		DBII ₀₇		DQ ₀₅₂		DQ ₀₅₀		DERR ₀₁		DQ ₀₅₅		DQ ₀₅₆	
DF	C		DQ ₀₆₃		DQ ₀₆₁		RD ₀₃		DQ ₀₅₉		DQ ₀₅₇		SEV ₀₃		C		DQ ₀₆₃		DQ ₀₆₁		RDI ₀₃		DQ ₀₅₉		DQ ₀₅₇		SEV ₀₃	
DG	N		N		N		N		N		N		N		N		N		N		N		N		N		N	
DH	C		DBI ₀₅		DQ ₀₅₃		RDQS _{01..C}		DQ ₀₅₁		DQ ₀₄₉		SEV ₀₂		C		DQ ₀₅₅		DQ ₀₅₃		RDQS _{01..C}		DQ ₀₅₁		DQ ₀₄₉		SEV ₀₂	
DJ	C		DBI ₀₆		DQ ₀₅₄		DQ ₀₅₂		RDQS _{01..I}		DQ ₀₅₀		DQ ₀₄₈		C		DBII ₀₆		DQ ₀₅₄		DQ ₀₅₂		RDQS _{01..I}		DQ ₀₅₀		DQ ₀₄₈	
DK	D		D		D		D		D		D		D		D		D		D		D		D		D		D	
DL	M		M		M		M		M		M		M		M		M		M		M		M		M		M	
DM	C		DQ ₀₄₇		DQ ₀₄₅		WDQS _{01..C}		DQ ₀₄₃		DQ ₀₄₁		ECC ₀₃		C		DQ ₀₄₇		DQ ₀₄₅		WDQS _{01..C}		DQ ₀₄₃		DQ ₀₄₁		ECC ₀₃	
DN	C		DBI ₀₅		DQ ₀₄₆		DQ ₀₄₄		WDQS _{01..I}		DQ ₀₄₂		DQ ₀₄₀		C		DBII ₀₅		DQ ₀₄₆		DQ ₀₄₄		WDQS _{01..I}		DQ ₀₄₂		DQ ₀₄₀	
DP	N		N		N		N		N		N		N		N		N		N		N		N		N		N	
DR	C		DBI ₀₄		DQ ₀₃₈		DQ ₀₃₆		DPAR ₀₁		DQ ₀₃₄		DQ ₀₃₂		C		DBII ₀₄		DQ ₀₃₈		DQ ₀₃₆		DPAR ₀₁		DQ ₀₃₄		DQ ₀₃₂	
DT	C		DQ ₀₃₉		DQ ₀₃₇		RD ₀₂		DQ ₀₃₅		DQ ₀₃₃		ECC ₀₂		C		DQ ₀₃₉		DQ ₀₃₇		RDI ₀₂		DQ ₀₃₅		DQ ₀₃₃		ECC ₀₂	
DU	D		D		D		D		D		D		D		D		D		D		D		D		D		D	
DV	M		M		M		M		M		M		M		M		M		M		M		M		M		M	
DW	C		AERR ₀		R ₀₈		R ₀₆		R ₀₅		R ₀₀		R ₀₂		C		AERR ₀		R ₀₈		R ₀₆		R ₀₅		R ₀₀		R ₀₂	
DY	C		R ₀₉		R ₀₇		CK _{0..C}		R ₀₄		R ₀₃		R ₀₁		C		R ₀₉		R ₀₇		CK _{0..C}		R ₀₄		R ₀₃		R ₀₁	
EA	C		RA ₀		APAR ₀		Co ₆		CK _{0..I}		Co ₃		Co ₁		C		RAk ₀		APAR ₀		Clk ₆		CK _{0..I}		Clk ₃		Clk ₁	
EB	C		ARFU ₀		Co ₇		Co ₅		Co ₄		Co ₂		Co ₀		C		ARFU ₀		Clk ₇		Clk ₅		Clk ₄		Clk ₂		Clk ₀	
EC	D		D		D		D		D		D		D		D		D		D		D		D		D		D	
ED	M		M		M		M		M		M		M		M		M		M		M		M		M		M	
EE	C		DBI ₀₃		DQ ₀₃₀		DQ ₀₂₈		DERR ₀₀		DQ ₀₂₆		DQ ₀₂₄		C		DBII ₀₃		DQ ₀₃₀		DQ ₀₂₈		DERR ₀₀		DQ ₀₂₆		DQ ₀₂₄	
EF	C		DQ ₀₃₁		DQ ₀₂₉		RD ₀₁		DQ ₀₂₇		DQ ₀₂₅		SEV ₀₁		C		DQ ₀₃₁		DQ ₀₂₉		RDI ₀₁		DQ ₀₂₇		DQ ₀₂₅		SEV ₀₁	
EG	N		N		N		N		N		N		N		N		N		N		N		N		N		N	
EH	C		DQ ₀₂₃		DQ ₀₂₁		RDQS _{00..C}		DQ ₀₁₉		DQ ₀₁₇		SEV ₀₀		C		DQ ₀₂₃		DQ ₀₂₁		RDQS _{00..C}		DQ ₀₁₉		DQ ₀₁₇		SEV ₀₀	
EJ	C		DBI ₀₂		DQ ₀₂₂		DQ ₀₂₀		RDQS _{00..I}		DQ ₀₁₈		DQ ₀₁₆		C		DBII ₀₂		DQ ₀₂₂		DQ ₀₂₀		RDQS _{00..I}		DQ ₀₁₈		DQ ₀₁₆	
EK	D		D		D		D		D		D		D		D		D		D		D		D		D		D	
EL	M		M		M		M		M		M		M		M		M		M		M		M		M		M	
EM	C		DQ ₀₁₅		DQ ₀₁₃		WDQS _{00..C}		DQ ₀₁₁		DQ ₀₀₉		ECC ₀₁		C		DQ ₀₁₅		DQ ₀₁₃		WDQS _{00..C}		DQ ₀₁₁		DQ ₀₀₉		ECC ₀₁	
EN	C		DBI ₀₁		DQ ₀₁₄		DQ ₀₁₂		WDQS _{00..I}		DQ ₀₁₀		DQ ₀₀₈		C		DBII ₀₁		DQ ₀₁₄		DQ ₀₁₂		WDQS _{00..I}		DQ ₀₁₀		DQ ₀₀₈	
EP	N		N		N		N		N		N		N		N		N		N		N		N		N		N	
ER	C		DBI ₀₀		DQ ₀₆		DQ ₀₄		DPAR ₀₀		DQ ₀₂		DQ ₀₀		C		DBII ₀₀		DQ ₀₆		DQ ₀₄		DPAR ₀₀		DQ ₀₂		DQ ₀₀	
ET	C		DQ ₀₇		DQ ₀₅		RD ₀₀		DQ ₀₃		DQ ₀₁		ECC ₀₀		C		DQ ₀₇		DQ ₀₅		RDI ₀₀		DQ ₀₃		DQ ₀₁		ECC ₀₀	
EU	D		D		D		D		D		D		D		D		D		D		D		D		D		D	

Table 102 — HBM3 Bump Map Footprint : Columns 91 to 118 (cont'd)

	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118
EV	M		M		M		M		M		M		M		M		M		M		M		M		M		M	
EW	C		DBIp7		DQp62		DQp60		DERRp1		DQp58		DQp56		C		DBII7		DQ162		DQ160		DERR11		DQ158		DQ156	
EY	C		DQp63		DQp61		RDp3		DQp59		DQp57		SEVp3		C		DQ163		DQ161		RDI3		DQ159		DQ157		SEV13	
FA	N		N		N		N		N		N		N		N		N		N		N		N		N		N	
FB	C		DQp55		DQp53		RDQS1_c		DQp51		DQp49		SEVp2		C		DQ155		DQ153		RDQS1_c		DQ151		DQ149		SEV12	
FC	C		DBIp6		DQp54		DQp52		RDQS1_t		DQp50		DQp48		C		DBII6		DQ154		DQ152		RDQS1_t		DQ150		DQ148	
FD	D		D		D		D		D		D		D		D		D		D		D		D		D		D	
FE	M		M		M		M		M		M		M		M		M		M		M		M		M		M	
FF	C		DQp47		DQp45		WDQS1_c		DQp43		DQp41		ECCp3		C		DQ147		DQ145		WDQS1_c		DQ143		DQ141		ECC13	
FG	C		DBIp5		DQp46		DQp44		WDQS1_t		DQp42		DQp40		C		DBII5		DQ146		DQ144		WDQS1_t		DQ142		DQ140	
FH	N		N		N		N		N		N		N		N		N		N		N		N		N		N	
FJ	C		DBIp4		DQp38		DQp36		DPARp1		DQp34		DQp32		C		DBII4		DQ138		DQ136		DPAR11		DQ134		DQ132	
FK	C		DQp39		DQp37		RDp2		DQp35		DQp33		ECCP2		C		DQ139		DQ137		RDI2		DQ135		DQ133		ECC12	
FL	D		D		D		D		D		D		D		D		D		D		D		D		D		D	
FM	M		M		M		M		M		M		M		M		M		M		M		M		M		M	
FN	C		AERRp		Rp8		Rp6		Rp8		Rp0		Rp2		C		AERR1		R18		R16		R15		R10		R12	
FP	C		Rp9		Rp7		CKp_c		Rp4		Rp3		Rp1		C		R19		R17		CKL_c		R14		R13		R11	
FR	C		RAp		APARp		Cp6		CKp_t		Cp3		Cp1		C		RAI		APARI		C16		CKL_t		C13		C11	
FT	C		ARFUp		Cp7		Cp5		Cp4		Cp2		Cp0		C		ARFU1		C17		C15		C14		C12		C10	
FU	D		D		D		D		D		D		D		D		D		D		D		D		D		D	
FV	M		M		M		M		M		M		M		M		M		M		M		M		M		M	
FW	C		DBIp3		DQp30		DQp28		DERRp0		DQp26		DQp24		C		DBII3		DQ130		DQ128		DERR10		DQ126		DQ124	
FY	C		DQp31		DQp29		RDp1		DQp27		DQp25		SEVp1		C		DQ131		DQ129		RDI1		DQ127		DQ125		SEV11	
GA	N		N		N		N		N		N		N		N		N		N		N		N		N		N	
GB	C		DQp23		DQp21		RDQS0_c		DQp19		DQp17		SEVp0		C		DQ123		DQ121		RDQS10_c		DQ119		DQ117		SEV10	
GC	C		DBIp2		DQp22		DQp20		RDQS0_t		DQp18		DQp16		C		DBII2		DQ122		DQ120		RDQS10_t		DQ118		DQ116	
GD	D		D		D		D		D		D		D		D		D		D		D		D		D		D	
GE	M		M		M		M		M		M		M		M		M		M		M		M		M		M	
GF	C		DQp15		DQp13		WDQS0_c		DQp11		DQp9		ECCp1		C		DQ115		DQ113		WDQS0_c		DQ111		DQ119		ECC11	
GG	C		DBIp1		DQp14		DQp12		WDQS0_t		DQp10		DQp8		C		DBII1		DQ114		DQ112		WDQS0_t		DQ110		DQ108	
GH	N		N		N		N		N		N		N		N		N		N		N		N		N		N	
GJ	C		DBIp0		DQp6		DQp4		DPARp0		DQp2		DQp0		C		DBII0		DQ116		DQ114		DPAR10		DQ112		DQ10	
GK	C		DQp7		DQp5		RDp0		DQp3		DQp1		ECCp0		C		DQ117		DQ115		RDI0		DQ113		DQ111		ECC10	
GL	D		D		D		D		D		D		D		D		D		D		D		D		D		D	

Table 102 — HBM3 Bump Map Footprint : Columns 91 to 118 (cont'd)

	91	92	93	94	95	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115	116	117	118
GM	M		M		M		M		M		M		M		M		M		M		M		M		M		M	
GN	C		C		C		C		C		C		C		C		C		C		C		C		C		C	
GP	N		N		N		N		N		N		N		N		N		N		N		N		N		N	
GR	C		C		C		C		C		C		C		C		C		C		C		C		C		C	
GT	D		E		C		D		E		C		D		E		C		D		E		C		D		E	
GU	D		C		E		D		C		E		D		C		E		D		C		E		D		C	
GV	D		E		C		D		E		C		D		E		C		D		E		C		D		E	
GW	D		C		E		D		C		E		D		C		E		D		C		E		D		C	
GY	D		E		C		D		E		C		D		E		C		D		E		C		D		E	
HA	D		C		E		D		C		E		D		C		E		D		C		E		D		C	

11.4 HBM3 Bump Map (cont'd)

Table 103 — HBM3 Bump Map Footprint : Columns 119 to 148

	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148
A	E		D		C		E		D		C		E		D		C		E		D		C		E		D		B	
B		C		D		E		C		D		E		C		D		E		C		D		E		C		D		B
C	E		D		C		E		D		C		E		D		C		E		D		C		E		D		B	
D		C		D		E		C		D		E		C		D		E		C		D		E		C		D		B
E	E		D		C		E		D		C		E		D		C		E		D		C		E		D		B	
F		C		D		E		C		D		E		C		D		E		C		D		E		C		D		B
G	C		C		C		C		C		C		C		C		C		C		C		C		C		C		B	
H	N		N		N		N		N		N		N		N		N		N		N		N		N		N		B	
J	C		C		C		C		C		C		C		C		C		C		C		C		C		C		B	
K		M		M		M		M		M		M		M		M		M		M		M		M		M		M		B

Table 103 — HBM3 Bump Map Footprint : Columns 119 to 148 (cont'd)

	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148		
L	D		D		D		D		D		D		D		D		D		D		D		D		D		D		B			
M	C		DQe7		DQe8		RDe0		DQe3		DQe1		ECCe0		C		DQa7		DQa5		RDa0		DQa3		DQa1		ECCa0		B			
N	C		DBIe0		DQe6		DQe4		DPARe0		DQe2		DQe0		C		DBIa0		DQa6		DQa4		DPARa0		DQa2		DQa0		B			
P		N		N		N		N		N		N		N		N		N		N		N		N		N		B				
R	C		DBIe1		DQe14		DQe12		WDQS0_1		DQe10		DQe8		C		DBIa1		DQa14		DQa12		WDQS0_1		DQa10		DQa8		B			
T		C		DQe15		DQe13		WDQS0_2		DQe11		DQe9		ECCe1		C		DQa15		DQa13		WDQS0_5		DQa11		DQa9		ECCa1		B		
U	M		M		M		M		M		M		M		M		M		M		M		M		M		M		B			
V		D		D		D		D		D		D		D		D		D		D		D		D		D		D		B		
W	C		DBIe2		DQe22		DQe20		RDQS0_1		DQe18		DQe16		C		DBIa2		DQa22		DQa20		RDQS0_1		DQa18		DQa16		B			
Y		C		DQe23		DQe21		RDQS0_5		DQe19		DQe17		SEVe0		C		DQa23		DQa21		RDQS0_5		DQa19		DQa17		SEVe0		B		
AA	N		N		N		N		N		N		N		N		N		N		N		N		N		N		B			
AB		C		DQe31		DQe29		RDe1		DQe27		DQe25		SEVe1		C		DQa31		DQa29		RDa1		DQa27		DQa25		SEVe1		B		
AC	C		DBIe3		DQe30		DQe28		DERRe0		DQe26		DQe24		C		DBIa3		DQa30		DQa28		DERRa0		DQa26		DQa24		B			
AD		M		M		M		M		M		M		M		M		M		M		M		M		M		M		B		
AE	D		D		D		D		D		D		D		D		D		D		D		D		D		D		D		B	
AF		C		ARFUe		Ce7		Ce5		Ce4		Ce2		Ce0		C		ARFUa		Ca7		Ca5		Ca4		Ca2		Ca0		B		
AG	C		RAe		APArE		Ce6		CKe_1		Ce3		Ce1		C		RAa		APArA		Ca6		CKa_1		Ca3		Ca1		B			
AH		C		Re9		Re7		CKe_c		Re4		Re3		Re1		C		Ra9		Ra7		CKa_c		Ra4		Ra3		Ra1		B		
AJ	C		AFRRe		Re8		Re6		Re5		Re0		Re2		C		AERRa		Ra8		Ra6		Ra5		Ra0		Ra2		B			
AK		M		M		M		M		M		M		M		M		M		M		M		M		M		M		B		
AL	D		D		D		D		D		D		D		D		D		D		D		D		D		D		D		B	
AM		C		DQe39		DQe37		RDe2		DQe35		DQe33		ECCe1		C		DQa39		DQa37		RDa2		DQa35		DQa33		ECCa2		B		
AN	C		DBIe4		DQe38		DQe36		DPARe1		DQe34		DQe32		C		DBIa4		DQa38		DQa36		DPARa1		DQa34		DQa32		B			
AP		N		N		N		N		N		N		N		N		N		N		N		N		N		N		B		
AR	C		DBIe5		DQe46		DQe44		WDQS0_1		DQe42		DQe40		C		DBIa5		DQa46		DQa44		WDQS0_1		DQa42		DQa40		B			
AT		C		DQe47		DQe45		WDQS0_5		DQe43		DQe41		ECCe3		C		DQa47		DQa45		WDQS0_5		DQa43		DQa41		ECCa3		B		
AU	M		M		M		M		M		M		M		M		M		M		M		M		M		M		B			
AV		D		D		D		D		D		D		D		D		D		D		D		D		D		D		B		
AW	C		DBIe6		DQe54		DQe52		RDQS0_1		DQe50		DQe48		C		DBIa6		DQa54		DQa52		RDQS0_1		DQa50		DQa48		B			
AV		C		DQe55		DQe53		RDQS0_5		DQe51		DQe49		SEVe2		C		DQa55		DQa53		RDQS0_5		DQa51		DQa49		SEVe2		B		
BA	N		N		N		N		N		N		N		N		N		N		N		N		N		N		B			
BB		C		DQe53		DQe61		RDe3		DQe59		DQe57		SEVe3		C		DQa53		DQa61		RDa3		DQa59		DQa57		SEVe3		B		
BC	C		DBIe7		DQe62		DQe60		DERRe1		DQe58		DQe56		C		DBIa7		DQa62		DQa60		DERRa1		DQa58		DQa56		B			
BD		M		M		M		M		M		M		M		M		M		M		M		M		M		M		B		

Table 103 — HBM3 Bump Map Footprint : Columns 119 to 148 (cont'd)

	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148
BE	D		D		D		D		D		D		D		D		D		D		D		D		D		D		B	
BF	C		DQf7		DQf5		RDf0		DQf3		DQf1		ECCf0		C		DBIb7		DQb5		RDf0		DQb3		DQb1		ECCb0		B	
BG	C		DBIf0		DQf6		DQf4		DPARf0		DQf2		DQf0		C		DBIb0		DQb6		DQb4		DPARb0		DQb2		DQb0		B	
BH	N		N		N		N		N		N		N		N		N		N		N		N		N		N		B	
BJ	C		DBIf1		DQf14		DQf12		WDQSf0_1		DQf10		DQf8		C		DBIb1		DQb14		DQb12		WDQSb0_1		DQb10		DQb8		B	
BK	C		DQf5		DQf13		WDQSf0_6		DQf11		DQf9		ECCf1		C		DBIb5		DQb13		WDQSb0_5		DQb11		DQb9		ECCb1		B	
BL	M		M		M		M		M		M		M		M		M		M		M		M		M		M		B	
BM	D		D		D		D		D		D		D		D		D		D		D		D		D		D		B	
BN	C		DBIf2		DQf22		DQf20		RDQSf0_1		DQf18		DQf16		C		DBIb2		DQb22		DQb20		RDQSb0_1		DQb18		DQb16		B	
BP	C		DQf23		DQf21		RDQSf0_6		DQf19		DQf17		SEVf0		C		DQb23		DQb21		RDQSb0_6		DQb19		DQb17		SEVb0		B	
BR	N		N		N		N		N		N		N		N		N		N		N		N		N		N		B	
BT	C		DQf31		DQf19		RDM		DQf27		DQf25		SEVf1		C		DQb31		DQb29		RDf1		DQb27		DQb25		SEVb1		B	
BU	C		DBIf3		DQf30		DQf28		DERRf0		DQf26		DQf24		C		DBIb3		DQb30		DQb28		DERRb0		DQb26		DQb24		B	
BV	M		M		M		M		M		M		M		M		M		M		M		M		M		M		B	
BW	D		D		D		D		D		D		D		D		D		D		D		D		D		D		B	
BV	C		ARFuf		Cf7		Cf5		Cf4		Cf2		Cf0		C		ARFUb		Cb7		Cb5		Cb4		Cb2		Cb0		B	
CA	C		RAf		APRF		Cff		CKf1		Cff		Cff		C		RAb		APArb		Cb6		CKb1		Cb3		Cb1		B	
CB	C		Rf9		Rf7		CKf_c		Rf4		Rf3		Rf1		C		Rb9		Rb7		CKb_c		Rb4		Rb3		Rb1		B	
CC	C		AERRf		Rf8		Rf6		Rf5		Rf0		Rf2		C		AERRb		Rb8		Rb6		Rb5		Rb0		Rb2		B	
CD	M		M		M		M		M		M		X		M		M		M		M		M		M		M		B	
CE	D		D		D		D		D		D		D		D		D		D		D		D		D		D		B	
CF	C		DQb39		DQb37		RDf2		DQb35		DQb33		ECCf2		C		DQb39		DQb37		RDf2		DQb35		DQb33		ECCb2		B	
CG	C		DBIf4		DQf38		DQf36		DPARf1		DQf34		DQf32		C		DBIb4		DQb38		DQb36		DPARb1		DQb34		DQb32		B	
CH	N		N		N		N		N		N		N		N		N		N		N		N		N		N		B	
CJ	C		DBIf5		DQf46		DQf44		WDQSf0_1		DQf42		DQf40		C		DBIb5		DQb46		DQb44		WDQSb1_f		DQb42		DQb40		B	
CK	C		DQf47		DQf45		WDQSf0_6		DQf43		DQf41		ECCf3		C		DQb47		DQb45		WDQSb0_6		DQb43		DQb41		ECCb3		B	
CL	M		M		M		M		M		M		M		M		M		M		M		M		M		M		B	
CM	D		D		D		D		D		D		D		D		D		D		D		D		D		D		B	
CN	C		DBIf6		DQf54		DQf52		RDQSf0_1		DQf50		DQf48		C		DBIb6		DQb54		DQb52		RDQSb0_1		DQb50		DQb48		B	
CP	C		DQf55		DQf53		RDQSf1_c		DQf51		DQf49		SEVf2		C		DQb55		DQb53		RDQSb1_c		DQb51		DQb49		SEVb2		B	
CR	N		N		N		N		N		N		N		N		N		N		N		N		N		N		B	
CT	C		DQf53		DQf51		RDM		DQf59		DQf57		SEVf3		C		DQb53		DQb61		RDf3		DQb59		DQb57		SEVb3		B	
CU	C		DBIf7		DQf62		DQf60		DERRf1		DQf58		DQf56		C		DBIb7		DQb62		DQb60		DERRb1		DQb58		DQb56		B	
CV	M		M		M		M		M		M		M		M		M		M		M		M		M		M		B	

Table 103 — HBM3 Bump Map Footprint : Columns 119 to 148 (cont'd)

	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148
CW	D		D		D		D		D		D		D		D		D		D		D		D		D		B			
CV		WS0e		WS0e		WS0c		WS0c		WS0a		WS0a		WSI		WSI		CAPTURE_WR		CAPTURE_WR		WRCK		WRCK		RESET_B		RESET_B		B
DA	M		M		M		M		M		M		M		M		M		M		M		M		M		M		B	
DB		WS0f		WS0f		WS0d		WS0d		WS0b		WS0b		SELECT_WIR		SELECT_WIR		UPDATE_WR		UPDATE_WR		SHIFTWR		SHIFTWR		WRST_B		WRST_B		B
DC	D		D		D		D		D		D		D		D		D		D		D		D		D		D		B	

Student

Table 103 — HBM3 Bump Map Footprint : Columns 119 to 148 (cont'd)

DD	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	B
DE	C	DBIg7	DQg62	DQg60	DERg1	DQg58	DQg56	C	DBIc7	DQc62	DQc60	DERrcl	DQc55	DQc56	B					
DF	C	DQg63	DQg61	RDg3	DQg59	DQg57	SEVg3	C	DQc63	DQc61	RDX3	DQc59	DQc57	SEVg3	B					
DG	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	B	
DH	C	DQg55	DQg53	RDQSg1_t	DQg51	DQg49	SEVg2	C	DQc55	DQc53	RDQSg1_t	DQc51	DQc49	SEVg2	B					
DJ	C	DBIg6	DQg54	DQg52	RDQSg1_t	DQg50	DQg48	C	DBIc6	DQc54	DQc52	RDQSg1_t	DQc50	DQc48	B					
DK	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	B	
DL	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	B	
DM	C	DQg47	DQg45	WDQSg1_t	DQg43	DQg41	ECCg3	C	DBIc7	DQc47	DQc45	WDQSg1_t	DQc43	DQc41	ECCg3	B				
DN	C	DBIg5	DQg46	DQg44	WDQSg1_t	DQg42	DQg40	C	DBIc5	DQc46	DQc44	WDQSg1_t	DQc42	DQc40	B					
DP	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	B	
DR	C	DBIg4	DQg38	DQg36	DPARg1	DQg34	DQg32	C	DBIc4	DQc38	DQc36	DPARcl	DQc34	DQc32	B					
DT	C	DQg39	DQg37	RDg2	DQg35	DQg33	ECCg2	C	DQc39	DQc37	RDX2	DQc35	DQc33	ECCg2	B					
DU	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	B	
DV	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	B	
DW	C	AERRg	Rg8	Rg6	Rg5	Rg0	Rg1	C	AERRg	Rg8	Rg6	Rg5	Rg0	Rg2	Rg1	Rg3	Rg4	Rg2	B	
DY	C	Rg9	Rg7	CKg_c	Rg4	Rg3	Rg1	C	Rg9	Rg7	CKg_c	Rg4	Rg3	Rg1	Rg2	Rg3	Rg4	Rg1	Rg2	B
EA	C	RAg	APARg	Cg6	CKg_t	Cg3	Cg1	C	RAc	APARc	Cc6	CKg_t	Cc3	Cc1	Cc2	Cc3	Cc4	Cc1	Cc2	B
EB	C	ARFUg	Cg7	Cg5	Cg4	Cg2	Cg0	C	ARFUc	Cc7	Cc5	Cc4	Cc2	Cc0	Cc1	Cc2	Cc3	Cc1	Cc2	B
EC	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	B	
ED	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	B	
EE	C	DBIg3	DQg40	DQg28	DERrg0	DQg26	DQg24	C	DBIc3	DQc30	DQc28	DERr0	DQc26	DQc24	B					
EF	C	DQg31	DQg29	RDg1	DQg27	DQg25	SEVg1	C	DQc31	DQc29	RDX1	DQc27	DQc25	SEVc1	B					
EG	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	B	
EH	C	DQg23	DQg21	RDQSg0_c	DQg19	DQg17	SEVg0	C	DQc23	DQc21	RDQSg0_c	DQc19	DQc17	SEVf0	B					
EJ	C	DBIg2	DQg22	DQg20	RDQSg0_t	DQg18	DQg16	C	DBIc2	DQc22	DQc20	RDQSg0_t	DQc18	DQc16	B					
EK	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	B	
EL	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	B	
EM	C	DBIg1	DQg14	DQg12	WDQSg0_c	DQg11	DQg9	ECCg1	C	DQc15	DQc13	WDQSg0_c	DQc11	DQc9	ECCc1	B				
EN	C	DBIg1	DQg14	DQg12	WDQSg0_f	DQg10	DQg8	C	DBIc1	DQc14	DQc12	WDQSg0_f	DQc10	DQc8	B					
EP	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	B	
ER	C	DBIg0	DQg6	DQg4	DPARg0	DQg2	DQg0	C	DBIc0	DQc6	DQc4	DPARcl	DQc2	DQc0	B					
ET	C	DQg7	DQg5	RDg0	DQg3	DQg1	ECCg0	C	DQc7	DQc5	RDX0	DQc3	DQc1	ECCc0	B					
EU	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	B	

Table 103 — HBM3 Bump Map Footprint : Columns 119 to 148 (cont'd)

	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148
EV	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	B		
EW	C	DBIh7	DQh62	DQh60	DERRh1	DQh58	DQh56	C	DBIh7	DQd62	DQd60	DERRd1	DQd58	DQd56	SEV43	B														
EV	C	DQh63	DQh61	RDh63	DQh59	DQh57	SEVh3	C	DQd63	DQd61	RDh3	DQd59	DQd57	SEV43	B															
FA	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	B			
FB	C	DQh55	DQh53	RDQSh1_c	DQh51	DQh49	SEVh2	C	DQd55	DQd53	RDQSh1_c	DQd51	DQd49	SEV42	B															
FC	C	DBIh6	DQh54	DQh52	RDQSh1_t	DQh50	DQh48	C	DBIh6	DQd54	DQd52	RDQSh1_t	DQd50	DQd48	B															
FD	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	B				
FE	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	B			
FF	C	DQh47	DQh45	WDQSh1_c	DQh43	DQh41	ECCh3	C	DQd47	DQd45	WDQSh1_c	DQd43	DQd41	ECCd3	B															
FG	C	DBIh5	DQh46	DQh44	WDQSh1_t	DQh42	DQh40	C	DBIh5	DQd46	DQd44	WDQSh1_t	DQd42	DQd40	B															
FH	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	B				
FJ	C	DBIh4	DQh39	DQh37	RDh2	DQh35	DQh33	ECCh2	C	DQd39	DQd37	RDM2	DQd35	DQd33	ECCd2	B														
FK	C	DQh39	DQh37	RDh2	DQh35	DQh33	ECCh2	C	DQd39	DQd37	RDM2	DQd35	DQd33	ECCd2	B															
FL	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	B				
FM	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	B			
FN	C	AERRh	Rh8	Rh6	Rh5	Rh0	Rh2	C	AERRd	Rd8	Rd6	Rd5	Rd0	Rd2	B															
FP	C	Rh9	Rh7	CKh_c	Rh4	Rh3	Rh1	C	Rd9	Rd7	CKd_c	Rd4	Rd3	Rd1	B															
FR	C	RAh	APARh	Ch6	Chk_t	Ch3	Ch1	C	RAd	APARD	Cd6	CKd_t	Cd3	Cd1	B															
FT	C	ARFUh	Ch7	Ch5	Ch4	Ch2	Ch0	C	ARFUd	Cd7	Cd5	Cd4	Cd2	Cd0	B															
FU	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	B				
FV	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	B			
FW	C	DBIh3	DQh30	DQh28	DERRh0	DQh26	DQh24	C	DBIh3	DQd30	DQd28	DERRd0	DQd26	DQd24	B															
FY	C	DQh31	DQh29	RDh1	DQh27	DQh25	SEVh1	C	DQd31	DQd29	RDM1	DQd27	DQd25	SEV41	B															
GA	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	B				
GB	C	DQh23	DQh21	RDQSh0_c	DQh19	DQh17	SEVh0	C	DQd23	DQd21	RDQSh0_c	DQd19	DQd17	SEV40	B															
GC	C	DBIh2	DQh22	DQh20	RDQSh0_t	DQh18	DQh16	C	DBIh2	DQd22	DQd20	RDQSh0_t	DQd18	DQd16	B															
GD	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	B				
GE	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	M	B				
GF	C	DQh15	DQh13	WDQSh0_c	DQh11	DQh9	ECCh1	C	DQd15	DQd13	WDQSh0_c	DQd11	DQd9	ECCd1	B															
GG	C	DBIh1	DQh14	DQh12	WDQSh0_t	DQh10	DQh8	C	DBIh1	DQd14	DQd12	WDQSh0_t	DQd10	DQd8	B															
GH	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	N	B				
GJ	C	DBIh0	DQh6	DQh4	DPARh0	DQh2	DQh0	C	DBIh0	DQd6	DQd4	DPARd0	DQd2	DQd0	B															
GK	C	DQh7	DQh5	RDh0	DQh3	DQh1	ECCh0	C	DQd7	DQd5	RDM0	DQd3	DQd1	ECCd0	B															
GL	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	D	B				

Table 103 — HBM3 Bump Map Footprint : Columns 119 to 148 (cont'd)

	119	120	121	122	123	124	125	126	127	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143	144	145	146	147	148
GM		M		M		M		M		M		M		M		M		M		M		M		M		M		M		B
GN	C		C		C		C		C		C		C		C		C		C		C		C		C		C		B	
GP	N		N		N		N		N		N		N		N		N		N		N		N		N		N		B	
GR	C		C		C		C		C		C		C		C		C		C		C		C		C		C		B	
GT	C		D		E		C		D		E		C		D		E		C		D		E		C		D		B	
GU	E		D		C		E		D		C		E		D		C		E		D		C		E		D		B	
GV	C		D		E		C		D		E		C		D		E		C		D		E		C		D		B	
GW	E		D		C		E		D		C		E		D		C		E		D		C		E		D		B	
GV	C		D		E		C		D		E		C		D		E		C		D		E		C		D		B	
HA	E		D		C		E		D		C		E		D		C		E		D		C		E		D		B	

12 HBM DRAM Assembly

The HBM3 DRAM assembly is not defined by this standard. The shape and materials of the die to die interfaces between the die in the HBM3 DRAM are not defined in this standard and the shape (annular, cone, cylinder, etc.) and materials (Cu, W) are not defined or restricted in this standard. However, these interfaces must fit within the electrical requirements of the channel interface.

13 Test and Boundary Scan

HBM3 DRAMs provide two separate test interfaces as described below:

- a direct access(DA) test port intended for the vendor to access the HBM3 device independent of the host;
- an IEEE 1500 Standard test port, to be controlled by the host.

13.1 Direct Access (DA) Test Port

A direct access (DA) test port is available via DA[39:0] for vendor specific test implementations. Two microbumps are associated with each DA pin. A depopulated area for probing is located close to the DA port region in columns 21 to 36 of the HBM3 bump matrix (see HBM3 Ballout).

Access to the DA test port is controlled via pin DA0. When DA0 = LOW, DA[39:1] drivers are in Hi-Z and input receivers are disabled allowing the bus to float. When DA0 = HIGH, DA[39:1] are enabled for vendor specific test features and the IEEE 1500 port is disabled. CATTRIP and TEMP[1:0] outputs remain active but their state may not be valid and shall be ignored. The DA0 input is equipped with an internal pull-down resistor which ensures that DA0 is held LOW and the test port remains inactive even if the pin is left floating.

The DA test port may be enabled at any time after the power ramp has been completed and all supply voltages are within their defined ranges (t_{INIT0}), and after waiting for at least t_{INIT1} time. The level of the RESET_n pin shall be irrelevant for DA test port enabling.

The DA test port may be disabled at any time by pulling DA0 to LOW. The HBM3 DRAM may then resume normal operation after performing a device initialization as described in the Initialization Sequence with Stable Power clause.

18 DA pins are designated to connect point-to-point to each HBM3 DRAM. 22 pins are designated to connect in parallel to up to four HBM3 DRAM devices on a multi drop bus as shown in Figure 97. The function of each of these pins is vendor specific. Table 104 defines which DA pins are allocated for point-to-point and for multi drop.

Table 104 — Direct Access (DA) Pin Allocation

Pin Group	DA Pin List	Pin Count
Point to Point	DA[17:0]	18
Multi Drop	DA[39:18]	22

13.1 Direct Access (DA) Test Port (cont'd)




Figure 97 — DA Port Connection Diagram For Multiple HBM3 DRAM Devices

13.1.1 DA Test Port Lockout

The DA test port can be disabled (locked) by setting MR8 OP0 bit to 1. The bit is defined for channels a or e only. Once the bit is set to 1, the DA test port will remain disabled unless power is removed from the HBM3 DRAM. Any chip reset through pulling RESET_n LOW or via IEEE1500 HBM_RESET instruction, or writing a 0 via an MRS command or IEEE1500 instruction MODE_REGISTER_DUMP_SET will not clear the locked state.

13.2 IEEE Standard 1500

The IEEE Standard 1500 compliant test access port provides a direct test connection between a host and the HBM3 DRAM. The HBM3 DRAM's test port extends the standard specification and replicates the WSO output per channel. This allows some instructions to be executed in parallel across channels, and eliminates the need for cross-channel arbitration for WSO.

IEEE 1500 operations may be asserted at any time after device initialization and during normal memory operation including when the HBM3 DRAM is in power-down or self refresh mode. See clause Interaction with Mission Mode Operation for how the various instructions interact with normal operation, and requirements for returning to normal operation. See also clause Initialization Sequence For Use Of IEEE1500 Instruction Including Lane Repairs for a subset of operations that are allowed before the device initialization has been completed.

Please refer to ieee.org for more details about the IEEE1500 standard

13.2.1 Interaction Between DA Test Port and IEEE1500 Test Access Port

DA0 = LOW selects the IEEE1500 test access port and DA0 = HIGH selects the DA test port. It is possible to operate the HBM3 DRAM without using the test ports. In this case the internal pull-down resistor on DA0 or pulling DA0 LOW in the system will keep the DA test port disabled, and pulling WRST_n LOW in the system will keep the IEEE1500 test port disabled.

13.2.1 Interaction Between DA Test Port and IEEE1500 Test Access Port (cont'd)

Table 105 summarizes the status of the test access port signals.

Table 105 — Test Access Port Signal Status

WRST_n	DA0, MR8 OP0	Signal Name	Type	Status
LOW	DA0 = LOW or MR8 OP0 = 1	Other IEEE1500 inputs ¹	Input	X (Don't Care)
		WSO	Output	V (Valid) ²
		DA[39:1]	I/O	X (Don't Care)
HIGH	DA0 = LOW or MR8 OP0 = 1	Other IEEE1500 inputs ¹	Input	Active
		WSO	Output	V (Valid) ²
		DA[39:1]	I/O	X (Don't Care)
Don't Care	DA0 = HIGH and MR8 OP0 = 0	Other IEEE1500 inputs ¹	Input	X (Don't Care)
		WSO	Output	V (Valid) ²
		DA[39:1]	I/O	Vendor specific ³

NOTE 1 WRCK, SelectWIR, ShiftWR, CaptureWR, UpdateWR, WSI.
 NOTE 2 V = Valid Signal (either HIGH or LOW, but not floating).
 NOTE 3 Please refer to vendor's datasheet.

13.2.2 IEEE1500 Test Access Port I/O Signals

Table 106 — IEEE1500 Test Port Signal List and Description

Symbol	Type	Description
WRCK	Input	Dedicated clock used to operate IEEE Std 1500 functions.
WRST_n	Input	When pulled LOW, WRST_n asynchronously puts the IEEE1500 test port into its normal system mode. No WRCK clocks are required when WRST_n is LOW. See WDR Reset State
WSI	Input	IEEE1500 test port serial input
SelectWIR	Input	SelectWIR determines whether the instruction register (WIR) or a wrapper data register is being accessed.
CaptureWR	Input	Controls a Capture operation in the selected wrapper register (WR)
ShiftWR	Input	Controls a Shift operation in the selected wrapper register (WR)
UpdateWR	Input	Controls an Update operation in the selected wrapper register (WR)
WSO[a:p]	Output	IEEE1500 test port per-channel serial output

13.2.3 IEEE1500 Test Access Port Functional Description

Figure 98 shows the HBM3 DRAM's IEEE1500 compliant architecture that uses an asymmetrical WSP (Wrapper Serial Port) with a single WSI and sixteen per channel WSOs. The standard compliant register stack is shown in the figure, including the Wrapper Bypass Register (WBY), Wrapper Boundary Register (WBR), and Wrapper Data Registers (WDR). The C, S and U notation for the registers refer to Capture, Shift and Update respectively, and indicate for each of the registers which functions are supported by that register. For example, the WBY only provides a Shift stage, whereas the WDRs provide Shift/Capture and Update stages.

13.2.3 IEEE1500 Test Access Port Functional Description (cont'd)




Figure 98 — IEEE Std. 1500 Logic Diagram

The WSO[a:p] output drivers are permanently enabled, with their drive state being LOW, HIGH, or undefined based on the current instruction loaded into the WIR. For example, if BYPASS is the current instruction, then WSO output data is defined only after one or more WRCK clock cycles have been applied. A WSO output will drive a LOW when a channel is disabled via the CHANNEL_DISABLE instruction or marked as “not present / not working” in the DEVICE_ID WDR.

The Wrapper Instruction Register (WIR) logic is included in Figure 98, and Figure 99 shows further details of the WIR implementation. The WIR and instruction opcodes are described in clause IEEE1500 Test Access Port Instruction Register, and the instructions supported by the HBM3 DRAM in clause Test Instructions. The five channel select bits of the WIR shift stage in Figure 99 are decoded to generate the CHSelect[a:p] outputs which control the per channel operation of the instructions. When a channel is not selected for an active instruction, then the CaptureWDR[a:p], ShiftWDR[a:p] and UpdateWDR[a:p] enables of the WSP are gated off. This will disable the WDRs of unselected channels for the decoded instruction. This gating is shown by the logic AND gates at the output of the de-multiplexer in Figure 98.




Figure 99 — WIR Channel Select Logic Diagram

13.2.3 IEEE1500 Test Access Port Functional Description (cont'd)

HBM3 DRAMs are allowed to support less than 16 channels. The availability of each channel is coded in the DEVICE_ID WDR bits [23:8]. Unavailable channels do not respond to IEEE1500 instructions.

Figure 100 illustrates an IEEE1500 port operation sequence with a minimum number of WRCK cycles:

- Signal SelectWIR is set at clock edge T0. Control signals CaptureWR, ShiftWR and UpdateWR are all inactive as they are not allowed to change coincident with SelectWIR. SelectWIR must be kept stable until after completion of the complete sequence which spans until clock edge T4.
- A WDR capture operation is performed at clock edge T1 with CaptureWR sampled High at T1.
- A single WDR shift operation is performed at clock edge T2 with ShiftWR sampled High at T2.
- A WDR update operation is performed at clock edge T3b with UpdateWR sampled High at T3b. Please note that the update operation occurs on the falling WRCK clock edge.
- For some IEEE1500 port instructions a capture, shift or update event may not be specified; please refer to the description of each instruction for details.




Figure 100 — IEEE1500 Port Operation

13.3 Wrapper Data Register (WDR) Types

13.3.1 Read Only (R) Wrapper Data Registers

WDR bit fields that are specified as read-only capture data into the shift stage register when a CaptureWR event is performed. The read-only WDRs keep their state during an UpdateWR event and do not have an update stage register. Read-only WDRs shift out their content during a ShiftWR event. Data shifted into WSI during the ShiftWR event is ignored.

13.3.2 Write Only (W) Wrapper Data Registers

WDR bit fields that are specified as write-only copy all data bits into the update stage register when an UpdateWR event is performed. When a write-only WDR is connected between WSI and WSO, any CaptureWR event has no effect on the WDR. Write-only WDRs shift out their content during the ShiftWR event.

13.3.3 Read and Write (R/W) Wrapper Data Registers

R/W WDRs operate as merged function of write-only and read-only WDRs. They capture data bits into the shift stage register during a CaptureWR event and copy bits from the shift stage into the update stage simultaneously when the UpdateWR event is performed.

13.3.4 WDR Reset State

Asserting WRST_n to LOW asynchronously asserts these states on the HBM3 DRAM's IEEE1500 test port logic:

- all WDRs place their update and / or shift stages (where applicable) into a state that ensures that the HBM3 DRAM returns to mission mode operation and all test modes are disabled;
- the WIR is set to BYPASS, effectively clearing any prior EXTEST_RX, EXTEST_TX, or CHANNEL_ID instruction, thus returning all functional pins to their normal functional mode. Boundary scan chain content is undefined;
- No change to any previously loaded SOFT_REPAIR, HARD_REPAIR, SOFT_LANE_REPAIR, or HARD_LANE_REPAIR register content;
- the content of the DWORD_MISR and AWORD_MISR registers is undefined;
- the AWORD MISR is disabled by setting bit 2 in the AWORD_MISR_CONFIG WDR to 0;
- the CHANNEL_DISABLE WDR is reset (refer to the CHANNEL_DISABLE instruction for conditions to re-enable a disabled channel);
- any ongoing MBIST operation will be terminated.

13.4 IEEE1500 Test Access Port Instruction Encodings

The HBM3 DRAM supports a 13-bit Wrapper Instruction Register (WIR). Bits WIR[12:8] select the channel and bits WIR[7:0] encode the test instruction. When SelectWIR is asserted, the WIR will not respond to the CaptureWR event and nothing will be captured into the WIR.

The WIR channel selection definition applies only to instructions defined in Table 108 (WIR[7:0] = 00h to 1Fh). The definition does not apply to vendor specific instructions, and vendors may use bits WIR[12:8] for different purposes.

Table 107 — WIR Channel Selection Definition

WIR[12:8]	Channel Select	WIR[12:8]	Channel Select	WIR[12:8]	Channel Select
00h	Channel a	08h	Channel i	1Ch	8 channel (1 st group)
01h	Channel b	09h	Channel j	1Dh	8 channel (2 nd group)
02h	Channel c	0Ah	Channel k	1Fh	All channels
03h	Channel d	0Bh	Channel l	Xh	Ignored (all channels selected)
04h	Channel e	0Ch	Channel m		
05h	Channel f	0Dh	Channel n		
06h	Channel g	0Eh	Channel o	All others	Reserved
07h	Channel h	0Fh	Channel p		
NOTE1 See the vendor datasheets for the mapping of channels for 1Ch and 1Dh					

13.5 Test Instructions

Test instructions supported by the HBM3 DRAM are listed in Table 108 and subsequently described in detail.

Table 108 — Instruction Register Encodings

WIR [12:8]	WIR [7:0]	Instruction	Description	Register Type	WDR Length
Xh	00h	BYPASS	Bypass	R/W	1
1Fh, 0Fh-00h	01h	EXTEST_RX	Microbump boundary scan Rx test (open/ short)	R	122
1Fh, 0Fh-00h	02h	EXTEST_TX	Microbump boundary scan Tx test (open/ short)	W	122
	03h	RFU			
	04h	RFU			
Xh	05h	HBM_RESET	Functional reset excluding Wrapper Data Registers (WDRs) and any IEEE1500 test port logic or I/Os	W	1
1Fh, 0Fh-00h	06h	MBIST	HBM3 DRAM resident Memory BIST engine test		Vendor specific
0Fh-00h	07h	SOFT_REPAIR	Soft repair of failing memory array bit cell		26
0Fh-00h	08h	HARD_REPAIR	Hard repair of DRAM failing memory array bit cell		26
1Fh, 0Fh-00h	09h	DWORD_MISR	Read back for DWORD MISR and write of a seed value	R/W	320
1Fh, 0Fh-00h	0Ah	AWORD_MISR	Read back for AWORD MISR	R	38
1Fh, 0Fh-00h	0Bh	CHANNEL_ID	All TX I/Os go HIGH (except I/Os in MIDSTACK region)	W	1
	0Ch	RFU			
1Fh, 0Fh-00h	0Dh	AWORD_MISR_CONFIG	Allows IEEE1500 test port access to configure the AWORD MISR test feature	W	8
1Fh, 0Fh-00h	0Eh	DEVICE_ID	Returns the HBM3 DRAM's unique identification code	R	160
Xh	0Fh	TEMPERATURE	Returns a 9-bit binary temperature code	R	9
1Fh, 0Fh-00h	10h	MODE_REGISTER_DUMP_SET	Returns and set the HBM3 DRAM's Mode Register values	R/W	128
1Fh, 0Fh-00h	11h	READ_LFSR_COMPARE_STICKY	Reads the sticky bit error for LFSR Compare feature	R	99
0Fh-00h	12h	SOFT_LANE_REPAIR	Soft Lane Remapping	R/W	40
0Fh-00h	13h	HARD_LANE_REPAIR	Hard Lane Remapping	R/W	40

Table 108 — Instruction Register Encodings (cont'd)

WIR [12:8]	WIR [7:0]	Instruction	Description	Register Type	WDR Length
1Fh, 0Fh-00h	14h	CHANNEL_DISABLE	Disables a channel (All-channel disable is optional)	W	1
1Fh, 0Fh-00h	15h	CHANNEL TEMPERATURE	Returns a 9-bit binary channel temperature code per SID	R	36
Xh	16h	WOSC_RUN	WDQS Interval Oscillator	W	1
Xh	17h	WOSC_COUNT	WDQS Interval Oscillator Count	R	25
0Fh-00h	18h	ECS_ERROR_LOG	Error Check and Scrub (ECS) Error Log Information	R	216
0Fh-00h	19h	HS_REP_CAP	Returns whether banks have repair resources or not	R	256
1Ch, 1Dh ⁴	1Ah	SELF_REP	Self repair	R/W	9
1Ch, 1Dh ⁵	1Bh	SELF_REP_RESULTS	Self repair results	R	8
	1Ch-3Fh	RFU			
Vendor specific	40h-FFh	Vendor specific			
NOTE 1 Unsupported instruction codes will default to the BYPASS instruction when the WIR is updated with the unsupported encoding.					
NOTE 2 Channels that are not selected by WIR[12:8] do not respond to the instruction and ignore any Update, Capture and Shift events.					
NOTE 3 WDRs shift out the least significant bit on the WSO port at the first WRCK of the shift sequence. WSO output timing and valid data window are defined in Table .					
NOTE 4 WIR[12:8] value is 1Ch for enabling self repair on 8 channels and 1Dh for the other 8 channels. The channels associated with 1Ch and 1Dh are vendor specific.					
NOTE 5 WIR[12:8] value is 1Ch for retrieving the self repair results on 8 channels and 1Dh for the other 8 channels. The channels associated with 1Ch and 1Dh are vendor specific.					
NOTE 6 Global test instructions (WIR[12:8] = Xh) drive the same data on the WSO outputs of all active channels during ShiftWR events. Inactive channels (channels that are marked as “not present / not working” in the DEVICE_ID WDR and channels that have been disabled using the CHANNEL_DISABLE instruction) drive a static LOW on their WSO outputs.					

13.5.1 BYPASS

The BYPASS instruction places a single bit WDR between WSI and each channel's WSO. Data is shifted from WSI to WSO through the one bit WDR by WRCK.

BYPASS is the default instruction after asserting WRST_n to LOW.

Wrapper Data Register

When BYPASS is the current instruction, the 1-bit shift register as shown in Table 109 is connected between WSI and WSO[a:p], and the WSO outputs of all active channels drive the same data during ShiftWR events.

CaptureWR

When BYPASS is the current instruction, the CaptureWR event will have no effect.

UpdateWR

When BYPASS is the current instruction, the UpdateWR event will have no effect.

Table 109 — BYPASS Wrapper Data Register

Bit Position	Bit Field	Type	Description
0	BYPASS	-	Single bit bypass shift register per IEEE1500 Standard

13.5.2 EXTEST_RX and EXTEST_TX

EXTEST_RX and EXTEST_TX are both intended for DC I/O connectivity testing similar to board level boundary scan. The receive notation in EXTEST_RX designates that the HBM3 I/O will sample the logic value and capture into the data register the value that is present at the micro bump interface. The transmit notation in EXTEST_TX designates that the HBM3 I/O will drive the logic value shifted into the data register at the micro bump interface. All HBM3 bidirectional I/O, inputs and outputs support both instructions. Differential inputs and outputs (CK_t/CK_c, WDQS_t/WDQS_c and RDQS_t/RDQS_c) also support both instructions on both the true and complement pins.

While EXTEST_RX is the current instruction, all functional pins of the selected channel(s) enter a High-Z state, including the output-only pins AERR, DERR, RDQS_t/RDQS_c, TEMP[1:0] and CATTRIP. See also clause 13.8 Boundary Scan.

I/O signals power up in input mode by default. The host will put all AWORD and DWORD drivers into High-Z state prior to loading the EXTEST_TX instruction into the WIR. As soon as EXTEST_TX becomes the current instruction, all AWORD and DWORD signals will change to output mode and remain in output mode until reset of the test logic or until a different instruction is updated on the channel.

A channel disabled either via the corresponding CHANNEL_AVAILABLE bit in the DEVICE ID WDR or via the CHANNEL_DISABLE instruction will not respond to the EXTEST_TX or EXTEST_RX instructions.

Wrapper Data Register

When EXTEST_RX or EXTEST_TX is the current instruction, the Wrapper Boundary Register (WBR) as shown in Table 110 is connected between WSI and WSO.

CaptureWR

When EXTEST_RX is the current instruction, the CaptureWR event will capture the input values into the shift stage of the WDR. The captured data is shifted out on WSO during a subsequent ShiftWR event. Inputs must be stable for the setup and hold times t_{SEXT} and t_{HEXT} .

When EXTEST_TX is the current instruction, the CaptureWR event will have no effect.

ShiftWR

The Wrapper Boundary Register (WBR) does not provide an update stage. When EXTEST_TX is the current instruction, the value driven on the outputs is directly derived from the WDR's shift stage and will update with each ShiftWR event. The new data will be stable after t_{OVEXT} time.

UpdateWR

When EXTEST_RX or EXTEST_TX is the current instruction, the UpdateWR event will have no effect.

13.5.2 EXTEST_RX and EXTEST_TX (cont'd)

Table 110 — Wrapper Boundary Register (WBR)

Bit Position	Bit Field	Type	Description
121	TEMP0 0	O I	Signals in MIDSTACK region - channel n only - channels a to m, o and p (reserved bit)
120	TEMP1 CATTRIP 0	O O I	Signals in MIDSTACK region - channel n only - channel o only - channels a to m and p (reserved bit)
119	DBI7	I/O	DWORD1 (PC1)
118	DQ63	I/O	
117	DQ62	I/O	
116	DQ61	I/O	
115	DQ60	I/O	
114	RD3	I/O	
113	DERR1	I/O	
112	DQ59	I/O	
111	DQ58	I/O	
110	DQ57	I/O	
109	DQ56	I/O	
108	SEV3	I/O	
107	DBI6	I/O	
106	DQ55	I/O	
105	DQ54	I/O	
104	DQ53	I/O	
103	DQ52	I/O	
102	RDQS1_c	I/O	
101	RDQS1_t	I/O	
100	DQ51	I/O	
99	DQ50	I/O	
98	DQ49	I/O	
97	DQ48	I/O	
96	SEV2	I/O	
95	DBI5	I/O	
94	DQ47	I/O	
93	DQ46	I/O	
92	DQ45	I/O	
91	DQ44	I/O	
90	WDQS1_c	I/O	
89	WDQS1_t	I/O	
88	DQ43	I/O	
87	DQ42	I/O	
86	DQ41	I/O	

Table 110 — Wrapper Boundary Register (WBR) (cont'd)

Bit Position	Bit Field	Type	Description
85	DQ40	I/O	DWORD1 (PC1) (cont'd)
84	ECC3	I/O	
83	DBI4	I/O	
82	DQ39	I/O	
81	DQ38	I/O	
80	DQ37	I/O	
79	DQ36	I/O	
78	RD2	I/O	
77	DPAR1	I/O	
76	DQ35	I/O	
75	DQ34	I/O	
74	DQ33	I/O	
73	DQ32	I/O	
72	ECC2	I/O	
71	AERR	I/O	AWORD
70	R9	I/O	
69	R8	I/O	
68	R7	I/O	
67	R6	I/O	
66	CK_c	I/O	
65	R5	I/O	
64	R4	I/O	
63	R0	I/O	
62	R3	I/O	
61	R2	I/O	
60	R1	I/O	
59	RA	I/O	
58	ARFU	I/O	
57	APAR	I/O	DWORD0 (PC0)
56	C7	I/O	
55	C6	I/O	
54	C5	I/O	
53	CK_t	I/O	
52	C4	I/O	
51	C3	I/O	
50	C2	I/O	
49	C1	I/O	
48	C0	I/O	
47	DBI3	I/O	
46	DQ31	I/O	
45	DQ30	I/O	
44	DQ29	I/O	
43	DQ28	I/O	
42	RD1	I/O	

Table 110 — Wrapper Boundary Register (WBR) (cont'd)

Bit Position	Bit Field	Type	Description
41	DERR0	I/O	DWORD0 (PC0) (cont'd)
40	DQ27	I/O	
39	DQ26	I/O	
38	DQ25	I/O	
37	DQ24	I/O	
36	SEV1	I/O	
35	DBI2	I/O	
34	DQ23	I/O	
33	DQ22	I/O	
32	DQ21	I/O	
31	DQ20	I/O	
30	RDQS0_c	I/O	
29	RDQS0_t	I/O	
28	DQ19	I/O	
27	DQ18	I/O	
26	DQ17	I/O	
25	DQ16	I/O	
24	SEV0	I/O	
23	DBI1	I/O	
22	DQ15	I/O	
21	DQ14	I/O	
20	DQ13	I/O	
19	DQ12	I/O	
18	WDQS0_c	I/O	
17	WDQS0_t	I/O	
16	DQ11	I/O	
15	DQ10	I/O	
14	DQ9	I/O	
13	DQ8	I/O	
12	ECC1	I/O	
11	DBI0	I/O	
10	DQ7	I/O	
9	DQ6	I/O	
8	DQ5	I/O	
7	DQ4	I/O	
6	RD0	I/O	
5	DPAR0	I/O	
4	DQ3	I/O	
3	DQ2	I/O	
2	DQ1	I/O	
1	DQ0	I/O	
0	ECC0	I/O	

13.5.3 HBM_RESET

The HBM_RESET instruction initiates an asynchronous functional reset of the HBM3 DRAM, equivalent to asserting RESET_n to LOW.

The HBM_RESET condition is not self-clearing. Instead, the reset state must explicitly be set and cleared. To accomplish an HBM3 reset, the HBM_RESET bit must be held as 1 for a minimum duration of t_{RES} which equals t_{PW_RESET} (see Initialization Sequence with Stable Power).

It is pointed out that the Wrapper Serial Port (WSP) itself including the associated control logic and WDRs is not reset by the HBM_RESET instruction. The DA port signal pins are also not affected by the HBM_RESET instruction.

Wrapper Data Register

When HBM_RESET is the current instruction, the data register as shown in Table 111 is connected between WSI and WSO[a:p], and the WSO outputs of all active channels drive the same data during ShiftWR events.

CaptureWR

When HBM_RESET is the current instruction, the CaptureWR event will have no effect.

UpdateWR

When HBM_RESET is the current instruction, the UpdateWR event will load the value from the shift stage into the update stage and initiate or clear the functional reset.

Table 111 — HBM_RESET Wrapper Data Register

Bit Position	Bit Field	Type	Description
0	HBM_RESET	W	0 - Clear the functional reset 1 - Initiate the functional reset

Internally, the RESET_n pin and the HBM_RESET instruction are logically combined such that when either is true then the internal reset state is true. During power-up it is required that WRST_n be driven LOW, thus ensuring that the uninitialized IEEE1500 test port logic does not interfere with the power-up initialization sequence.




Figure 101 — RESET_n and HBM_RESET Logic

13.5.3 HBM3_RESET (cont'd)

After the power-up initialization, the RESET_n input is HIGH, and subsequent stable power resets may be asserted by either driving the RESET_n input LOW, or by using the HBM_RESET instruction. Note that the HBM_RESET instruction does not bring the HBM3 DRAM out of reset while the external RESET_n input is driven LOW. Similarly, the HBM3 DRAM cannot be brought out of reset using the RESET_n input while reset is asserted using the HBM_RESET instruction.

Table 112 — RESET_n and HBM_RESET Truth Table

RESET_n	HBM_RESET	Internal Reset State
LOW	0	Reset asserted by RESET_n
LOW	1	Reset asserted by both RESET_n pin and HBM_RESET instruction
HIGH	0	Exit reset state
HIGH	1	Reset asserted by HBM_RESET instruction

13.5.4 MBIST

The MBIST instruction is used for HBM3 DRAM hosted memory built in self-test. HBM devices must support memory MBIST. This instruction format and data register field configuration is required for IEEE Std 1500 access to the test feature. MBIST engine clock source can be WRCK as a direct clock source or reference clock source or an internal clocked mode independent of WRCK and independent of any I/O functional clocks is also acceptable

Wrapper Data Register

When MBIST is the current instruction, the vendor specific data register as shown in Table 113 is connected between WSI and WSO.

CaptureWR

When MBIST is the current instruction, the CaptureWR event will capture R or R/W bit fields into the shift stage of the WDR.

UpdateWR

When MBIST is the current instruction, the UpdateWR event will load the W and R/W bit fields from the shift stage to the update stage of the WDR simultaneously.

Table 113 — MBIST Wrapper Data Register

Bit Position	Bit Field	Type	Description
Vendor specific	Vendor specific		Vendor specific

13.5.5 SOFT_REPAIR

The SOFT_REPAIR instruction allows the user to temporarily repair bit cells in the HBM3 DRAM without using permanent fusing mechanism to initiate the repair. This feature is intended to enable validation that the intended repair works as expected. Once a soft repair is validated, the user may choose to perform a fused hard repair via the HARD_REPAIR instruction. If DRAM power is removed or the DRAM is RESET, the SOFT_REPAIR will revert to the un-repaired state.

Repair resources (redundant rows) are provided per PC and per bank. The actual number of repair resources are vendor specific. The number and availability of repair resources are provided via the HS REP CAP instruction. The use of SOFT_REPAIR will not decrement the HS REP CAP register so the host controller must track the resources used. If there is no repair resource available in a certain bank then the host controller should not issue a SOFT_REPAIR to that bank. However, if a SOFT_REPAIR sequence is issued to a bank with no repair resource available, the DRAM will ignore the programming sequence.

The SOFT_REPAIR granularity indicating the number of repaired rows per SOFT_REPAIR is vendor specific. The address bits associated with the granularity are also vendor specific and indicated in the PPR_RA[15:0] field of the DEVICE_ID WDR. See Table 120 for more details.

The SOFT_REPAIR supports an Undo and Lock function. The SOFT_REPAIR Undo will restore a previously used repair resource back to its unused state and the same time reactivate the original (unrepaired) row instead. The complete address information comprising the PC, SID, bank and row address must be provided with the SOFT_REPAIR instruction as described in Table 114, and the SOFT_REPAIR_UNDO and SOFT_REPAIR_START fields must set to “1”.

The host controller can lock down a used soft repair resource by issuing the SOFT_REPAIR instruction with the SOFT_REPAIR_LOCK and SOFT_REPAIR_START bits as “1”. Each SOFT_REPAIR resource supports the Lock feature. For both UNDO/LOCK cases, the HBM3 DRAM may ignore the row address bit if it so chooses, as the SID, PC, BK are enough to uniquely identify the SOFT_REPAIR resource. The row address may be ignored if there is only single repair resource. If a host issues a SOFT_REPAIR on an already repaired but unlocked row then HBM3 DRAM will allocate another repair resource in response to a host request if an available resource exists. Support for the feature is vendor specific. A locked repair resource cannot be used to replace another row or being set back to the unused state using the Undo function. Only a chip reset (RESET_n pulled LOW) or power-cycling can unlock a locked repair resource.

When using soft repair specifically with the Undo function, the host controller must manage and schedule the refresh operation properly on the valid data of a row address. If a row has been repaired, all refresh commands will exclude the original row from being refreshed and refresh the repair row instead. Similarly, unused repair resources will not be refreshed which includes those resources that had been allocated but were then set back to the unused state using the Undo operation. Especially when switching back and forth between an original and a repair row, regular refresh commands may not hit both rows within the required refresh interval. A possible method to prevent a potential data loss is to explicitly issue ACTIVATE and PRECHARGE commands to the mapped-out rows before and after the SOFT_REPAIR operations.

The SOFT_REPAIR UNDO and LOCK are mutually exclusive. So, in the case of any SOFT_REPAIR instruction issued, the SOFT_REPAIR UNDO and LOCK must not be set “1” at the same time.

A channel must be in bank idle state as long as the SOFT_REPAIR instruction is loaded in the WIR.

13.5.5 SOFT_REPAIR (cont'd)

Wrapper Data Register

When the SOFT_REPAIR instruction is updated the data register as shown in Table 114 is connected between WSI and WSO.

CaptureWR

When SOFT_REPAIR is the current instruction, the CaptureWR event will have no effect.

UpdateWR

When SOFT_REPAIR is the current instruction, the UpdateWR event will load the write only bit field from the shift stage into the update stage simultaneously. Completion of the update event will initiate the soft repair sequence.

Table 114 — SOFT_REPAIR Wrapper Data Register

Bit Position	Bit Field	Type	Description
[25]	SOFT_REPAIR_LOCK	W	0b – SOFT_REPAIR is open 1b – SOFT_REPAIR is hard-locked
[24]	SOFT_REPAIR_UNDO	W	0b – Do SOFT_REPAIR (SOFT_REPAIR enabled) 1b – Undo SOFT_REPAIR (SOFT_REPAIR not enabled)
[23]	SOFT_PC	W	PC
[22:21]	SOFT_SID	W	SID[1:0]
[20:17]	SOFT_BK	W	BA[3:0]
[16:1]	SOFT_ROW	W	RFU, RA[14:0] ¹
[0]	SOFT_REPAIR_START	W	0b – Disabled (Default) 1b – Enabled

NOTE 1 SOFT_ROW includes an additional bit to support future row addressing, i.e., RA15.

13.5.6 HARD_REPAIR

The HARD_REPAIR instruction is used to permanently repair failing bit cells detected in the HBM3 DRAM. A fuse rupture scheme is used to implement the repair. The repair sequence will be initiated on update of the data register. After some vendor specified time period fuse rupture automatically completes and repair is affected. Hard repair will be permanent. Completion of HARD_REPAIR requires a subsequent chip reset (RESET_n pulled LOW) as described in Interaction with Mission Mode Operation. The HBM vendor is required to specify the time to wait after updating the HARD_REPAIR WDR as well as any requirements for WRCK clocking if required to perform the repair.

All channels of the HBM3 DRAM must be in bank idle state as long as the HARD_REPAIR instruction is loaded in the WIR.

Wrapper Data Register

When HARD_REPAIR is the current instruction, the data register as shown in Table 115 is connected between WSI and WSO.

CaptureWR

When HARD_REPAIR is the current instruction, the CaptureWR event will have no effect.

UpdateWR

When HARD_REPAIR is the current instruction, the UpdateWR event will load the write-only bit fields from the shift stage into the update stage and initiate the hard repair sequence. The hard repair is completed after a waiting time of t_{HREP}.

Table 115 — HARD_REPAIR Wrapper Data Register

Bit Position	Bit Field	Type	Description
[25:24]	RESERVED		
[23]	HARD_PC	W	PC
[22:21]	HARD_SID	W	SID[1:0]
[20:17]	HARD_BK	W	BA[3:0]
[16:1]	HARD_ROW	W	RFU, RA[14:0] ¹
[0]	HARD_REPAIR_START	W	0b: Disabled (default) 1b: Enabled

NOTE 1 HARD_ROW includes an additional bit to support future row addressing, i.e., RA15.

13.5.7 DWORD_MISR

This instruction captures and shifts out the DWORD MISR value on the WSO output. The instruction may also be used to preload data for use in LFSR mode. The DWORD MISR is associated with the DWORD IO test feature.

Note that the MISR content is not specified after shifting out the MISR content. The host should reinitialize the MISR before continuing with additional testing, e.g., by using the MISR Preset function in Mode Register 7 (MR7). See clause HBM3 Loopback Test Modes for DWORD MISR mode features and usage.

Wrapper Data Register

When DWORD_MISR is the current instruction, the data register as shown in Table 116 is connected between WSI and WSO. The notation is "..._Q0" to "..._Q3" for the 4 UI per CK clock cycle latched by WDQS in MISR mode or driven along with RDQS in LFSR mode.

CaptureWR

When DWORD_MISR is the current instruction, the CaptureWR event will load the respective MISR values into the shift stage of the WDR. A minimum waiting time of tSMISR between the last data capture into the DWORD MISR and this CaptureWR event must be observed.

UpdateWR

When DWORD_MISR is the current instruction, the UpdateWR event will load the bits from the shift stage of the WDR into the DWORD MISR.

Table 116 — DWORD_MISR Wrapper Data Register

Bit Position	Bit Field	Type	Description
[319:160]	DWORD1	R/W	DWORD1: DQ[63:32], DBI[7:4], ECC[3:2] and SEV[3:2] (Same bit ordering as DWORD0)
[159:120]	DWORD0_BYT3	R/W	Byte 3 of DWORD0: DQ[31:24], DBI3 and SEV1 (Same ordering as Byte 0)
[119:80]	DWORD0_BYT2	R/W	Byte 2 of DWORD0: DQ[23:16], DBI2 and SEV0 (Same ordering as Byte 0)
[79:40]	DWORD0_BYT1	R/W	Byte 1 of DWORD0: DQ[15:8], DBI1 and ECC1 (Same ordering as Byte 0)
39	DWORD0_DBI0_Q0	R/W	Byte 0 of DWORD0
38	DWORD0_DBI0_Q1	R/W	
37	DWORD0_DBI0_Q2	R/W	
36	DWORD0_DBI0_Q3	R/W	
35	DWORD0_DQ7_Q0	R/W	
34	DWORD0_DQ7_Q1	R/W	
33	DWORD0_DQ7_Q2	R/W	

Table 116 — DWORD_MISR Wrapper Data Register (cont'd)

Bit Position	Bit Field	Type	Description
32	DWORD0_DQ7_Q3	R/W	Byte 0 of DWORD0 (cont'd)
31	DWORD0_DQ6_Q0	R/W	
30	DWORD0_DQ6_Q1	R/W	
29	DWORD0_DQ6_Q2	R/W	
28	DWORD0_DQ6_Q3	R/W	
27	DWORD0_DQ5_Q0	R/W	
26	DWORD0_DQ5_Q1	R/W	
25	DWORD0_DQ5_Q2	R/W	
24	DWORD0_DQ5_Q3	R/W	
23	DWORD0_DQ4_Q0	R/W	
22	DWORD0_DQ4_Q1	R/W	
21	DWORD0_DQ4_Q2	R/W	
20	DWORD0_DQ4_Q3	R/W	
19	DWORD0_DQ3_Q0	R/W	
18	DWORD0_DQ3_Q1	R/W	
17	DWORD0_DQ3_Q2	R/W	
16	DWORD0_DQ3_Q3	R/W	
15	DWORD0_DQ2_Q0	R/W	
14	DWORD0_DQ2_Q1	R/W	
13	DWORD0_DQ2_Q2	R/W	
12	DWORD0_DQ2_Q3	R/W	
11	DWORD0_DQ1_Q0	R/W	
10	DWORD0_DQ1_Q1	R/W	
9	DWORD0_DQ1_Q2	R/W	
8	DWORD0_DQ1_Q3	R/W	
7	DWORD0_DQ0_Q0	R/W	
6	DWORD0_DQ0_Q1	R/W	
5	DWORD0_DQ0_Q2	R/W	
4	DWORD0_DQ0_Q3	R/W	
3	DWORD0_ECC0_Q0	R/W	
2	DWORD0_ECC0_Q1	R/W	
1	DWORD0_ECC0_Q2	R/W	
0	DWORD0_ECC0_Q3	R/W	

13.5.8 AWORD_MISR

This instruction captures and shifts out the AWORD MISR value on the WSO output. The MISR in this instruction is associated with the AWORD loopback test feature. The data register bit positions are specified in Table 117.

Note that the content of the MISR is not specified after shifting out the MISR content. The host should reinitialize the MISR using the AWORD_MISR_CONFIG instruction before continuing with additional testing. See HBM3 Loopback test Modes for MISR mode features and usage.

Wrapper Data Register

When AWORD_MISR is the current instruction, the data register as shown in Table 117 is connected between WSI and WSO. The notation is "..._R" for bits latched on the rising CK clock edge and "..._F" for bits latched on the falling CK clock edge.

CaptureWR

When AWORD_MISR is the current instruction, the CaptureWR event will load the respective MISR values into the shift stage of the WDR. A minimum waiting time of tSMISR between the last data capture into the AWORD MISR and this CaptureWR event must be observed.

UpdateWR

When AWORD_MISR is the current instruction, the UpdateWR event will have no effect.

13.5.8 AWORD_MISR (cont'd)

Table 117 – AWORD_MISR Wrapper Data Register

Bit Position	Bit Field	Type	Description
37	R1_R	R	AWORD
36	R1_F	R	
35	R2_R	R	
34	R2_F	R	
33	R3_R	R	
32	R3_F	R	
31	R0_R	R	
30	R0_F	R	
29	R4_R	R	
28	R4_F	R	
27	R5_R	R	
26	R5_F	R	
25	R6_R	R	AWORD (cont'd)
24	R6_F	R	
23	R7_R	R	
22	R7_F	R	
21	R8_R	R	
20	R8_F	R	
19	R9_R	R	
18	R9_F	R	
17	ARFU_R	R	
16	ARFU_F	R	
15	C7_R	R	
14	C7_F	R	
13	C6_R	R	
12	C6_F	R	
11	C5_R	R	
10	C5_F	R	
9	C4_R	R	
8	C4_F	R	
7	C3_R	R	
6	C3_F	R	
5	C2_R	R	
4	C2_F	R	
3	C1_R	R	
2	C1_F	R	
1	C0_R	R	
0	C0_F	R	

13.5.9 CHANNEL_ID

This instruction enables the HBM3 channel identification by driving all bidirectional DWORD I/Os to HIGH, unless a channel is disabled either via the corresponding CHANNEL_AVAILABLE bit in the DEVICE ID WDR or via the CHANNEL_DISABLE instruction. In these cases a channel will not respond to the CHANNEL_ID instruction.

Wrapper Data Register

When CHANNEL_ID is the current instruction, the data register as shown in Table 118 is connected between WSI and WSO.

CaptureWR

When CHANNEL_ID is the current instruction, the CaptureWR event will have no effect.

UpdateWR

When CHANNEL_ID is the current instruction, the UpdateWR event will load the enable bit from the shift stage into the update stage of the WDR. All DWORD bidirectional I/Os (DQ, DBI, RD, ECC/SEV and DPAR) will drive a HIGH latest after t_{OVCHN} when the enable bit is 1, and return to their default state latest after t_{OZCHN} when the enable bit is 0 or a different instruction has been loaded in the WIR. Output pins (RDQS_t/c, DERR) maintain the default state regardless of the CHANNEL_ID instruction. DBI, ECC and DPAR will drive a HIGH even if the respective function is disabled in the Mode Register.

Table 118 — CHANNEL_ID Wrapper Data Register

Bit Position	Bit Field	Type	Description
0	ENABLE	W	0 - TX return to their default state 1 - TX drive a HIGH

13.5.10 AWORD_MISR_CONFIG

This instruction configures the AWORD MISR for subsequent tests. See HBM3 Loopback test Modes for MISR mode features and usage.

Wrapper Data Register

When AWORD_MISR_CONFIG is the current instruction, the data register as shown in Table 119 is connected between WSI and WSO.

CaptureWR

When AWORD_MISR_CONFIG is the current instruction, the CaptureWR event will have no effect.

13.5.10 AWORD_MISR_CONFIG (cont'd)

UpdateWR

When AWORD_MISR_CONFIG is the current instruction, the UpdateWR event will load the configuration bits from the shift stage into the update stage of the WDR and configures the AWORD MISR into the desired mode. The new configuration is valid for subsequent AWORD MISR operation once the t_{CMISR} timing has elapsed.

Table 119 — AWORD_MISR_CONFIG Wrapper Data Register

Bit Position	Bit Field	Type	Description
[7:3]	VENDOR_SPECIFIC	W	00000 - No action (default) All others - Reserved for vendor specific the AWORD MISR Configuration
2	ENABLE	W	0 - Off 1 - On
[1:0]	MODE[1:0]	W	00 - Preset a) The 38-bit AWORD MISR is preset to 0x2AAAAAAAAh; b) the AWORD LFSR_COMPARE_STICKY bits are all cleared to 0; c) the AWORD preamble clock filter circuit is enabled. 01 - LFSR Compare mode 10 - Register mode: AWORD transfers are captured directly to the MISR register. Note that Register mode cannot be used to set an alternate seed value (see Test method for AWORD (Write) Register Mode) 11 - MISR mode

13.5.11 DEVICE_ID

This instruction allows shift out of the DEVICE_ID that provides various information about the HBM3 DRAM including a device specific unique serial number. The per channel ID data registers are intended to support vendors who require additional resolution for identifying the device.

Wrapper Data Register

When the DEVICE_ID instruction is updated the data register as shown in Table 120 is connected between WSI and WSO.

CaptureWR

When DEVICE_ID is the current instruction, the CaptureWR event will load the respective identification field values into the shift stage of the WDR.

UpdateWR

When DEVICE_ID is the current instruction, the UpdateWR event will have no effect.

13.5.11 DEVICE_ID (cont'd)**Table 120 — DEVICE_ID Wrapper Data Register**

Bit Position	Bit Field	Type	Description
[159:155]	OPT_FEATURES[4:0]	R	Reserved to indicate the support of optional features that may be added in a future revision of this standard. 00000 - default
[154]	SHARED_REP_RES	R	Sharing of HS_REP_CAP with self repair 0: Self repair resources are separate from hard/soft resources 1: Self repair resources are shared with hard/soft resources
[153]	PPR_RSVD ²	R	Reserved row addresses associated with a single soft or hard repair. 0 - default
[152:138]	PPR_RA[14:0]	R	Row addresses associated with a single soft or hard repair. Encoding: 0 - row address is evaluated 1 - row address is ignored bit 0: RA0 bit 1: RA1 ... bit 14: RA14
137	RAADEC_C	R	RAA Counter Decrement per REF Command for RFM level C (MR8 OP[5:4] = 11). The field shall be ignored when the ARFM bit is 0 Same encoding as in RAADEC
[136:135]	RAAMMT_C[1:0]	R	RAA Maximum Management Threshold (RAAMMT) for RFM level C (MR8 OP[5:4] = 11). The field shall be ignored when the ARFM bit is 0 Same encoding as in RAAMMT
[134:132]	RAAIMT_C[2:0]	R	RAA Initial Management Threshold (RAAIMT) for RFM level C (MR8 OP[5:4] = 11) The field shall be ignored when the ARFM bit is 0. Same encoding as in RAAIMT
131	RAADEC_B	R	RAA Counter Decrement per REF Command for RFM level B (MR8 OP[5:4] = 10). The field shall be ignored when the ARFM bit is 0 Same encoding as in RAADEC
[130:129]	RAAMMT_B[1:0]	R	RAA Maximum Management Threshold (RAAMMT) for RFM level B (MR8 OP[5:4] = 10). The field shall be ignored when the ARFM bit is 0 Same encoding as in RAAMMT
[128:126]	RAAIMT_B[2:0]	R	RAA Initial Management Threshold (RAAIMT) for RFM level B (MR8 OP[5:4] = 10). The field shall be ignored when the ARFM bit is 0 Same encoding as in RAAIMT

Table 120 — DEVICE_ID Wrapper Data Register (cont'd)

Bit Position	Bit Field	Type	Description
125	RAADEC_A	R	RAA Counter Decrement per REF Command for RFM level A (MR8 OP[5:4] = 01). The field shall be ignored when the ARFM bit is 0 Same encoding as in RAADEC
[124:123]	RAAMMT_A[1:0]	R	RAA Maximum Management Threshold (RAAMMT) for RFM level A (MR8 OP[5:4] = 01). The field shall be ignored when the ARFM bit is 0 Same encoding as in RAAMMT
[122:120]	RAAIMT_A[2:0]	R	RAA Initial Management Threshold (RAAIMT) for RFM level A (MR8 OP[5:4] = 01). The field shall be ignored when the ARFM bit is 0 Same encoding as in RAAIMT
119	RAADEC	R	Default RAA Counter Decrement per REF Command. The field shall be ignored when the RFM bit is 0. 0 - $1.0 \times$ RAAIMT 1 - $0.5 \times$ RAAIMT
[118:117]	RAAMMT[1:0]	R	Default RAA Maximum Management Threshold (RAAMMT) The field shall be ignored when the RFM bit is 0. 00 - $3 \times$ RAAIMT 01 - $4 \times$ RAAIMT 10 - $5 \times$ RAAIMT 11 - $6 \times$ RAAIMT
[116:114]	RAAIMT[2:0]	R	Default RAA Initial Management Threshold (RAAIMT) The field shall be ignored when the RFM bit is 0. 000 - 32 001 - 40 010 - 48 011 - 56 100 - 64 101 - 72 110 - 80 111 - Reserved
113	ARFM	R	Adaptive Refresh Management (ARFM) 0 – Adaptive Refresh Management is not supported 1 – Adaptive Refresh Management is supported
112	RFM	R	Refresh Management (RFM) 0 - Refresh Management not required 1 - Refresh Management required
[111:104]	MANUFACTURING_YEAR[7:0]	R	Binary encoded year: 2020 = 00000000; 2024 = 00000100
[103:96]	MANUFACTURING_WEEK[7:0]	R	Binary encoded week: WW52 = 00110100

Table 120 — DEVICE_ID Wrapper Data Register (cont'd)

Bit Position	Bit Field	Type	Description
[95:32]	SERIAL_NO[63:0]	R	Unique device ID
[31:28]	MANUFACTURER_ID[3:0]	R	0001 - Samsung 0110 - SK Hynix 1100 - CXMT 1111 - Micron All others - Reserved
[27:24]	DENSITY[3:0]	R	Memory density per channel (see HBM3 Channel Addressing) 0000 - 2 Gb 0001 - 4 Gb (8 Gb 8-High) 0010 - 6 Gb (8 Gb 12-High) 0011 - 8 Gb (8 Gb 16-High) 0100 - 4 Gb 0101 - 8 Gb (16 Gb 8-High) 0110 - 12 Gb (16 Gb 12-High) 0111 - 16 Gb (16 Gb 16-High) 1000 - 6 Gb 1001 - 12 Gb (24 Gb 8-High) 1010 - 18 Gb (24 Gb 12-High) 1011 - 24 Gb (24 Gb 16-High) 1100 - 8 Gb 1101 - 16 Gb (32 Gb 8-High) 1110 - 24 Gb (32 Gb 12-High) 1111 - 32 Gb (32 Gb 16-High)
[23:8]	CHANNEL_AVAILABLE[15:0] ¹	R	Channel Available 0 - Channel not present / not working 1 - Channel present / working Channel encoding (1 bit per channel): bit 8: channel a bit 9: channel b ... bit 22: channel o bit 23: channel p
[7:0]	MODEL_PART_NUMBER[7:0]	R	Vendor reserved
NOTE 1 A channel marked as “not present / not working” keeps all AWORD and DWORD input and output buffers permanently disabled and drives that channel’s WSO to LOW.			
NOTE 2 The PPR_RVSD field will only be used in the future if additions to the addressing table increase the row address to include RA15. If future additions to the addressing table increase the bank, column, or pseudo channel address then the PPR_RSVD will remain at the default.			
NOTE 3 HBM3 devices must output bits [159:155] even if the optional features are not used.			

13.5.12 TEMPERATURE

This instruction captures the HBM3 DRAM's junction temperature. Temperature reporting is specified as a 9-bit field: bit 0 or LSB indicates the validity of the temperature sensor read-out, and the remaining 8 bits indicate the temperature in degrees Celsius.

Wrapper Data Register

When TEMPERATURE is the current instruction, the data register as shown in Table 121 is connected between WSI and WSO[a:p], and the WSO outputs of all active channels drive the same data during ShiftWR events.

CaptureWR

When TEMPERATURE is the current instruction, the CaptureWR event will load the temperature field values into the shift stage of the WDR.

UpdateWR

When TEMPERATURE is the current instruction, the UpdateWR event will have no effect.

Table 121 — TEMPERATURE Wrapper Data Register

Bit Position	Bit Field	Type	Description
[8:1]	TEMP[7:0]	R	Temperature in degrees Celsius. Examples: 8'b 0000 0000 = -40 °C 8'b 0010 1000 = 0 °C 8'b 0100 0001 = 25 °C 8'b 1010 0111 = 127 °C
[0]	VALID	R	Temperature sensor output valid 0 – Invalid 1 – Valid

13.5.13 MODE_REGISTER_DUMP_SET

The MODE_REGISTER_DUMP_SET instruction provides read (dump) and write (set) access to the HBM3 Mode Registers.

Wrapper Data Register

When MODE_REGISTER_DUMP_SET is the current instruction, the data register as shown in Table 122 is connected between WSI and WSO.

CaptureWR

When MODE_REGISTER_DUMP_SET is the current instruction, the CaptureWR event will capture the Mode Register content into the shift stage of the WDR. Reserved Mode Registers and bit fields marked as “RFU” capture an ‘X’ value. The Mode Register content itself does not change with the CaptureWR event. A minimum waiting time of $t_{MRSS} = t_{MOD}$ must be observed between an MRS command and this Capture WR event.

UpdateWR

When MODE_REGISTER_DUMP_SET is the current instruction, the UpdateWR event will simultaneously load the bits from the shift stage to the mode registers. The updated mode register content will be valid for subsequent mission mode operation after t_{UPDMRS} .

Table 122 — MODE_REGISTER_DUMP_SET Wrapper Data Register

Bit Position	Bit Field	Type	Description
[127:120]	MR15	R/W	MR15[7:0]
[119:112]	MR14	R/W	MR14[7:0]
[111:104]	MR13	R/W	MR13[7:0]
[103:96]	MR12	R/W	MR12[7:0]
[95:88]	MR11	R/W	MR11[7:0]
[87:80]	MR10	R/W	MR10[7:0]
[79:72]	MR9	R/W	MR9[7:0]
[71:64]	MR8	R/W	MR8[7:0]
[63:56]	MR7	R/W	MR7[7:0]
[55:48]	MR6	R/W	MR6[7:0]
[47:40]	MR5	R/W	MR5[7:0]
[39:32]	MR4	R/W	MR4[7:0]
[31:24]	MR3	R/W	MR3[7:0]
[23:16]	MR2	R/W	MR2[7:0]
[15:8]	MR1	R/W	MR1[7:0]
[7:0]	MR0	R/W	MR0[7:0]

13.5.14 READ_LFSR_COMPARE_STICKY

This instruction is used to capture the LFSR Compare Sticky error data to be shifted out on the WSO output. The instruction is associated with the AWORD and DWORD I/O loopback test features. Data register bit positions are specified in the Data Register clause of this instruction in Table 123. Note that the content of the MISR and LFSR Compare Sticky error data registers is not specified after shifting out the sticky error content. The host should reinitialize the MISR registers (such as with MR7 Preset and AWORD_MISR_CONFIG preset) before continuing with additional testing. See clause HBM3 Loopback Test Modes for MISR mode features and usage.

While both the AWORD and DWORD sticky error bits share a common WDR, the bits are set and cleared only by their respective AWORD or DWORD Preset and LFSR Compare operations. For example, an AWORD_MISR_CONFIG preset operation clears the AWORD sticky error bits, and the state of the DWORD sticky error bits is undefined; therefore, the host should ignore the DWORD sticky error bits when operating the AWORD LFSR Compare mode. Conversely, the DWORD_MISR_CONFIG preset operation clears the DWORD sticky error bits, and the state of the AWORD sticky error bits is undefined; therefore, the host should ignore the AWORD sticky error bits when operating the DWORD LFSR Compare mode.

Wrapper Data Register

When READ_LFSR_COMPARE_STICKY is the current instruction, the data register as shown in Table 123 is connected between WSI and WSO.

CaptureWR

When READ_LFSR_COMPARE_STICKY is the current instruction, the CaptureWR event will load the sticky error values into the shift stage of the WDR.

UpdateWR

When READ_LFSR_COMPARE_STICKY is the current instruction, the UpdateWR event will have no effect.

13.5.14 READ_LFSR_COMPARE_STICKY (cont'd)**Table 123 — READ_LFSR_COMPARE_STICKY Wrapper Data Register**

Bit Position	Bit Field	Type	Description
[98:59]	DWORD1	R	DWORD1: DQ[63:32], DBI[7:4], ECC[3:2] and SEV[3:2] (same ordering as DWORD0)
58	AWORD_R1	R	AWORD
57	AWORD_R2	R	
56	AWORD_R3	R	
55	AWORD_R0	R	
54	AWORD_R4	R	
53	AWORD_R5	R	
52	AWORD_R6	R	
51	AWORD_R7	R	
50	AWORD_R8	R	
49	AWORD_R9	R	AWORD
48	AWORD_ARFU	R	
47	AWORD_C7	R	
46	AWORD_C6	R	
45	AWORD_C5	R	
44	AWORD_C4	R	
43	AWORD_C3	R	
42	AWORD_C2	R	
41	AWORD_C1	R	
40	AWORD_C0	R	
[39:30]	DWORD0_BYT3	R	Byte 3 of DWORD0: DQ[31:24], DBI3 and SEV1 (same ordering as Byte 0)
[29:20]	DWORD0_BYT2	R	Byte 2 of DWORD0: DQ[23:16], DBI2 and SEV0 (same ordering as Byte 0)
[19:10]	DWORD0_BYT1	R	Byte 1 of DWORD0: DQ[15:8], DBI1 and ECC1 (same ordering as Byte 0)
9	DWORD0_DBIO	R	Byte 0 of DWORD0 (PC0)
8	DWORD0_DQ7	R	
7	DWORD0_DQ6	R	
6	DWORD0_DQ5	R	
5	DWORD0_DQ4	R	
4	DWORD0_DQ3	R	
3	DWORD0_DQ2	R	
2	DWORD0_DQ1	R	
1	DWORD0_DQ0	R	
0	DWORD0_ECC0	R	

13.5.15 SOFT_LANE_REPAIR and HARD_LANE_REPAIR

SOFT_LANE_REPAIR and HARD_LANE_REPAIR instructions can only be issued as part of the device initialization and before normal memory operation has commenced, e.g., before the CK clock has started to toggle.

Wrapper Data Register

When either SOFT_LANE_REPAIR or HARD_LANE_REPAIR is the current instruction, the LANE_REPAIR wrapper data register as shown in Table 124 is connected between WSI and WSO.

Figure 102 illustrates the interaction between SOFT_LANE_REPAIR and HARD_LANE_REPAIR instructions and the associated registers. It is pointed out that the actual I/O lane remapping is derived from the content of the lane repair shadow register.

CaptureWR

When either SOFT_LANE_REPAIR or HARD_LANE_REPAIR is the current instruction, the CaptureWR event will load the lane remapping data from the lane repair shadow register into the shift stage of the WDR. This internal lane repair shadow register is pre-loaded with the repair data from a preceding HARD_LANE_REPAIR operation upon HBM3 DRAM initialization (RESET_n pulled Low). The memory controller may use these data to configure the lane repair accordingly at the host; it may also use these data as a seed value for subsequent lane repair operations.

UpdateWR

When SOFT_LANE_REPAIR is the current instruction, the UpdateWR event will load the lane remapping data from the shift stage of the WDR into the lane repair shadow register and force the I/O lanes to be remapped accordingly. This remapping is non-persistent; it will be lost when RESET_n is pulled low or the device loses power. Pulling WRST_n low does not reset the lane repair shadow register.

When HARD_LANE_REPAIR is the current instruction, the UpdateWR event will load the lane remapping data from the shift stage of the WDR into the hard lane repair register. The controller must wait t_{HLREP} to allow the HBM3 DRAM to complete this operation and permanently store the repair vector.

Only a single broken lane can be repaired at a time, in order to limit the current constraint of the associated circuits. If multiple lanes are to be repaired, it is required to shift in the repair vectors for each broken lane sequentially, with all other lane repair setting = Fh, and initiate each actual lane repair with a separate UpdateWR event.

The UpdateWR event itself does not lead to an actual re-mapping of the I/O lanes. For such re-mapping to get effective it is required to initiate a chip reset by pulling RESET_n LOW for at least t_{PW_RESET} , which copies the repair vector from the hard lane repair register into the lane repair shadow register as shown in Figure 102.

13.5.15 SOFT_LANE_REPAIR and HARD_LANE_REPAIR (cont'd)**Table 124 — LANE_REPAIR Wrapper Data Register**

Bit Position	Bit Field	Type	Description
[39:36]	DWORD1_BYT3[3:0]	R/W	Lane remapping applied to DWORD1 byte 3 0h: SEV3 1h - 8h: DQ56 - DQ63 9h: DBI7 Ah - Eh: Reserved Fh: No lane remapping (default)
[35:32]	DWORD1_BYT2[3:0]	R/W	Lane remapping applied to DWORD1 byte 2 0h: SEV2 1h - 8h: DQ48 - DQ55 9h: DBI6 Ah - Eh: Reserved Fh: No lane remapping (default)
[31:28]	DWORD1_BYT1[3:0]	R/W	Lane remapping applied to DWORD1 byte 1 0h: ECC3 1h - 8h: DQ40 - DQ47 9h: DBI5 Ah - Eh: Reserved Fh: No lane remapping (default)
[27:24]	DWORD1_BYT0[3:0]	R/W	Lane remapping applied to DWORD1 byte 0 0h: ECC2 1h - 8h: DQ32 - DQ39 9h: DBI4 Ah - Eh: Reserved Fh: No lane remapping (default)
[23:20]	AWORD_RA[3:0]	R/W	Lane remapping applied to AWORD. 0h – 9h: R0 – R9 Ah – Eh: Reserved Fh: No lane remapping (default)
[19:16]	AWORD_CA[3:0]	R/W	Lane remapping applied to AWORD. 0h – 7h: C0 – C7 8h: APAR 9h: ARFU Ah – Eh: Reserved Fh: No lane remapping (default)
[15:12]	DWORD0_BYT3[3:0]	R/W	Lane remapping applied to DWORD 0 byte 3 0h: SEV1 1h – 8h: DQ24 – DQ31 9h: DBI3 Ah – Eh: Reserved Fh: No lane remapping (default)

Table 124 — LANE REPAIR Wrapper Data Register (cont'd)

Bit Position	Bit Field	Type	Description
[11:8]	DWORD0_BYT2[3:0]	R/W	Lane remapping applied to DWORD0 byte 2 0h: SEV0 1h - 8h: DQ16 - DQ23 9h: DBI2 Ah - Eh: Reserved Fh: No lane remapping (default)
[7:4]	DWORD0_BYT1[3:0]	R/W	Lane remapping applied to DWORD0 byte 1 0h: ECC1 1h - 8h: DQ8 - DQ15 9h: DBI1 Ah - Eh: Reserved Fh: No lane remapping (default)
[3:0]	DWORD0_BYT0[3:0]	R/W	Lane remapping applied to DWORD0 byte 0 0h: ECC0 1h - 8h: DQ0 - DQ7 9h: DBI0 Ah - Eh: Reserved Fh: No lane remapping (default)




Figure 102 — Registers Associated with Lane Repair Instructions

13.5.16 CHANNEL_DISABLE

This instruction disables one channel or all channels specified in WIR[12:8]. The instruction may only be issued after tINIT3 timing has been met and only before the CK clock is started for the first time. The disabled channel will transition into a safe low-power state where they do not respond to commands. All AWORD and DWORD input and output buffers will be turned off, thus allowing all external signals to float. It will also not respond to EXTEST_RX, EXTEST_TX, and CHANNEL_ID instructions. Both RESET_n and WRST_n must be maintained HIGH during the all-channel disable state. The channel's WSO output will remain active and drive a LOW.

The all-channel disable option shall be used during host-side HTOL and/or other reliability tests to prevent unintentional degradation of the HBM3 DRAM. This option may only be issued after tINIT3 timing has been met, before the CK clock is started for the first time after exit from reset state and only if no other IEEE1500 instruction other than BYPASS or DEVICE_ID has been loaded before.

A disabled channel can be enabled again by pulling both RESET_n and WRST_n to LOW and following the procedure described in the Initialization Sequence with Stable Power clause.

Wrapper Data Register

When CHANNEL_DISABLE is the current instruction, the data register as shown in Figure 103 — Channel Disable Instruction. Table 125 is connected between WSI and WSO.

CaptureWR

When CHANNEL_DISABLE is the current instruction, the CaptureWR event will have no effect.

UpdateWR

When CHANNEL_DISABLE is the current instruction, the UpdateWR event will load the disable bit from the shift stage into the update stage of the WDR and asynchronously transition into a safe low power state when the bit is 1. Input and output buffers will be disabled latest after tCHDIS.




Figure 103 — Channel Disable Instruction

13.5.16 CHANNEL_DISABLE (cont'd)

Table 125 — CHANNEL_DISABLE Wrapper Data Register

Bit Position	Bit Field	Type	Description
0	CH_DIS	W	0 – Channel is enabled (default). Clearing the bit to 0 does not re-enable a channel. 1 – Channel is disabled

13.5.17 CHANNEL TEMPERATURE

This instruction captures the channel's junction temperature. Temperature reporting is specified as a 9-bit field per SID: the LSB indicates the validity of the temperature sensor read-out, and the remaining 8 bits indicate the temperature in degrees Celsius.

Wrapper Data Register

When CHANNEL_TEMPERATURE is the current instruction, the data register as shown in Table 126 is connected between WSI and WSO.

CaptureWR

When CHANNEL_TEMPERATURE is the current instruction, the CaptureWR event load the temperature field values into the shift stage of the WDR.

UpdateWR

When CHANNEL TEMPERATURE is the current instruction, the UpdateWR event will have no effect.

13.5.17 CHANNEL TEMPERATURE (cont'd)**Table 126 — CHANNEL_TEMPERATURE Wrapper Data Register**

Bit Position	Bit Field	Type	Description
[35:28]	CHANNEL_SID3_TEMP[7:0]	R	Maximum temperature per channel for SID3 in Degrees Celsius. Same encoding as in CHANNEL_SID0_TEMP[7:0]
27	CHANNEL_SID3_VALID	R	Channel Temperature sensor output valid for SID3 0 – Invalid 1 – Valid
[26:19]	CHANNEL_SID2_TEMP[7:0]	R	Maximum temperature per channel for SID2 in Degrees Celsius. Same encoding as in CHANNEL_SID0_TEMP[7:0]
18	CHANNEL_SID2_VALID	R	Channel Temperature sensor output valid for SID2 0 – Invalid 1 – Valid
[17:10]	CHANNEL_SID1_TEMP[7:0]	R	Maximum temperature per channel for SID1 in Degrees Celsius. Same encoding as in CHANNEL_SID0_TEMP[7:0]
9	CHANNEL_SID1_VALID	R	Channel Temperature sensor output valid for SID1 0 – Invalid 1 – Valid
[8:1]	CHANNEL_SID0_TEMP[7:0]	R	Maximum temperature per channel for SID0 in Degree Celsius. Examples: 8'b 0000 0000 = -40 °C 8'b 0010 1000 = 0 °C 8'b 0100 0001 = 25 °C 8'b 1010 0111 = 127 °C
0	CHANNEL_SID0_VALID	R	Channel Temperature sensor output valid for SID0 0 – Invalid 1 – Valid

NOTE 1 For unsupported SID fields the HBM3 DRAM will report the sensor output as invalid and the temperature as all zeros.

NOTE 2 Device may report the same maximum temperature value for all the channels within the same core-die or individual channel temperatures based on number of unique temperature sensors (Figure 104)

NOTE 3 If a channel is distributed across multiple dies (within the same SID), as shown in Figure 105, the device reports the maximum channel temperature value between the core-dies across which the channel is distributed

13.5.17 CHANNEL TEMPERATURE (cont'd)




Figure 104 — Example Channel Configuration 1




Figure 105 — Example Channel Configuration 2

13.5.18 WOSC_RUN and WOSC_COUNT

The WOSC_RUN and WOSC_COUNT instructions are associated with the WDQS Interval Oscillator in the HBM3 DRAM.

Wrapper Data Register

When WOSC_RUN is the current instruction, the WOSC_RUN wrapper data register as shown in Table 127 is connected between WSI and WSO[a:p], and the WSO outputs of all active channels drive the same data during ShiftWR events.

When WOSC_COUNT is the current instruction, the WOSC_COUNT wrapper data register as shown in Table 128 is connected between WSI and WSO[a:p], and the WSO outputs of all active channels drive the same data during ShiftWR events.

CaptureWR

When WOSC_RUN is the current instruction, the CaptureWR event will have no effect.

When WOSC_COUNT is the current instruction, the CaptureWR event will load the WDQS oscillator count value into the shift stage of the WDR and update the WOSC_COUNT_VALID field of the WDR.

UpdateWR

When WOSC_RUN is the current instruction, the UpdateWR event will load the value from the shift stage into the update stage and start or stop the WDQS Interval Oscillator.

When WOSC_COUNT is the current instruction, the UpdateWR event will have no effect.

Table 127 — WOSC_RUN Wrapper Data Register

Bit Position	Bit Field	Type	Description
0	WOSC_START_STOP	W	0 – Stop WDQS Interval Oscillator (default) 1 – Start WDQS Interval Oscillator

Table 128 — WOSC_COUNT Wrapper Data Register

Bit Position	Bit Field	Type	Description
[24:1]	WOSC_COUNT_VALUE	R	Oscillator count value. Range 0 to $2^{24}-1$
[0]	WOSC_COUNT_VALID	R	0 – Count is invalid (default) 1 – Count is valid

NOTE 1 The WDQS oscillator count value is used to train WDQS to the data valid window. The value reported in this WDR can be used by the memory controller to periodically adjust the phase of WDQS relative to data.

NOTE 2 The contents of bits [23:0] is reset by starting the oscillator.

13.5.19 ECS Error Log

This instruction is used to capture ECS Error Log information reading from the WDR. The registers in this instruction are associated with the Error type and Error address(position) as the ECS operation result during ECS period. The error types are NE, CE_S, CE_M, UE. The encoding of error types is the same as burst position 4~7 of severity transmission in Table 59. See clause of Error Check and Scrub(ECS). HBM3 device will store detailed information about errors detected during ECS operation period. The latest logging information will follow priority update rule in the following order such as UE, CE_M, CE_S, NE of Table 57. In case of CE_S, error information would be logged in HBM3 for host-polling when #ERRECS during current or previous ECS period is larger than the #ERRTH, where the #ERRECS means accumulated the number of errors events detected during previous ECS period, not the number of error bits. At this time the error address will be logged and readout through IEEE1500 WSO. The registers logged ECS error information will be cleared by host.

Wrapper Data Register

When the ECS Error Log instruction is updated the data register as shown in Table 129 is connected between WSI and WSO.

CaptureWR

When ECS Error Log is the current instruction, the CaptureWR event will load the respective error log field values into the shift stage of the WDR.

UpdateWR

When ECS Error Log is the current instruction, the UpdateWR event will have no effect.

13.5.19 ECS Error Log (cont'd)**Table 129 — ECS Error Log Wrapper Data Register**

Bit Position	Bit Field	Type	Description
[215:190]	SID3_PC1_ECS[25:0]	R	ECS error log for SID3, PC1 Same encoding as in SID0_PC0_ECS
189	SID3_PC1_ECS_VALID	R	ECS error log valid of SID3, PC1 Same encoding as in SID0_PC0_ECS_VALID
[188:163]	SID3_PC0_ECS[25:0]	R	ECS error log for SID3, PC0 Same encoding as in SID0_PC0_ECS
162	SID3_PC0_ECS_VALID	R	ECS error log valid of SID3, PC0 Same encoding as in SID0_PC0_ECS_VALID
[161:136]	SID2_PC1_ECS[25:0]	R	ECS error log for SID2, PC1 Same encoding as in SID0_PC0_ECS
135	SID2_PC1_ECS_VALID	R	ECS error log valid of SID2, PC1 Same encoding as in SID0_PC0_ECS_VALID
[134:109]	SID2_PC0_ECS[25:0]	R	ECS error log for SID2, PC0 Same encoding as in SID0_PC0_ECS
108	SID2_PC0_ECS_VALID	R	ECS error log valid of SID2, PC0 Same encoding as in SID0_PC0_ECS_VALID
[107:82]	SID1_PC1_ECS[25:0]	R	ECS error log for SID1, PC1 Same encoding as in SID0_PC0_ECS
81	SID1_PC1_ECS_VALID	R	ECS error log valid of SID1, PC1 Same encoding as in SID0_PC0_ECS_VALID
[80:55]	SID1_PC0_ECS[25:0]	R	ECS error log for SID1, PC0 Same encoding as in SID0_PC0_ECS
54	SID1_PC0_ECS_VALID	R	ECS error log valid of SID1, PC0 Same encoding as in SID0_PC0_ECS_VALID
[53:28]	SID0_PC1_ECS[25:0]	R	ECS error log for SID0, PC1 Same encoding as in SID0_PC0_ECS
27	SID0_PC1_ECS_VALID	R	ECS error log valid of SID0, PC1 Same encoding as in SID0_PC0_ECS_VALID
[26:1]	SID0_PC0_ECS[25:0]	R	ECS error log for SID0, PC0 [25:22] – Bank address BA[3:0] [21:7] – Row address RA[14:0] [6:2] – Column address CA[4:0] [1:0] – Error Type[1:0] 00b: NE 01b: CEs 10b: UE 11b: CEm
0	SID0_PC0_ECS_VALID	R	ECS error log valid for SID0, PC0 0 – Invalid (default) 1 – Valid

13.5.20 HS REP CAP

The HS REP CAP instruction tells the host whether a bank(s) has resources for either hard repair or soft repair. For each bank of the DRAM, the Gray-coded encoding indicates whether there are no resources, 1 resource or 2 or more resources.

This instruction shall be used by the host before performing any hard or soft repair. This register will be updated with the completion of a hard repair only. The DRAM may also share resources with self repair. In this case the completion of self repair will also update this register. The sharing of resources between hard/soft repair and self repair is vendor specific and identified in the SHARED REP RES field of the DEVICE_ID.

Wrapper Data Register

When HS REP CAP is the current instruction, the wrapper data register as shown in Table 130 is connected between WSI and WSO.

CaptureWR

When HS REP CAP is the current instruction, the CaptureWR event will load the resource field value into the shift stage register.

UpdateWR

When HS REP CAP is the current instruction, the UpdateWR event will have no effect.

Table 130 — HS REP CAP Wrapper Data Register

Bit Position	Bit Field	Type	Description
[255:192]	HS_REPAIR_RES_SID3	R	SID3 PC0 Banks [15:0] and PC1 Banks [15:0]
[191:128]	HS_REPAIR_RES_SID2	R	SID2 PC0 Banks [15:0] and PC1 Banks [15:0]
[127:64]	HS_REPAIR_RES_SID1	R	SID1 PC0 Banks [15:0] and PC1 Banks [15:0]
[63:32]	HS_REPAIR_RES_SID0	R	SID0 PC1 Banks [15:0]
[31:2]			SID0 PC0 Banks [15:1]
[1:0]			Resources available for SID0 PC0 Bank 0 00b: No resource available 01b: 1 resource 10b: Reserved 11b: 2 or more resources

13.5.21 SELF_REP and SELF_REP_RESULTS

The SELF_REP and SELF_REP_RESULTS instructions are associated with HBM3 self repair.

Wrapper Data Register

When SELF_REP is the current instruction, the SELF_REP wrapper data register as shown in Table 131 is connected between WSI and WSO.

When SELF_REP_RESULTS is the current instruction, the SELF_REP_RESULTS wrapper data register as shown in Table 132 is connected between WSI and WSO.

CaptureWR

When SELF_REP is the current instruction, the CaptureWR event will capture the SR_PROGRESS to the shift stage register.

When SELF_REP_RESULTS is the current instruction, the CaptureWR event will capture the SID[3:0]_RESULTS to the shift stage register.

UpdateWR

When SELF_REP is the current instruction, the UpdateWR event will copy the SELFR_REF_RATE, SID-SELECT and REP_TYPE into the update stage register.

When SELF_REP_RESULTS is the current instruction, the UpdateWR event will have no effect.

13.5.21 SELF_REP and SELF_REP_RESULTS (cont'd)

Table 131 — SELF_REP Wrapper Data Register

Bit Position	Bit Field	Type	Description
[8]	SHARED_OVERRIDE ²	W	0b: DRAM must leave 1 resource when resources shared (default) 1b: DRAM can use all resources for Self-repair when shared
[7:6]	SELFR REP RATE	W	00b: 1 x tREFI 01b: 0.5 x tREFI 10b: 0.25 x tREFI 11b: Reserved
[5:4]	SID_SELECT	W	00b: SID0 01b: SID1 10b: SID2 11b: SID3
[3:2]	REP_TYPE	W	11b: Run self-test and auto-repair 10b: Auto-repair only 01b: Run self-test only and no auto-repair 00b: Disabled/Cancel1
[1:0]	SR_PROGRESS	R	00b: Not running (default) 01b: Self-test in progress 10b: Auto-repair in progress 11b: Complete
NOTE 1 Cancel will only stop the SELF_REPAIR when the self-test is in progress (SR_PROGRESS = 01b) and SR_PROGRESS is set to 00b (not running) after cancel.			
NOTE 2 When resources are shared between self and hard/soft repair the SHARED_OVERRIDE field allows the DRAM to use all the resources for self repair. When the resources are not shared the field is do not care.			

Table 132 — SELF_REP_RESULTS Wrapper Data Register

Bit Position	Bit Field	Type	Description
[7:6]	SID3_RESULTS	R	SID3 SELF_REP results
[5:4]	SID2_RESULTS	R	SID2 SELF_REP results
[3:2]	SID1_RESULTS	R	SID1 SELF_REP results
[1:0]	SID0_RESULTS	R	SID0 SELF_REP results 00b: SELF_REP test has not run since INIT or No fails remain after most recent run 01b: Fail(s) remain 10b: Unrepairable fail(s) remain 11b: SELF_REP should be run again
NOTE 1 For unsupported SID fields, the DRAM will report the results as 00b (SELF-REPAIR test has not run).			
NOTE 2 DRAM may report the same SELF_REP_RESULTS value for up to 8 channels as selected by WIR[12:8]=1Ch or 1Dh, or individual results.			

13.6 Interaction with Mission Mode Operation

Table 133 defines the interaction of the various IEEE1500 instructions with mission mode operation, and any instruction exit requirements (see also Table 108 for all IEEE1500 instructions).

Table 133 — IEEE1500 Port Instruction Interactions

Instruction	Interaction with Mission Mode	Post Instruction Requirements
BYPASS DWORD_MISR ¹ AWORD_MISR ¹ READ_LFSR_COMPARE_STICKY ¹ DEVICE_ID TEMPERATURE MODE_REGISTER_DUMP_SET (dump) CHANNEL_TEMPERATURE WOSC_RUN WOSC_COUNT ECS_ERROR_LOG SELF REP_RESULTS HS REP_CAP	Instructions may be used at any time. Core memory content is retained if refresh specifications are met.	None
SOFT_REPAIR ^{2,5} SOFT_LANE_REPAIR ² MODE_REGISTER_DUMP_SET (set) AWORD_MISR_CONFIG ³	Core memory content is retained if refresh specifications are met.	Meet IEEE1500 Port AC Timings (see Table)
EXTTEST_RX, EXTEST_TX MBIST CHANNEL_ID HARD_REPAIR ⁴ HARD_LANE_REPAIR ⁴ CHANNEL_DISABLE ⁶ SELF REP ⁴	HBM3 interface state and core memory content are not defined.	Reset
NOTE 1 While accessing these MISR-related registers has no interaction with mission mode, operating the AWORD and DWORD MISR modes may result in memory content loss unless the channel is put into self refresh mode. See HBM3 Loopback Test Modes.		
NOTE 2 Soft memory array and lane repairs imply that memory content is at least partially incorrect. While the HBM3 DRAM imposes no restrictions on the interface state and memory content, the host should consider the health of the memory content based on the repair(s) being applied.		
NOTE 3 See HBM3 Loopback Test Modes for proper sequencing of the AWORD MISR test modes.		
NOTE 4 Self/Hard memory array and hard lane repairs involve blowing fuses. Normal operation on any channel is not supported when the self/hard repair operations are used. A chip reset with RESET_n pulled LOW is required after self/hard repair operations before returning the HBM3 DRAM to normal operation.		
NOTE 5 For SOFT_REPAIR it is required that the channel is held in bank idle state from the time when the SOFT_REPAIR instruction is loaded in the WIR until the SOFT_REPAIR instruction is unloaded.		
NOTE 6 In case of all channel operation, refer to CHANNEL_DISABLE instruction for conditions to re-enable a disabled channel.		

13.7 IEEE1500 Test Port AC Timing Parameters

Table 134 — IEEE1500 Test Port AC Timings

Parameter	Symbol	Values		Unit	Notes
		Min	Max		
IEEE1500 Port I/O Timings					
WRCK clock period	t_{CKTP}	20	-	ns	
WRCK clock high pulse width	t_{CKTPH}	0.45	-	t_{CKTP}	
WRCK clock low pulse width	t_{CKTPL}	0.45	-	t_{CKTP}	
WRST_n pulse width low	t_{WRSTL}	100	-	ns	
IEEE1500 port operation after WRST_n deassertion	t_{WINIT1}	3	-	t_{CKTP}	
Rising WRST_n edge to WRCK setup time	t_{SWRST}		-	ns	
WSP input setup time to WRCK rising edge	t_{SR}		-	ns	3
WSP input hold time from WRCK rising edge	t_{HR}		-	ns	3
WSP input setup time to WRCK falling edge	t_{SF}		-	ns	4
WSP input hold time from WRCK falling edge	t_{HF}		-	ns	4
WSO output valid time from WRCK falling edge	t_{OVWSO}	-		ns	5
EXTEST_RX Instruction Related Timings					
Input setup time to WRCK rising edge	t_{SEXT}			ns	6
Input hold time from WRCK rising edge	t_{HEXT}			ns	6
EXTEST_TX Instruction Related Timings					
Output valid time from WRCK rising edge	t_{OVEXT}	-		ns	7
HBM3_RESET Instruction Related Timings					
HBM_RESET instruction minimum active time	t_{RES}	t_{PW_RESET}	-	ns	8
SOFT_REPAIR and HARD_REPAIR Instruction Related Timings					
SOFT_REPAIR minimum waiting time	t_{SREP}		-	ns, μ s or nWRCK	9
HARD_REPAIR minimum waiting time	t_{HREP}		-	ns, μ s or nWRCK	10
DWORD_MISR and AWORD_MISR Instruction Related Timings					
DWORD and AWORD MISR data capture to WDR data capture delay	t_{SMISR}		-	ns	11
CHANNEL_ID Instruction Related Timings					
Output high time from WRCK falling edge	t_{OVCHN}	-		ns	12
Output return to default state delay	t_{OZCHN}	-		ns	13

Table 134 — IEEE1500 Test Port AC Timings (cont'd)

Parameter	Symbol	Values		Unit	Notes
		Min	Max		
Mode_Register_Dump_Set Instruction Related Timings					
WDR update to Mode Register valid delay	t_{UPDMRS}		-	ns	14
MRS command to WDR data capture delay	t_{MRSS}	t_{MOD}	-	nCK	15
AWORD_MISR_CONFIG Instruction Related Timings					
AWORD MISR configuration to MISR operation delay	t_{CMISR}		-	ns	16
SOFT_LANE_REPAIR and HARD_LANE_REPAIR Instruction Related Timings					
SOFT_LANE_REPAIR minimum waiting time	t_{SLREP}		-	ns or μ s	17
HARD_LANE_REPAIR minimum waiting time	t_{HLREP}		-	ns or μ s	18
CHANNEL_DISABLE Instruction Related Timing					
Channel disable to input and output buffer disable delay	t_{CHDIS}			ns or μ s	19
SELF_REPAIR Instruction Related Timings					
Self-test and Auto-repair test time	t_{SELF_HEAL}	-		s	20
Auto-repair test time	$t_{SELF REP}$	-		s	20
Self-test test time	t_{SELF_NR}	-		s	20
Self-test cancel time	t_{SELF_CANCEL}	-		μ s	20

Table 134 — IEEE1500 Test Port AC Timings (cont'd)

Parameter	Symbol	Values		Unit	Notes
		Min	Max		
NOTE 1	AC timing parameters apply to each channel of the HBM3 device independently except for timings related to IEEE1500 input pins that are common to all channels. No timing parameters are specified across channels, and all channels operate independently of each other.				
NOTE 2	All parameters assume proper device initialization.				
NOTE 3	Parameter applies to WSI, SelectWIR, ShiftWR, and CaptureWR inputs.				
NOTE 4	Parameter applies to UpdateWR input.				
NOTE 5	Parameter applies to WSO output changes resulting from Wrapper Instruction Register (WIR), Wrapper Bypass Register (WBY) or any Wrapper Data Register (WDR) shift operation.				
NOTE 6	Parameter applies to all HBM3 inputs and bidirectional IOs in the CaptureWR cycle when the active instruction is EXTEST_RX.				
NOTE 7	Parameter applies to all HBM outputs and bidirectional IOs in the ShiftWR cycle when the active instruction is EXTEST_TX.				
NOTE 8	Parameter applies when the active instruction is HBM_RESET; it is measured from either the falling WRCK edge that loads the HBM_RESET instruction in the UpdateWIR cycle (in case no WDR is associated with the instruction) or the falling WRCK edge that sets the WDR bit to '1' in the UpdateWR cycle (in case a WDR is associated with the instruction) until either the HBM_RESET instruction is invalidated or the WDR bit is set back to '0'. The minimum value equals the RESET_n minimum low time with stable power (t_{pw_RESET}).				
NOTE 9	Parameter applies when the active instruction is SOFT_REPAIR; it describes the minimum time for the HBM3 device to perform the internal soft repair; it is measured from the falling WRCK edge that loads the repair vector and repair start bit in the UpdateWR cycle until the instruction is invalidated.				
NOTE 10	Parameter applies when the active instruction is HARD_REPAIR; it describes the minimum time for the HBM3 device to perform the internal hard repair; it is measured from the falling WRCK edge that loads the repair vector and repair start bit in the UpdateWR cycle until the instruction is invalidated.				
NOTE 11	Parameter applies when the active instruction is DWORD_MISR or AWORD_MISR; it is measured from the last CK clock that updates the data in the respective MISR until the rising WRCK edge associated with the CaptureWR cycle that copies the MISR data into the WDR shift register.				
NOTE 12	Parameter applies when the active instruction is CHANNEL_ID; it describes the maximum duration from either the falling WRCK edge that sets the CHANNEL_ID instruction in the UpdateWIR cycle (when no WDR is associated with the instruction) or the falling WRCK edge in the UpdateWR cycle that sets the enable bit in the WDR to '1' (when a WDR is associated with the instruction) until the bidirectional IOs drive a High.				
NOTE 13	Parameter applies when the active instruction is CHANNEL_ID; it describes the maximum duration from either the falling WRCK edge that sets any instruction other than CHANNEL_ID instruction in the UpdateWIR cycle (when no WDR is associated with the instruction) or the falling WRCK edge in the UpdateWR cycle that sets the enable bit in the WDR to '0' (when a WDR is associated with the instruction) until the bidirectional IOs return to their default state.				
NOTE 14	Parameter applies when the active instruction is MODE_REGISTER_DUMP_SET; it describes the minimum required delay between the falling WRCK edge in the UpdateWR cycle that loads the Mode Registers from the WDR shift register until any valid command other than RNOP and CNOP can be issued at the command interface.				
NOTE 15	Parameter applies when the active instruction is MODE_REGISTER_DUMP_SET; it describes the minimum required delay between the last MRS command that loads any Mode Register and the rising WRCK edge in the CaptureWR cycle that copies the Mode Register content into the WDR shift register.				
NOTE 16	Parameter applies when the active instruction is AWORD_MISR_CONFIG; it describes the minimum required delay between the falling WRCK edge in the UpdateWR cycle that loads the AWORD MISR configuration until the MISR configuration is valid for any subsequent AWORD or DWORD MISR operation in the CK clock domain.				
NOTE 17	Parameter applies when the active instruction is SOFT_LANE_REPAIR; it describes the minimum time for the HBM3 device to perform the internal soft lane repair; it is measured from the falling WRCK edge that loads the repair vector in the UpdateWR cycle until the instruction is invalidated.				
NOTE 18	Parameter applies when the active instruction is HARD_LANE_REPAIR; it describes the minimum time for the HBM3 device to perform the internal hard lane repair; it is measured from the falling WRCK edge that loads the repair vector in the UpdateWR cycle until the instruction is invalidated.				
NOTE 19	Parameter applies when the active instruction is CHANNEL_DISABLE; it describes the minimum waiting time for disabling the channel's input and output buffers after the UpdateWR event that sets the CHANNEL_DISABLE WDR to 1.				
NOTE 20	Parameter represents the maximum time the operation will take to complete and therefore the minimum time the host must wait.				

13.7 IEEE1500 Test Port AC Timing Parameters (cont'd)




Figure 106 — IEEE1500 Port Input and Output Timings



Figure 107 — IEEE1500 EXTEST_RX and EXTEST_TX Instruction Related Timings




Figure 108 — IEEE1500 SOFT_REPAIR and HARD_REPAIR Instruction Related Timings

13.7 IEEE1500 Test Port AC Timing Parameters (cont'd)






Figure 109 — IEEE1500 Soft_Lane_Repair And Hard_Lane_Repair Instruction Related Timings




NOTE 1 Same timings for data inputs and DWORD MISR with DWORD_MISR instruction.
NOTE 2 $t_{OVWSO} = 0$ for illustration purpose.

Figure 110 — IEEE1500 DWORD_MISR / AWORD_MISR Instruction Related Timings



NOTE 1 t_{OVCHN} and t_{OZCHN} refer to set/reset of the Enable bit in the WDR.

Figure 111 — IEEE1500 CHANNEL_ID Instruction Related Timings

13.7 IEEE1500 Test Port AC Timing Parameters (cont'd)

A.C. = any command allowed in bank idle state.

Figure 112 — IEEE1500 MODE_REGISTER_DUMP_SET Instruction Related Timings

13.8 Boundary Scan

The HBM3 DRAM supports a boundary scan chain per channel via the IEEE1500 test port. The boundary scan operation is associated with IEEE1500 test port instructions EXTEST_RX and EXTEST_TX.

Scan data is shifted in through WSI and out through the respective WSO, based on the active channel selections in the WIR (see Table 107). All functional pins are included in the boundary scan chains. Table 110 lists the micro-bump boundary scan chain order. Bit position 0 is the first bit shifted in on WSI and out on the WSOs.

Three global pins in the MIDSTACK area are routed to the channel n and o scan chains: TEMP[1:0] are associated with channel n, and CATTRIP is associated with channel o. The boundary scan chain length for all channels is 122 bits (see Table 110), with dummy WDR bit padding as needed on the MSB end of the chains. Matched length boundary scan chains allow all channel chains to be loaded with matching data with one shift operation when WIR[12:8] = 1Fh.

All input-only and output-only pins are implemented as bi-directionals to aid in SIP package level testing and fault isolation. Effectively, all pins support both EXTEST_RX and EXTEST_TX instructions.

I/O signals power up in input mode by default. As soon as EXTEST_TX becomes the current instruction, the I/Os will change to output mode, and the outputs will drive the values shifted into the WDR shift stage.

When EXTEST_RX is the current instruction, all functional pins of the selected channel(s) enter a High-Z state, including the output-only pins AERR, DERR, RDQS_t/RDQS_c, TEMP and CATTRIP. On a subsequent CaptureWR event the pins will capture the input values into the WDR shift stage.

Boundary scan mode entry may be asserted at any time after device initialization and before normal memory operation has commenced, e.g., before the CK clock has started to toggle. Upon exiting the scan mode, the state of the HBM3 DRAM is unknown and the integrity of the data content of the memory array is not guaranteed and therefore the reset initialization sequence is required before returning to normal operation.

Annex A – (Informative) Differences between JESD238A and JESD238

This table describes the key changes made to the standard (JESD238A) in comparison to its predecessor (JESD238). Minor editorial changes and format updates of figures and tables are not included.

Page	Clause Number / Description of Changes
3	3.1.1 Table 2 Note 2 added
6	3.2 Table 4 note numbers modified
11	4.1 Updated Figure 4
12	4.3 Updated Figure 5
14	4.4 Updated Figure 6
15	4.4 Initialization Sequence (Figure 7) : Added tWINIT1 and DEVICE_ID(optional)
18	5 Mode Register (Table 12) : Added new Parity Latency (100 – 4nCK)
22	5 Mode Register (Table 19) : ... DWORD MISR Operation – WRITE condition update
49	6.3.2.6 Figure 27 modified (changed REMpb to REFpb)
75	6.3.3.4 Mode Register Set (MRS) Command : MRS command and tWRMRS text update
79	6.3.4.1 Power-Down Entry and Exit (Figure 48, Note 2) : Supplemented tWRPDE timing
92-93	6.4.2 Data Parity (Figures 62~65) : Added PL=4 text conditions and related notes
107	6.8.2 General Loopback ... Behaviour : Cycles processed in MISR mode clarification
108	6.8.3.1 Test Method for A WORD (Write) MISR Mode; changed paragraph d)
134	6.12 Self Repair instruction clarification
163	10 AC Timings (Table 93) : Specified tRFFCab/pb values for 24Gb die density
164	10 AC Timings (Table 93) etc. : Added tWRMRS timing parameter definition and value
165	10 AC Timings (Table 93, Note 18) : Changed tRTW(min) timing parameter definition
170	11.3 HBM3 Stack Height (Table 96) : Added Width and Length parameters and values, Notes 2/3
209	13.5 Test Instructions (Table 108) : Specified all-channel disable instruction as optional
226	13.5.11 Device_ID (Table 120) : Added 00000 – default clause to Bit Position [159:155]
228	13.5.11 Device ID (Table 120): Added new Manufacturer ID (1100 – CXMT), Added NOTE 3
236	13.5.16 CHANNEL_DISABLE : All-channel disable instruction text update
245	13.5.21 SELF_REP and SELF_REP_RESULTS (Table 132, Note 2) : all to up to 8 channels change
246	13.6 Interaction with Mission Mode Operation (Table 133) : Added Note 6
248-249	13.7 IEEE1500 Test Port AC Timing Parameters (Table 134) : Added SELF_REPAIR Instruction Related Timings, added NOTE 20
253	13.8 Boundary Scan : TEMP[1:0] change channel n to channel o



Standard Improvement Form

JEDEC Standard JESD238A

The purpose of this form is to provide the Technical Committees of JEDEC with input from the industry regarding usage of the subject standard. Individuals or companies are invited to submit comments to JEDEC. All comments will be collected and dispersed to the appropriate committee(s).

If you can provide input, please complete this form and return to:

JEDEC
Attn: Publications Department
3103 North 10th Street
Suite 240 South
Arlington, VA 22201-2107

Fax: 703.907.7583

- 1. I recommend changes to the following:**

Requirement, clause number _____

Test method number _____ Clause number _____

The referenced clause number has proven to be:

Other

- ## 2. Recommendations for correction:

- ### 3. Other suggestions for document improvement:

Submitted by

Name: _____

Company: _____

Address: _____

City/State/Zip: _____

Phone: _____

E-mail: _____

Date: _____

