



What are the steps followed to configure advanced drive partitioning from ONTAP boot menu option 9 on HA pair?

https://kb.netapp.com/on-prem/ontap/Ontap_OS/OS-KBs/What_are_the_steps_followed_to_configure_...

Updated: Thu, 09 Jul 2026 17:46:11 GMT

Applies to

- ONTAP 9.2 and later
 - ADP (Advanced Drive Partitioning)
 - New set up installations
 - Systems being repurposed or decommissioned
-
- Excludes [ASA r2 systems](#)

Answer

WARNING

- This menu option erases **ALL** data on the disks of the **node** and **HA partner** when partitions are shared between node and HA partner as well resets your node configuration to the factory default settings.
- This article covers boot menu options only. For a complete process follow [How to decommission or repurpose an HA Pair with ONTAP 9](#).
- If an HA pair is using [encrypting SAS or NVMe drives \(SED, NSE, FIPS\)](#), you must follow [Returning a FIPS drive or SED to unprotected mode](#) for all drives within the HA pair prior to initializing the system (boot options 4 or 9). Failure to do this may result in future data loss if the drives are re-purposed.
- Only follow this process after the node has been removed from a cluster (unjoined) and is not joined to another cluster, see [Removing nodes from the cluster](#).

ADP (Advanced Drive Partitioning) Details

Beginning with ONTAP 9.2, a new Advanced Drive Partitioning option is available from the Boot Menu ([Managing a node by using the boot menu](#)) that provides additional management features for disks that are configured for root-data or root-data-data partitioning.

The following management features are available under the Boot Menu Option 9:

- Unpartition all disks and remove their ownership information

This option is useful if the system is configured with partitioned disks and you need to reinitialize the system with a different configuration.

- Clean configuration and initialize system with partitioned disks

This option is useful for the following:

- System is configured with whole disks and you need to configure it for root-data partitioning
- System is incorrectly configured for root-data partitioning and you need to correct it
- There is an AFF platform or a FAS platform with only SSDs attached that is configured for root-data partitioning and you can reinitialize it with root-data-data partitioning to gain increased storage efficiency
- Clean configuration and initialize system with whole disks

Option 9 (Configure Advanced Drive Partitioning) has been added to the [Boot Menu](#):

ADP Submenu

From the menu select option 9:

- (1) Normal Boot.
- (2) Boot without /etc/rc.
- (3) Change password.
- (4) Clean configuration and initialize all disks.
- (5) Maintenance mode boot.
- (6) Update flash from backup config.
- (7) Install new software first.
- (8) Reboot node.
- (9) Configure Advanced Drive Partitioning.

Selection (1-9)? 9

When Option 9 is selected, the **Advanced Drive Partitioning Boot Menu Options** submenu displays the following:

```
*****
* Advanced Drive Partitioning Boot Menu Options *
*****

(9a) Destroy aggregates, unpartition all disks and remove their ownership
information.
(9b) Clean configuration and initialize node with partitioned disks.
(9c) Clean configuration and initialize node with whole disks.
(9d) Reboot the node.
(9e) Return to main boot menu.
(9f) Remove disk ownership
```

Option 9a: Unpartition all disks and remove their ownership information:

- Execute on each node of the HA pair first

Note: Allow first node to complete before executing on the partner node

- Removes existing aggregates owned by this controller
- Destroys the existing partitions owned by this controller
- Removes ownership from all locally owned disks

Option 9b: Clean configuration and initialize system with partitioned disks:

Prerequisite: Disks must be unpartitioned and unowned (Option 9a)

- Execute this option on each node of the HA pair after Option 9a completes

Note: Allow first node to complete before executing on the partner node

- Performs a wipe-clean of configuration
- Automatically assigns local disk ownership and determines partition layout (data, parity, and spares)
- Reinitializes the controller with partitioned disks

Option 9c: Clean configuration and initialize system with whole disks:

Prerequisite: Disks must be unpartitioned and unowned (Option 9a)

- Execute this option on each node of the HA pair after Option 9a completes

Note: Allow first node to complete before executing on the partner node

- Performs a wipe-clean of configuration
- Automatically assigns local disk ownership
- Reinitializes the controller with whole disks

Option 9d: Reboot the node

Option 9e: Return to the main boot menu

Option 9f: Remove disk ownership

- Available in ONTAP 9.11.1 and later
- Removes disk and partition ownership only from the node executing the option

Additional Information

- Refer to the [HWU Hardware Universe](#) to view ADP partition format information in the supported Shelve/Drives table for both AFF and FAS platforms
- To partition additional new disks that are added to a system that is already set up for Advanced Disk Partition, please refer to this article [How to partition a drive manually in ONTAP 9](#)