



How to use boot menu option "(6) Update flash from backup config." within ONTAP

https://kb.netapp.com/on-prem/ontap/OHW/OHW-KBs/How_to_use_boot_menu_option_6_Update_flas...

Updated: Thu, 09 Jul 2026 17:46:55 GMT

Applies to

- AFF Systems
- FAS Systems
- ONTAP 9

Description

- Typical [boot device replacement](#) procedures use the [system node restore-backup](#) command to copy node configuration information back to the node with the boot device replaced
- While this is the recommended procedure, there might be reasons this command is not available to utilize in all situations

- This article describes an alternative option

Procedure

1. Before proceeding ensure the auto-giveback options are disabled.

```
cluster1::> storage failover modify -auto-giveback false -auto-giveback-  
after-panic false -node *
```

2. Connect via console or SP/BMC via system console to the node with the replaced boot device.
3. Follow all the documented boot device replacement procedures up to the point of restoring the node configuration. Follow the "No Network" substeps and answer these questions as below.

```
Do you want to restore the backup configuration now? {y|n} n  
The node must be rebooted to start using the newly installed software. Do  
you want to reboot now? {y|n} y
```

4. At boot, the following menu will be presented:

```
The boot device has changed. System configuration information  
could be lost. Use option (6) to restore the system configuration, or  
option (4) to initialize all disks and setup a new system.  
Normal Boot is prohibited.
```

```
Please choose one of the following:
```

5. If [node root volume encryption](#) is enabled, temporarily restore either the [external key manager](#) or [onboard key manager](#) configuration on the boot device (without select the Normal Boot option at the end of the process). If node root volume encryption is not used, proceed to the next step.
6. At the boot menu, select option 6:

```
Selection (1-11)? 6
```

7. Read the confirmation question and press y to continue with the restore.

```
This will replace all flash-based configuration with the last backup to  
  
disks. Are you sure you want to continue?: y
```

Note: if you choose N in error, follow [How to perform the option 7](#) to get back to option 6 to restore the node configuration.

8. The node will continue to boot and the configuration will be restored. Any messages at bootup will show the node name as `localhost`.
9. The node will reach waiting for giveback.

```
Waiting for giveback...(Press Ctrl-C to abort wait)
```

10. From the cluster, issue a giveback of the [only the CFO aggregate](#) for the node.

```
cluster1::> storage failover giveback -ofnode cluster1-01 -only-cfo-  
aggregates true
```

11. While the node configuration is being restored you will see a few messages such as below.

```
varfs_backup_restore: bootarg.abandon_varfs is set! Skipping /var backup.
```

```
varfs_backup_restore: update checksum for varfs.tgz
```

```
varfs_backup_restore: No checksum generated for oldvarfs.tgz, file not  
found
```

```
varfs_backup_restore: restore using /mroot/etc/varfs.tgz
```

```
varfs_backup_restore: attempting to restore /var/kmip to the boot device
```

```
varfs_backup_restore: successfully restored /var/kmip to the boot device
```

```
varfs_backup_restore: attempting to restore env file to the boot device
```

```
varfs_backup_restore: successfully restored env file to the boot device
```

12. Then the node will reboot to load the node configuration. Since only the CFO aggregate was given back, this does not impact the data aggregates which are still taken over.

```
varfs_backup_restore: Rebooting to load the new varfs
```

13. The node will continue to boot and the configuration will be restored. Any messages at bootup will now show the current node name.
14. If using Onboard Key Manager (OKM) the **boot process must be stopped with CTRL-C during boot** in order to return to the boot menu. Perform the [How to restore onboard key manager server configuration from the ONTAP boot menu](#) procedure.
15. The node will reach waiting for giveback.

```
Waiting for giveback...(Press Ctrl-C to abort wait)
```

16. From the cluster, issue a regular giveback for the node.

```
cluster1::> storage failover giveback -ofnode cluster1-01
```

17. Enable the auto-giveback options.

```
cluster1::> storage failover modify -auto-giveback true -auto-giveback-  
after-panic true -node *
```

Additional Information

- [Option 6 resets ha-config from mcc or mccip to ha during boot recovery process in 4-node MetroCluster](#)
Some bootargs are lost running 'Option 6' from the boot menu for 4-Node NetApp MetroCluster (MCC or MCCIP) on NetApp AFF A400 or FAS8300 storage systems running ONTAP 9.7.X: