

- U1 Front Door Courtesy Light Switch Assembly LH
- V1 Rear Differential Lock Position Switch
- V2 Differential Lock Shift Actuator
- V3 Rear Speed Sensor (Skid Control Sensor Wire)
- W1 Fuel Tank Solenoid Return Valve Assembly
- W2 Fuel Tank Solenoid Main Valve Assembly
- X1 Fuel Sender Gage Assembly (Rear)
- X2 Fuel Pump (Sub)
- Y1 No. 3 Room Light Assembly
- Y2 No. 3 Room Light Assembly
- Y3 Center Stop Light Assembly
- Y4 No. 2 Room Light Assembly
- Y5 No. 1 Room Light Assembly
- a1 Rear Wiper Motor Assembly
- a2 Rear Speaker Assembly RH
- b1 Back Door Lock Assembly
- b2 Rear Speaker Assembly LH
- b3 Back Door Courtesy Light Switch Assembly
- b4 License Plate Light Assembly
- c1 Rear Window Defogger (Back Door Glass RH)
- c2 Rear Window Defogger (Back Door Glass RH)
- d1 Rear Window Defogger (Back Door Glass LH)
- e1 License Plate Light Assembly
- f1 Rear Window Defogger (Back Door Glass LH)

## Position of Parts in Body (RHD 2-Door Except Pick-Up)

