PT MERDEKA TSINGSHAN INDONESIA

STANDARD OPERATING PROCEDURE

GRANULATION POST

制粒岗位

MTI-CHP-CPM-SOP-008_Rev. 000

Information Security Classification
B – Business Information

Rev.	Revision Status	Date	Prepared by	Reviewed by	Approved by
0	Issued for Use	24-APR-2024	*Approval as attached*	*Approval as attached*	*Approval as attached*
C0	Issued for Approval	24-APR-2024	Song Yuhua	Li Jianjun	Clark Wu
B0	Issued for Review	24-APR-2024	Song Yuhua	Li Jianjun	
A0	Issued for Internal Discipline Review	24-APR-2024	Song Yuhua		

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

DOCUMENT CHANGE STATUS

No.	Page	Section	Change Log	Revision by	Revision date	Revision version
1.						
2.						
3.						

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

Table of Contents

DOCUMENT CHANGE STATUS 2
Table of Contents 3
1. Purpose 目的 4
2. Functional Description 功能说明 4
3. References 参考 4
4. PPE 个人保护装备 4
5. Hazards & Control 危害与控制 5
6. Equipment 工具/ 设备 5
7. Procedure 程序 6
8. Granulation Post 制粒岗位 Questionnaire 18
9. Appendix 19

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

1. Purpose 目的

This procedure covers the operator's responsibility for visual inspection, start up and shutdown of the granulation post under complete closure.

此程序涵盖操作员对完全关闭下的制粒岗位进行目视操作前检查、启动运行和停车的责任。

2. Functional Description 功能说明

It is the responsibility of the operator to ensure that the granulation post is visually inspected before and after each shift to determine whether it can start and operate safely, or whether other activities (such as maintenance and repair or other operator tasks) must be performed before starting, to determine the sequential operation method of the granulation post and smooth operation, Stop order of normal stops and emergency stops.

操作员有责任确保在从停机启动之前和每个班次开始时对制粒岗位进行目视检查，确定是否可以启动并安全运行，或者是否必须在开始启动之前执行其他活动(例如维护修理或其他操作员任务)，确定制粒岗位的按照顺序启动的操作方法及平稳运行，正常停车和紧急停车的停止顺序。

3. References 参考

- MTI-CP-SOP-Post Technical Operation Procedures. MTI-CP-SOP岗位操作规程
- Disc Pelletizer (4302-DSP-001/002/003). 圆盘造球机 (4302-DSP-001/002/003)
- Disc Feeder (4302-DSF-001/002/003). 圆盘给料机 (4302-DSF-001/002/003)
- Quantitative Feeding Belt (4302-QFB-001/002/003). 称重皮带给料机 (4302-QFB-001/002/003)
- Belt Conveyors (4302-BCV-001). 胶带机 (4302-BCV-001)
- Calcium Chloride Delivery Pump (4505-PSO-001/002). 氯化钙输送泵 (4505-PSO-001/002)

4. PPE 个人保护装备



耳塞　安全帽　眼镜　劳保鞋　手套　工作服



防尘口罩

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

5. Hazards & Control 危害与控制

Description of Hazard / Environmental Issue 危害	Control Strategy 控制
1. Mechanical injury; 2. Dust; 3. Electric shock; 4. Slippery conditions and a trip to the danger; 5. Asphyxia; 6. Chemical Corrosion; 7. Object falling from high altitudes; 8. Noise. 1. 机械伤害; 2. 灰尘; 3. 触电; 4. 湿滑的条件，绊倒危险; 5. 窒息; 6. 化学腐蚀; 7. 高空坠物; 8. 噪音	1. Install a protective cover on the rotating part of the equipment; 2. Wear dust mask as required; 3. Do not contact the electrical switch with wet hands during operation, Regular inspection of the equipment leakage protection device is complete, effective; 4. Please hold the handrail up and down the stairs; 5. Clear clearance or maintenance operations; 6. Wear good labor protection goods, and spare a large amount of clean water on site; 7. Wear labor protection goods and check the safety of stacking items on the operation platform; 8. Wear the earplugs to protect your hearing. 1. 设备的转动部位安装防护罩; 2. 按要求佩戴防尘口罩; 3. 操作时不要湿手接触电器开关，定期检查设备漏电保护装置齐全、有效; 4. 上下楼梯请扶好扶手; 5. 清仓或维修作业执行审批程序; 6. 穿戴好劳保护品，现场备用大量清水; 7. 穿戴好劳保护品，检查各平台的物品堆放安全性; 8. 佩戴好耳塞，保护听力。

6. Equipment 工具/ 设备

4302-PDG-001/002	Plough Discharger 犁式卸料器
4302-BIN-001/002/003	Mixture Bin混合料仓
4302-ACN-001 ~ 012	Air Cannon空气炮
4505-TNK-001	Calcium Chloride Solution Storage Tank氯化钙储槽
	Clean the site tools清扫现场工具

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

7. Procedure 程序

№	Stage	Key Points
1	General Check 普查	1. Confirm the pre-job technical training; 2. Wear suitable labor protection products, check and confirm that there is no unsafe state or safety risks on the site; 3. Check and clean the equipment and the site sanitation; 4. Contact with the process before and after and give clear instructions. 1. 确认经过岗前技术培训; 2. 穿戴好适合的劳保护品，检查确认现场没有存在不安全状态或安全隐患; 3. 检查并打扫设备、现场卫生; 4. 与前后工序取得联系，并发出明确指令
2	Inspect Disc Pelletizer (4302-DSP-001/002/003) 检查圆盘造球机 (4302-DSP-001/002/003)	1. Check whether the installation of the equipment rack is stable and whether the connecting bolts are fastened; 2. Check whether the connection of the motor and reducer is good and the oil level of the reducer is normal; 3. Check whether the concentricity of the equipment coupling meets the requirements and the bearing lubrication is good; 4. Open the lubrication device, check whether there is any lubricating oil overflow around the disc teeth, and replace the lubricating oil to ensure that the disc teeth lubrication is normal; 5. Check whether there are foreign objects around the machine and around the turntable; 6. Check whether the signal of the circuit control cabinet is normal; 7. Disc moving disk ball making machine, to determine that there is no abnormality; 8. Click to open the main motor to check whether the direction of the disk is correct; 9. Click and open the rotary scraper motor to check whether the rotation direction of the scraper is correct. Facing the disc, the disk rotates clockwise, and the bottom scraper rotates counterclockwise; 10. Adjust the clearance between the scraper by 15mm, and tighten the bolts after adjustment. 11. Check the scraper along the scraper and the scraper 20mm 1. 检查设备机架安装的是否稳定，连接螺栓是否紧

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		固； 2. 检查电机、减速机连接是否完好，减速机油镜油位是否正常； 3. 检查设备联轴器同心度是否符合要求、轴承润滑情况良好； 4. 开启润滑装置，检查盘齿周边有无润滑油外溢，采用润滑油挤压置换确保盘齿润滑正常； 5. 检查机器周围及转盘周围是否有异物阻挡运转； 6. 检查电路控制柜信号是否正常； 7. 盘动圆盘造球机，确定无异常； 8. 点动开启主电机，查看圆盘方向是否正确； 9. 点动开启旋转刮刀电机，查看刮刀旋转方向是否正确，人面对盘看，圆盘顺时针旋转，底刮刀逆时针旋转； 10. 调整刮刀离地盘间隙15mm，调整后将螺栓拧紧。 11. 检查盘沿刮刀紧贴盘壁、盘壁刮刀20mm。
3	Inspect Disc Feeder(4302-DSF-001/002/003)	1. Check that the lubrication and sealing of all bearings are good, the reducer oil level is appropriate, and the operation is flexible; 2. Check whether the disk is horizontal, and check that the hand disk movement is flexible; 3. Check to determine whether the motor wiring is correct, check whether the rotation direction of the disk and the scraper is correct. Facing the disc, the disk rotates clockwise, and the bottom scraper rotates counterclockwise; 4. Check whether the position of the scraper and the movable sleeve meets the requirements of the feeding quantity 1. 检查各部轴承润滑与封闭良好，减速机油位适当，运转灵活； 2. 检查圆盘是否水平，检查用手盘动操作是否灵活； 3. 检查确定电机接线是否正确，检查圆盘和刮刀旋转方向是否正确，人面对盘看，圆盘顺时针旋转，底刮刀逆时针旋转； 4. 检查刮板和活动套筒的位置是否符合喂料量的要求
4	Inspect Quantitative Feeding Belt(4302-	1. Each bearing is well lubricated and closed, the oil level of the reducer is appropriate, the upper and lower roller

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
	QFB-001/002/003) 检查称重皮带给料机 (4302-QFB-001/002/003)	lubrication is good, the operation is flexible, whether the wear of the first and tail wheels and the belt are sandwiched with materials, and whether the cleaning device of the first and tail wheels is in good condition; 2. Check whether each part of the conveyor is intact, whether the tension of the conveyor belt is appropriate, and whether the corresponding belt tightening device and dust prevention facilities are in good condition; 3. Whether the electrical facilities and control system are intact, whether the protective device is firm, and whether the funnel baffle and liner are damaged; 4. Check whether the cushion rollers of the impact load parts are intact; 5. Check the installation of belt sweeper; 6. Clean the dust debris between the pressure head of the quantitative belt scale weighing sensor, loosen the maintenance bolt on the support to make the load-bearing screw in good contact with the sensor; 7. Whether the installed electrical facilities and signal devices are intact and responsive; 8. Turn on the power supply and check the Q value of the quantitative belt scale instrument: apply a load to the weighing frame, the Q value should rise. If the Q value falls, the signal input is reversed, and two signal lines of the sensor should be changed; 9. Place the field control box in the manual position, press the start button, slowly rotate the potentiometer, watch whether the running direction of the belt is correct and whether the belt can deviate 10. After checking and contacting the post, press the start button; 11. During the operation process, check whether the tape machine emergency stop device, belt deviation correction are in good condition. 1. 各部轴承润滑与封闭良好，减速机油位适当，上下托滚润滑良好，运转灵活，首、尾轮磨损情况与皮带间是否夹有物料，首、尾轮的清扫装置是否完好； 2. 全面检查输送机各部分是否完好无损，输送带的张紧度是否合适，相应的皮带拉紧装置及防尘设施是否完好； 3. 电器设施和控制系统是否完好，防护装置是否牢固，漏斗挡板和衬板是否损坏； 4. 检查承受冲击载荷部位的缓冲托辊是否完好；

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		5. 检查皮带清扫器安装是否正常； 6. 将定量皮带秤称重传感器压头间粉尘杂物清扫干净，松开支架上的维护螺栓，使承重螺杆与传感器良好接触； 7. 装设的电器设施及信号装置是否完好和反应灵敏； 8. 接通电源，查看定量皮带秤仪表Q值：稍给称量框架施加负载，Q值应上升，若Q值降落，则阐明信号输入接反，应对换传感器的两根信号线； 9. 将现场控制盒置于手动位置，按一下启动按钮，迟缓旋动电位器，观看定量皮带秤皮带运转方向能否正确，皮带是否跑偏； 10. 检查无误并与前后岗位联系后，按下启动按钮； 11. 运转过程中，检查称重皮带给料机急停装置、皮带纠偏是否控制灵敏
5	Inspect Belt Conveyors (4302-BCV-001) 检查胶带机 (4302-BCV-001)	1. Each bearing is well lubrication and closed, the reducer oil level is appropriate, the upper and lower roller lubrication is good, the operation is flexible, whether the wear of the first and tail wheels and the tape are filled with materials, and whether the cleaning device of the first and tail wheels is in good condition; 2. Comprehensively check whether all parts of the belt conveyors are intact, whether the tension of the tape is appropriate, and whether the corresponding tape tightening device and dust-proof facilities are in good condition; 3. Whether the electrical facilities and control system are intact, whether the protective device is firm, and whether the funnel baffle and liner are damaged; 4. Check whether the cushion rollers of the impact load parts are intact; 5. Check the installation of belt sweeper; 6. Whether the installed electrical facilities and signal devices are intact and responsive; 7. Place the field control box in the manual position, press the start button, slowly rotate the potentiometer, and watch whether the running direction of the tape is correct, and whether the belt can run away; 8. After checking and contacting the post, press the start button; 9. During the operation process, check whether the tape machine emergency stop device, belt deviation correction and speed measuring sensor are in good condition.

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		1. 各部轴承润滑与封闭良好，减速机油位适当，上下托滚润滑良好，运转灵活，首、尾轮磨损情况与胶带间是否夹有物料，首、尾轮的清扫装置是否完好； 2. 全面检查胶带机各部分是否完好无损，胶带的张紧度是否合适，相应的胶带拉紧装置及防尘设施是否完好； 3. 电器设施和控制系统是否完好，防护装置是否牢固，漏斗挡板和衬板是否损坏； 4. 检查承受冲击载荷部位的缓冲托辊是否完好； 5. 检查胶带机清扫器安装是否正常； 6. 装设的电器设施及信号装置是否完好和反应灵敏； 7. 将现场控制盒置于手动位置，按一下启动按钮，迟缓旋动电位器，观看胶带运转方向能否正确，皮带是否跑偏； 8. 检查无误并与前后岗位联系后，按下启动按钮； 9. 运转过程中，检查胶带机急停装置、皮带纠偏和测速传感器是否控制灵敏
6	Inspect Calcium Chloride Delivery Pump(4505-PSO-001/002) 检查氯化钙输送泵(4505-PSO-001/002)	1. Check whether the pump inlet pipeline and auxiliary pipeline, flange and valve installation meet the requirements, whether the anchor bolts and ground wire are good, and whether the coupling is installed; 2. Turn the pump shaft 3 times, should be flexible without block; 3. Check whether the lubricating oil level is normal. The oil level should be between 1/2 and 2/3 of the oil lens; 4. Check the sealing condition of the pump is normal; 5. Point to move to confirm the correct steering; 6. Check whether the pump control cabinet voltmeter, signal lights and other instrument indicators are normal; 7. Check whether there is air in the pump unit, if it should be excluded; 8. Check that the pump head is at the level of the calcium chloride solution storage tank (4505-TNK-001); 9. Check that the conveying pump is in the normal condition, and that the outlet valve (50BA) are temporarily closed after opening flexibly; 10. Check the backup pump outlet valve closed. 1. 检查泵出入口管线及附属管线，法兰、阀门安装是否符合要求，地脚螺栓及地线是否良好，联轴器及防护罩是否装好； 2. 手动转动泵轴3圈，应灵活无阻滞； 3. 检查润滑油油位是否正常，油位应在油镜的1/2 ~

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		2/3之间; 4. 检查泵的密封状况是否正常; 5. 点动确认转向正确; 6. 检查泵控制柜电压表、信号灯等仪表指示是否正常; 7. 检查泵机组是否有空气，如有应予以排除; 8. 检查泵头是否处于氯化钙储槽(4505-TNK-001)液位下; 9. 检查输送泵处于正常状态，出口阀门(50BA)开启灵活后暂时处于关闭状态; 10. 检查备用泵出口阀关闭状态
7	Check the other Equipment and Facilities 检查其它设备设施	1. Plough Discharger(4302-PDG-001/002) a. Check whether the mechanism is flexible, whether the lifting of the plow is normal, whether the drive of the sliding car roller is flexible, whether the rise and fall reach the height, and the push rod has no self-locking sliding phenomenon; b. Check whether the plow wear is serious, the controller has not failed, and the horizontal roller is not stuck and astringent; c. Check the tightness of the plow and the tape machine 1. 犁式卸料器(4302-PDG-001/002) a. 检查机构是否灵活，犁头升降是否正常，下滑车托辊传动是否灵活，起落是否达到高度，推杆有无不自锁下滑现象; b. 检查犁头磨损是否严重，控制器无失灵，水平托辊灵活没有不转动现象; c. 检查犁头与胶带机结合松紧适当 2. Mixture Bin(4302-BIN-001/002/003) a. Check whether the inlet and outlet pipes and auxiliary pipes and flanges of each warehouse meet the requirements, and whether the seal of each warehouse is in good condition; b. Check the material level control assembly for normal operation 2. 混合料仓(4302-BIN-001/002/003) a. 检查各仓出入口管路及附属管路、法兰是否符合要求，各仓密封是否完好; b. 检查料位控制组件是否正常。

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		3. Air Cannon(4302-ACN-001 ~ 012) a. Check whether the connecting bolts of each flange are loose; b. Check whether all the air pipes and connections are loose and leaky; c. Check whether all the pneumatic components are working normally and flexibly; d. Check to ensure that the airflow direction is consistent with the solenoid valve arrow; e. Check that the intake ball valve (15BA) is normal f. Before operation, ensure that the bin feeding opening has been started or opened; g. Check the drain well. 3. 空气炮(4302-ACN-001 ~ 012) a. 检查各个法兰的连接螺栓是否松动; b. 检查全部空气管道及连接处是否松动漏气; c. 检查全部气动元件工作是否正常、灵活; d. 检查确保气流方向与电磁阀箭头保持一致; e. 检查进气球阀(15BA)是否正常; f. 操作前应确保料仓下料口已启动或打开; g. 检查疏水阀排水良好。 4. Calcium Chloride Solution Storage Tank(4505-TNK-001) a. Check whether the inlet and outlet pipelines and auxiliary pipelines of calcium chloride solution storage tank, whether the installation of flange and valve(40BF、50BF) meet the requirements, and whether the storage tank leaks liquid; b. Check the level control assembly is normal. 4. 氯化钙储槽(4505-TNK-001) a. 检查储槽出入口管线及附属管线，法兰、阀门(40BF,50BF)安装是否符合要求，储槽是否漏液; b. 检查液位控制组件是否正常。 5. Other a. Check whether the feeding chute(4302-CHE-001/002/003) of the mixing bin (4302-BIN-001/002/003) is working normally; b. Open the spray brake valve of calcium chloride solution (50BA, FIT001/002/003), Check if the calcium chloride solution is discharged normally. 5. 其它 a. 检查称重皮带给料机(4302-QFB-001/002/003)下

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		料溜槽(4302-CHE-001/002/003)是否正常工作 b. 打开氯化钙溶液喷淋闸阀(50BA,FIT001/002/003)，查看是否有氯化钙溶液正常排出
8	Inspect Materials Level 检查物料料位	1. Check the material level of the mixture bin (4302-BIN-001/002/003) to ensure sufficient materials; 2. Check that the pressure of the air cannon (4302-ACN-001~012) reaches 0.4~0.8MPa; 3. Check whether the disk feeder (4302-DSF-001/002/003) is stored; 4. Check whether the material is stored on the weighing belt feeder (4302-QFB-001/002/003), and there is no adhesive deposit on the surface of the head and tail wheel and the belt joint; 5. Check whether material are stored on the disc pelletizer (4302-DSP-001/002 /003); 6. Check whether the material is stored on the tape machine (4302-BCV-001), and there is no adhesive deposit on the surface of the head and tail wheel and the belt joint; 7. Check the level of the calcium chloride solution storage tank (4505-TNK-001) to ensure that the solution is sufficient. 1. 检查混合料仓(4302-BIN-001/002/003)料位，确保物料充足； 2. 检查空气炮(4302-ACN-001～012)压力是否达到0.4～0.8MPa； 3. 检查圆盘给料机(4302-DSF-001/002/003)是否存料； 4. 检查称重皮带给料机(4302-QFB-001/002/003)上是否存料，首尾轮表面与皮带结合部无黏附积矿存在； 5. 检查圆盘造球机(4302-DSP-001/002/003)上是否存料； 6. 检查胶带机(4302-BCV-001)上是否存料，首尾轮表面与皮带结合部无黏附积矿存在； 7. 检查氯化钙储槽(4505-TNK-001)液位，确保在溶液充足
9	Start-Up of the Granulation Post 制粒岗位开机	1. No-load start should be guaranteed when starting; 2. The driving sequence is along the material direction, from back to front that is the reverse drive, each equipment needs to be switched on later; At the same time, confirm that the process behind the granulating

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		post has been started and has the feeding conditions: Open the belt conveyors (4302-BCV-001)⟹Open the disc pelletizer (4302-DSP-001/002/003)⟹Start the centralized lubrication system⟹Start the main motor and fan motor of the ball-making machine⟹ After 30 seconds to start the ball machine scraper motor fan motor⟹Start the ball machine scraper motor after 30 seconds⟹Start the main motor of the ball maker after 60 seconds⟹Open the quantitative feeding belt (4302-QFB-001/002/003)⟹Open the ball valve (50BA) and spray brake valve of calcium chloride solution (FIT001/002/003),open the inlet valve (40BF) and the outlet valve (50BF),and open the calcium chloride delivery pump (4505-PSO-001/002)⟹ Open the disc feeder (4302-DSF-001/002/003)⟹ Open plough discharger (4302-PDG-001/002),the plough head of the driving unloader (4302-PDG-001/002) falls⟹Open the air cannon (4302-ACN-001~012)⟹When the mixing bin is fed normally, the air gun should not be started to avoid the compaction of the mixture and cause material blockage⟹Open the intake air ball valve (15BA), the gas will automatically enter the gun body, press the start button to give an air signal to the reversing valve. The air gun will emit strong impact air flow through the exhaust port, and automatically restore the inflation state after the energy is released⟹. 1. 启动时应保证空载启动； 2. 开车顺序为沿物料走向，从后往前开即逆向开车，各设备都需要延时开启；同时，确认制粒岗位后面的工序已经开车并具备给料条件： 开启胶带机(4302-BCV-001)⟹开启圆盘造球机(4302-DSP-001/002/003)⟹启动集中润滑系统⟹启动造球机主电机风扇电机⟹30秒后启动造球机刮刀电机风扇电机⟹30秒后启动造球机各刮刀电机⟹60秒后启动造球机主电机⟹开启称重皮带给料机(4302-QFB-001/002/003)⟹打开氯化钙溶液喷淋球阀(50BA)和闸阀(FIT001/002/003)，打开进口阀门(40BF)、出口阀门

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		(50BF)，开启氯化钙输送泵(4505-PSO-001/002)⟶开启圆盘给料机(4302-DSF-001/002/003)⟶开启犁式卸料器(4302-PDG-001/002)，操作犁式卸料器犁头(4301-PDG-001)落下⟶开启空气炮(4302-ACN-001～012)[混合料仓正常下料时，不可启动空气炮，避免混合料夯实，造成物料堵塞⟶打开进气球阀(15BA)，气体便自动进入炮体，按下起动按纽，给换向阀一个气信号，空气炮通过排气口喷出强大冲击气流，能量释放后自动恢复充气状态]
10	The Granulation Post Stops 制粒岗位停机	1. Orderly shutdown a. The materials in the standby machine should be discharged before stopping; b. Stop in the reverse order of driving order, Each equipment needs to stop: Stop air cannon (4302-ACN-001~012), Close the air intake ball valve (15BA)⟶Stop the plough discharger (4302-PDG-001/002), lift the unloader plow (4302-PDG-001/002)⟶Stop the disc feeder (4302-DSF-001/002/003)⟶Stop the calcium chloride delivery pump (4505-PSO-001/002), Close the inlet valve (40BF) and the outlet valve (50BF)⟶Stop quantitative feeding belt (4302-QFB-001/002/003)⟶Stop disc pelletizer (4302-DSP-001/002/003)[Stop the main motor of the ball-maker⟶ Stop the ball-making machine scraper motor after 30 seconds⟶ Stop the ball scraper, the fan machine after 30 seconds⟶ Stop the main motor and fan motor of the ball-making machine⟶Stop the centralized lubrication system]⟶Stop the belt conveyors (4302-BCV-001)⟶Clean the site for hygiene. 1. 正常停车 a. 停车时应待机内物料排净后再停车； b. (2)按照开车顺序逆序停车，各设备都需要延时停止： 停止空气炮(4302-ACN-001～012)，关闭进气球阀(15BA) 停止犁式卸料器(4302-PDG-001/002)，操作

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		卸料器犁头(4302-PDG-001/002)抬起 停止圆盘给料机(4302-DSF-001/002/003) 停止氯化钙输送泵(4505-PSO-001/002)，关闭进口阀门(40BF)、出口阀门(50BF) 停止称重皮带给料机(4302-QFB-001/002/003) 停止圆盘造球机(4302-DSP-001/002/003)： 停止造球机主电机 30秒后停止造球机刮刀电机 30秒后停止造球机刮刀电机风扇电机 停止造球机主电机风扇电机 停止集中润滑系统 停止胶带机(4302-BCV-001) 打扫现场卫生。 2. Emergency Stop a. In an emergency, Close disk feeder (4302-DSF-001/002/003), close calcium chloride delivery pump (4505-PSO-001/002), close quantitative feeding belt (4302-QFB-001/002/003), close disc pelletizer (4302-DSP-001/002/003), close belt conveyors (4302-BCV-001), close plough discharger (4302-PDG-001/002),after all stop operation, check whether the start/stop button of each equipment is in stop state, Close the spray valve of the calcium chloride solution (50BA), meanwhile, the upper level equipment shall stop; b. After the accident, the equipment is restored to normal. If production still needs to be conducted, and the operation shall be restarted in the driving sequence; c. After the accident treatment, the equipment returns to normal. If the production is not necessary, operate according to the normal parking order 2. 紧急停车 a. 当出现紧急事故，关闭圆盘给料机(4302-DSF-001/002/003)，关闭氯化钙输送泵(4505-PSO-001/002)，关闭称重皮带给料机(4302-QFB-001/002/003)，关闭圆盘造球机(4302-DSP-001/002/003)，关闭胶带机(4302-BCV-001)，关闭犁式卸料器(4302-PDG-001/002)，全部停止运行后，检查各设备的启动/停止按钮是否处于停止状态，关闭氯化钙溶液喷淋阀门(50BA)，同时，上一级设备均需停车；

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		b. 事故处理后，设备恢复正常，如仍需要进行生产，按照开车顺序重新启动操作； c. 事故处理后，设备恢复正常，如不需要进行生产，按照正常停车顺序进行操作
11	Permits & Isolation Sheets 许可证和隔离表	1. Only authorized isolators can sign off and cancel permits and registration sheets. 1. 只有经过授权的隔离者才能签署和取消许可证和登记表。

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

8. Granulation Post 制粒岗位 Questionnaire

Declaration of Understanding

I (_____Learner_____) have completed the theory assessment and had all my valid, reliable, and consistent with my level of knowledge in the assessment task.

Signature
Date:

I (_____Assessor_____) have witnessed the above learner complete the theory assessment and believe the assessment has provided a valid, reliable, and consistent result.

Signature
Date:

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

9. Appendix

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

Standard Operating Procedure
标准操作程序

Granulation posts in the chloride plant
CP 制粒岗位

SOP Details 程序明细

Processing Department 氯化厂	Procedure Level 程序级别: **3**	Revision Number 修订编号: 0
Date Approved 审批日期:	Date Issued 颁布日期:	Next Review Date 下次审核日期:
Details of Revision 修订明细:		

Revision Details 修订明细

Rev. No 版本号	Date 日期	Section 章节	Page 页码	Revision Description 修订说明	Reviewed By 审核人
1					
2					
3					

Approvals 批准

Document Owner 程序持有人	Song Yuhua 宋裕华	Date: 日期: 2024.4.24	Signature 签字	
Processing Superintendent 氯化高级副经理	Cao Guibin 曹桂宾	Date: 日期: 2024.4.24	Signature 签字	
Processing Senior Manager 氯化高级经理	Li Jianjun 李建军	Date: 日期: 2024.04.24	Signature 签字	
Safety Department Manager 安全部经理	Airlangga Putra R.J	Date: 日期: 24.04.24	Signature 签字	
Deputy General Manager 副总经理	Li Xinhua 李新华	Date: 日期 2024.4.24	Signature 签字	
General Manager 总经理	Clark Wu 吴迎林	Date: 日期: 2024.4.24	Signature 签字	