PT MERDEKA TSINGSHAN INDONESIA

STANDARD OPERATING PROCEDURE

STANDBY ASTER POST

备用焙砂仓岗位

MTI-CHP-CPM-SOP-009_Rev. 000

Information Security Classification
B – Business Information

Rev.	Revision Status	Date	Prepared by	Reviewed by	Approved by
0	Issued for Use	24-APR-2024	*Approval as attached*	*Approval as attached*	*Approval as attached*
C0	Issued for Approval	24-APR-2024	Song Yuhua	Li Jianjun	Clark Wu
B0	Issued for Review	24-APR-2024	Song Yuhua	Li Jianjun	
A0	Issued for Internal Discipline Review	24-APR-2024	Song Yuhua		

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

DOCUMENT CHANGE STATUS

No.	Page	Section	Change Log	Revision by	Revision date	Revision version
1.						
2.						
3.						

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

Table of Contents

DOCUMENT CHANGE STATUS 2
Table of Contents 3
1. Purpose 目的 4
2. Functional Description 功能说明 4
3. References 参考 4
4. PPE 个人保护装备 4
5. Hazards & Control 危害与控制 5
6. Equipment 工具/ 设备 5
7. Procedure 程序 6
8. Standby Aster Post 备用焙砂仓岗位 Questionnaire 17
9. Appendix 18

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

1. Purpose 目的

This procedure covers the operator's responsibility for visual inspection, start up and shutdown of the standby aster post under complete closure.

此程序涵盖操作员对完全关闭下的备用焙砂仓岗位进行目视操作前检查、启动运行和停车的责任。

2. Functional Description 功能说明

It is the responsibility of the operator to ensure that the standby aster post is visually inspected before and after each shift to determine whether it can start and operate safely, or whether other activities (such as maintenance and repair or other operator tasks) must be performed before starting, to determine the sequential operation method of the standby aster post and smooth operation, Stop order of normal stops and emergency stops.

操作员有责任确保在从停机启动之前和每个班次开始时对备用焙砂仓岗位进行目视检查，确定是否可以启动并安全运行，或者是否必须在开始启动之前执行其他活动(例如维护修理或其他操作员任务)，确定备用焙砂仓岗位的按照顺序启动的操作方法及平稳运行，正常停车和紧急停车的停止顺序。

3. References 参考

- MTI-CP-SOP-Post Technical Operation Procedures. MTI-CP-SOP岗位操作规程
- Dust Collector Fan(4314-FAN-001/002). 除尘风机(4314-FAN-001/002)
- Roots Fan(4314-FAN-003/004). 罗茨风机(4314-FAN-003/004)
- Pneumatic Conveying(4314-PCV-001). 气力输送泵(4314-PCV-001)
- Buried Scraper Conveyor(4314-SCV-001). 埋刮板输送机(4314-SCV-001)

4. PPE 个人保护装备



This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

5. Hazards & Control 危害与控制

Description of Hazard / Environmental Issue 危害	Control Strategy 控制
1. Mechanical injury; 2. Dust; 3. Electric shock; 4. Slippery conditions and a trip to the danger; 5. Asphyxia; 6. Object falling from high altitudes; 7. Noise. 1. 机械伤害; 2. 灰尘; 3. 触电; 4. 湿滑的条件，绊倒危险; 5. 窒息; 6. 高空坠物; 7. 噪音。	1. Install a protective cover on the rotating part of the equipment; 2. Wear dust mask as required and mask; 3. Do not contact the electrical switch with wet hands during operation, Regular inspection of the equipment leakage protection device is complete, effective; 4. Please hold the handrail up and down the stairs; 5. Clear clearance or maintenance operations; 6. Wear labor protection goods and check the safety of stacking items on the operation platform; 7. Wear the earplugs to protect your hearing. 1. 设备的转动部位安装防护罩; 2. 按要求佩戴防尘口罩和面罩; 3. 操作时不要湿手接触电器开关，定期检查设备漏电保护装置齐全、有效; 4. 上下楼梯请扶好扶手; 5. 清仓或维修作业执行审批程序; 6. 穿戴好劳保护品，检查各平台的物品堆放安全性; 7. 佩戴好耳塞，保护听力。

6. Equipment 工具/ 设备

4314-BIN-001/002	Bin料仓
4314-DUC-001/002	Dust Collector除尘器
4314-ADG-001/002	Star Ash Discharge Valve星型卸灰阀
4314-CHE-001/002	Air Chute空气溜槽
4314-CHE-003/004	Chute溜槽
	Clean the site tools清扫现场工具

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

7. Procedure 程序

№	Stage	Key Points
1	General Check 普查	1. Confirm the pre-job technical training; 2. Wear suitable labor protection products, check and confirm that there is no unsafe state or safety risks on the site; 3. Check and clean the equipment and the site sanitation; 4. Contact with the process before and after and give clear instructions. 1. 确认经过岗前技术培训; 2. 穿戴好适合的劳保护品，检查确认现场没有存在不安全状态或安全隐患; 3. 检查并打扫设备、现场卫生; 4. 与前后工序取得联系，并发出明确指令。
2	Inspect Dust Collector Fan(4314-FAN-001/002/005) 检查除尘风机(4314-FAN-001/002)	1. Manual turning 2~3 turn, flexible rotation, no scraping, stuck and other abnormal phenomena; 2. The fan air outlet valve is normal, and the fan inlet valve is closed; 3. Close the power switch, first click to confirm the correct steering, no noise and other abnormal conditions; 4. After the fan starts and runs, observe the change of the fan sound, check the vibration and noise of the fan bearing and motor bearing, and check the vibration of the fan (including impeller and connector); 5. Check whether the lubricating oil level of the fan is normal. 1. 手动盘车2～3转，转动灵活，不得有刮蹭、卡住等异常现象; 2. 风机出风阀门正常，风机进口阀门关闭; 3. 合上电源开关，先点动确认转向正确、无杂音等异常情况; 4. 风机启动运行后，观察风机声音的变化，检查风机轴承、电机轴承的振动和噪声，检查风机振动(包括叶轮、联轴器); 5. 检查风机润滑油位是否正常。
3	Inspect Roots Fan(4314-FAN-003/004) 检查罗茨风机(4314-FAN-003/004)	1. Check before start-up a. Check whether the air inlet air filter is unblocked and whether the filter inlet is fully open; b. Check whether the pipe, valve, muffler, air filter, etc. are stable; c. Manual disc moving coupling or pulley two or three

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		laps, check whether stuck; d. Check the running direction of the fan, with the arrow direction marked on the fan protective cover shall prevail; e. Check the lubricating oil in the gear tank to ensure that the oil mark is added to the specified mark and the oil quality is qualified; f. Check that the valves and bypass valves on the inlet and outlet pipes are all open to ensure that the pipeline is smooth. 2. Start and run a. It is strictly prohibited to start with pressure, should open the vent valve before starting, and then start the fan, to confirm that the fan inlet valve is fully open, the outlet valve is fully closed, start the motor power supply; b. When the outlet pressure of the fan is higher than the operating pressure, gradually open the air valve, and adjust to the required flow, the fan begins to operate normally, and the vent valve can be slowly closed only after the fan is operated normally; c. The fan is running at full load but not overloaded. It is strictly prohibited to completely close the air duct to avoid accidents; and the air volume cannot be adjusted through the valve, and should be adjusted by bypass; d. After the equipment, observe whether each instrument is in good working condition and the data is normal; e. During the operation of the fan, check whether the temperature of the bearing and lubricating oil is normal. When the equipment operates under rated condition, the temperature rise of the bearing shall not be higher than 55℃, and the temperature of the lubricating oil in the tank shall not exceed 65℃; f. Check whether there is abnormal sound and abnormal movement of the fan. If there is abnormal sound such as impact sound, it should be shut down immediately and can be restarted after the fault is eliminated. 3. Stop a. The normal shutdown of Roots fan is to first open the bypass pipe and "vent". After the wind pressure drops (basically zero), the power can be cut off, and then close the intake valve system. The abnormal

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		shutdown should also consider opening the bypass pipe for "vent". 1. 启动前的检查 a. 检查进风口空气滤清器是否畅通，滤清器进口是否完全打开； b. 检查管道、阀门、消声器、空气滤清器等是否稳固； c. 手动盘动联轴器或带轮两三圈，检查是否灵活； d. 检查风机运转方向，以风机防护罩上标注的箭头方向为准； e. 检查齿轮油箱内润滑油，确保按规定牌号加到油标线的中位且油质合格； f. 检查进出口管道上的阀门及旁路阀门等全部为可开启状态，确保管路畅通。 2. 启动和运行 a. 严禁带压启动，启动前应先打开放空阀，然后才能启动风机，要确认风机进气阀全开，出气阀全关，此时启动电机电源； b. 当风机出口压力高于操作压力时逐步打开出风阀门，调节到所需流量，风机开始正常运转，待风机运转正常后方可将放空阀缓慢关闭； c. 风机满载运行但不得超载运行，运行中严禁完全关闭出风道，以免造成事故；并且风量不能通过阀门调整，应通过旁路调整； d. 设备启动后要观察各仪表是否处于良好工作状态且数据正常； e. 风机运转过程中，应检查轴承和润滑油温度是否正常，设备在额定工况下运转时，轴承温升不得高于55℃，油箱内润滑油温度不得超过65℃； f. 检查风机是否有异响和异动，若发现有撞击声、摩檫声等异响异动，应立即停机，待故障消除后方可重新启动。

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		3. 停机 a. 罗茨风机的正常停机是首先打开旁通管，进行“放风”，待风压降下来后(基本为零)，才能切断电源，然后关闭进气阀系统；非正常停机也应首先考虑打开旁通管，进行“放风”。
4	Inspect Pneumatic Conveying(4314-PCV-001) 检查气力输送泵(4314-PCV-001)	1. The bolts of the pump body are reliably connected and well sealed; 2. The air source control instrument is complete, correct arrangement, reliable connection; 3. Delivery pump assembly is installed correctly, reliable connection between the parts and well sealed; 4. Check whether the electrical equipment and the grounding wire are in good condition; 5. All the pneumatic conveying systems are fixed firmly as required, and the fasteners are fastened; 6. Check the operation of each valve, requiring each valve to operate in place, open and close flexibly; 7. Check whether the PLC control system is normal; 8. Ontology test a. Connect the control air source with a pressure of 0.5MPa to the air inlet of the gas control box; b. Manual operation of the solenoid valve to control the opening of the feed valve, check whether the opening of the valve meets the requirements, and close the cone valve and the seal ring is consistent, and pour water in the close of the place to check the sealing effect, if there is no leakage is qualified; c. Manually operate the solenoid valve to check whether the exhaust valve is flexible. 9. Air tightness test of the whole machine (including gas source pipeline and discharge pipe) Close the pressure relief valve at the end of the discharge pipe (remove after passing the test), operate the feed solenoid valve to close the inlet valve; manually open the inlet valve, close the air source stop valve, maintain the pressure, and conduct the following checks: a. Apply soap to the joints and bolt holes to see whether there are bubbles to check the air leakage; b. Pour soapy water into the sealing ring between the feed valve and the pump body and check the sealing condition; c. If any air leakage is found, stop the test, close the intake valve, open the pressure relief valve, release

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		the pressure to the warehouse pump is zero, and then find out the cause of the air leakage for treatment. After the treatment, boost the pressure inspection until the air leakage, the air tightness test is qualified. Then turn the intake valve to the automatic position. 10. Before the pneumatic conveying pump is opened, the actuator is closed, the star ash discharge valve (4314-ADG-001/002) is closed, start the Roots fan (4314-FAN-003/004), open the intake valve, no-load test for 5~10 minutes, blow away the pipeline debris and welding slag; 11. After the successful no-load test run, open the bin (4314-BIN-001/002) (4314-ADG-001/002) and feed. 1. 泵体各螺栓连接可靠，密封良好； 2. 控制气源的仪表齐全，排列正确，连接可靠； 3. 输送泵总成安装正确，各部分之间连接可靠、密封良好； 4. 检查电气设备和接地线是否完好； 5. 所有气力输送系统按要求固定牢固，紧固件紧固； 6. 进行各阀门的动作检验，要求各阀门动作到位，开、闭灵活； 7. 检查PLC控制系统是否正常； 8. 本体检验 a. 将压力≥0.5MPa 的控制气源接至气控箱进气口； b. 手动操作电磁阀控制进料阀的开启，检查开启时阀门的开度是否满足要求，以及关闭时锥阀与密封圈是否吻合完好，并以水倒在其密合处检查密封效果，如无任何渗漏则合格； c. 手动操作电磁阀检查排气阀开启是否灵活。 9. 整机气密性试验（含气源管路及出料管） 关闭出料管端泄压阀（测试合格后拆除），操作进料电磁阀，使进料阀关闭；手动开启进气阀，待气压上升，关闭气源截止阀，保压并进行下列检查： a. 各连接处、螺栓孔处涂上皂液看是否有泡以检查漏气情况；

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		b. 在进料阀与泵体间的密封圈密封处倒肥皂水，检查其密封情况； c. 如发现漏气，应停止试验，关闭进气阀，打开泄压阀，泄压至仓泵内压力为零时，再找出漏气原因进行处理。处理完毕后再升压检查，直至完全不漏气为止，则气密性试验合格。然后将进气阀调至自动位置。 10. 气力输送泵开启之前，执行结构关闭，星型卸灰阀(4314-ADG-001/002)关闭，启动罗茨风机(4314-FAN-003/004)，打开进气阀，空载试验5～10分钟，将管路杂物和焊渣吹走； 11. 空载试运转成功后，打开料仓(4314-BIN-001/002)的星型卸灰阀(4314-ADG-001/002)并给料。
5	Inspect Buried Scraper Conveyor(4314-SCV-001) 检查埋刮板输送机(4314-SCV-001)	1. Check whether the bolts are fastened; 2. All bearings, transmission parts and speed reducer shall be equipped with sufficient lubricating oil; 3. Comprehensively check whether all parts of the conveyor are intact and whether the tightness of the scraper chain is appropriate; 4. Before driving, it should be determined whether the rotation direction of the motor meets the work requirements; 5. Check whether the scraper chain and drive device are in good condition; 6. Manual drive and observe whether the scraper chain touches or deviates with the housing card. 1. 检查各螺栓是否紧固； 2. 所有轴承、传动部件和减速器内应有足够的润滑油； 3. 全面检查输送机各部分是否完好无损，刮板链条松紧度是否合适； 4. 开车前应判明电机旋转方向是否符合工作要求； 5. 检查刮板链条和驱动装置是否完好无损； 6. 手动盘车，观察刮板链条是否与壳体卡碰或跑偏。
6	Check the other Equipment and Facilities	1. Bin(4314-BIN-001/002) a. Check whether the inlet and outlet pipes and auxiliary pipes and flanges of each warehouse meet

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
	检查其它设备设施	the requirements, and whether the seal of each warehouse is in good condition; b. Check the material level control assembly for normal operation. 1. 料仓(4314-BIN-001/002) a. 检查料仓出入口管路及附属管路、法兰是否符合要求，料仓密封是否完好； b. 检查料位控制组件是否正常。 2. Dust Collector(4314-DUC-001/002) a. Whether the electrical high and low voltage system and PLC control are normal; b. Whether the inlet valve of the filter chamber of each unit is open; c. Whether all the solenoid pulse valves are normal and the action sequence is correct; d. All measurement circuits are normal and signal; e. All control valves are in the automatic mode and in the desired position; f. Open all inspection entrances and doors to check whether the equipment moving parts are stuck in dust or external objects; after inspection, close all inspection population and doors and check all pipes and equipment inspection holes for closure; g. Whether the sealing strip of the air chamber is sealed, and whether the fastening bolt of air box sealing cover is in good condition; h. Connect the pressure measuring device to the pressure measuring port of the bag filter; i. Check whether the bag back blowing pressure is 0.4MPa~0.5MPa; j. Check whether the compressed air ball valve (***) is normal;Start the fan, observe the air load running resistance, and measure the air volume of the inlet and outlet; k. Check whether the water drain trap is normal; l. Check whether the bag dust bag falls off and whether there is ash phenomenon at the fan outlet. 2. 除尘器(4314-DUC-001/002) a. 电气高低压系统、PLC控制是否正常； b. 除尘器各单元过滤室的进口阀门是否都打开； c. 所有电磁脉冲阀是否正常，动作顺序正确； d. 所有测量回路是否正常、有信号；

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		e. 所有提升阀处于自动模式和需要的位置； f. 打开所有检查入口、门，检查设备运动部件是否被灰尘或外来物卡住；检查后，关闭所有检查人口、门，并检查所有管道和设备检查孔是否关闭； g. 反吹风气室密封条是否是密封完好，气箱密封盖紧固螺栓是否完好； h. 接通测压装置到除尘器的测压口； i. 检查反吹风压力是否是0.4MPa ~ 0.5MPa； j. 检查压缩空气球阀(***)是否正常；启动风机，观察空负荷运行阻力，测量进出风口的风量； k. 检查疏水阀是否正常； l. 检查布袋除尘器布袋是否脱落，风机出口是否有冒灰现象。 3. Star Ash Discharge Valve(4314-ADG-001/002) a. Check that the rotor is rotated in the correct direction. 3. 星型卸灰阀(4314-ADG-001/002) a. 检查转子的旋转方向是否正确。 4. Air Chute(4314-CHE-001/002) and Chute(4314-CHE-003/004) a. Check whether the feeding chute is in good condition; b. Check whether the blocking material detection switch of the lower feeding chute is normal. 4. 空气溜槽(4314-CHE-001/002)和溜槽(4314-CHE-003/004) a. 检查各下料溜槽是否完好； b. 检查下料溜槽的堵料检测开关是否正常。
7	Inspect Materials Level 检查物料料位	1. Check the material level of each warehouse (4314-BIN-001/002) to ensure sufficient material; 2. Check whether the pneumatic conveying (4314-PCV-001) and the pipeline have stored; 3. Check whether the material is stored in the buried scraper conveyor(4314-SCV-001)； 4. Check whether the dust collector(4314-DUC-001/002)

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		has ash; 5. Check the air chute(4314-CHE-001/002) and chute(4314-CHE-003/004)has ash. 1. 检查各仓(4314-BIN-001/002)料位，确保物料充足； 2. 检查气力输送泵(4314-PCV-001)内是否存料，管路是否存料； 3. 检查埋刮板输送机(4314-SCV-001)内是否存料； 4. 检查除尘器(4314-DUC-001/002)是否存灰； 5. 检查空气溜槽(4314-CHE-001/002)和溜槽(4314-CHE-003/004)是否存料。
8	Start-Up Of Standby Aster Post 备用焙砂仓岗位开机	1. No-load start should be guaranteed when starting; 2. The driving sequence is along the material direction, from back to front that is the reverse drive, Each equipment needs to be switched on later;At the same time, confirm that the process behind the standby aster post has been started and has the feeding conditions: Turn on buried scraper conveyor(4314-SCV-001)⟹ Turn on star ash discharge valve(4314-ADG-001/002) ⟹Turn on dust collector fan(4314-FAN-001/002) ⟹Turn on dust collector(4314-DUC-001/002) ⟹Turn on roots fan(4314-FAN-003/004)⟹ Turn on pneumatic conveying(4314-PCV-001). 1. 启动时应保证空载启动； 2. 开车顺序为沿物料走向，从后往前开即逆向开车，各设备都需要延时开启；同时，确认备用焙砂仓岗位后面的工序已经开车并具备给料条件： 开启埋刮板输送机(4314-SCV-001)⟹开启星型卸灰阀(4314-ADG-001/002)⟹开启除尘风机(4314-FAN-001/002)⟹开启除尘器(4314-DUC-001/002) ⟹开启罗茨风机(4314-FAN-003/004)⟹开启气力输送泵(4314-PCV-001)。
9	The Standby Aster Post Stops 备用焙砂仓岗位停机	1. Orderly shutdown a. The materials in the standby machine should be discharged before stopping; b. Stop in the reverse order of driving order, Each equipment needs to stop: Stop the pneumatic conveying(4314-PCV-001) ⟹Stop the roots fan(4314-FAN-003/004) ⟹Stop the dust collector(4314-DUC-001/002) ⟹Stop the dust collector fan(4314-FAN-

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		001/002)⟹Stop the star ash discharge valve(4314-ADG-001/002)⟹Stop the buried scraper conveyor(4314-SCV-001)⟹Clean the site for hygiene. 1. 正常停车 a. 停车时应待机内物料排净后再停车； b. 按照开车顺序逆序停车，各设备都需要延时停止： 停止气力输送泵(4314-PCV-001)⟹停止罗茨风机(4314-FAN-003/004)，停止除尘器(4314-DUC-001/002)⟹停止除尘风机(4314-FAN-001/002)⟹停止星型卸灰阀(4314-ADG-001/002)⟹停止埋刮板输送机(4314-SCV-001)⟹打扫现场卫生。 2. Emergency Stop a. When an emergency occurs, Stop the pneumatic conveying(4314-PCV-001), roots fan(4314-FAN-003/004), dust collector fan(4314-FAN-001/002), buried scraper conveyor(4314-SCV-001), After all stop operation, check whether the start/stop button of each equipment is in the stop state, close the star ash discharge valve(4314-ADG-001/002), at the same time, the upper level of equipment all need to stop; b. After the accident, the equipment is restored to normal. If production still needs to be conducted, and the operation shall be restarted in the driving sequence; c. After the accident treatment, the equipment returns to normal. If the production is not necessary, operate according to the normal parking order. 2. 紧急停车 a. 当出现紧急事故，关闭气力输送泵(4314-PCV-001)、罗茨风机(4314-FAN-003/004)、除尘风机(4314-FAN-001/002)、埋刮板输送机(4314-SCV-001)，全部停止运行后，检查各设备的启动/停止按钮是否处于停止状态，关闭星型卸灰阀(4314-

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		ADG-001/002)，同时，上一级设备均需停车； b. 事故处理后，设备恢复正常，如仍需要进行生产，按照开车顺序重新启动操作； c. 事故处理后，设备恢复正常，如不需要进行生产，按照正常停车顺序进行操作。
10	Permits ＆Isolation Sheets 许可证和隔离表	1. Only authorised isolators can sign off and cancel permits and registration sheets. 1. 只有经过授权的隔离者才能签署和取消许可证和登记表。

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

8. Standby Aster Post 备用焙砂仓岗位 Questionnaire

Declaration of Understanding

I (_____Learner_____) have completed the theory assessment and had all my valid, reliable, and consistent with my level of knowledge in the assessment task.

Signature
Date:

I (_____Assessor_____) have witnessed the above learner complete the theory assessment and believe the assessment has provided a valid, reliable, and consistent result.

Signature
Date:

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

9. Appendix

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

Standard Operating Procedure
标准操作程序

Standby aster posts in the chloride plant
CP 备用焙砂仓岗位

SOP Details 程序明细

Processing Department 氯化厂	Procedure Level 程序级别: **3**	Revision Number 修订编号: 0
Date Approved 审批日期:	Date Issued 颁布日期:	Next Review Date 下次审核日期:
Details of Revision 修订明细:		

Revision Details 修订明细

Rev. No 版本号	Date 日期	Section 章节	Page 页码	Revision Description 修订说明	Reviewed By 审核人
1					
2					
3					

Approvals 批准

Document Owner 程序持有人	Song Yuhua 宋裕华	Date: 日期: 2024.4.24	Signature 签字	
Processing Superintendent 氯化高级副经理	Cao Guibin 曹桂宾	Date: 日期: 2024.4.24	Signature 签字	
Processing Senior Manager 氯化高级经理	Li Jianjun 李建军	Date: 日期: 2024.04.24	Signature 签字	
Safety Department Manager 安全部经理	Airlangga Putra R.J	Date: 日期: 24.04.24	Signature 签字	
Deputy General Manager 副总经理	Li Xinhua 李新华	Date: 日期 2024.4.24	Signature 签字	
General Manager 总经理	Clark Wu 吴迎林	Date: 日期: 2024.4.24	Signature 签字	