PT MERDEKA TSINGSHAN INDONESIA

STANDARD OPERATING PROCEDURE

LIME MILK PREPARATION POST

石灰乳制备岗位

MTI-CHP-CPM-SOP-017_Rev. 000

Information Security Classification
B – Business Information

Rev.	Revision Status	Date	Prepared by	Reviewed by	Approved by
0	Issued for Use	24-APR-2024	*Approval as attached*	*Approval as attached*	*Approval as attached*
C0	Issued for Approval	24-APR-2024	Song Yuhua	Li Jianjun	Clark Wu
B0	Issued for Review	24-APR-2024	Song Yuhua	Li Jianjun	
A0	Issued for Internal Discipline Review	24-APR-2024	Song Yuhua		

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

DOCUMENT CHANGE STATUS

No.	Page	Section	Change Log	Revision by	Revision date	Revision version
1.						
2.						
3.						

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

Table of Contents

DOCUMENT CHANGE STATUS 2
Table of Contents 3
1. Purpose 目的 4
2. Functional Description 功能说明 4
3. References 参考 4
4. PPE 个人保护装备 4
5. Hazards & Control 危害与控制 5
6. Equipment 工具/ 设备 6
7. Procedure 程序 6
8. Lime Milk Preparation Post 石灰乳制备岗位 Questionnaire 17
9. Appendix 18

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

1. Purpose 目的

This procedure covers the operator's responsibility for visual inspection, start up and shutdown of the lime milk preparation post under complete closure.

此程序涵盖操作员对完全关闭下的石灰乳制备岗位进行目视操作前检查、启动运行和停车的责任。

2. Functional Description 功能说明

It is the responsibility of the operator to ensure that the lime milk preparation post is visually inspected before and after each shift to determine whether it can start and operate safely, or whether other activities (such as maintenance and repair or other operator tasks) must be performed before starting, to determine the sequential operation method of the lime milk preparation post and smooth operation, Stop order of normal stops and emergency stops.

操作员有责任确保在从停机启动之前和每个班次开始时对石灰乳制备岗位进行目视检查，确定是否可以启动并安全运行，或者是否必须在开始启动之前执行其他活动(例如维护修理或其他操作员任务)，确定石灰乳制备岗位的按照顺序启动的操作方法及平稳运行，正常停车和紧急停车的停止顺序。

3. References 参考

- MTI-CP-SOP-Post Technical Operation Procedures.MTI-CP-SOP岗位操作规程
- Screw Conveyor(4524-CNV-001/002).螺旋输送机(4524-CNV-001/002)
- Lime Pump(4524-PSL-003/004/007/008).石灰乳输送泵(4524-PSL-003/004/007/008)
- Lime Preparation Tank(4524-TNK-001/002).石灰乳制备槽(4524-TNK-001/002)
- Lime Storage Tank(4524-TNK-003).石灰乳储槽(4524-TNK-003)

4. PPE 个人保护装备



This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

5. Hazards & Control 危害与控制

Description of Hazard / Environmental Issue 危害	Control Strategy 控制
1. Mechanical injury; 2. Dust; 3. Electric shock; 4. Slippery conditions and a trip to the danger; 5. Asphyxia; 6. Liquid corrosion; 7. Object falling from high altitudes; 8. Vehicle collision crush; 9. Liquid sputtering; 10. Noise. 1. 机械伤害; 2. 灰尘; 3. 触电; 4. 湿滑的条件，绊倒危险; 5. 窒息; 6. 液体腐蚀; 7. 高空坠物; 8. 车辆碰撞碾压; 9. 液体喷溅; 10. 噪音。	1. Install a protective cover on the rotating part of the equipment; 2. Wear dust mask as required; 3. Do not contact the electrical switch with wet hands during operation,Regular inspection of the equipment leakage protection device is complete, effective; 4. Please hold the handrail up and down the stairs; 5. Clearclearance or maintenance operations; 6. Wear appropriate labor protection supplies, once the skin contact with hydrochloric acid solution, immediately rinse with a lot of water; 7. Wear labor protection goods and check the safety of stacking items on the operation platform; 8. Walk along the prescribed route, and stay away from the lime transport vehicles; 9. Wear protective masks and gloves, as well as other protective products as required; 10. Wear the earplugs to protect your hearing. 1. 设备的转动部位安装防护罩; 2. 按要求佩戴防尘口罩; 3. 操作时不要湿手接触电器开关，定期检查设备漏电保护装置齐全、有效; 4. 上下楼梯请扶好扶手; 5. 清仓或维修作业执行审批程序; 6. 穿戴适宜的劳保用品，一旦皮肤接触到盐酸溶液，立即用大量清水冲洗; 7. 穿戴好劳保护品，检查各平台的物品堆放安全性; 8. 按照规定的路线行走，远离石灰运输车辆; 9. 按要求戴好防护面具和防护手套，以及其它劳保护品; 10. 佩戴好耳塞，保护听力。

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

6. Equipment 工具/ 设备

4524-BIN-001/002/003/004	Lime Silos石灰仓
4524-AGT-001/002	Agitator Of Lime Preparation Tank石灰乳制备槽搅拌器
4524-AGT-003	Agitator Of Lime Storage Tank石灰乳储槽搅拌器
4524-DUC-001/002/003/004	Dust Collector除尘器
4524-ADG-001/002/003/004	Discharge Valve卸料阀
4524-PSU-001	Chemical submerged pump药剂液下泵
	Clean the site tools清扫现场工具

7. Procedure 程序

№	Stage	Key Points
1	General Check 普查	1. Confirm the pre-job technical training; 2. Wear suitable labor protection products, check and confirm that there is no unsafe state or safety risks on the site; 3. Check and clean the equipment and the site sanitation; 4. Contact with the process before and after, and give clear instructions. 1. 确认经过岗前技术培训; 2. 穿戴好适合的劳保护品，检查确认现场没有存在不安全状态或安全隐患; 3. 检查并打扫设备、现场卫生; 4. 与前后工序取得联系，并发出明确指令。
2	Inspect Screw Conveyor (4524-CNV-001/002) 检查螺旋输送机(4524-CNV-001/002)	1. Check whether the lubricating grease in the bearing is appropriate; 2. Check whether the oil quality and quantity of the lubricating oil in the reducer are normal; 3. Check whether the bolts are fastened; 4. Check whether the cover plate of the screw conveyor must be tightly covered and whether the conveyor is clean; 5. Check whether the spiral blade is deformed ; 6. Determine whether the rotation direction of the motor meets the work requirements; 7. Check whether the spray head of the screw conveyor is normal and blocked. 1. 检查轴承内润滑脂是否合适; 2. 检查减速机内的润滑油油质、油量是否正常; 3. 检查各螺栓是否紧固; 4. 检查螺旋输送机的盖板必须盖严，输送机内是否清理干净; 5. 检查螺旋叶片是否变形; 6. 判明电机旋转方向是否符合工作要求;

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		7. 检查螺旋输送机的喷淋头是否正常，是否堵塞。
3	Inspect Lime Pump(4524-PSL-001/002/003/004) 检查石灰乳输送泵(4524-PSL-003/004/007/008)	1. Check whether the pump inlet pipeline and auxiliary pipeline, flange and valve installation meet the requirements, whether the anchor bolts and ground wire are good, and whether the coupling is installed; 2. Turn the pump shaft 3 times, should be flexible without block; 3. Check whether the lubricating oil level is normal. The oil level should be between 1/2 and 2/3 of the oil lens; 4. Check the sealing condition of the pump is normal; 5. Point to move to confirm the correct steering; 6. Check whether the voltage meter, signal lamp and other meters of the pump control cabinet are normal; 7. Check whether the pump unit has air, if so, should be excluded; 8. Check whether the pump head is under the level of the lime preparation tank(4524-TNK-001/002) or Lime storage tank(4524-TNK-003). 1. 检查泵出入口管线及附属管线，法兰、阀门安装是否符合要求，地脚螺栓及地线是否良好，联轴器及防护罩是否装好； 2.手转动泵轴3圈，应灵活无阻滞； 3.检查润滑油油位是否正常，油位应在油镜的1/2 ~ 2/3 之间； 4.检查泵的密封状况是否正常； 5. 点动确认转向正确； 6. 检查泵控制柜电压表、信号灯等仪表指示是否正常； 7. 检查泵机组是否有空气，如有应予以排除； 8. 检查泵头是否处于石灰乳制备槽(4524-TNK-001/002)或石灰乳储槽(4524-TNK-003)液位下。
4	Inspect Lime Preparation Tank (4524-TNK-001/002), Lime Storage Tank(4524-TNK-003) 检查石灰乳制备槽(4524-TNK-001/002)，石灰乳储槽 (4524-TNK-003)	1. Check whether the inlet and outlet pipelines and auxiliary pipelines, whether the installation of flange and valve meet the requirements, and whether the slurry storage tank leaks liquid; 2. Check the level control assembly is normal. 1. 检查出入口管线及附属管线，法兰、阀门安装是否符合要求，储浆槽是否漏液； 2. 检查液位控制组件是否正常。
5	Check the other Equipment and Facilities	1. Lime silos(4524-BIN-001/002/003/004) a. Check whether the inlet and outlet pipes and auxiliary pipes and flanges of each warehouse meet

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
	检查其它设备设施	the requirements, and whether the seal of each warehouse is in good condition; b. Check the material level control assembly for normal operation. 1. 石灰仓(4524-BIN-001/002/003/004) a. 检查各仓出入口管路及附属管路、法兰是否符合要求，各仓密封是否完好； b. 检查料位控制组件是否正常。 2. Dust Collector(4524-DUC-001/002/003/004) a. Whether the electrical high and low voltage system and PLC control are normal; b. Whether the inlet valve of the filter chamber of each unit is open; c. Whether all the solenoid pulse valves are normal and the action sequence is correct; d. All measurement circuits are normal and signal; e. All control valves are in the automatic mode and in the desired position; f. Open all inspection entrances and doors to check whether the equipment moving parts are stuck in dust or external objects; after inspection, close all inspection population and doors and check all pipes and equipment inspection holes for closure; g. Whether the sealing strip of the air chamber is sealed, and whether the fastening bolt of air box sealing cover is in good condition; h. Connect the pressure measuring device to the pressure measuring port of the dust collector; i. Check whether the bag back blowing pressure is 0.4MPa~0.5MPa; j. Check whether the compressed air ball valve (25BA) is normal; Start the fan, observe the air load running resistance, and measure the air volume of the inlet and outlet; k. Check the operation condition of the ash removal device of the dust collector. 2. 除尘器(4524-DUC-001/002/003/004) a. 电气高低压系统、PLC控制是否正常； b. 除尘器各单元过滤室的进口阀门是否都打开； c. 所有电磁脉冲阀是否正常，动作顺序正确； d. 所有测量回路是否正常、有信号； 所有调节阀处于自动模式和需要的位置； 打开所有检查入口、门，检查设备运动部件是否被灰尘或外来物卡住；检查后，关闭所有检查人

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		口、门，并检查所有管道和设备检查孔是否关闭； e. 反吹风气室密封条是否是密封完好，气箱密封盖紧固螺栓是否完好； f. 接通测压装置到除尘器的测压口； g. 检查反吹风压力是否是0.4MPa ~ 0.5MPa； h. 检查压缩空气球阀是否正常；启动风机，观察空负荷运行阻力，测量进出风口的风量； i. 检查除尘器排灰装置工作情况。 3. Agitator of lime preparation tank and agitator of lime storage tank(4524-AGT-001/002/003) a. Check whether the screws of the mixing paddle are fastened; b. Check whether the positive and reverse version of the agitator is correct; c. Check the surface of the mixer is smooth, without rough and pitting phenomenon; d. Check whether the mechanical seal of the mixer is good and whether the oil seal is normal; e. Electric mixer idling, check for abnormal sound, whether the up and down are concentric or shaking. 3. 石灰乳制备槽搅拌器和石灰乳储槽搅拌器(4524-AGT-001/002/003) a. 检查搅拌桨的螺丝是否紧固； b. 检查搅拌器的正反转是否正确； c. 检查搅拌器的搅拌桨表面光滑，无粗糙和点蚀现象； d. 检查搅拌器的机械密封是否良好，各油封是否正常； e. 电动搅拌器进行空转，检查是否有异常声响，上下是否同心或摇晃。 4. Chemical submerged pump(4524-PSU-001) a. Check whether there is debris in the lower pump tank and the pipeline blockage; b. Check whether the fastening screws of the equipment and motor are loose, whether the bearing is intact, and whether the lubricating oil is intact; c. Check whether the electrical part of the equipment is in good condition and whether the motor shell is

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		well grounded; d. Check whether the steering of the motor is correct; e. Check whether the pump head is under the ground trough liquid level. 4. 药剂液下泵(4524-PSU-001) a. 检查液下泵槽内有无杂物，管路堵塞情况； b. 检查设备、电机的紧固螺丝是否松动，轴承是否完好，润滑油是否完好； c. 检查设备电气部分是否完好，电机外壳是否接地良好； d. 检查电机的转向是否正确； e. 检查泵头是否处于地槽液位下。 5. Valve a. Check the new water gate valve (150GA,150GA) of the lime milk preparation tank (4524-TNK-001/002) and the bottom gate valve (100GA,100GA); New water stop valve (25GB,25GB) for the spiral conveyor (4524-CNV-001/002); Lime milk conveying pump (4524-PSL-007/008) inlet three gate valves (100BF,100BF,100BF,100BF,100BF,100BF), two check valves (80CH,80CH) and two butterfly valves (80BF,80BF); Bottom gate valve (100GA) of lime milk storage tank (4524-TNK-003); Lime milk delivery pump (4524-PSL-003/004) inlet three gate valves (125BF,125BF,125BF), two check valves (100CH100CH) and two butterfly valves (100BF,100BF) and lime bin (4524-BIN-001/002/003/004) feeding valve (4524-ADG-001/002/003/004) whether it is intact and flexible. 5. 阀门 a. 检查石灰乳制备槽(4524-TNK-001/002)的新水闸阀(150GA,150GA)，底部闸阀(100GA,100GA)；螺旋输送机(4524-CNV-001/002)的新水截止阀(25GB,25GB)；石灰乳输送泵(4524-PSL-007/008)入口六个闸阀(100BF,100BF,100BF,100BF,100BF,100BF)，出口两个止回阀(80CH,80CH)、两个蝶阀(80BF,80BF)；石灰乳储槽(4524-TNK-003)的底部闸阀(100GA)；石灰乳输送泵(4524-PSL-003/004)入口三个闸阀

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		(125BF,125BF,125BF)，出口两个止回阀(100CH,100CH)、两个蝶阀(100BF,100BF)；石灰仓(4524-BIN-001/002/003/004)卸料阀门(4524-ADG-001/002/003/004)是否完好、灵活。
6	Inspect Materials Level 检查物料料位	1. Check the material position of each warehouse to ensure sufficient lime (4524-BIN-001/002/003/004); 2. Check whether the material is stored in the spiral conveyor (4524-CNV-001/002); 3. Check whether the lime milk preparation tank (4524-TNK-001/002) is filled with raw water; 4. Check whether there are empty grooves in the lime milk storage tank (4524-TNK-003)； 5. Check whether the dust collector(4524-DUC-001/002/003/004) has ash. 1. 检查各仓料位，确保石灰充足(4524-BIN-001/002/003/004)； 2. 检查螺旋输送机(4524-CNV-001/002)内是否存料； 3. 检查石灰乳制备槽(4524-TNK-001/002)内是否充满新水； 4. 检查石灰乳储槽(4524-TNK-003)内是否是空槽； 5. 检查布袋除尘器(4524-DUC-001/002/003/004)是否存灰。
7	Start-Up Of The Lime Milk Preparation Post 石灰乳制备岗位开机	1. No-load start should be guaranteed when starting; 2. The driving sequence is along the material direction, from back to front that is the reverse drive, Each equipment needs to be switched on later;At the same time, Confirm that the process behind the lime milk preparation post has been started and has the feeding conditions: Open the new water brake valve (150GA) of the lime milk preparation tank (4524-TNK-001/002) and fill it with new water ⟹ Start the lime milk preparation tank (4524-AGT-001/002) of the lime milk preparation tank (4524-TNK-001/002) ⟹ Open the new water stop valve (25GB) of the spiral conveyor (4524-CNV-001/002) and start the spray system ⟹ Start the dust collector(4524-DUC-001/002/003/004) ⟹ Start the screw conveyor (4524-CNV-001/002), open the lime bin (4524-BIN-001/002/003/004) feeding valve (4524-ADG-001/002/003/004) ⟹ After the preparation of the lime milk in the lime milk preparation tank (4524-TNK-

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		001/002), start the lime milk storage tank mixer (4524-AGT-003) in the lime milk storage tank (4524-TNT-003) ⟹ Open the lime milk conveying pump (4524-PSL-007/008) outlet two check valves (80 CH), two butterfly valves (80BF), start the lime milk conveying pump (4524-PSL-007/008), open the lime milk conveying pump (4524-PSL-007/008) inlet three gate valves (100BF), pump the prepared lime milk into the lime milk storage tank (4524-TNK-003)⟹ After the preparation of the lime milk pump in the lime milk preparation tank (4524-TNK-001/002), close the three gate valves (100BF) of the lime milk conveying pump (4524-PSL-001/002), stop the lime milk conveying pump (4524-PSL-001/002), and close the lime milk conveying pump (4524-PSL-001/002) outlet two check valves (80CH) and two butterfly valves (80BF) ⟹ At this point, complete one stage of lime milk preparation; then, prepare the lime milk in turn⟹ When lime milk is required for positions such as desulfurization tower (4306-TOW-004), neutralization tank (4402-TNK-002/003), iron channel (4402-TNK-011/012) and lead-zinc tank (4402-TNK-014/015), Open the lime milk conveying pump (4524-PSL-003 / 004) outlet two check valves (100 CH), two butterfly valves (100BF), start the lime milk conveying pump (4524-PSL-003/004), open the three gate valves (125BF) of the lime milk conveying pump (4524-PSL-001/002), Pump the lime milk stored in the lime milk storage tank (4524-TNK-003) into the required position. 1. 启动时应保证空载启动； 2. 开车顺序为沿物料走向，从后往前开即逆向开车，各设备都需要延时开启；同时，确认石灰乳制备岗位后面的工序已经开车并具备给料条件： 打开石灰乳制备槽(4524-TNK-001/002)的新水闸阀(150GA)，注满新水⟹启动石灰乳制备槽(4524-TNK-001/002)的石灰乳制备槽搅拌器(4524-AGT-001/002)⟹打开螺旋输送机(4524-CNV-001/002)的新水截止阀(25GB)，启动喷淋系统⟹启动除尘器(4524-DUC-001/002/003/004)⟹启动螺旋输送机(4524-CNV-001/002)，打开石灰仓(4524-BIN-001/002/003/004)卸料阀门(4524-ADG-001/002/003/004)⟹待石灰乳制备槽(4524-TNK-

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		001/002)的石灰乳制备完成后，启动石灰乳储槽(4524-TNK-003)的石灰乳储槽搅拌器(4524-AGT-003)⟹打开石灰乳输送泵(4524-PSL-007/008)出口两个止回阀(80CH)、两个蝶阀(80BF)，启动石灰乳输送泵(4524-PSL-007/008)，打开石灰乳输送泵(4524-PSL-007/008)入口三个闸阀(100BF)，将制备完成的石灰乳泵入石灰乳储槽(4524-TNK-003)⟹石灰乳制备槽(4524-TNK-001/002)内制备完成石灰乳泵完后，关闭石灰乳输送泵(4524-PSL-001/002)入口三个闸阀(100BF)，停止石灰乳输送泵(4524-PSL-001/002)，关闭石灰乳输送泵(4524-PSL-001/002)出口两个止回阀(80CH)、两个蝶阀(80BF)⟹此时，完成一个阶段的石灰乳制备；然后，轮番进行石灰乳的制备工作⟹待脱硫塔(4306-TOW-004)、中和槽(4402-TNK-002/003)、除铁槽(4402-TNK-011/012)和除铅锌槽(4402-TNK-014/015)等岗位需要石灰乳时，打开石灰乳输送泵(4524-PSL-003/004)出口两个止回阀(100CH,100CH)、两个蝶阀(100BF)，启动石灰乳输送泵(4524-PSL-003/004)，打开石灰乳输送泵(4524-PSL-001/002)入口三个闸阀(125BF)，将石灰乳储槽(4524-TNK-003)储备的石灰乳泵入所需的岗位。
8	The Lime Milk Preparation Post Stops 石灰乳制备岗位停机	1. Orderly shutdown a. The materials in the standby machine should be discharged before stopping; b. According to the reverse order of driving and material discharge order, each equipment needs to stop: When lime milk is not required for desulfurization tower (4306-TOW-004), neutralization tank (4402-TNK-002/003), iron channel (4402-TNK-011/012) and lead-zinc tank (4402-TNK-014/015), Close three gate valves (125BF) at the lime milk delivery pump (4524-PSL-007/008), Stop the lime milk conveying pump (4524-PSL-003/004), Close two check valves (100CH) of (4524-PSL-003/004) of lime milk conveying pump and two butterfly valves (100BF)⟹ Close the lime milk pump inlet three gate valves (100BF) (4524-PSL-007/008), stop the lime milk pump (4524-PSL-007/008), and close the lime milk pump (4524-PSL-

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		007/008) outlet two check valves (80CH) and two butterfly valves (80BF)⟹ Close the lime bin (4524-BIN-001/002/003/004) (4524-ADG-001/002/003/004) and stop the spiral conveyor (4524-CNV-001/002)⟹ Stop the new water stop valve (25GB) of the spiral conveyor (4524-CNV-001/002) and close the spray system⟹Stop the dust collector(4524-DUC-001/002/003/004)⟹ The lime milk storage tank mixer (4524-AGT-003) for stopping the lime milk storage tank (4524-TNT-003) ⟹ Stop the mixer (4524-AGT-001/002) for the lime milk preparation tank (4524-TNK-001/002) ⟹Clean the site for hygiene. 1. 正常停车 a. 停车时应待机内物料排净后再停车； b. 按照开车顺序逆序和物料排净顺序停车，各设备都需要延时停止： 待脱硫塔(4306-TOW-004)、中和槽(4402-TNK-002/003)、除铁槽(4402-TNK-011/012)和除铅锌槽(4402-TNK-014/015)等岗位不需要石灰乳时，关闭石灰乳输送泵(4524-PSL-007/008)入口三个闸阀(125BF)，停止石灰乳输送泵(4524-PSL-003/004)，关闭石灰乳输送泵(4524-PSL-003/004)出口两个止回阀(100CH)、两个蝶阀(100BF)⟹关闭石灰乳输送泵(4524-PSL-007/008)入口三个闸阀(100BF)，停止石灰乳输送泵(4524-PSL-007/008)，关闭石灰乳输送泵(4524-PSL-007/008)出口两个止回阀(80CH)、两个蝶阀(80BF)⟹关闭石灰仓(4524-BIN-001/002/003/004)卸料阀门(4524-ADG-001/002/003/004)，停止螺旋输送机(4524-CNV-001/002)⟹停止螺旋输送机(4524-CNV-001/002)的新水截止阀(25GB)，关闭喷淋系统⟹停止除尘器(4524-DUC-001/002/003/004)⟹停止石灰乳储槽(4524-TNK-003)的石灰乳储槽搅拌器(4524-AGT-003)⟹停止石灰乳制备槽(4524-TNK-001/002)的石灰乳制备槽搅拌器(4524-AGT-001/002)；打扫现场卫生。

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		2. Emergency Stop a. When an emergency occurs, Close screw conveyor(4524-CNV-001/002), lime pump(4524-PSL-003/004/007/008), lime preparation tank(4524-TNK-001/002), lime storage tank(4524-TNK-003), agitator of lime preparation tank(4524-AGT-001/002), agitator of lime storage tank(4524-AGT-003) and bag filter, After all stop the operation, Check whether the start / stop button of each device is in the stop state, Close new water brake valve (150GA) of lime emulsion preparation tank (4524-TNK-001/002), new water stop valve (25GB) for screw conveyor (4524-CNV-001/002), lime milk conveying pump (4524-PSL-007/008) has three gate valves (100BF), two check valves (80CH) and two butterfly valves (80BF); lime milk conveying pump (4524-PSL-003/004) has three gate valves (125BF), two check valves at the outlet (100CH) and two butterfly valves (100BF), at the same time, the next level of equipment all need to stop; b. After the accident, the equipment is restored to normal. If production still needs to be conducted, the operation shall be restarted in the driving sequence; c. After the accident treatment, the equipment returns to normal. If the production is not necessary, operate according to the normal parking order. 2. 紧急停车 a. 当出现紧急事故，关闭螺旋输送机(4524-CNV-001/002)，石灰乳输送泵(4524-PSL-003/004/007/008)，石灰乳制备槽(4524-TNK-001/002)，石灰乳储槽(4524-TNK-003)，石灰乳制备槽搅拌器(4524-AGT-001/002)，石灰乳储槽搅拌器(4524-AGT-003)和布袋除尘器，全部停止运行后，检查各设备的启动/停止按钮是否处于停止状态，关闭石灰乳制备槽(4524-TNK-001/002)的新水闸阀(150GA)，螺旋输送机(4524-CNV-001/002)的新水截止阀(25GB)，石灰乳输送泵(4524-PSL-007/008)入口三个闸阀(100BF)、出口两个止回阀(80CH)、两个蝶阀(80BF)；石灰乳输送泵(4524-PSL-003/004)入口三个闸阀(125BF)、出口两个止回阀(100CH)、两个蝶阀(100BF)，同时，下一级设备均需停车；

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

№	Stage	Key Points
		b. 事故处理后，设备恢复正常，如仍需要进行生产，按照开车顺序重新启动操作; c. 事故处理后，设备恢复正常，如不需要进行生产，按照正常停车顺序进行操作。
9	Permits &Isolation Sheets 许可证和隔离表	1. Only authorized isolators can sign off and cancel permits and registration sheets. 1. 只有经过授权的隔离者才能签署和取消许可证和登记表。

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

8. Lime Milk Preparation Post 石灰乳制备岗位 Questionnaire

Declaration of Understanding

I (_____Learner_____) have completed the theory assessment and had all my valid, reliable, and consistent with my level of knowledge in the assessment task.

Signature
Date:

I (_____Assessor_____) have witnessed the above learner complete the theory assessment and believe the assessment has provided a valid, reliable, and consistent result.

Signature
Date:

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

9. Appendix

This publication may not be reproduced, stored in the system, transferred in any form by any means, electronic, mechanical, photocopying, recorded, or otherwise without the permission of PT. Merdeka Tsingshan Indonesia.

Standard Operating Procedure
标准操作程序

Lime milk preparation posts in the chloride plant
CP 石灰乳制备岗位

SOP Details 程序明细

Processing Department 氯化厂	Procedure Level 程序级别: **3**	Revision Number 修订编号: 0
Date Approved 审批日期:	Date Issued 颁布日期:	Next Review Date 下次审核日期:
Details of Revision 修订明细:		

Revision Details 修订明细

Rev. No 版本号	Date 日期	Section 章节	Page 页码	Revision Description 修订说明	Reviewed By 审核人
1					
2					
3					

Approvals 批准

Document Owner 程序持有人	Song Yuhua 宋裕华	Date: 日期: 2024.4.24	Signature 签字	
Processing Superintendent 氯化高级副经理	Cao Guibin 曹桂宾	Date: 日期: 2024.4.24	Signature 签字	
Processing Senior Manager 氯化高级经理	Li Jianjun 李建军	Date: 日期: 2024.04.24	Signature 签字	
Safety Department Manager 安全部经理	Airlangga Putra R.J	Date: 日期: 24.04.24	Signature 签字	
Deputy General Manager 副总经理	Li Xinhua 李新华	Date: 日期 2024.4.24	Signature 签字	
General Manager 总经理	Clark Wu 吴迎林	Date: 日期: 2020.6.24	Signature 签字	