HUSKEY POCKET

User Manual

User guide and feature list

Hardware password manager • no cloud • no internet connection

Contents

Contents 2
1. What is Huskey Pocket? 3
2. Getting Started (Initial Setup) 3
3. Unlocking and Locking 3
4. Everyday Use: Your Credentials 4
5. Typing Credentials on a Computer 4
6. Password Generator 5
7. Second Factor (TOTP Codes) 5
8. Sharing with a QR Code 5
9. Folders (Categories) 5
10. Backups: Import and Export 6
11. USB Storage Mode 6
12. Security Features 6
13. Settings 7
15. FAQ and Troubleshooting 9

1. What is Huskey Pocket?

Huskey Pocket is a hardware password manager: a standalone physical device that stores your encrypted credentials and types them for you on a computer by emulating a keyboard. It does not connect to the internet or cloud, does not require an account, and the key that protects your data never leaves the device. Unlock it with a PIN on the touchscreen, choose a credential, and the device types it on your computer as if you had entered it yourself.

2. Getting Started (Initial Setup)

The first time you turn on the device, it guides you through a short setup:

1. Choose a language (Spanish or English) and keyboard style.
2. Create a six-digit PIN and enter it again to confirm. This PIN protects your entire vault; choose it carefully and memorize it.
3. Set the date and time. TOTP code accuracy depends on the PCF85063 RTC. To retain the time while the device is off, connect an external RTC backup battery; the main battery does not replace it.
4. Setup is complete. The device takes you to the lock screen.

> The PIN cannot be recovered. A factory reset erases the vault, and FRP then requires verification of the previous PIN before allowing setup. If you do not remember that PIN, you may permanently lose access to the device.

3. Unlocking and Locking

Unlock

Enter your six-digit PIN on the lock screen. If it is correct, the vault opens. Verification derives the key using PBKDF2-HMAC-SHA256 with 50,000 iterations, so it may take a moment.

Failed attempts

- After the first three failed attempts, the device tells you how many attempts remain.
- On the fourth attempt, it shows a final-attempt warning.
- After the fifth consecutive incorrect vault PIN, the firmware starts a factory reset. Vault data is removed and FRP retains its own record for verifying the previous PIN.

Lock

The device locks automatically after the timeout you configure. You can also lock it manually. When it locks, the key is cleared from memory and you must enter the PIN again.

4. Everyday Use: Your Credentials

Viewing and searching entries

The main screen shows your credentials. Search by name, filter by folder (category), and mark frequently used entries as favorites for quick access.

Entry types

Type	Purpose
Web / account	Stores a name, username, password, notes or URL, and a category. Commonly used for websites and apps.
Secret	Stores a single sensitive value (a PIN, code, or general key) with its name and category.

Creating an entry

1. Tap the new-entry button.
2. Choose a type (web account or secret).
3. Fill in the fields. You can enter a password or generate one (see section 5).
4. Optionally assign a folder, then save.

Editing or deleting

Open an entry to view its details. From there, edit any field or delete it. You can also select multiple entries and delete them in a batch.

5. Typing Credentials on a Computer

This is the core feature: instead of copying and pasting, the device types the credential on the connected computer. The entry detail screen has buttons for sending each field:

Action	What it does
Type username	Types the username into the field where the cursor is.
Tab	Sends Tab to move from the username field to the password field.
Type password	Types the password.
Enter	Sends Enter to submit the form.
Type secret	Types the value from a Secret entry.
Type second-factor code	Types the current six-digit TOTP code (see section 7).

> *Typical sign-in sequence: place the cursor in the site's username field, tap "Type username," then "Tab," then "Type password," and finally "Enter." The password is not displayed on the computer screen or placed on its clipboard.*

Choosing a connection: Bluetooth or USB

Connect to the computer over Bluetooth or USB, as selected in Settings. In either case, the device behaves like a keyboard.

Bluetooth pairing

The first time you pair over Bluetooth, both devices display the same six-digit code. Confirm on the Huskey Pocket screen that the codes match. This prevents another device from pairing without your permission. The device types only after the connection is encrypted and confirmed.

6. Password Generator

The generator creates random passwords using the ESP32-S3 random-number generator. You can adjust:

- Length (8 to 32 characters).
- Whether to include uppercase letters, numbers, and symbols.
- Whether to exclude ambiguous characters (such as l, 1, O, 0) to make passwords easier to read and transcribe.

Passwords are generated with the chip's hardware random-number generator using unbiased sampling. Use the generator when creating or editing an entry, or on its own.

7. Second Factor (TOTP Codes)

Huskey Pocket can act as your two-factor authentication app. It stores a service's secret and generates six-digit codes that change every 30 seconds, like Google Authenticator.

Setting up a second factor

1. Open an entry and go to its second-factor settings.
2. Enter the secret provided by the service (the text string usually shown with its setup QR code).
3. Save. The entry will then show a six-digit code with a countdown.

When a site asks for the second-factor code, type it directly from the device using the corresponding button.

> *The device's time must be correct for the codes to work. If codes fail, check the date and time in Settings.*

8. Sharing with a QR Code

From an entry's details, display its contents as a QR code for another device to scan (for example, to transfer a credential to your phone). The QR code shows the information on screen, so use it only in a private setting.

9. Folders (Categories)

Organize entries into folders. The device includes some by default (Finance, Work, Streaming, Hobby, Personal), and you can create your own. Filtering by folder shows only entries in that category. A Favorites view is also available.

10. Backups: Import and Export

Export credentials to microSD as an encrypted .hky backup or an unencrypted CSV. To import, put the file in /import. The card mounts after the access screen appears; wait for firmware initialization to finish before opening Import / Export.

Format	When to use it
Encrypted backup (.hky)	Recommended. Protects the backup with its own password, separate from your PIN. The file cannot be read without that password.
Unencrypted CSV	For specific cases only (for example, migrating to or from a browser password manager). The file is readable plain text, so handle it carefully.

Export

1. Open Import / Export in Settings.
2. Choose an encrypted backup or CSV export.
3. For an encrypted backup, set an export password. Memorize it; you will need it to restore the backup.
4. The file is saved to the microSD card.

Import

1. Put the file on the microSD card and insert it.
2. Open Import / Export and choose the file.
3. If it is an encrypted backup, enter its export password.
4. The device imports the entries and reports how many were added.

> An unencrypted CSV contains readable passwords. Delete it from the card and computer when you are finished. The .hky file is encrypted; CSV contents are readable. Store both files carefully and delete CSV files when you no longer need them.

11. USB Storage Mode

USB storage mode exposes the microSD card as a drive to the connected computer. This mode only provides access to the card; it does not install firmware updates.

- This is an exclusive mode: while it is active, the device cannot be used as a credential manager. It restarts when entering and leaving the mode.
- You can enable read-only mode so the computer can copy backups but cannot modify or delete files on the card.
- The mode exits automatically when the cable is disconnected or when you tap the exit button.

> *Your encrypted vault is stored in the device's internal memory, not on the microSD card. In this mode the computer sees only the card's files (your backups), never your credentials.*

12. Security Features

Huskey Pocket includes protections for real-world theft, loss, and coercion scenarios. They are optional except for brute-force protection, and can be configured in Settings.

Decoy PIN

A second PIN opens an empty vault that looks like the real one. If someone forces you to unlock the device, you can enter this PIN: they will see a working manager without your real credentials and without any indication that another vault exists. You can configure how often it is cleared automatically.

Lost Mode (Dead Man's Switch)

If enabled, the firmware starts a factory reset after the selected period passes without a genuine unlock. It depends on the RTC retaining a valid time. It is intended for a lost or forgotten device: if you do not use it within the configured period, a factory reset starts when the period expires. Disabled by default (0 days).

Snatch Lock

While the device is unlocked, the firmware polls the IMU and locks the device if acceleration and rotation exceed the selected thresholds. Detection is software-based, no fixed response time is guaranteed, and the feature is disabled by default.

Factory Reset Protection (FRP)

If the device is factory-reset (by you or by someone who forces the PIN), it asks for the original PIN after restarting before allowing setup. This prevents a stolen device from being reused. After several incorrect attempts at this PIN, the device is permanently locked.

Brute-force protection

Always active: five consecutive incorrect PIN attempts start a factory reset. This removes the vault data; it does not certify physical erasure of every Flash cell.

13. Settings

The Settings menu is organized into sections:

Section	Contents
Security	Change PIN, decoy PIN, Lost Mode, Snatch Lock, and factory reset.
Device	Keyboard mode (Bluetooth or USB), keyboard layout, and USB storage mode.
General	Language, theme (light/dark), accent color, auto-lock, date and time, and time zone.
System	Import / export, delete exports from the card, device information, and firmware version.

Personalization
Choose a light or dark theme and an accent color (blue, light blue, purple, orange, pink, or green), as well as the language (Spanish or English) and keyboard style.

14. Complete Feature List

Credential management

- Web/account entries (name, username, password, notes/URL, category).
- Secret entries (single sensitive value).
- Create, edit, and delete entries.
- Select multiple entries and delete them in a batch.

- Quick search by name.
- Organize entries into folders (categories), including default and custom folders.
- Mark favorites and view the Favorites list.

Typing on a computer

- Bluetooth keyboard emulation (BLE HID).
- USB keyboard emulation.
- Type username, password, secret, and second-factor code individually.
- Tab and Enter keys for navigating forms.
- Bluetooth pairing with numeric confirmation; transmission only over an encrypted link.
- Forget paired devices.

Passwords and second factor

- Password generator using the hardware RNG (length, uppercase, numbers, symbols, ambiguous-character exclusion).
- TOTP second factor (six-digit codes that rotate every 30 seconds).
- Type TOTP codes on the computer.

Backups

- Encrypted .hky export and import with a separate password.
- CSV export and import (compatible with browsers).
- Share an entry through an on-screen QR code.
- USB storage mode with an optional read-only setting.
- Delete exported files from the card.

Security

- Six-digit PIN with strengthened verification.
- Decoy PIN (fake vault for coercion) with configurable auto-reset.
- Lost Mode / Dead Man's Switch (factory reset after N days).
- Motion-sensor Snatch Lock (three sensitivity levels).
- Factory Reset Protection (FRP) with permanent lockout.
- Brute-force protection (factory reset after five failed attempts).
- Configurable auto-lock on inactivity.
- Deep sleep with peripheral power-down.

System and interface

- Touch interface with on-screen keyboards (full and T9).
- Spanish and English languages.
- Light and dark themes with several accent colors.
- PCF85063 real-time clock; requires an external backup battery to retain time while the device is off.
- Battery and time indicators in the status bar.

15. FAQ and Troubleshooting

I forgot my PIN. How can I recover it?

The PIN cannot be recovered. A factory reset erases the vault, and FRP requires the previous PIN before the device can be set up again. If you do not remember that PIN, you may lose access to the device.

Second-factor codes do not work.

This is usually caused by the time. Check that the date, time, and time zone are correct in Settings.

Unlocking takes a moment.

This is expected: the device deliberately performs a costly calculation to make brute-force attacks harder.

I cannot see the device in Bluetooth pairing.

Bluetooth is enabled only while the vault is unlocked. Enter your PIN and make sure Bluetooth keyboard mode is selected.

I lost the device.

If Lost Mode was enabled, the contents are erased when the configured period expires. Otherwise, the contents remain encrypted and the firmware starts a factory reset after five consecutive incorrect PIN attempts. FRP then requires the previous PIN.

> *Keep encrypted .hky backups in a safe place. Firmware 1.0.1 includes keyboard and microSD startup fixes.*