

dhcp

- dynamic host configuration protocol
- it works in application layer
- it is used to get an IP address and other configuration parameters automatically to a system.
- dhcp is a client –server model
- dhcp server wait at port number 67
- dhcp client wait at port number 68
- dhcp uses the service of UDP

dhcp(contd...)

DHCP client will be daemon process and automatically starts execution whenever you switch on the system at run level 6.

run level 6 is boot step.

dhcp client will request to dhcp server.

All these steps are done by using 4 steps is called as "DORA"

dhcp

D - discover

O - offer

R – Request

A – Acknowledgement