



© BMW AG

00197017

# Part Number Description Ib Qty Each
ONLY FOR REPAIR AT THE DEALERS FOR ADDITIONAL INFORMATION SEE SERVICE
INFORMATION BULLETIN 75/2004 :

01 83 30 0 402 336

REPAIR PLUG, 3-PIN - NO. 610611

0.04

1

1

\$29.32



Function: 3-pole for throttle-valve potentiometer, headlight.

02 **83 30 0 402 337** REPAIR PLUG, 4-PIN - NO. 610612

0.05

\$27.86

Function: 4-pin for oxygen sensor, electronic immobilizer ring aerial, fuel level sensor.

•

03	83 30 0 402 338	REPAIR PLUG, 2-PIN - NO. 610613	0.02	1	\$43.49
----	-----------------	---------------------------------	------	---	---------





Function: 2-pin for camshaft sensor, coolant-temperature sensor, knock sensor, on-board socket, front brake-light switch.

04 83 30 0 402 339

REPAIR PLUG, 2-PIN - NO. 610614

0.04

\$24.24





Function: 2-pole for injection valve.



05 83 30 0 402 340

REPAIR PLUG, 4-PIN - NO. 610615

0.04

\$22.08





Function: 4-pin for throttle-valve actuator.



06 83 30 0 402 341

REPAIR PLUG, 3-PIN - NO. 610616

0.03

\$24.13





Function: 3-pole for ignition coil, gearbox potentiometer, fuel pump.



07 **83 30 0 402 342** 

REPAIR PLUG, 2-PIN - NO. 610617

0.04

\$20.25





Function: 2-pole for horn, wheel-speed sensor.



08 83 30 0 402 343

REPAIR PLUG, 2-PIN - NO. 610618

0.04

\$15.35





Function: 2-pin for on-board socket. Approximately 410mm in length.



09 83 30 0 402 344

REPAIR PLUG, 2-PIN - NO. 610619

0.02

1 \$32.04





Function: 2-pole for brake-light switch, wheel-speed sensor.



10 **83 30 0 409 690** 

REPAIR PLUG, 4-PIN - NO. 610621

0.05

\$28.82





Function: 4-pole for throttle-valve potentiometer.

